

Annexure I				
S.No.	SPN	MANUFACTURER	PART NO.	DESCRIPTION
1	1.01.0001.1.01.5	CU	8265	WASHER,PLAIN
2	1.01.0002.1.01.6	CU	43828	CLAMP,HOSE
3	1.01.0003.1.01.7	CU	44680	LEVER,THROTTLE
4	1.01.0004.1.01.8	CU	63495	HOSE,PLAIN
5	1.01.0005.1.01.9	CU	65434	SPACER,MOUNTING
6	1.01.0006.1.01.1	CU	68139	ELBOW, MALE ADAPTER
7	1.01.0007.1.01.2	CU	68174	KEY,SQUARE
8	1.01.0008.1.01.3	CU	68645	ELBOW,MALE ADAPTER
9	1.01.0009.1.01.4	CU	69558	DOWEL,PIN
10	1.01.0010.1.01.5	CU	69901	PLUG,PIPE
11	1.01.0011.1.01.6	CU	69936	NUT,HEAVY HEXAGON
12	1.01.0012.1.01.7	CU	70183	RING,RETAINING
13	1.01.0013.1.01.8	CU	70437	BUSHING
14	1.01.0014.1.01.9	CU	70550	DOWEL,PIN
15	1.01.0015.1.01.1	CU	70690	DRIVER,GOVERNOR PLUNGER
16	1.01.0016.1.01.2	CU	70699	RING,RETAINING
17	1.01.0017.1.01.3	CU	70700	SPRING,COMPRESSION
18	1.01.0018.1.01.4	CU	70713	RETAINER,SPRING
19	1.01.0019.1.01.5	CU	FP3904166	SLEEVE
20	1.01.0020.1.01.6	CU	70717	SHIM,FUEL PUMP GOVERNOR
21	1.01.0021.1.01.7	CU	70720	GEAR,TACHOMETER DRIVE
22	1.01.0022.1.01.8	CU	70732	GASKET,TACHOMETER
23	1.01.0023.1.01.9	CU	70811	SHIM
24	1.01.0024.1.01.1	CU	70820	PLUNGER,GOVERNOR SPRING
25	1.01.0025.1.01.2	CU	70897	NUT,LOCK
26	1.01.0026.1.01.3	CU	100192	SHAFT,FUEL PUMP DRIVE
27	1.01.0027.1.01.4	CU	100215	SHAFT,FUEL PUMP DRIVE
28	1.01.0028.1.01.5	CU	100765	COVER,FUEL CONTROL
29	1.01.0029.1.01.6	CU	101918	HUB,JAW COUPLING
30	1.01.0030.1.01.7	CU	102030	SEAL,O RING
31	1.01.0031.1.01.8	CU	104087	SHAFT,TACHOMETER DRIVE
32	1.01.0032.1.01.9	CU	106339	SEAL,OIL
33	1.01.0033.1.01.1	CU	107261	WEIGHT,GOVERNOR
34	1.01.0034.1.01.2	CU	107981	CAP,FILLER
35	1.01.0035.1.01.3	CU	108186	LOCKWIRE,TPT ROLLER PIN
36	1.01.0036.1.01.4	CU	108187	LOCKWIRE,TPT ROLLER PIN
37	1.01.0037.1.01.5	CU	109319	LOCKPLATE
38	1.01.0038.1.01.6	CU	109333	PLUNGER,PRS REGULATOR
39	1.01.0039.1.01.7	CU	109915	SCREW,SLOTTED SET
40	1.01.0040.1.01.8	CU	115508	NUT,LOCK
41	1.01.0041.1.01.9	CU	116391	BUSHING
42	1.01.0042.1.01.1	CU	116935	CONNECTOR,MALE
43	1.01.0043.1.01.2	CU	116936	ELBOW,MALE ADAPTER
44	1.01.0044.1.01.3	CU	118939	PIN,ROLL
45	1.01.0045.1.01.4	CU	119984	CONNECTOR,MALE
46	1.01.0046.1.01.5	CU	120437	ELBOW,MALE ADAPTER
47	1.01.0047.1.01.6	CU	121229	ELBOW,MALE ADAPTER
48	1.01.0048.1.01.7	CU	123078	GASKET,WATER PUMP
49	1.01.0049.1.01.8	CU	123128	GEAR,ACCESSORY DRIVE
50	1.01.0050.1.01.9	CU	123558	GUIDE,VALVE CROSSHEAD
51	1.01.0051.1.01.1	CU	125485	GEAR,ACCESSORY DRIVE
52	1.01.0052.1.01.2	CU	125741	CLAMP,T BOLT
53	1.01.0053.1.01.3	CU	126333	SEAL,O RING
54	1.01.0054.1.01.4	CU	127554	COLLET,VALVE
55	1.01.0055.1.01.5	CU	127930	INSERT,VALVE
56	1.01.0056.1.01.6	CU	129859	ELBOW,MALE UNION
57	1.01.0057.1.01.7	CU	130083	BEARING,THRUST
58	1.01.0058.1.01.8	CU	130394	CONNECTION,WATER BYPASS
59	1.01.0059.1.01.9	CU	132770	BUSHING
60	1.01.0060.1.01.1	CU	134809	BELT,V
61	1.01.0061.1.01.2	CU	135675	THERMOSTAT
62	1.01.0062.1.01.3	CU	135957	VALVE,INTAKE
63	1.01.0063.1.01.4	CU	140314	CLAMP,T BOLT
64	1.01.0064.1.01.5	CU	140315	CLAMP,T BOLT
65	1.01.0065.1.01.6	CU	140330	BUSHING
66	1.01.0066.1.01.7	CU	140332	CLAMP,T BOLT
67	1.01.0067.1.01.8	CU	140558	SHAFT,ACCESSORY DRIVE
68	1.01.0068.1.01.9	CU	145623	SEAL,O RING
69	1.01.0069.1.01.1	CU	145701	VALVE,EXHAUST
70	1.01.0070.1.01.2	CU	146437	WEIGHT,GOVERNOR
71	1.01.0071.1.01.3	CU	146483	SCREEN,FILTER
72	1.01.0072.1.01.4	CU	146856	BOLT,CONNECTING ROD
73	1.01.0073.1.01.5	CU	147100	CONNECTION,FUEL CROSSOVER
74	1.01.0074.1.01.6	CU	147389	SCREW,CROSSHEAD ADJUSTING

75	1.01.0075.1.01.7	CU	147610	BUSHING
76	1.01.0076.1.01.8	CU	149503	BARREL,GOVERNOR
77	1.01.0077.1.01.9	CU	153526	SEAT,BYPASS VALVE
78	1.01.0078.1.01.1	CU	154087	SEAL,RECTANGULAR RING
79	1.01.0079.1.01.2	CU	154088	SEAL,RECTANGULAR RING
80	1.01.0080.1.01.3	CU	163022	SHIELD,HEAT
81	1.01.0081.1.01.4	CU	165006	SCREW,HEXAGON HEAD CAP
82	1.01.0082.1.01.5	CU	166009	SPRING,COMPRESSION
83	1.01.0083.1.01.6	CU	167157	BALL,CHECK
84	1.01.0084.1.01.7	CU	168306	SCREW,SLOTTED SET
85	1.01.0085.1.01.8	CU	170296	GUIDE,VALVE SPRING
86	1.01.0086.1.01.9	CU	172034	GUIDE,VALVE SPRING
87	1.01.0087.1.01.1	CU	173086	GASKET,INJECTOR
88	1.01.0088.1.01.2	CU	173176	SPRING,COMPRESSION
89	1.01.0089.1.01.3	CU	173718	LEVER,THROTTLE
90	1.01.0090.1.01.4	CU	174299	RETAINER,SCREEN
91	1.01.0091.1.01.5	CU	175755	RING,RETAINING
92	1.01.0092.1.01.6	CU	175830	PLUG,EXPANSION
93	1.01.0093.1.01.7	CU	175864	SHAFT,FUEL PUMP
94	1.01.0094.1.01.8	CU	177417	SHAFT,LUB OIL PUMP DRIVE
95	1.01.0095.1.01.9	CU	177419	SHAFT,LUB OIL PUMP
96	1.01.0096.1.01.1	CU	178456	BELT,V
97	1.01.0097.1.01.2	CU	180753	TUBE,WATER TRANSFER
98	1.01.0098.1.01.3	CU	180862	SLINGER,OIL
99	1.01.0099.1.01.4	CU	185138	RETAINER,INJECTOR CUP
100	1.01.0100.1.01.5	CU	185139	ADAPTER,INJECTOR
101	1.01.0101.1.01.6	CU	186780	SEAL,THERMOSTAT
102	1.01.0102.1.01.7	CU	186917	CLAMP,V BAND
103	1.01.0103.1.01.8	CU	187368	ADAPTER,PLAIN
104	1.01.0104.1.01.9	CU	187420	BUSH
105	1.01.0105.1.01.1	CU	188040	BEARING,THRUST
106	1.01.0106.1.01.2	CU	193552	DAMPER,VIBRATION
107	1.01.0107.1.01.3	CU	193736	SEAL,O RING
108	1.01.0108.1.01.4	CU	195952	SEAL,O RING
109	1.01.0109.1.01.5	CU	198843	BRACE,AIR COMPRESSOR
110	1.01.0110.1.01.6	CU	199510	BUSHING
111	1.01.0111.1.01.7	CU	199843	PLUNGER,PRS REGULATOR
112	1.01.0112.1.01.8	CU	200307	SEAL,OIL
113	1.01.0113.1.01.9	CU	200354	INSERT,VALVE
114	1.01.0114.1.01.1	CU	200600	BEARING,CONNECTING ROD
115	1.01.0115.1.01.2	CU	200601	BEARING,CONNECTING ROD
116	1.01.0116.1.01.3	CU	200602	BEARING,CONNECTING ROD
117	1.01.0117.1.01.4	CU	200819	ORIFICE,FUL FLOW LIMITING
118	1.01.0118.1.01.5	CU	202897	DIAPHRAGM,FUL PUMP DAMPER
119	1.01.0119.1.01.6	CU	203131	NUT,HEAVY HEXAGON
120	1.01.0120.1.01.7	CU	203426	PIN,ROLL
121	1.01.0121.1.01.8	CU	203850	UNION,MALE
122	1.01.0122.1.01.9	CU	204193	SHAFT,LUB OIL PUMP DRIVE
123	1.01.0123.1.01.1	CU	205052	SHAFT,IDLER
124	1.01.0124.1.01.2	CU	205065	SHAFT,LUB OIL PUMP
125	1.01.0125.1.01.3	CU	205080	PLUNGER,PRS REGULATOR
126	1.01.0126.1.01.4	CU	205091	COLLET,VALVE
127	1.01.0127.1.01.5	CU	205112	BEARING,THRUST
128	1.01.0128.1.01.6	CU	205126	WASHER,PLAIN
129	1.01.0129.1.01.7	CU	205156	BUSHING
130	1.01.0130.1.01.8	CU	205227	PLUG,EXPANSION
131	1.01.0131.1.01.9	CU	205243	IMPELLER,WATER PUMP
132	1.01.0132.1.01.1	CU	205439	RING,RETAINING
133	1.01.0133.1.01.2	CU	205464	SPRING,COMPRESSION
134	1.01.0134.1.01.3	CU	205841	BEARING,CONNECTING ROD
135	1.01.0135.1.01.4	CU	206224	PLUG,EXPANSION
136	1.01.0136.1.01.5	CU	206948	SEAL,OIL
137	1.01.0137.1.01.6	CU	207226	BUSHING
138	1.01.0138.1.01.7	CU	207233	TUBE,WATER TRANSFER
139	1.01.0139.1.01.8	CU	207251	GEAR,WATER PUMP
140	1.01.0140.1.01.9	CU	207344	BUSHING
141	1.01.0141.1.01.1	CU	207378	TUBE,WATER TRANSFER
142	1.01.0142.1.01.2	CU	209806	SHAFT,WATER PUMP
143	1.01.0143.1.01.3	CU	209971	TUBE,COMPRESSOR AIR INLET
144	1.01.0144.1.01.4	CU	210570	TUBE,CPR WATER OUTLET
145	1.01.0145.1.01.5	CU	211315	SEAL,O RING
146	1.01.0146.1.01.6	CU	211633	SHAFT,GOVERNOR
147	1.01.0147.1.01.7	CU	211636	GEAR,GOVERNOR
148	1.01.0148.1.01.8	CU	211662	BEARING,THRUST
149	1.01.0149.1.01.9	CU	211999	SPRING,VALVE
150	1.01.0150.1.01.1	CU	212601	SHAFT,FUEL PUMP DRIVE
151	1.01.0151.1.01.2	CU	212610	GEAR,TACHOMETER DRIVE

152	1.01.0152.1.01.3	CU	213559	SOCKET,CAM FOLLOWER
153	1.01.0153.1.01.4	CU	214836	CORE,AFTERCOOLER
154	1.01.0154.1.01.5	CU	214951	BEARING,CONNECTING ROD
155	1.01.0155.1.01.6	CU	216484	DIPSTICK, BLANK
156	1.01.0156.1.01.7	CU	217302	HOSE,PLAIN
157	1.01.0157.1.01.8		Shifted to Annexure II	
158	1.01.0158.1.01.9	CU	218153	BUSHING
159	1.01.0159.1.01.1	CU	250843	RING,RETAINING
160	1.01.0160.1.01.2	CU	251152	SPRING,COMPRESSION
161	1.01.0161.1.01.3	CU	255180	BREATHER,CRANKCASE
162	1.01.0162.1.01.4	CU	500109	GAUGE,PRESSURE
163	1.01.0163.1.01.5	CU	500184	CABLE,FLEXIBLE DRIVE
164	1.01.0164.1.01.6	CU	501151	HOURLMETER
165	1.01.0165.1.01.7	CU	501253	PULLEY,ALTERNATOR
166	1.01.0166.1.01.8	CU	502041	DIPSTICK
167	1.01.0167.1.01.9	CU	504760	STUD
168	1.01.0168.1.01.1	CU	504867	BELT,V
169	1.01.0169.1.01.2	CU	2865287	ASSEMBLY,OIL PAN
170	1.01.0170.1.01.3	CU	2865519	SWITCH,MAGNETIC
171	1.01.0171.1.01.4	CU	2880039	GASKET EXH OUT CONNECTION
172	1.01.0172.1.01.5	CU	2885050	GASKET,FUEL PUMP
173	1.01.0173.1.01.6	CU	2897691	SWITCH,PRESSURE
174	1.01.0174.1.01.7	CU	3000060	TUBE,CPR WATER INLET
175	1.01.0175.1.01.8	CU	3000174	HUB,SPLINE COUPLING
176	1.01.0176.1.01.9	CU	3001405	LOCKPLATE
177	1.01.0177.1.01.1	CU	3002834	BUSHING
178	1.01.0178.1.01.2	CU	3002956	TUBE,WATER TRANSFER
179	1.01.0179.1.01.3	CU	3005132	DRIVE, ACCESSORY
180	1.01.0180.1.01.4	CU	3005407	MANIFOLD,AIR INTAKE
181	1.01.0181.1.01.5	CU	3005752	WEIGHT CARRIER
182	1.01.0182.1.01.6	CU	3006696	CLAMP,INJECTOR
183	1.01.0183.1.01.7	CU	3006699	ROLLER,TAPPET
184	1.01.0184.1.01.8	CU	3006745	RING,RETAINING
185	1.01.0185.1.01.9	CU	3008062	HOUSING,FLYWHEEL
186	1.01.0186.1.01.1	CU	3009213	LOCKPLATE
187	1.01.0187.1.01.2	CU	3010146	SPRING,COMPRESSION
188	1.01.0188.1.01.3	CU	3010510	SEAL,O RING
189	1.01.0189.1.01.4	CU	3010615	COOLER,OIL
190	1.01.0190.1.01.5	CU	3011951	BUSHING
191	1.01.0191.1.01.6	CU	3012531	SHAFT,IDLER
192	1.01.0192.1.01.7	CU	3012532	SHAFT,LUB OIL PUMP DRIVE
193	1.01.0193.1.01.8	CU	3013266	SCREW,CONNECTING ROD CAP
194	1.01.0194.1.01.9	CU	3013330	PIN,CAM FOLLOWER ROLLER
195	1.01.0195.1.01.1	CU	3013331	PIN,CAM FOLLOWER ROLLER
196	1.01.0196.1.01.2	CU	3014092	COVER,GEAR
197	1.01.0197.1.01.3	CU	3014778	GASKET,LUB OIL PUMP COVER
198	1.01.0198.1.01.4	CU	3015527	PULLEY,WATER PUMP
199	1.01.0199.1.01.5	CU	3015585	SCREW,TWELVE POINT CAP
200	1.01.0200.1.01.6	CU	3015665	SHAFT,TACHOMETER DRIVE
201	1.01.0201.1.01.7	CU	3016142	HOSE,PLAIN
202	1.01.0202.1.01.8	CU	3016477	ELBOW,PLAIN UNION
203	1.01.0203.1.01.9	CU	3016826	ROLLER,CAM FOLLOWER
204	1.01.0204.1.01.1	CU	3017511	ROLLER,TAPPET
205	1.01.0205.1.01.2	CU	3017759	INSERT,VALVE
206	1.01.0206.1.01.3	CU	3017961	ROD,PUSH
207	1.01.0207.1.01.4	CU	3018889	CONNECTOR,FEMALE
208	1.01.0208.1.01.5	CU	3023079	CORE COOLER
209	1.01.0209.1.01.6	CU	3023891	ROD,ENGINE CONNECTING
210	1.01.0210.1.01.7	CU	3025100	WASHER,PLAIN
211	1.01.0211.1.01.8	CU	3025887	SHAFT,WATER PUMP
212	1.01.0212.1.01.9	CU	3026556	BEARING,THRUST
213	1.01.0213.1.01.1	CU	3026557	BEARING,THRUST
214	1.01.0214.1.01.2	CU	3026832	HOSE,FLEXIBLE
215	1.01.0215.1.01.3	CU	3028075	BUSHING
216	1.01.0216.1.01.4	CU	3028269	BUSHING
217	1.01.0217.1.01.5	CU	3028291	SEAL,O RING
218	1.01.0218.1.01.6	CU	3028293	CROSSHEAD,VALVE
219	1.01.0219.1.01.7	CU	3028946	DISC,VALVE
220	1.01.0220.1.01.8	CU	3030514	HOSE,ELBOW
221	1.01.0221.1.01.9	CU	3030772	HOSE,ELBOW
222	1.01.0222.1.01.1	CU	3030774	ELBOW HOSE
223	1.01.0223.1.01.2	CU	3030790	HOSE,HUMP
224	1.01.0224.1.01.3	CU	3033411	TEE,MALE UNION
225	1.01.0225.1.01.4	CU	3033740	VALVE,CHECK
226	1.01.0226.1.01.5	CU	3033742	PLUG,THREADED
227	1.01.0227.1.01.6	CU	3034222	PUMP,GEAR FUEL
228	1.01.0228.1.01.7	CU	3034243	PUMP,GEAR FUEL

229	1.01.0229.1.01.8	CU	3035110	VALVE EXHAUST
230	1.01.0230.1.01.9	CU	3035331	SEAL,GROMMET
231	1.01.0231.1.01.1	CU	3036933	ROLLER,CAM FOLLOWER
232	1.01.0232.1.01.2	CU	3036966	RETAINER,VALVE SPRING
233	1.01.0233.1.01.3	CU	3037732	TUBE,FUEL SUPPLY
234	1.01.0234.1.01.4	CU	3037733	TUBE,FUEL SUPPLY
235	1.01.0235.1.01.5	CU	3038218	GUIDE & SPRING
236	1.01.0236.1.01.6	CU	3039532	TEE,MALE ADAPTER
237	1.01.0237.1.01.7	CU	3040377	BELT,V
238	1.01.0238.1.01.8	CU	3042827	SHAFT,WATER PUMP
239	1.01.0239.1.01.9	CU	3043650	INSERT,PISTON
240	1.01.0240.1.01.1	CU	3043909	BUSHING
241	1.01.0241.1.01.2	CU	3045047	PLUG,INJECTOR ORIFICE
242	1.01.0242.1.01.3	CU	3045986	SEAL,O RING
243	1.01.0243.1.01.4	CU	3046200	SPIDER,JAW COUPLING
244	1.01.0244.1.01.5	CU	3046418	ROD,PUSH
245	1.01.0245.1.01.6	CU	3046419	ROD,PUSH
246	1.01.0246.1.01.7	CU	3046431	ROD,PUSH
247	1.01.0247.1.01.8	CU	3046432	ROD,PUSH
248	1.01.0248.1.01.9	CU	3048912	TUBE,FUEL DRAIN
249	1.01.0249.1.01.1	CU	3048916	TUBE,FUEL DRAIN
250	1.01.0250.1.01.2	CU	3050163	CONNECTION,WATER BYPASS
251	1.01.0251.1.01.3	CU	3052218	RETAINER,INJECTOR SPRING
252	1.01.0252.1.01.4	CU	3054258	INJECTOR
253	1.01.0253.1.01.5	CU	3054999	SCREEN,FILTER
254	1.01.0254.1.01.6	CU	3056356	HARNESS,WIRING
255	1.01.0255.1.01.7	CU	3057139	ROD,PUSH
256	1.01.0256.1.01.8	CU	3058653	SEAL,O RING
257	1.01.0257.1.01.9	CU	3062415	SPRING,COMPRESSION
258	1.01.0258.1.01.1	CU	3072817	GASKET,FUEL PUMP
259	1.01.0259.1.01.2	CU	3081040	DAMPER,VIBRATION
260	1.01.0260.1.01.3	CU	3081053	HOSE,PLAIN
261	1.01.0261.1.01.4	CU	3081212	SPRING,VALVE
262	1.01.0262.1.01.5	CU	3081248	ROLLER,CAM FOLLOWER
263	1.01.0263.1.01.6	CU	3081283	BLOCK,CYLINDER
264	1.01.0264.1.01.7	CU	3086191	INSERT,VALVE
265	1.01.0265.1.01.8	CU	3086192	INSERT,VALVE
266	1.01.0266.1.01.9	CU	3086436	VALVE,EXHAUST
267	1.01.0267.1.01.1	CU	3096077	GASKET,FUEL PUMP
268	1.01.0268.1.01.2	CU	3166554	ELEMENT,LUB OIL FILTER
269	1.01.0269.1.01.3	CU	3167063	CONTROL,GOVERNOR
270	1.01.0270.1.01.4	CU	3167224	INHIBITOR,CORROSION
271	1.01.0271.1.01.5	CU	3167836	HOSE,FLEXIBLE
272	1.01.0272.1.01.6	CU	3201311	GUIDE,VALVE STEM
273	1.01.0273.1.01.7	CU	3225253	TUBE,FUEL BYPASS
274	1.01.0274.1.01.8	CU	3225660	CAP, DUST
275	1.01.0275.1.01.9	CU	3227327	TUBE,LUB OIL TRANSFER
276	1.01.0276.1.01.1	CU	3229083	CONNECTION,FUEL BLOCK
277	1.01.0277.1.01.2	CU	3229284	BRACKET FAN
278	1.01.0278.1.01.3	CU	3230038	MOTOR,HYDRAULIC
279	1.01.0279.1.01.4	CU	3231404	PICKUP,MAGNETIC
280	1.01.0280.1.01.5			Shifted to Annexure II
281	1.01.0281.1.01.6	CU	3232013	TUBE,TUR OIL DRAIN
282	1.01.0282.1.01.7	CU	3232556	BUSHING
283	1.01.0283.1.01.8	CU	3233140	TUBE,OIL GAUGE
284	1.01.0284.1.01.9	CU	3234408	PLUG,EXPANSION
285	1.01.0285.1.01.1	CU	3235591	NUT,HEXAGON FLANGE
286	1.01.0286.1.01.2	CU	3235704	HOSE,PLAIN
287	1.01.0287.1.01.3	CU	3236199	TUBE,FUEL TRANSFER
288	1.01.0288.1.01.4	CU	3236201	TUBE,FUEL SUPPLY
289	1.01.0289.1.01.5	CU	3236202	TUBE,FUEL TRANSFER
290	1.01.0290.1.01.6	CU	3236450	GEAR,LUBRICATING OIL PUMP
291	1.01.0291.1.01.7	CU	3236452	GEAR,LUB OIL PUMPING
292	1.01.0292.1.01.8	CU	3236454	GEAR,LUBRICATING OIL PUMP
293	1.01.0293.1.01.9	CU	3240551	VALVE,SOLENOID
294	1.01.0294.1.01.1	CU	3240573	VALVE,SOLENOID
295	1.01.0295.1.01.2	CU	3241306	NOZZLE,PISTON COOLING
296	1.01.0296.1.01.3	CU	3241328	LINER,CYLINDER
297	1.01.0297.1.01.4	CU	3241630	HEAD,CYLINDER
298	1.01.0298.1.01.5	CU	3241793	PUMP,FUEL
299	1.01.0299.1.01.6	CU	3245718	RING SET PISTON (SERVICE)
300	1.01.0300.1.01.7	CU	3264349	PUMP,WATER AND IDLER
301	1.01.0301.1.01.8	CU	3310169	ELEMENT,LUB OIL FILTER
302	1.01.0302.1.01.9	CU	3392696	COVER,HAND HOLE
303	1.01.0303.1.01.1	CU	3406702	SLEEVE,INJECTOR
304	1.01.0304.1.01.2	CU	3414063	CONNECTION,OIL SUCTION
305	1.01.0305.1.01.3	CU	3521033	SHAFT & WHEEL

306	1.01.0306.1.01.4	CU	3521918	IMPELLER,TUR COMPRESSOR
307	1.01.0307.1.01.5	CU	3545647	KIT,TURBO REPAIR HC5A
308	1.01.0308.1.01.6	CU	3609826	SEAL,WATER PUMP
309	1.01.0309.1.01.7	CU	3629006	SPRING,VALVE
310	1.01.0310.1.01.8	CU	3634007	SEAL,WATER PUMP
311	1.01.0311.1.01.9	CU	3803853	TURBOCHARGER
312	1.01.0312.1.01.1	CU	3804414	KIT,ENGINE PISTON
313	1.01.0313.1.01.2	CU	3818271	HOSE,PLAIN
314	1.01.0314.1.01.3	CU	3872252	CONNECTOR,PIPE
315	1.01.0315.1.01.4	CU	3872258	CONNECTOR,PIPE
316	1.01.0316.1.01.5	CU	3872278	CONNECTOR,PIPE
317	1.01.0317.1.01.6	CU	3872294	CONNECTOR,PIPE
318	1.01.0318.1.01.7	CU	3872299	CONNECTOR,PIPE
319	1.01.0319.1.01.8	CU	3872813	INDICATOR,RESTRICTION
320	1.01.0320.1.01.9	CU	3872815	INSERT,VALVE
321	1.01.0321.1.01.1	CU	3872844	CONNECTION,WATER BYPASS
322	1.01.0322.1.01.2	CU	3872845	TUBE,WATER BYPASS
323	1.01.0323.1.01.3	CU	3873355	CONNECTION,WATER OUTLET
324	1.01.0324.1.01.4	CU	3873542	BREATHER,CRANKCASE
325	1.01.0325.1.01.5	CU	3874152	VALVE,CHECK
326	1.01.0326.1.01.6	CU	3874153	VALVE,CHECK
327	1.01.0327.1.01.7	CU	3874400	TUBE,WATER OUTLET
328	1.01.0328.1.01.8	CU	3874401	TUBE,WATER OUTLET
329	1.01.0329.1.01.9	CU	3874427	TEE,MALE BRANCH PIPE
330	1.01.0330.1.01.1	CU	3875875	ACTUATOR
331	1.01.0331.1.01.2	CU	3878470	PUMP,HYDRAULIC
332	1.01.0332.1.01.3	CU	3878472	COMPRESSOR,AIR
333	1.01.0333.1.01.4	CU	3879074	ELEMENT,AIR CLEANER
334	1.01.0334.1.01.5	CU	3879075	ELEMENT,AIR CLEANER
335	1.01.0335.1.01.6	CU	3880282	SHAFT,ACCESSORY DRIVE
336	1.01.0336.1.01.7	CU	3880416	TUBE,FUEL SUPPLY
337	1.01.0337.1.01.8	CU	3880497	SHAFT,ACCESSORY DRIVE
338	1.01.0338.1.01.9	CU	3880524	KIT REPAIR 2CYL AIR COMPR
339	1.01.0339.1.01.1	CU	3880812	NOZZLE,PISTON COOLING
340	1.01.0340.1.01.2	CU	3881230	PULLEY,ACCESSORY DRIVE
341	1.01.0341.1.01.3	CU	3881680	GEAR,LUBRICATING OIL PUMP
342	1.01.0342.1.01.4	CU	3884126	PLUNGER,PRS REGULATOR
343	1.01.0343.1.01.5	CU	3931904	SEALANT LIQUIDE GASKET
344	1.01.0344.1.01.6	CU	4009247	PIN,CAM FOLLOWER ROLLER
345	1.01.0345.1.01.7	CU	4009248	PIN,CAM FOLLOWER ROLLER
346	1.01.0346.1.01.8	CU	4024946	UPPER ENGINE GASKET SET
347	1.01.0347.1.01.9	CU	4055279	ELEMENT,AIR CLEANER
348	1.01.0348.1.01.1	CU	4055280	ELEMENT,AIR CLEANER
349	1.01.0349.1.01.2	CU	4071443	PIN,TAPPET ROLLER
350	1.01.0350.1.01.3	CU	4071444	PIN,TAPPET ROLLER
351	1.01.0351.1.01.4	CU	4072619	IMPELLER,WATER PUMP
352	1.01.0352.1.01.5	CU	4072621	PUMP,WATER
353	1.01.0353.1.01.6	CU	4073133	CAMSHAFT
354	1.01.0354.1.01.7	CU	4073134	CAMSHAFT
355	1.01.0355.1.01.8	CU	4073137	BEARING,THRUST
356	1.01.0356.1.01.9	CU	4084693	FILTER,FUEL
357	1.01.0357.1.01.1	CU	4095009	PIN,PISTON
358	1.01.0358.1.01.2	CU	4327021	SWITCH,TEMPERATURE
359	1.01.0359.1.01.3	CU	4345448	GUIDE,VALVE SPRING
360	1.01.0360.1.01.4	CU	4352578	KIT,UPPER ENGINE GASKET
361	1.01.0361.1.01.5	CU	4371769	KIT,LINER
362	1.01.0362.1.01.6	CU	4376512	KIT,LOWER ENGINE GASKET
363	1.01.0363.1.01.7	CU	4912321	GASKET,CYLINDER HEAD
364	1.01.0364.1.01.8	CU	4952020	GEAR,ACCESSORY DRIVE
365	1.01.0365.1.01.9	CU	4971772	GAUGE,TEMPERATURE
366	1.01.0366.1.01.1	CU	4979720	PUMP, LUB OIL
367	1.01.0367.1.01.2	CU	4987064	DAMPER,VIBRATION
368	1.01.0368.1.01.3	CU	5277629	KIT,UNLOADER VALVE
369	1.01.0369.1.01.4	CU	500108 M	GAUGE,TEMPERATURE
370	1.01.0370.1.01.5	CU	9235 1	BEARING,THRUST
371	1.01.0371.1.01.6	CU	9300 1	KEY,SQUARE
372	1.01.0372.1.01.7	CU	AK 4032 SS	HOSE,FLEXIBLE
373	1.01.0373.1.01.8	CU	AK 4045 SS	HOSE,FLEXIBLE
374	1.01.0374.1.01.9	CU	AK 4060 MS	HOSE,FLEXIBLE
375	1.01.0375.1.01.1	CU	AK 5014 SS	HOSE,FLEXIBLE
376	1.01.0376.1.01.2	CU	AK 5015 SS	HOSE,FLEXIBLE
377	1.01.0377.1.01.3	CU	AK 5090 SS	HOSE,FLEXIBLE
378	1.01.0378.1.01.4	CU	AK 6020 SS	HOSE,FLEXIBLE
379	1.01.0379.1.01.5	CU	AK 6045 SS	HOSE,FLEXIBLE
380	1.01.0380.1.01.6	CU	AK 6065 SS	HOSE,FLEXIBLE
381	1.01.0381.1.01.7	CU	AK16011 6MS	HOSE,FLEXIBLE
382	1.01.0382.1.01.8	CU	AK16015 6MS	HOSE,FLEXIBLE

383	1.01.0383.1.01.9	CU	AK16018 6MS	HOSE,FLEXIBLE
384	1.01.0384.1.01.1	CU	AK16022 6MC	HOSE,FLEXIBLE
385	1.01.0385.1.01.2	CU	AK16027 NF	HOSE,FLEXIBLE
386	1.01.0386.1.01.3	CU	AR40130	PLUNGER GOVERNOR
387	1.01.0387.1.01.4	CU	AR96295	SHELL, ASSEMBLY
388	1.01.0388.1.01.5	CU	AX1008862	LABOUR CHARGES OF OVERHAULING
389	1.01.0389.1.01.6	CU	BM28848	DRIVE TACHOMETER
390	1.01.0390.1.01.7	CU	BM33880	SHAFT, FUEL PUMP DRIVE
391	1.01.0391.1.01.8	CU	BM68540	COVER,HAND HOLE
392	1.01.0392.1.01.9	CU	BM74081	SHAFT,THROTTLE
393	1.01.0393.1.01.1	CU	BM76340	DAMPER,FUEL PUMP
394	1.01.0394.1.01.2	CU	BM78930	SHAFT,THROTTLE
395	1.01.0395.1.01.3	CU	JE-AX1003115	TRANSPORTAION CHARGES
396	1.01.0396.1.01.4	CU	KIT2865146	KIT,PISTON RINGS
397	1.01.0397.1.01.5	CU	KIT2865301	KIT,BARREL PLUNGER & CUP
398	1.01.0398.1.01.6	CU	KIT3238194	KIT PISTON, RING SET V-28
399	1.01.0399.1.01.7	CU	KIT3238195	KIT INJ BARREL PLUNGER
400	1.01.0400.1.01.8	CU	KIT3238204	ELEMENT LUB OIL FILTER
401	1.01.0401.1.01.9	CU	KIT3238493	KIT FUEL FILTER AND RING
402	1.01.0402.1.01.1	CU	KIT3238535	KIT PISTON ENGINE
403	1.01.0403.1.01.2	CU	KIT3239991	SET MAIN BEARING (010)
404	1.01.0404.1.01.3	CU	KIT3240239	GASKET SET
405	1.01.0405.1.01.4	CU	KIT3247965	GASKET SET VTA-1710
406	1.01.0406.1.01.5	CU	KIT3803471	SET PISTON RING
407	1.01.0407.1.01.6	CU	KIT3879488	KIT SUPER BYP.FILTER ELEM
408	1.01.0408.1.01.7	CU	KIT3880784	KIT INJECTOR REPAIR-KT
409	1.01.0409.1.01.8	CU	KIT3881132	CRANKSHAFT
410	1.01.0410.1.01.9	CU	KITAR 4220	SET, MAIN BEAR..STD.
411	1.01.0411.1.01.1	CU	KITAR 4221	SET, MAIN BEAR..STD.
412	1.01.0412.1.01.2	CU	KITAR 4222	SET, MAIN BEAR..STD.
413	1.01.0413.1.01.3	CU	KITAR12271	SHELL,MAIN BEARING .010
414	1.01.0414.1.01.4	CU	KITAR95138	GASKET SET
415	1.01.0415.1.01.5	CU	KITBM68356	GASKET GOVERNOR SET
416	1.01.0416.1.01.6	CU	S 212	NUT,REGULAR HEXAGON
417	1.01.0417.1.01.7	CU	S 221	NUT,HEAVY HEXAGON
418	1.01.0418.1.01.8	CU	S 251	NUT,REGULAR HEXAGON JAM
419	1.01.0419.1.01.9	CU	S 670	WASHER,PLAIN
420	1.01.0420.1.01.1	CU	S 679	WASHER,PLAIN
421	1.01.0421.1.01.2	CU	S 911 B	PLUG,PIPE
422	1.01.0422.1.01.3	CU	S 962 E	DRAINCOCK
423	1.01.0423.1.01.4	CU	S 988	ELBOW,PLAIN STREET PIPE
424	1.01.0424.1.01.5	CU	S 1039	ELBOW,FEMALE UNION
425	1.01.0425.1.01.6	CU	S 1040	ELBOW,PLAIN ADAPTER
426	1.01.0426.1.01.7	CU	S 1059	COUPLING,PLAIN PIPE
427	1.01.0427.1.01.8	CU	S 16002	BEARING,BALL
428	1.01.0428.1.01.9	CU	S 16069	BEARING,BALL
429	1.01.0429.1.01.1	CU	4020347	Isolator Vibration
430	1.01.0430.1.01.2	CU	3229945	GASKET EX OUT CONNECTION
431	1.01.0431.1.01.3	CU	AK 10070 SS	HOSE FLEXIBLE
432	1.01.0432.1.01.4	CU	3077198	GASKET ROCKER LEVER COVER
433	1.01.0433.1.01.5	CU	501385	CABLE FLEXABLE DRIVE
434	1.01.0434.1.01.6	CU	3020943	GASKET EXHAUST MOHIFOLD
435	1.01.0435.1.01.7	CU	3066497	SCREW HEX FLANG HEAD CAP
436	1.01.0436.1.01.8	CU	3872268	CONNECTOR PIPE
437	1.01.0437.1.01.9	CU	3049187	GASKET RKR LEVER HOUSING
438	1.01.0438.1.01.1	CU	3872284	CONNECTOR PIPE
439	1.01.0439.1.01.2	CU	AK-10072 SS	HOSE FLEXABLE
440	1.01.0440.1.01.3	CU	3035310	WASHER PLAIN
441	1.01.0441.1.01.4	CU	3076522	GASKET WATER PUMP
442	1.01.0442.1.01.5	CU	125742	CLAMP BOLT
443	1.01.0443.1.01.6	CU	3820664	HOSE PLAIN
444	1.01.0444.1.01.7	CU	3046286	SPACER MOUNTING
445	1.01.0445.1.01.8	CU	3004316	OIL SEAL
446	1.01.0446.1.01.9	CU	67532	LOCK NUT
447	1.01.0447.1.01.1	CU	3628902	WASHER PLAIN
448	1.01.0448.1.01.2	CU	AK-10032 SS	HOSE
449	1.01.0449.1.01.3	CU	AK-880 SS	HOSE
450	1.01.0450.1.01.4	CU	3030768	HOES HUMP
451	1.01.0451.1.01.5	CU	30307 R	HOSE ELBOW
452	1.01.0452.1.01.6	CU	3058356	HORNESS WIRING
453	1.01.0453.1.01.7	CU	3167127	SHAFT FAN DRIVE
454	1.01.0454.1.01.8	CU	66912-1A	SCREW HEX HEAD CAP
455	1.01.0455.1.01.9	CU	205354	SCREW TWALVE POINT CAP
456	1.01.0456.1.01.1	CU	4055075	SWITCH PRESSURE
457	1.01.0457.1.01.2	CU	3095026	SCREW HEX FLANGE HEAD CAP
458	1.01.0458.1.01.3	CU	4926975	SENCER TEMPRATURE
459	1.01.0459.1.01.4	CU	4071829	GAUGE TEMPRATURE

460	1.01.0460.1.01.5	CU	3801689	TURBOCHARGER HC5A
461	1.01.0461.1.01.6	CU	3411335	THERMOSTAT
462	1.01.0462.1.01.7	CU	3051371	PUMP WATER IDLER
463	1.01.0463.1.01.8	CU	3880663	PISTONS TING SET /KTA-1150
464	1.01.0464.1.01.9	CU	4026171	GASKAT FUEL PUMP
465	1.01.0465.1.01.1	CU	4912939	MOTOR SHORTING
466	1.01.0466.1.01.2	CU	3881509	HEAD CYLINDER
467	1.01.0467.1.01.3	CU	3879458	FUEL PUMP
468	1.01.0468.1.01.4	CU	3239790	INJECTOR ASSY
469	1.01.0469.1.01.5	CU	AR-3016676	INJECTOR LESS LINK
470	1.01.0470.1.01.6	CU	3880781	KIT BARELL & PLUNGER
471	1.01.0471.1.01.7	CU	3240746	COMPRESSOR AIR
472	1.01.0472.1.01.8	CU	3239097	PUMP WATER
473	1.01.0473.1.01.9	CU	127950	GASKET CONNECTION
474	1.01.0474.1.01.1	CU	3166497	PUMP WATER
475	1.01.0475.1.01.2	CU	147278	SUPPORT FAN
476	1.01.0476.1.01.3	CU	3246943	FAN HUB
477	1.01.0477.1.01.4	CU	3232548	FAN ENGINE
478	1.01.0478.1.01.5	CU	4344837	Pump Fuel
479	1.01.0479.1.01.6	CU	6304465	Alternator
480	1.01.0480.1.01.7	CU	3238514	B CHECK KIT
481	1.01.0481.1.01.8	CU	3238358	KIT AIR CLEANER ELEMENT
482	1.01.0482.1.01.9	CU	4021119	RADIATOR
483	1.01.0483.1.01.1	CU	3238528	B CHECK KIT
484	1.01.0484.1.01.2	CU	AR7944	AIR COMPRESSOR
485	1.01.0485.1.01.3	CU	3873512	RADIATOR
486	1.01.0486.1.01.4	CU	3879481KC445	PUMP FUEL W CAL CODE
487	1.01.0487.1.01.5	CU	3240743	AIR COMPRESSOR
488	1.01.0488.1.01.6	CU	3103972/6322723	PUMP , WATER & IDLER
489	1.01.0489.1.01.7	CU	3240744	AIR COMPRESSOR
490	1.01.0490.1.01.8	CU	3879533KC894	PUMP FUEL W.CAL CODE
491	1.01.0491.1.01.9	CU	5301090	AIR COMPRESSOR
492	1.01.0492.1.01.1	CU	5254004	PUMP FUEL INJECTION
493	1.01.0493.1.01.2	CU	3973114	PUMP , WATER & IDLER
494	1.01.0494.1.01.3	CU	3329289	FUEL WATER FS1000
495	1.01.0495.1.01.4	CU	AX1006742/ FS19763.G	FUEL FILTER
496	1.01.0496.1.01.5	CU	4331005/2882674	LUB OIL FILTER
497	1.01.0497.1.01.6	CU	3238627	B CHECK KIT
498	1.01.0498.1.01.7	CU	3238665	KIT AIR CLEANER ELEMENT
499	1.01.0499.1.01.8	CU	3411760	INJECTOR
500	1.01.0500.1.01.9	CU	3284454	PUMP,FUEL
501	1.01.0501.1.01.1	CU	A062Y519	RADIATOR
502	1.01.0502.1.01.2	CU	4344509	TLA FUEL FILTER
503	1.01.0503.1.01.3	CU	3095556KG19	PT PUMP
504	1.01.0504.1.01.4	CU	4911769	PT PUMP
505	1.01.0505.1.01.5	CU	3093637	PUMP FUEL INJECTION
506	1.01.0506.1.01.6	CU	3093696	HARNESS WIRING (Main Engine Harness wiring)
507	1.01.0507.1.01.7	CU	4067815	HARNESS,WIRING (Engine Accessory- Alternator Harness wiring)
508	1.01.0508.1.01.8	CU	5260634	PUMP,FUEL TRANSFER (FUEL LIFT)
509	1.01.0509.1.01.9	CU	5594395	SENSOR,FUEL PRESSURE
510	1.01.0510.1.01.1	CU	4076493/2897331	SENSOR, AMBIENT AIR PRESSURE
511	1.01.0511.1.01.2	CU	3408472/3865349/ 4327239	SENSOR,SPEED (MAGNETIC PICKUP UNIT)
512	1.01.0512.1.01.3	CU	3408560	SENSOR OIL PRESSURE
513	1.01.0513.1.01.4	CU	3408556	COOLANT PRESSURE SENSOR/INTAKE MANIFOLD PRESSURE SENSOR
514	1.01.0514.1.01.5	CU	4954905/3096153	COOLANT TEMPERATURE SENSOR/FUEL TEMPERATURE SENSOR/LUBE OIL TEMPERATURE SENSOR
515	1.01.0515.1.01.6	CU	4088832	INTAKE MANIFOLD TEMPERATURE SENSOR
516	1.01.0516.1.01.7	CU	0193-0486, A055K311	SENSOR COOLANT LEVEL
517	1.01.0517.1.01.8	CU	3400698	ALTERNATOR
518	1.01.0518.1.01.9	CU	3093176	ALTERNATOR Belt
519	1.01.0519.1.01.1	CU	5413006/3003343	BELT V RIBBED (RADIATOR FAN BELT)
520	1.01.0520.1.01.2	CU	4081237	Motor starting(self starter)
521	1.01.0521.1.01.3	CU	3003697	BLANKET TURBOCHARGER HEAT
522	1.01.0522.1.01.4	CU	3594190	TURBOCHARGER
523	1.01.0523.1.01.5	CU	3035766	ENGINE HOURMETER
524	1.01.0524.1.01.6	CU	3031734	TACHOMETER
525	1.01.0525.1.01.7	CU	3658780	FUEL RELAY
526	1.01.0526.1.01.8	CU	3021420	SOLENOID FUEL SHUT OFF VALVE
527	1.01.0527.1.01.9	CU	3050692	SWITCH,MAGNETIC

528	1.01.0528.1.01.1	CU	3094043	CLAMP V BAND
529	1.01.0529.1.01.2	CU	201989	CLAMP-V BAND 5.00
530	1.01.0530.1.01.3	CU	131536 / 3093594	WATER PUMP
531	1.01.0531.1.01.4	CU	2871203	Module Electronic control
532	1.01.0532.1.01.5	CU	3238132	KIT Air cleaner NTA 855 BC
533	1.01.0533.1.01.6	CU	3878141	Radiator(KTA 115 0)
534	1.01.0534.1.01.7	CU	3413254	RADIATOR
535	1.01.0535.1.01.8	CU	3413433	RADIATOR
536	1.01.0536.1.01.9	CU	4963761	RADIATOR
537	1.01.0537.1.01.1	CU	4950317	PUMP , WATER & IDLER
538	1.01.0538.1.01.2	CU	3801918	TURBO CHARGER
539	1.01.0539.1.01.3	CU	4071418 KE230	PUMP FUEL W CAL CODE
540	1.01.0540.1.01.4	CU	3238515	B CHECK KIT
541	1.01.0541.1.01.5	CU	3238155	KIT AIR CLEANER ELEMENT
542	1.01.0542.1.01.6	CU	3889310	LUB OIL PRE FILTER
543	1.01.0543.1.01.7	CU	3873576	LUB OIL BYPASS FILTER
544	1.01.0544.1.01.8	CU	4084133	FUEL FILTER
545	1.01.0545.1.01.9	CU	3238543	B CHECK KIT
546	1.01.0546.1.01.1	CU	3875559	AIR CLEANER ELEMENT INNER
547	1.01.0547.1.01.2	CU	3875560	AIR CLEANER ELEMENT OUTER
548	1.01.0548.1.01.3	CU	4968914/ AX1005332	AIR CLEANER ELEMENT INNER
549	1.01.0549.1.01.4	CU	FH 23457	Fuel Filter Assy with priming pump
550	1.01.0550.1.01.5	CU	3558028	AIR COMPRESSOR
551	1.01.0551.1.01.6	CU	4072352	COOLANT FILTER
552	1.01.0552.1.01.7	CU	218027	COMPRESSOR DRIVE GASKET
553	1.01.0553.1.01.8	CU	4104832	WATER HOSE
554	1.01.0554.1.01.9	CU	3814312	AIR CLEANER ELEMENT
555	1.01.0555.1.01.1	CU	3814313	AIR CLEANER ELEMENT
556	1.01.0556.1.01.2	CU	3954904	FUEL FILTER
557	1.01.0557.1.01.3	CU	3978040	FUEL FILTER
558	1.01.0558.1.01.4	CU	4055579	AIR CLEANER ELEMENT INNER
559	1.01.0559.1.01.5	CU	4055580	AIR CLEANER ELEMENT OUTER
560	1.01.0560.1.01.6	CU	00500410/3229873	GAUGE,TEMPERATURE
561	1.01.0561.1.01.7	CU	4071831	GAUGE,TEMPERATURE
562	1.01.0562.1.01.8	CU	4071832	LUB OIL PRESSURE GAUGE
563	1.01.0563.1.01.9	CU	4071835	OIL SENSOR PRESSURE
564	1.01.0564.1.01.1	CU	3015232	GAUGE, PRESSURE
565	1.01.0565.1.01.2	CU	503473	CABLE FLEXIBLE DRIVE
566	1.01.0566.1.01.3	CU	500188	CABLE FLEXIBLE DRIVE
567	1.01.0567.1.01.4	CU	3166925	MAGNETIC SWITCH
568	1.01.0568.1.01.5	CU	2879766	TACHO METER
569	1.01.0569.1.01.6	CU	3066311	ROCKER LIVER GASKET
570	1.01.0570.1.01.7	CU	4920076	GASKET ROCKER LEVER COVER
571	1.01.0571.1.01.8	CU	3876031	SHAFT FAN HUB
572	1.01.0572.1.01.9	CU	3067459	GASKET,ROCKER LEVER COVER
573	1.01.0573.1.01.1	CU	3408631	TEMP. SWITCH
574	1.01.0574.1.01.2	CU	3240080	CHECK VALVE FOR FUEL FILTER
575	1.01.0575.1.01.3	CU	3240088	FUEL LINE NRV
576	1.01.0576.1.01.4	CU	4913273	COIL ELBOW NRV
577	1.01.0577.1.01.5	CU	5036752/4331011	FUEL FILTER
578	1.01.0578.1.01.6	CU	4008708/4331003	LUB OIL FILTER
579	1.01.0579.1.01.7	CU	400879/4907485	RESISTOR CORROSION
580	1.01.0580.1.01.8	CU	3878758	Radiator
581	1.01.0581.1.01.9	CU	4039265	TURBOCHARGER
582	1.01.0582.1.01.1	CU	3926787	INJECTOR
583	1.01.0583.1.01.2	CU	3881226	COMPRESSOR, AIR
584	1.01.0584.1.01.3	CU	3071497	INJECTOR
585	1.01.0585.1.01.4	CU	RO 3525998 SUB.3801918	TURBOCHARGER
586	1.01.0586.1.01.5	CU	3069177	GASKET,TURBOCHARGER
587	1.01.0587.1.01.6	CU	201048	GASKET CONNECTION
588	1.01.0588.1.01.7	CU	3060613	HOSE,PLAIN
589	1.01.0589.1.01.8	CU	208326	CLAMP,T BOLT
590	1.01.0590.1.01.9	CU	216487	GASKET, CONNECTION
591	1.01.0591.1.01.1	CU	3069103	GASKET,FUEL PUMP
592	1.01.0592.1.01.2	CU	3414709	PULLEY,ALTERNATOR
593	1.01.0593.1.01.3	CU	3873966	PLATE COVER
594	1.01.0594.1.01.4	CU	3873964	BLOCK,PIVOT
595	1.01.0595.1.01.5	CU	3228679	KEY,SQUARE
596	1.01.0596.1.01.6	CU	3229047	SLEEVE
597	1.01.0597.1.01.7	CU	3229045	PULLEY,FAN
598	1.01.0598.1.01.8	CU	5278681	RADIATOR
599	1.01.0599.1.01.9	CU	3815424	SEPARATOR,FUEL WATER
600	1.01.0600.1.01.1	CU	3184454	PUMP,FUEL
601	1.01.0601.1.01.2	CU	4072315/4347439	RADIATOR FAN

602	1.01.0602.1.01.3	CU	S-102-A	SCREW HEXAGON HEAD CUP
603	1.01.0603.1.01.4	CU	S-605	WASHER LOCK
604	1.01.0604.1.01.5	CU	3167217	COOLANT(5ltrs.)
605	1.01.0605.1.01.6	CU	4008709	COOLANT FILTER
606	1.01.0606.1.01.7	CU	5036752	FUEL FILTER
607	1.01.0607.1.01.8	CU	4070801	FUEL WATER SEPARATOR
608	1.01.0608.1.01.9	CU	4008708	LUBE OIL FILTER
609	1.01.0609.1.01.1	CU	0-3610008-01-01	PRIMARY AIR FILTER
610	1.01.0610.1.01.2	CU	0-3610008-01-02	SAFETY AIR FILTER
611	1.01.0611.1.01.3	CU	584867	V BELT
612	1.01.0612.1.01.4	CU	178636	V BELT
613	1.01.0613.1.01.5	CU	3028521	V BELT
614	1.01.0614.1.01.6	CU	3098363	V BELT
615	1.01.0615.1.01.7	CU	5413209	V BELT
616	1.01.0616.1.01.8	CU	3289279	V BELT
617	1.01.0617.1.01.9	CU	4933315	V BELT
618	1.01.0618.1.01.1	CU	3103697	V BELT
619	1.01.0619.1.01.2	CU	A4656Y11	WATER SEPARATOR
620	1.01.0620.1.01.3	CU	4020552	ELEMENT,AIR CLEANER
621	1.01.0621.1.01.4	CU	5483426	ALTERNATOR BELT
622	1.01.0622.1.01.5	CU	3408625/ 3408636	TEMP. SWITCH
623	1.01.0623.1.01.6	CU	4071912	HOSE PIPE
624	1.01.0624.1.01.7	CU	4071913	HOSE PIPE
625	1.01.0625.1.01.8	CU	500185	HOSE METER CABLE
626	1.01.0626.1.01.9	CU	3235129	VALVE,PRESSURE REGULATOR
627	1.01.0627.1.01.1	CU	4345748	Fuel Pump
628	1.01.0628.1.01.2	CU	3016791	OIL Seal
629	1.01.0629.1.01.3	CU	4072233	Overhaul Gasket (Upper)
630	1.01.0630.1.01.4	CU	4072229	Overhaul Gasket (Lower)
631	1.01.0631.1.01.5	CU	4963718	Fuel Pump Solenoid
632	1.01.0632.1.01.6	CU	4024808	Valve Solenoid
633	1.01.0633.1.01.7	CU	4921473	Sensor
634	1.01.0634.1.01.8	CU	4921499	Sensor
635	1.01.0635.1.01.9	CU	3100141	BELT,V RIBBED
636	1.01.0636.1.01.1	CU	3903475	Seal Ract. Ring
637	1.01.0637.1.01.2	CU	4024883	SEALOIL
638	1.01.0638.1.01.3	CU	5259499	SEAL OIL
639	1.01.0639.1.01.4	CU	5272471	GASKET,REAR COVER
640	1.01.0640.1.01.5	CU	3944293	GASKET,GEAR HOUSING
641	1.01.0641.1.01.6	CU	4924947	ELEMENT,AIR CLEANER
642	1.01.0642.1.01.7	CU	3880315	Fan Hub
643	1.01.0643.1.01.8	CU	AX 1005287	Feed Pump
644	1.01.0644.1.01.9	CU	3878153	Hose Pipe
645	1.01.0645.1.01.1	CU	3522294	Turbo charger
646	1.01.0646.1.01.2	CU	3005144(KTA1150)	Acc Drive
647	1.01.0647.1.01.3	CU	3005133(NTA855LBC)	Acc Drive
648	1.01.0648.1.01.4	CU	3878707	Fan Hub
649	1.01.0649.1.01.5	CU	3878709	SHAFT,FAN HUB
650	1.01.0650.1.01.6	CU	3878710	SPACER,FAN
651	1.01.0651.1.01.7	CU	3878705	FAN,ENGINE
652	1.01.0652.1.01.8	CU	3236287	Bearing
653	1.01.0653.1.01.9	CU	142176	NUT,LOCK
654	1.01.0654.1.01.1	CU	3232608	KEY,SQUARE
655	1.01.0655.1.01.2	CU	4331011	Fuel Filter
656	1.01.0656.1.01.3	CU	4331003	Lub Oil Filter
657	1.01.0657.1.01.4	CU	4907485	RESISTOR,CORROSION
658	1.01.0658.1.01.5	CU	4962810	Fuel Filter
659	1.01.0659.1.01.6	CU	4104821	Coolant Filter
660	1.01.0660.1.01.7	CU	3040349	V .Belt
661	1.01.0661.1.01.8	CU	3875341	Silencer
662	1.01.0662.1.01.9	CU	3801468	Overhaul Gasket (Bottom)
663	1.01.0663.1.01.1	CU	4071920	Hose Flexible
664	1.01.0664.1.01.2	CU	3090942	Fuel Pump
665	1.01.0665.1.01.3	CU	3104683	BELT,V RIBBED
666	1.01.0666.1.01.4	CU	3101314	BELT,V RIBBED
667	1.01.0667.1.01.5	CU	5262314	After Cooler
668	1.01.0668.1.01.6	CU	3873967	Bearing, Roller
669	1.01.0669.1.01.7	CU	3008947	Seal Key, Way
670	1.01.0670.1.01.8	CU	2884976	Gasket Pan Oil
671	1.01.0671.1.01.9	CU	3227452	Cover, Oil
672	1.01.0672.1.01.1	CU	SM-90	Self-starter
673	1.01.0673.1.01.2	CU	5278100 (24V)	Self-starter
674	1.01.0674.1.01.3	CU	339A112003896675	V-Belt for accessories drive
675	1.01.0675.1.01.4	CU	3815084 SUB 2867709	ALTERNATOR PULLY
676	1.01.0676.1.01.5	CU	2872279 SUB 5594276	Position Sensor
677	1.01.0677.1.01.6	CU	4358810 SUB 5491435	Pressure Sensor
678	1.01.0678.1.01.7	CU	2897334	Pressure Temp. Sensor

679	1.01.0679.1.01.8	CU	3030778	Hose, Elbow
680	1.01.0680.1.01.9	CU	3408636 SUB 4327024	SWITCH TEMP.
681	1.01.0681.1.01.1	CU	3408608 SUBS OEM PART NO 2897692	Switch Pressure
682	1.01.0682.1.01.2	CU	211498	Air Compressor Belt
683	1.01.0683.1.01.3	CU	KIT-3238543	B-check kit
684	1.01.0684.1.01.4	CU	3877642	Connection, Exhaust Outlet
685	1.01.0685.1.01.5	CU	3201119	LUBE OIL PUMP
686	1.01.0686.1.01.6	CU	3525998	TURBO CHARGER
687	1.01.0687.1.01.7	CU	4072315 SUB 4347439	FAN (ENGINE)
688	1.01.0688.1.01.8	CU	3792192/91 sub OEM part no 5452087	Turbo Charger
689	1.01.0689.1.01.9	CU	4963807	Electronic Control Module
690	1.01.0690.1.01.1	CU	4398686	Module, Aut Stg Control
691	1.01.0691.1.01.2	CU	4039331 SUB 4955158	TURBO CHARGER
692	1.01.0692.1.01.3	CU	4346256	Fuel Pump
693	1.02.0001.1.01.6	PL	3900025224	ELBOW
694	1.02.0002.1.01.7	PL	130X6MM.90LG	CONNECTING PIECE
695	1.02.0003.1.01.8	PL	ABA104-138/12	HOSE CLIP
696	1.02.0004.1.01.9	PL	ABA130-165/12	HOSE CLIP
697	1.02.0005.1.01.1	PL	ID 130-300LG	GUSETTED TUBE
698	1.02.0006.1.01.2	PL	ROHR130X2ST37BK.DIN2393	PRECISION STEEL TUBE WELDED 250MM LENGTH
699	1.02.0007.1.01.3		Shifted to Annexure II	
700	1.02.0008.1.01.4		Shifted to Annexure II	
701	1.02.0009.1.01.5	DE	0 001 417 058 /	SELF STARTER
702	1.02.0010.1.01.6	DE	0 120 339 537	ALTERNATOR
703	1.02.0011.1.01.7		Shifted to Annexure II	
704	1.02.0012.1.01.8		Shifted to Annexure II	
705	1.02.0013.1.01.9	DE	0 120 689 511 / 0 120 689 543	ALTERNATOR
706	1.02.0014.1.01.1	DE	0 290 800 052	SUPPRESSION CAPACITOR
707	1.02.0015.1.01.2	DE	0 330 001 016	SOLENOID COIL / SWITCH
708	1.02.0016.1.01.3	DE	0 330 004 004	SWITCH
709	1.02.0017.1.01.4	DE	0 331 101 005	CONTROL RELAY
710	1.02.0018.1.01.5	DE	0 331 101 006	CONTROL RELAY
711	1.02.0019.1.01.6	DE	0 331 402 206	SOLENOID
712	1.02.0020.1.01.7	DE	0 331 450 001	SOLENOID
713	1.02.0021.1.01.8	DE	0 331 450 002	SOLENOID
714	1.02.0022.1.01.9	DE	0 401 840 754	FUEL PUMP
715	1.02.0023.1.01.1	DE	0 401 870 070	FUEL PUMP
716	1.02.0024.1.01.2	DE	0 432 131 880	INJECTORS
717	1.02.0025.1.01.3	DE	0 432 291 520	INJECTORS
718	1.02.0026.1.01.4	DE	0 432 291 699	INJECTORS
719	1.02.0027.1.01.5	DE	0 433 171 066	NOZZLE
720	1.02.0028.1.01.6	DE	0 433 271 685	NOZZLE
721	1.02.0029.1.01.7	DE	0 433 271 819	NOZZLE
722	1.02.0030.1.01.8	DE	0 440 008 008 / 0 440 008 995	FEED PUMP
723	1.02.0031.1.01.9	DE	0 440 008 009 / 0 440 008 076	FEED PUMP
724	1.02.0032.1.01.1	DE	0 451 105 067	FILTER
725	1.02.0033.1.01.2	DE	0 460 426 073	FUEL PUMP
726	1.02.0034.1.01.3	DE	0148-01-001	DUMMY
727	1.02.0035.1.01.4	DE	0148-01-003	PARALLEL PIN
728	1.02.0036.1.01.5	DE	0148-01-004	DOWEL PIN
729	1.02.0037.1.01.6	DE	0148-01-005	ALLEN BOLT
730	1.02.0038.1.01.7	DE	0148-01-006	COVER
731	1.02.0039.1.01.8	DE	0148-01-008	SCREW PLUG
732	1.02.0040.1.01.9	DE	0148-01-009	CORE HOLE PLUG
733	1.02.0041.1.01.1	DE	0148-01-010	PLUG
734	1.02.0042.1.01.2	DE	0148-01-013	CAM THRUST PLATE
735	1.02.0043.1.01.3	DE	0148-01-015	BUSH
736	1.02.0044.1.01.4	DE	0148-01-016	BUSH
737	1.02.0045.1.01.5	DE	0148-01-017	SCREW PLUG
738	1.02.0046.1.01.6	DE	0148-01-018	SEALING RING
739	1.02.0047.1.01.7	DE	0148-01-019	CAP NUT
740	1.02.0048.1.01.8	DE	0148-01-020	ADJUSTING SCREW
741	1.02.0049.1.01.9	DE	0148-01-021	SPRING
742	1.02.0050.1.01.1	DE	0148-01-02149331	L. HOSE
743	1.02.0051.1.01.2	DE	0148-01-022	PRESSURE RELIEF VALVE
744	1.02.0052.1.01.3	DE	0148-01-025	SCREW PLUG
745	1.02.0053.1.01.4	DE	0148-01-027	SCREW PLUG
746	1.02.0054.1.01.5	DE	0148-01-028	MAIN BEARING
747	1.02.0055.1.01.6	DE	0148-01-028/1	MAIN BEARING (1U/S)
748	1.02.0056.1.01.7	DE	0148-01-028/2	MAIN BEARING (2U/S)
749	1.02.0057.1.01.8	DE	0148-01-028/3	MAIN BEARING (3U/S)
750	1.02.0058.1.01.9	DE	0148-01-028/4	MAIN BEARING (4U/S)
751	1.02.0059.1.01.1	DE	0148-01-028/5	MAIN BEARING (5 U/S)

752	1.02.0060.1.01.2	DE	0148-01-029	THRUST WASHER
753	1.02.0061.1.01.3	DE	0148-01-031	HEX BOLT
754	1.02.0062.1.01.4	DE	0148-01-034	OIL PIPE
755	1.02.0063.1.01.5	DE	0148-01-035	ALLEN BOLT
756	1.02.0064.1.01.6	DE	0148-01-036	O-SEAL
757	1.02.0065.1.01.7	DE	0148-01-037	COVER
758	1.02.0066.1.01.8	DE	0148-01-040	GASKET
759	1.02.0067.1.01.9	DE	0148-01-043	ROT. SHAFT LIP SEAL
760	1.02.0068.1.01.1	DE	0148-01-044	PACKING COMPOUND
761	1.02.0069.1.01.2	DE	0148-01-045	TAPPET BRIDGE PIPE
762	1.02.0070.1.01.3	DE	0148-01-046	TAPPET BRIDGE
763	1.02.0071.1.01.4	DE	0148-01-047	SLEEVE
764	1.02.0072.1.01.5	DE	0148-01-048	RUBBER RING
765	1.02.0073.1.01.6	DE	0148-01-050	OVER PRESSURE VALVE
766	1.02.0074.1.01.7	DE	0148-01-052	NOZZLE
767	1.02.0075.1.01.8	DE	0148-01-058	SPACER FOR SCREEN PLATE
768	1.02.0076.1.01.9	DE	0148-01-079	SOLUTION
769	1.02.0077.1.01.1	DE	0148-01-121	DIPSTICK
770	1.02.0078.1.01.2	DE	0148-01-128	CLAMP FOR TUBE
771	1.02.0079.1.01.3	DE	0148-01-132	ADAPTER
772	1.02.0080.1.01.4	DE	0148-01-134	TUBE
773	1.02.0081.1.01.5	DE	0148-01-135	BRACKET FOR ABOVE
774	1.02.0082.1.01.6	DE	0148-01-161	BOLT
775	1.02.0083.1.01.7	DE	0148-01-162	PIPE
776	1.02.0084.1.01.8	DE	0148-01-163	WASHER
777	1.02.0085.1.01.9	DE	0148-01-164	NUT
778	1.02.0086.1.01.1	DE	0148-01-165	HOSE CLIP
779	1.02.0087.1.01.2	DE	0148-01-166	RUBBER SLEEVE
780	1.02.0088.1.01.3	DE	0148-01-167	VACUUM HOSE
781	1.02.0089.1.01.4	DE	0148-01-168	SOCKET/ADAPTER
782	1.02.0090.1.01.5	DE	0148-01-169	SEALING RING
783	1.02.0091.1.01.6	DE	0148-01-170	HOSE CLIP
784	1.02.0092.1.01.7	DE	0148-01-171	RUBBER HOSE
785	1.02.0093.1.01.8	DE	0148-01-172	VALVE MECHAN CAS
786	1.02.0094.1.01.9	DE	0148-01-173	BREATHING ASSY.
787	1.02.0095.1.01.1	DE	0148-01-175	O SEAL
788	1.02.0096.1.01.2	DE	0148-01-177	CHEESE HEAD SCREW
789	1.02.0097.1.01.3	DE	0148-01-179	CHEESE HEAD SCREW
790	1.02.0098.1.01.4	DE	0148-01-183	VALVE INSERT
791	1.02.0099.1.01.5	DE	0148-01-192	OIL SEPARATOR
792	1.02.0100.1.01.6	DE	0148-01-193	HOSE CLIP
793	1.02.0101.1.01.7	DE	0148-01-194	PIPE ELBOW
794	1.02.0102.1.01.8	DE	0148-01-196	PLAIN WASHER
795	1.02.0103.1.01.9	DE	0148-01-197	OIL SEAL
796	1.02.0104.1.01.1	DE	0148-01-198	RUBBER SLEEVE
797	1.02.0105.1.01.2	DE	0148-01-200	PIPE ELBOW
798	1.02.0106.1.01.3	DE	0148-01-201	RUBBER SLEEVE
799	1.02.0107.1.01.4	DE	0148-01-202	BREATHING HOUSING
800	1.02.0108.1.01.5	DE	0148-01-203	HOSE CLIP
801	1.02.0109.1.01.6	DE	0148-01-204	OIL SEAL
802	1.02.0110.1.01.7	DE	0148-01-205	DIAPHRAGM FOR BREATHING
803	1.02.0111.1.01.8	DE	0148-01-2297	HALF STOP RING
804	1.02.0112.1.01.9	DE	0148-01-241	CAP
805	1.02.0113.1.01.1	DE	0148-01-245	CLAMP
806	1.02.0114.1.01.2	DE	0148-01-248	HOSE CLIP
807	1.02.0115.1.01.3	DE	0148-01-266	HEXAGON BOLT
808	1.02.0116.1.01.4	DE	0148-01-267	OIL FILLER
809	1.02.0117.1.01.5	DE	0148-01-269	BRACKET
810	1.02.0118.1.01.6	DE	0148-01-270	RUBBER SLEEVE
811	1.02.0119.1.01.7	DE	0148-01-271	PLAIN WASHER
812	1.02.0120.1.01.8	DE	0148-01-272	OIL FILLER
813	1.02.0121.1.01.9	DE	0148-01-356	RUBBER HOSE
814	1.02.0122.1.01.1	DE	0148-01-360	RUBBER SLEEVE
815	1.02.0123.1.01.2	DE	0148-01-361	CARRIER ASSEMBLY
816	1.02.0124.1.01.3	DE	0148-01-368	ROT. SHAFT LIP SEAL
817	1.02.0125.1.01.4	DE	0148-01-376	O' SEAL
818	1.02.0126.1.01.5	DE	0148-01-377	GASKET
819	1.02.0127.1.01.6	DE	0148-01-379	WASHER
820	1.02.0128.1.01.7	DE	0148-01-380	LUB OIL TUBE
821	1.02.0129.1.01.8	DE	0148-01-441	PACKING COMPOUND
822	1.02.0130.1.01.9	DE	0148-01-481	HOSE CLIP
823	1.02.0131.1.01.1	DE	0148-01-482	RUBBER SLEEVE
824	1.02.0132.1.01.2	DE	0148-01-483	BREATHING LINE
825	1.02.0133.1.01.3	DE	0148-01-487	HEXAGON BOLT
826	1.02.0134.1.01.4	DE	0148-01-488	PLAIN WASHER
827	1.02.0135.1.01.5	DE	0148-01-489	PIPE CLAMP
828	1.02.0136.1.01.6	DE	0148-01-490	HEXAGON NUT

829	1.02.0137.1.01.7	DE	0148-01-499	RUBBER GROMMET
830	1.02.0138.1.01.8	DE	0148-01-526	ELBOW
831	1.02.0139.1.01.9	DE	0148-02-002	OIL PAN GASKET
832	1.02.0140.1.01.1	DE	0148-02-003	BOLT
833	1.02.0141.1.01.2	DE	0148-02-004	WASHER
834	1.02.0142.1.01.3	DE	0148-02-017	SOLUTION
835	1.02.0143.1.01.4	DE	0148-02-046	BOLT
836	1.02.0144.1.01.5	DE	0148-02-047	SPRING WASHER
837	1.02.0145.1.01.6	DE	0148-02-048	WASHER
838	1.02.0146.1.01.7	DE	0148-02-050	HEXAGON BOLT
839	1.02.0147.1.01.8	DE	0148-02-054	BOLT
840	1.02.0148.1.01.9	DE	0148-04-001	CYLINDER
841	1.02.0149.1.01.1	DE	0148-04-002	SPACER RING
842	1.02.0150.1.01.2	DE	0148-04-003	SPACER RING
843	1.02.0151.1.01.3	DE	0148-04-004	SPACER RING
844	1.02.0152.1.01.4	DE	0148-04-005	O SEAL
845	1.02.0153.1.01.5	DE	0148-04-006	SPACER RING
846	1.02.0154.1.01.6	DE	0148-05-003	CHEESE HEAD SCREW
847	1.02.0155.1.01.7	DE	0148-05-041	CHEESE HEAD SCREW
848	1.02.0156.1.01.8	DE	0148-05-042	BELT PULLEY
849	1.02.0157.1.01.9	DE	0148-05-043	TORS. VIBRATE DAMPER
850	1.02.0158.1.01.1	DE	0148-05-048	BALL BEARING
851	1.02.0159.1.01.2	DE	0148-05-050	GEAR RIM
852	1.02.0160.1.01.3	DE	0148-05-051	FLY WHEEL BOLT
853	1.02.0161.1.01.4	DE	0148-05-063	HEXAGON BOLT
854	1.02.0162.1.01.5	DE	0148-05-064	BEARING FLANGE
855	1.02.0163.1.01.6	DE	0148-06-001	CONNECTING ROD
856	1.02.0164.1.01.7	DE	0148-06-002	BIG END BUSH
857	1.02.0165.1.01.8	DE	0148-06-003	BIG END BEARING
858	1.02.0166.1.01.9	DE	0148-06-003/1	BIG END BEARING (1U/S)
859	1.02.0167.1.01.1	DE	0148-06-003/2	BIG END BEARING (2U/S)
860	1.02.0168.1.01.2	DE	0148-06-003/3	BIG END BEARING (3U/S)
861	1.02.0169.1.01.3	DE	0148-06-003/4	BIG END BEARING (4U/S)
862	1.02.0170.1.01.4	DE	0148-06-003/5	CON ROD BEARING (5 U/S)
863	1.02.0171.1.01.5	DE	0148-06-004	CENTERING PIECE
864	1.02.0172.1.01.6	DE	0148-06-005	BIG END BOLT
865	1.02.0173.1.01.7	DE	0148-07-001	PISTON
866	1.02.0174.1.01.8	DE	0148-07-004	SET OF PISTON RING
867	1.02.0175.1.01.9	DE	0148-08-001	INLET VALVE
868	1.02.0176.1.01.1	DE	0148-08-002	VALVE SEAT INSERT
869	1.02.0177.1.01.2	DE	0148-08-003	EXHAUST VALVE
870	1.02.0178.1.01.3	DE	0148-08-004	VALVE SEAT INSERT
871	1.02.0179.1.01.4	DE	0148-08-005	PLAIN WASHER
872	1.02.0180.1.01.5	DE	0148-08-006	CYLINDER HEAD BOLT
873	1.02.0181.1.01.6	DE	0148-08-007	STUD
874	1.02.0182.1.01.7	DE	0148-08-008	STUD
875	1.02.0183.1.01.8	DE	0148-08-010	CYLINDER HEAD
876	1.02.0184.1.01.9	DE	0148-08-011	VALVE GUIDE
877	1.02.0185.1.01.1	DE	0148-08-012	VALVE GUIDE
878	1.02.0186.1.01.2	DE	0148-08-013	SQ. WASHER FOR BOLT
879	1.02.0187.1.01.3	DE	0148-08-014	STUD
880	1.02.0188.1.01.4	DE	0148-08-015	GASKET
881	1.02.0189.1.01.5	DE	0148-08-017	HEXAGON BOLT
882	1.02.0190.1.01.6	DE	0148-08-018	SEALING CONE
883	1.02.0191.1.01.7	DE	0148-08-019	O SEAL
884	1.02.0192.1.01.8	DE	0148-08-022	O SEAL
885	1.02.0193.1.01.9	DE	0148-08-023	LUB OIL RETURN LINE
886	1.02.0194.1.01.1	DE	0148-08-025	PLAIN WASHER
887	1.02.0195.1.01.2	DE	0148-08-027	HEXAGON BOLT
888	1.02.0196.1.01.3	DE	0148-08-028	SEALING SECTION
889	1.02.0197.1.01.4	DE	0148-08-029	TAPER COLLET PIECE
890	1.02.0198.1.01.5	DE	0148-08-030	VALVE CUP
891	1.02.0199.1.01.6	DE	0148-08-031	SHIM
892	1.02.0200.1.01.7	DE	0148-08-032	SHIM
893	1.02.0201.1.01.8	DE	0148-08-033	VALVE ROTATOR
894	1.02.0202.1.01.9	DE	0148-08-034	SHIM
895	1.02.0203.1.01.1	DE	0148-08-035	SHIM
896	1.02.0204.1.01.2	DE	0148-08-036	SHIM
897	1.02.0205.1.01.3	DE	0148-08-037	SHIM
898	1.02.0206.1.01.4	DE	0148-08-038	SPRING SEAL
899	1.02.0207.1.01.5	DE	0148-08-040	VALVE SPRING
900	1.02.0208.1.01.6	DE	0148-08-041	VALVE MECHAN. COVER
901	1.02.0209.1.01.7	DE	0148-08-043	GASKET
902	1.02.0210.1.01.8	DE	0148-08-044	BOLT
903	1.02.0211.1.01.9	DE	0148-08-047	VALVE SEAL
904	1.02.0212.1.01.1	DE	0148-10-001	CAMSHAFT
905	1.02.0213.1.01.2	DE	0148-10-002	CAM BOLT

906	1.02.0214.1.01.3	DE	0148-10-003	TOOTHED GEAR
907	1.02.0215.1.01.4	DE	0148-10-004	WASHER
908	1.02.0216.1.01.5	DE	0148-10-005	CAM SHAFT BOLT
909	1.02.0217.1.01.6	DE	0148-11-001	VALVE TAPPET
910	1.02.0218.1.01.7	DE	0148-11-002	O SEAL
911	1.02.0219.1.01.8	DE	0148-11-003	PUSH TUBE SLEEVE
912	1.02.0220.1.01.9	DE	0148-11-004	PUSH ROD
913	1.02.0221.1.01.1	DE	0148-11-005	O SEAL
914	1.02.0222.1.01.2	DE	0148-11-006	ROCKER ARM BRACKET
915	1.02.0223.1.01.3	DE	0148-11-007	ROCKER ARM
916	1.02.0224.1.01.4	DE	0148-11-008	R.A.SCREW
917	1.02.0225.1.01.5	DE	0148-11-009	ROCKER ADJUSTMENT NUT
918	1.02.0226.1.01.6	DE	0148-11-010	HEXAGON BOLT
919	1.02.0227.1.01.7	DE	0148-14-007	OIL PRESS PUMP
920	1.02.0228.1.01.8	DE	0148-15-006	SCREW PLUG
921	1.02.0229.1.01.9	DE	0148-15-008	ADAPTER
922	1.02.0230.1.01.1	DE	0148-15-012	SCREW FITTING
923	1.02.0231.1.01.2	DE	0148-15-019	PLATE
924	1.02.0232.1.01.3	DE	0148-15-020	BOLT
925	1.02.0233.1.01.4	DE	0148-15-021	SPIN ON FILTER
926	1.02.0234.1.01.5	DE	0148-15-022	LOCK WASHER
927	1.02.0235.1.01.6	DE	0148-15-023	HOSE CLIP
928	1.02.0236.1.01.7	DE	0148-15-161	OIL COOLER
929	1.02.0237.1.01.8	DE	0148-15-162	RUBBER STRIP
930	1.02.0238.1.01.9	DE	0148-15-164	COVER PLATE
931	1.02.0239.1.01.1	DE	0148-15-165	HEXAGON BOLT
932	1.02.0240.1.01.2	DE	0148-15-166	COVER PLATE
933	1.02.0241.1.01.3	DE	0148-15-168	O SEAL
934	1.02.0242.1.01.4	DE	0148-15-169	BOLT
935	1.02.0243.1.01.5	DE	0148-15-179	SPRING WASHER
936	1.02.0244.1.01.6	DE	0148-15-180	PLAIN WASHER
937	1.02.0245.1.01.7	DE	0148-15-194	WASHER
938	1.02.0246.1.01.8	DE	0148-15-208	CLAMPING SECTION
939	1.02.0247.1.01.9	DE	0148-15-209	CLAMPING SECTION
940	1.02.0248.1.01.1	DE	0148-15-243	OIL COOLER
941	1.02.0249.1.01.2	DE	0148-16-002	ANGLED RETAINER
942	1.02.0250.1.01.3	DE	0148-16-003	SEALING RING
943	1.02.0251.1.01.4	DE	0148-16-004	UNION FOR LUB OIL LINE
944	1.02.0252.1.01.5	DE	0148-16-009	GASKET
945	1.02.0253.1.01.6	DE	0148-16-010	PIPE LINE
946	1.02.0254.1.01.7	DE	0148-16-011	CLIP
947	1.02.0255.1.01.8	DE	0148-16-012	HEXAGON BOLT
948	1.02.0256.1.01.9	DE	0148-16-013	PIPE CLAMP
949	1.02.0257.1.01.1	DE	0148-16-014	HEXAGON BOLT
950	1.02.0258.1.01.2	DE	0148-16-015	SPRING WASHER
951	1.02.0259.1.01.3	DE	0148-16-017	BRACKET
952	1.02.0260.1.01.4	DE	0148-16-018	BRACKET
953	1.02.0261.1.01.5	DE	0148-16-020	PIPE LINE
954	1.02.0262.1.01.6	DE	0148-16-022	HEXAGON BOLT
955	1.02.0263.1.01.7	DE	0148-16-023	ADAPTER
956	1.02.0264.1.01.8	DE	0148-16-024	PIPE LINE
957	1.02.0265.1.01.9	DE	0148-16-028	GASKET
958	1.02.0266.1.01.1	DE	0148-16-029	HEXAGON BOLT
959	1.02.0267.1.01.2	DE	0148-16-030	PIPELINE
960	1.02.0268.1.01.3	DE	0148-16-031	CLIP
961	1.02.0269.1.01.4	DE	0148-16-032	RUBBER SLEEVE
962	1.02.0270.1.01.5	DE	0148-16-035	O SEAL
963	1.02.0271.1.01.6	DE	0148-16-036	PIPELINE
964	1.02.0272.1.01.7	DE	0148-16-041	HEXAGON BOLT
965	1.02.0273.1.01.8	DE	0148-16-042	FLANGE
966	1.02.0274.1.01.9	DE	0148-17-001	O SEAL
967	1.02.0275.1.01.1	DE	0148-17-002	FIP LUB OIL DRAIN PIPE
968	1.02.0276.1.01.2	DE	0148-17-003	CLAMP FOR ABOVE
969	1.02.0277.1.01.3	DE	0148-17-004	CONNECTING PIECE
970	1.02.0278.1.01.4	DE	0148-17-005	CLAMP FOR ABOVE
971	1.02.0279.1.01.5	DE	0148-17-014	PLAIN WASHER
972	1.02.0280.1.01.6	DE	0148-17-017	FUEL INJECTION PUMP
973	1.02.0281.1.01.7	DE	0148-17-032	FUEL SUPPLY PUMP
974	1.02.0282.1.01.8	DE	0148-17-046	SUPPLY PUMP
975	1.02.0283.1.01.9	DE	0148-17-061	SEALING RING
976	1.02.0284.1.01.1	DE	0148-17-0726	DELIVERY VALVE
977	1.02.0285.1.01.2	DE	0148-17-083	BANJO
978	1.02.0286.1.01.3	DE	0148-17-084	SEALING RING
979	1.02.0287.1.01.4	DE	0148-17-085	PIPE
980	1.02.0288.1.01.5	DE	0148-17-091	HEXAGON BOLT
981	1.02.0289.1.01.6	DE	0148-17-093	FUEL PUMP BOLT
982	1.02.0290.1.01.7	DE	0148-17-094	SPRING WASHER

983	1.02.0291.1.01.8	DE	0148-17-097	FUEL PUMP BOLT
984	1.02.0292.1.01.9	DE	0148-17-098	BOLT
985	1.02.0293.1.01.1	DE	0148-17-099	WASHER
986	1.02.0294.1.01.2	DE	0148-17-100	COUPLING PLATE
987	1.02.0295.1.01.3	DE	0148-17-101	PLAIN WASHER
988	1.02.0296.1.01.4	DE	0148-17-107	CHEASE HEAD SCREW
989	1.02.0297.1.01.5	DE	0148-17-110	FIP COUPLING ASSY
990	1.02.0298.1.01.6	DE	0148-17-8821	PUMPING ELEMENT
991	1.02.0299.1.01.7	DE	0148-18-001	AUTO TIMER ASSY.
992	1.02.0300.1.01.8	DE	0148-18-020	ROT SHAFT LIP SEAL
993	1.02.0301.1.01.9	DE	0148-18-021	BUSH
994	1.02.0302.1.01.1	DE	0148-18-022	BEARING RACE
995	1.02.0303.1.01.2	DE	0148-18-023	OIL SEAL
996	1.02.0304.1.01.3	DE	0148-18-024	O SEAL
997	1.02.0305.1.01.4	DE	0148-18-027	GEAR
998	1.02.0306.1.01.5	DE	0148-18-029	GEAR
999	1.02.0307.1.01.6	DE	0148-19-001	THRUST PAD
1000	1.02.0308.1.01.7	DE	0148-19-003	HEXAGON NUT
1001	1.02.0309.1.01.8	DE	0148-19-004	SEALING RING
1002	1.02.0310.1.01.9	DE	0148-19-005	NOZZLE
1003	1.02.0311.1.01.1	DE	0148-19-006	NOZZLE HOLDER
1004	1.02.0312.1.01.2	DE	0148-19-007	O SEAL
1005	1.02.0313.1.01.3	DE	0148-20-006	COPPER WASHER
1006	1.02.0314.1.01.4	DE	0148-20-007	GASKET
1007	1.02.0315.1.01.5	DE	0148-20-008	STAINER ELEMENT
1008	1.02.0316.1.01.6	DE	0148-20-009	FUEL PRE FILTER
1009	1.02.0317.1.01.7	DE	0148-20-015	SEALING RING
1010	1.02.0318.1.01.8	DE	0148-20-026	FILTER ELEMENT
1011	1.02.0319.1.01.9	DE	0148-20-027	FELT ELEMENT
1012	1.02.0320.1.01.1	DE	0148-20-028	FUEL FILTER BODY
1013	1.02.0321.1.01.2	DE	0148-20-083	HEXAGON BOLT
1014	1.02.0322.1.01.3	DE	0148-20-084	DISC PLATE
1015	1.02.0323.1.01.4	DE	0148-20-085	PIPE CLIP
1016	1.02.0324.1.01.5	DE	0148-20-088	BANJO FITTING
1017	1.02.0325.1.01.6	DE	0148-20-091	PIPE
1018	1.02.0326.1.01.7	DE	0148-20-094	RETAINER
1019	1.02.0327.1.01.8	DE	0148-20-095	RETAINER
1020	1.02.0328.1.01.9	DE	0148-20-112	FUEL PIPE
1021	1.02.0329.1.01.1	DE	0148-20-113	FUEL PIPE
1022	1.02.0330.1.01.2	DE	0148-20-114	FUEL PIPE
1023	1.02.0331.1.01.3	DE	0148-20-115	FUEL PIPE
1024	1.02.0332.1.01.4	DE	0148-20-115A	PIPE LINE
1025	1.02.0333.1.01.5	DE	0148-20-116	FUEL PIPE
1026	1.02.0334.1.01.6	DE	0148-20-116A	PIPE LINE
1027	1.02.0335.1.01.7	DE	0148-20-117	FUEL PIPE
1028	1.02.0336.1.01.8	DE	0148-20-118	FUEL PIPE
1029	1.02.0337.1.01.9	DE	0148-20-119	RETAINER
1030	1.02.0338.1.01.1	DE	0148-20-137	ADAPTER
1031	1.02.0339.1.01.2	DE	0148-21-012	PIPE CLIP
1032	1.02.0340.1.01.3	DE	0148-21-013	PIPE CLIP
1033	1.02.0341.1.01.4	DE	0148-21-014	BRACKET RUBBER
1034	1.02.0342.1.01.5	DE	0148-21-015	PIPE CLIP
1035	1.02.0343.1.01.6	DE	0148-21-029	PIPE CLIP
1036	1.02.0344.1.01.7	DE	0148-21-030	HIGH PRESSURE PIPE
1037	1.02.0345.1.01.8	DE	0148-21-031	HIGH PRESSURE PIPE
1038	1.02.0346.1.01.9	DE	0148-21-032	HIGH PRESSURE PIPE
1039	1.02.0347.1.01.1	DE	0148-21-033	HIGH PRESSURE PIPE
1040	1.02.0348.1.01.2	DE	0148-21-034	HIGH PRESSURE PIPE
1041	1.02.0349.1.01.3	DE	0148-21-035	HIGH PRESSURE PIPE
1042	1.02.0350.1.01.4	DE	0148-21-036	HIGH PRESSURE PIPE
1043	1.02.0351.1.01.5	DE	0148-21-037	HIGH PRESSURE PIPE
1044	1.02.0352.1.01.6	DE	0148-21-038	HIGH PRESSURE PIPE
1045	1.02.0353.1.01.7	DE	0148-21-039	HIGH PRESSURE PIPE
1046	1.02.0354.1.01.8	DE	0148-21-040	HIGH PRESSURE PIPE
1047	1.02.0355.1.01.9	DE	0148-21-041	HIGH PRESSURE PIPE
1048	1.02.0356.1.01.1	DE	0148-21-053	PIPE LINE
1049	1.02.0357.1.01.2	DE	0148-21-057	INJ. RETURN PIPE
1050	1.02.0358.1.01.3	DE	0148-21-058	BANJO BOLT
1051	1.02.0359.1.01.4	DE	0148-21-059	SEALING RING
1052	1.02.0360.1.01.5	DE	0148-21-066	ADAPTER
1053	1.02.0361.1.01.6	DE	0148-21-067	RUBBER GROMMET
1054	1.02.0362.1.01.7	DE	0148-21-068	RETAINER
1055	1.02.0363.1.01.8	DE	0148-21-072	BANJO BOLT
1056	1.02.0364.1.01.9	DE	0148-21-073	RETURN PIPE
1057	1.02.0365.1.01.1	DE	0148-21-077	RETURN PIPE
1058	1.02.0366.1.01.2	DE	0148-21-079	RETURN PIPE
1059	1.02.0367.1.01.3	DE	0148-21-080	BANJO FITTING

1060	1.02.0368.1.01.4	DE	0148-22-001	O SEAL
1061	1.02.0369.1.01.5	DE	0148-22-002	O SEAL
1062	1.02.0370.1.01.6	DE	0148-22-005	BATH AIR CLEANER
1063	1.02.0371.1.01.7	DE	0148-22-010	PAPER CARTRIDGE
1064	1.02.0372.1.01.8	DE	0148-22-011	SAFETY CARTRIDGE
1065	1.02.0373.1.01.9	DE	0148-22-012	SEALING NUT
1066	1.02.0374.1.01.1	DE	0148-22-015	DUST EJECTOR
1067	1.02.0375.1.01.2	DE	0148-22-043	PIPE
1068	1.02.0376.1.01.3	DE	0148-22-046	PIPE CLAMP
1069	1.02.0377.1.01.4	DE	0148-22-051	PIPE LINE
1070	1.02.0378.1.01.5	DE	0148-22-056	PIPE CLAMP
1071	1.02.0379.1.01.6	DE	0148-22-059	BRACKET
1072	1.02.0380.1.01.7	DE	0148-22-075	SOCKET/ADAPTER
1073	1.02.0381.1.01.8	DE	0148-22-081	HOSE CLIP
1074	1.02.0382.1.01.9	DE	0148-22-082	RUBBER SLEEVE
1075	1.02.0383.1.01.1	DE	0148-22-085	EXHAUST GASKET
1076	1.02.0384.1.01.2	DE	0148-22-107	HOSE CLIP
1077	1.02.0385.1.01.3	DE	0148-22-108	RUBBER SLEEVE
1078	1.02.0386.1.01.4	DE	0148-22-109	SCREW PLUG
1079	1.02.0387.1.01.5	DE	0148-22-111	ELBOW CONNECTOR
1080	1.02.0388.1.01.6	DE	0148-22-201	HEXAGON NUT
1081	1.02.0389.1.01.7	DE	0148-22-202	WASHER
1082	1.02.0390.1.01.8	DE	0148-22-205	SCREW PLUG
1083	1.02.0391.1.01.9	DE	0148-22-206	HOSE CLIP
1084	1.02.0392.1.01.1	DE	0148-22-207	RUBBERSLEEVE
1085	1.02.0393.1.01.2	DE	0148-22-214	PROFILE WASHER
1086	1.02.0394.1.01.3	DE	0148-22-241	INLET MANIFOLD
1087	1.02.0395.1.01.4	DE	0148-22-243	PLAIN WASHER
1088	1.02.0396.1.01.5	DE	0148-26-001	HOSE STRAP
1089	1.02.0397.1.01.6	DE	0148-26-002	PIPELINE
1090	1.02.0398.1.01.7	DE	0148-26-003	PIPE LINE
1091	1.02.0399.1.01.8	DE	0148-26-004	PIPELINE
1092	1.02.0400.1.01.9	DE	0148-26-005	PIPE LINE
1093	1.02.0401.1.01.1	DE	0148-26-021	SOCKET/ADAPTER
1094	1.02.0402.1.01.2	DE	0148-26-023	SOCKET/ADAPTER
1095	1.02.0403.1.01.3	DE	0148-26-024	FLAME GLOW PLUG
1096	1.02.0404.1.01.4	DE	0148-26-026	HEXAGON BOLT
1097	1.02.0405.1.01.5	DE	0148-26-027	SPRING WASHER
1098	1.02.0406.1.01.6	DE	0148-26-028	BRACKET
1099	1.02.0407.1.01.7	DE	0148-26-029	SOLENOID VALVE
1100	1.02.0408.1.01.8	DE	0148-26-030	HEXAGON BOLT
1101	1.02.0409.1.01.9	DE	0148-26-031	SPRING WASHER
1102	1.02.0410.1.01.1	DE	0148-26-039	PIPELINE
1103	1.02.0411.1.01.2	DE	0148-29-034	BALL JOINT
1104	1.02.0412.1.01.3	DE	0148-29-041	FIP SPRING TOP
1105	1.02.0413.1.01.4	DE	0148-29-049	TOW BAR
1106	1.02.0414.1.01.5	DE	0148-29-079	HOSE
1107	1.02.0415.1.01.6	DE	0148-29-082	BEARING
1108	1.02.0416.1.01.7	DE	0148-29-089	CONTROL LEVER
1109	1.02.0417.1.01.8	DE	0148-29-092	SHAFT
1110	1.02.0418.1.01.9	DE	0148-29-161	HEXAGON NUT
1111	1.02.0419.1.01.1	DE	0148-29-162	PLAIN WASHER
1112	1.02.0420.1.01.2	DE	0148-29-163	BALL JOINT
1113	1.02.0421.1.01.3	DE	0148-29-164	BELLOWS
1114	1.02.0422.1.01.4	DE	0148-29-165	TOW BAR
1115	1.02.0423.1.01.5	DE	0148-29-173	CONTROL LEVER
1116	1.02.0424.1.01.6	DE	0148-29-174	SPRING
1117	1.02.0425.1.01.7	DE	0148-29-175	PLATE FOR SPRING
1118	1.02.0426.1.01.8	DE	0148-29-189	BALL JOINT
1119	1.02.0427.1.01.9	DE	0148-33-000	SPECIAL GASKET
1120	1.02.0428.1.01.1	DE	0148-33-026	CYLINDER
1121	1.02.0429.1.01.2	DE	0148-33-073	PIPELINE
1122	1.02.0430.1.01.3	DE	0148-33-101	RETURN PIPE
1123	1.02.0431.1.01.4	DE	0148-33-123	UNION
1124	1.02.0432.1.01.5	DE	0148-33-127	ALLEN BOLT 10X45
1125	1.02.0433.1.01.6	DE	0148-33-129	O – SEAL
1126	1.02.0434.1.01.7	DE	0148-33-130	CHEASE HEAD SCREW
1127	1.02.0435.1.01.8	DE	0148-33-131	TOURQUE LIMITER
1128	1.02.0436.1.01.9	DE	0148-33-133	WHEEL NUT
1129	1.02.0437.1.01.1	DE	0148-33-135	AIR COMPRESSOR
1130	1.02.0438.1.01.2	DE	0148-33-137	PRESSURE REGULATOR
1131	1.02.0439.1.01.3	DE	0148-33-138	RELIEF VALVE
1132	1.02.0440.1.01.4	DE	0148-33-139	VALVE
1133	1.02.0441.1.01.5	DE	0148-33-1507	SNAP RING
1134	1.02.0442.1.01.6	DE	0148-33-161	BANJO BOLT
1135	1.02.0443.1.01.7	DE	0148-33-162	SEALING RING
1136	1.02.0444.1.01.8	DE	0148-33-163	PIPELINE

1137	1.02.0445.1.01.9	DE	0148-33-164	ADAPTER
1138	1.02.0446.1.01.1	DE	0148-33-165	SEALING RING
1139	1.02.0447.1.01.2	DE	0148-33-166	SEALING RING
1140	1.02.0448.1.01.3	DE	0148-33-167	SOCKET
1141	1.02.0449.1.01.4	DE	0148-33-168	PIPELINE
1142	1.02.0450.1.01.5	DE	0148-33-169	PIPELINE
1143	1.02.0451.1.01.6	DE	0148-33-181	PIPELINE
1144	1.02.0452.1.01.7	DE	0148-33-182	SEALING RING
1145	1.02.0453.1.01.8	DE	0148-33-183	NUT
1146	1.02.0454.1.01.9	DE	0148-33-184	ELBOW
1147	1.02.0455.1.01.1	DE	0148-33-185	HOSE CLIPS
1148	1.02.0456.1.01.2	DE	0148-33-186	VACUUM HOSE
1149	1.02.0457.1.01.3	DE	0148-33-187	VACUUM HOSE
1150	1.02.0458.1.01.4	DE	0148-33-188	SOCKET/ADAPTER
1151	1.02.0459.1.01.5	DE	0148-33-189	ELBOW
1152	1.02.0460.1.01.6	DE	0148-33-3381	STUD
1153	1.02.0461.1.01.7	DE	0148-33-7147	LAMINA
1154	1.02.0462.1.01.8	DE	0148-33-7554	CYLINDER ROLLER BEARING
1155	1.02.0463.1.01.9	DE	0148-33-8473	GASKET
1156	1.02.0464.1.01.1	DE	0148-33-8474	LEAF SPRING
1157	1.02.0465.1.01.2	DE	0148-33-8475	GASKET
1158	1.02.0466.1.01.3	DE	0148-33-8477	GASKET
1159	1.02.0467.1.01.4	DE	0148-33-9590	GASKET
1160	1.02.0468.1.01.5	DE	0148-33-9710	VALVE
1161	1.02.0469.1.01.6	DE	0148-33-9896	SCRAPER RING
1162	1.02.0470.1.01.7	DE	0148-33-9904	PISTON
1163	1.02.0471.1.01.8	DE	0148-33-9905	OIL RING
1164	1.02.0472.1.01.9	DE	0148-39-001	EXHAUST THERMOSTAT
1165	1.02.0473.1.01.1	DE	0148-39-002	LUB OIL PIPE FOR BLOWER
1166	1.02.0474.1.01.2	DE	0148-39-003	LUB OIL PIPE FOR BLOWER
1167	1.02.0475.1.01.3	DE	0148-39-004	LUB OIL PIPE
1168	1.02.0476.1.01.4	DE	0148-39-005	LUB OIL PIPE
1169	1.02.0477.1.01.5	DE	0148-39-007	UNION FOR LUB OIL PIPE
1170	1.02.0478.1.01.6	DE	0148-39-009	RUBBER HOSE
1171	1.02.0479.1.01.7	DE	0148-39-013	BEND FOR LUB OIL PIPE
1172	1.02.0480.1.01.8	DE	0148-39-014	UNION FOR LUB OIL PIPE
1173	1.02.0481.1.01.9	DE	0148-39-015	WASHER
1174	1.02.0482.1.01.1	DE	0148-39-033	METAL PIPE
1175	1.02.0483.1.01.2	DE	0148-39-034	WASHER
1176	1.02.0484.1.01.3	DE	0148-39-035	UNION
1177	1.02.0485.1.01.4	DE	0148-39-038	RUBBER HOSE
1178	1.02.0486.1.01.5	DE	0148-39-093	HEXAGON NUT
1179	1.02.0487.1.01.6	DE	0148-39-095	THRUST PAD
1180	1.02.0488.1.01.7	DE	0148-39-096	CLAMPING STRAP
1181	1.02.0489.1.01.8	DE	0148-39-097	HEXAGON BOLT
1182	1.02.0490.1.01.9	DE	0148-39-098	SPRING WASHER
1183	1.02.0491.1.01.1	DE	0148-39-099	DOMED WASHER
1184	1.02.0492.1.01.2	DE	0148-39-100	O – SEAL
1185	1.02.0493.1.01.3	DE	0148-39-101	RETURN PIPE
1186	1.02.0494.1.01.4	DE	0148-39-107	SOCKET/ADAPTER
1187	1.02.0495.1.01.5	DE	0148-39-109	HEXAGON BOLT
1188	1.02.0496.1.01.6	DE	0148-39-110	SPRING WASHER
1189	1.02.0497.1.01.7	DE	0148-39-111	PLAIN WASHER
1190	1.02.0498.1.01.8	DE	0148-39-112	COVER
1191	1.02.0499.1.01.9	DE	0148-39-113	O – SEAL
1192	1.02.0500.1.01.1	DE	0148-39-114	RING
1193	1.02.0501.1.01.2	DE	0148-39-115	BOLT
1194	1.02.0502.1.01.3	DE	0148-39-116	BOWL
1195	1.02.0503.1.01.4	DE	0148-39-117	SPACER
1196	1.02.0504.1.01.5	DE	0148-39-118	THRUST WASHER
1197	1.02.0505.1.01.6	DE	0148-39-119	BLOWER FAN COUPLING O SEAL
1198	1.02.0506.1.01.7	DE	0148-39-120	CLUTCH/ COUPLING
1199	1.02.0507.1.01.8	DE	0148-39-121	WASHER
1200	1.02.0508.1.01.9	DE	0148-39-122	CIRCLIP
1201	1.02.0509.1.01.1	DE	0148-39-123	BALL BEARING
1202	1.02.0510.1.01.2	DE	0148-39-125	ROT SHAFT LIP SEAL
1203	1.02.0511.1.01.3	DE	0148-39-126	SPACER RING
1204	1.02.0512.1.01.4	DE	0148-39-127	O SEAL
1205	1.02.0513.1.01.5	DE	0148-39-128	FAN ASSEMBLY
1206	1.02.0514.1.01.6	DE	0148-39-129	LOCK WASHER
1207	1.02.0515.1.01.7	DE	0148-39-130	SLOTTED ROUND NUT
1208	1.02.0516.1.01.8	DE	0148-39-131	ROT SHAFT LIP SEAL
1209	1.02.0517.1.01.9	DE	0148-39-132	DRIVER/ACTUATOR
1210	1.02.0518.1.01.1	DE	0148-39-134	SPRING WASHER
1211	1.02.0519.1.01.2	DE	0148-39-135	COOLING BLOWER
1212	1.02.0520.1.01.3	DE	0148-39-161	HEXAGON BOLT
1213	1.02.0521.1.01.4	DE	0148-39-162	WASHER

1214	1.02.0522.1.01.5	DE	0148-39-165	BRACKET
1215	1.02.0523.1.01.6	DE	0148-39-166	CHEESE HEAD SCREW
1216	1.02.0524.1.01.7	DE	0148-39-169	BEARING BUSH
1217	1.02.0525.1.01.8	DE	0148-39-170	COUPLING PIECE
1218	1.02.0526.1.01.9	DE	0148-39-171	ROT SHAFT LIP SEAL
1219	1.02.0527.1.01.1	DE	0148-39-174	BEARING
1220	1.02.0528.1.01.2	DE	0148-39-176	BUSH
1221	1.02.0529.1.01.3	DE	0148-39-178	SEALING RING
1222	1.02.0530.1.01.4	DE	0148-39-184	HOUSING/CASE
1223	1.02.0531.1.01.5	DE	0148-39-185	TRANSMISSION BOLT
1224	1.02.0532.1.01.6	DE	0148-39-191	SPRING WASHER
1225	1.02.0533.1.01.7	DE	0148-39-196	HEXAGON NUT
1226	1.02.0534.1.01.8	DE	0148-39-197	INTERMEDIATE SHAFT
1227	1.02.0535.1.01.9	DE	0148-39-198	RUBBER STOP
1228	1.02.0536.1.01.1	DE	0148-39-199	BOLT
1229	1.02.0537.1.01.2	DE	0148-39-200	DRIVE SHAFT
1230	1.02.0538.1.01.3	DE	0148-39-201	ROT SHAFT LIP SEAL
1231	1.02.0539.1.01.4	DE	0148-39-202	CIRCLIP
1232	1.02.0540.1.01.5	DE	0148-39-203	BALL BEARING
1233	1.02.0541.1.01.6	DE	0148-39-204	SPACER SLEEVE
1234	1.02.0542.1.01.7	DE	0148-39-205	CYL ROLLER BEARING
1235	1.02.0543.1.01.8	DE	0148-39-206	BL DRIVE GEAR
1236	1.02.0544.1.01.9	DE	0148-39-208	THRUST WASHER
1237	1.02.0545.1.01.1	DE	0148-39-209	BEARING BUSH
1238	1.02.0546.1.01.2	DE	0148-39-210	DRIVER/ACTUATOR
1239	1.02.0547.1.01.3	DE	0148-39-213	HEXAGON BOLT
1240	1.02.0548.1.01.4	DE	0148-39-214	O RING
1241	1.02.0549.1.01.5	DE	0148-39-217	O RING
1242	1.02.0550.1.01.6	DE	0148-39-218	COUPLING DISC
1243	1.02.0551.1.01.7	DE	0148-39-241	BLOWER OIL SUPPLY PIPE
1244	1.02.0552.1.01.8	DE	0148-39-242	BLOWER OIL SUPPLY PIPE
1245	1.02.0553.1.01.9	DE	0148-39-243	BLOWER OIL SUPPLY PIPE
1246	1.02.0554.1.01.1	DE	0148-39-256	RUBBER SLEEVE
1247	1.02.0555.1.01.2	DE	0148-39-287	PIPE
1248	1.02.0556.1.01.3	DE	0148-39-293	SOCKET/ADAPTER
1249	1.02.0557.1.01.4	DE	0148-39-295	SOLENOID VALVE
1250	1.02.0558.1.01.5	DE	0148-40-002	BOLT 6X25
1251	1.02.0559.1.01.6	DE	0148-40-004	PLATE
1252	1.02.0560.1.01.7	DE	0148-40-011	COVER
1253	1.02.0561.1.01.8	DE	0148-40-013	COVER
1254	1.02.0562.1.01.9	DE	0148-40-014	HEXAGON BOLT
1255	1.02.0563.1.01.1	DE	0148-40-017	RUBBER SECTION
1256	1.02.0564.1.01.2	DE	0148-40-018	COVER
1257	1.02.0565.1.01.3	DE	0148-40-019	SEALING SECTION
1258	1.02.0566.1.01.4	DE	0148-40-020	COVER
1259	1.02.0567.1.01.5	DE	0148-40-023	PLAIN WASHER
1260	1.02.0568.1.01.6	DE	0148-40-024	SEALING SECTION
1261	1.02.0569.1.01.7	DE	0148-40-025	RUBBER SECTION
1262	1.02.0570.1.01.8	DE	0148-40-029	SIDE BUFFER
1263	1.02.0571.1.01.9	DE	0148-40-032	LOCK
1264	1.02.0572.1.01.1	DE	0148-40-033	PLATE
1265	1.02.0573.1.01.2	DE	0148-40-034	COVER
1266	1.02.0574.1.01.3	DE	0148-40-035	HEXAGON BOLT
1267	1.02.0575.1.01.4	DE	0148-40-036	SEALING SECTION
1268	1.02.0576.1.01.5	DE	0148-40-037	PLUG
1269	1.02.0577.1.01.6	DE	0148-40-038	COVER
1270	1.02.0578.1.01.7	DE	0148-40-040	PLUG
1271	1.02.0579.1.01.8	DE	0148-40-043	RUBBER PIECE
1272	1.02.0580.1.01.9	DE	0148-40-047	PLUG
1273	1.02.0581.1.01.1	DE	0148-40-057	SEALING SECTION
1274	1.02.0582.1.01.2	DE	0148-40-089	HEXAGON NUT
1275	1.02.0583.1.01.3	DE	0148-40-090	RUBBER BUSH
1276	1.02.0584.1.01.4	DE	0148-40-125	WASHER
1277	1.02.0585.1.01.5	DE	0148-40-127	NUT
1278	1.02.0586.1.01.6	DE	0148-40-130	BRACKET
1279	1.02.0587.1.01.7	DE	0148-40-131	BRACKET
1280	1.02.0588.1.01.8	DE	0148-40-134	CONNECTING SHEET
1281	1.02.0589.1.01.9	DE	0148-40-139	RUBBER STOP
1282	1.02.0590.1.01.1	DE	0148-40-143	FRONT PLATE
1283	1.02.0591.1.01.2	DE	0148-40-145	CLAMPING SECTION
1284	1.02.0592.1.01.3	DE	0148-40-148	BRACKET
1285	1.02.0593.1.01.4	DE	0148-40-149	BOLT
1286	1.02.0594.1.01.5	DE	0148-40-156	SEALING SECTION
1287	1.02.0595.1.01.6	DE	0148-40-162	PLAIN WASHER
1288	1.02.0596.1.01.7	DE	0148-40-179	BRACKET AVM'S
1289	1.02.0597.1.01.8	DE	0148-40-181	CASE/BOX
1290	1.02.0598.1.01.9	DE	0148-40-183	CASE/BOX

1291	1.02.0599.1.01.1	DE	0148-40-188	COOL, AIR COWLING
1292	1.02.0600.1.01.2	DE	0148-40-189	RUBBER SEAL
1293	1.02.0601.1.01.3	DE	0148-40-190	HEXAGON BOLT
1294	1.02.0602.1.01.4	DE	0148-40-191	COVER
1295	1.02.0603.1.01.5	DE	0148-40-195	RAIL/BAR
1296	1.02.0604.1.01.6	DE	0148-40-196	FRAME
1297	1.02.0605.1.01.7	DE	0148-40-197	RAIL/BAR
1298	1.02.0606.1.01.8	DE	0148-40-198	SEALING STRIP
1299	1.02.0607.1.01.9	DE	0148-40-199	SECTIONAL RUBBER
1300	1.02.0608.1.01.1	DE	0148-41-013	COOLING AIR BAFFLE
1301	1.02.0609.1.01.2	DE	0148-41-014	STUD
1302	1.02.0610.1.01.3	DE	0148-41-015	EXHAUST GASKET
1303	1.02.0611.1.01.4	DE	0148-41-016	LOCKING COLLAR
1304	1.02.0612.1.01.5	DE	0148-41-018	HEXAGON NUT
1305	1.02.0613.1.01.6	DE	0148-41-019	EXHAUST MANIFOLD
1306	1.02.0614.1.01.7	DE	0148-41-081	NUT
1307	1.02.0615.1.01.8	DE	0148-41-082	STUD
1308	1.02.0616.1.01.9	DE	0148-41-083	EXHAUST MANIFOLD
1309	1.02.0617.1.01.1	DE	0148-41-084	RECTANGULAR RING
1310	1.02.0618.1.01.2	DE	0148-41-086	GASKET
1311	1.02.0619.1.01.3	DE	0148-41-088	NUT
1312	1.02.0620.1.01.4	DE	0148-41-089	PACKING COMPOUND
1313	1.02.0621.1.01.5	DE	0148-41-090	EXHAUST MANIFOLD
1314	1.02.0622.1.01.6	DE	0148-41-121	GASKET
1315	1.02.0623.1.01.7	DE	0148-41-122	SEALING RING
1316	1.02.0624.1.01.8	DE	0148-41-153	CORRUGATED TUBE
1317	1.02.0625.1.01.9	DE	0148-41-154	SQUARE FANGE
1318	1.02.0626.1.01.1	DE	0148-41-155	SEGMENT INNER RING
1319	1.02.0627.1.01.2	DE	0148-43-000	REPAIR KIT
1320	1.02.0628.1.01.3	DE	0148-43-001	BOLT
1321	1.02.0629.1.01.4	DE	0148-43-003	TURBOCHARGER
1322	1.02.0630.1.01.5	DE	0148-43-004	GASKET
1323	1.02.0631.1.01.6	DE	0148-43-006	TURBOCHARGER
1324	1.02.0632.1.01.7	DE	0148-43-007	BRACKET
1325	1.02.0633.1.01.8	DE	0148-43-008	STUD
1326	1.02.0634.1.01.9	DE	0148-43-011	NUT
1327	1.02.0635.1.01.1	DE	0148-43-013	HEXAGON BOLT
1328	1.02.0636.1.01.2	DE	0148-43-014	HEXAGON NUT
1329	1.02.0637.1.01.3	DE	0148-43-015	PLAIN WASHER
1330	1.02.0638.1.01.4	DE	0148-43-016	CLAMP
1331	1.02.0639.1.01.5	DE	0148-43-017	COVER
1332	1.02.0640.1.01.6	DE	0148-43-018	CLAMP
1333	1.02.0641.1.01.7	DE	0148-43-020	COVER
1334	1.02.0642.1.01.8	DE	0148-43-5628	RUBBER SLEEVE
1335	1.02.0643.1.01.9	DE	0148-43-8856	TURBO SUPPLY PIPE
1336	1.02.0644.1.01.1	DE	0148-43-8912	TURBO SUPPLY PIPE
1337	1.02.0645.1.01.2	DE	0148-44-060	CLAMPING STRAP
1338	1.02.0646.1.01.3	DE	0148-44-066	SET OF V BELTS
1339	1.02.0647.1.01.4	DE	0148-44-126	PLUG
1340	1.02.0648.1.01.5	DE	0148-44-129	HEXAGON BOLT
1341	1.02.0649.1.01.6	DE	0148-44-241	STARTER
1342	1.02.0650.1.01.7	DE	0148-44-244	STUD
1343	1.02.0651.1.01.8	DE	0148-46-001	MOUNTING FOOT
1344	1.02.0652.1.01.9	DE	0148-46-002	WASHER
1345	1.02.0653.1.01.1	DE	0148-46-005	MOUNTING FOOT
1346	1.02.0654.1.01.2	DE	0148-46-006	HEXAGON BOLT
1347	1.02.0655.1.01.3	DE	0148-48-017	OIL PRESSURE SWITCH
1348	1.02.0656.1.01.4	DE	0148-48-029	BRACKET
1349	1.02.0657.1.01.5	DE	0148-48-034	CONNECTOR
1350	1.02.0658.1.01.6	DE	0148-48-081	WIRING SET INTERNAL
1351	1.02.0659.1.01.7	DE	0148-48-083	WIRING SET
1352	1.02.0660.1.01.8	DE	0148-51-001	HEXAGON BOLT
1353	1.02.0661.1.01.9	DE	0148-51-002	SPRING WASHER
1354	1.02.0662.1.01.1	DE	0148-51-007	BUSH
1355	1.02.0663.1.01.2	DE	0148-51-010	FLANGE
1356	1.02.0664.1.01.3	DE	0148-51-011	DRIVING TAG
1357	1.02.0665.1.01.4	DE	0148-51-012	SEAL RING
1358	1.02.0666.1.01.5	DE	0148-51-013	SEAL RING
1359	1.02.0667.1.01.6	DE	0148-51-019	LUB OIL SENSOR
1360	1.02.0668.1.01.7	DE	0148-51-020	THERMOSTAT
1361	1.02.0669.1.01.8	DE	0148-51-021	TEMPER TRANSMITTER CYL. HEAD
1362	1.02.0670.1.01.9	DE	0148-51-028	TEMPER TRANSMITTER LUB OIL
1363	1.02.0671.1.01.1	DE	0148-51-053	TACHO GENERATOR
1364	1.02.0672.1.01.2	DE	0148-52-002	CONNECTING HOUSING
1365	1.02.0673.1.01.3	DE	0148-52-003	BELL HOUSING BOLT
1366	1.02.0674.1.01.4	DE	0148-52-004	BELL HOUSING BOLT
1367	1.02.0675.1.01.5	DE	0148-52-005	GASKET

1368	1.02.0676.1.01.6	DE	0148-52-006	PLATE
1369	1.02.0677.1.01.7	DE	0148-52-007	CHEESE HEAD SCREW
1370	1.02.0678.1.01.8	DE	0148-52-121	CLUTCH PLATE
1371	1.02.0679.1.01.9	DE	0148-52-122	THRUST PLATE
1372	1.02.0680.1.01.1	DE	0148-52-125	DISENGAGER
1373	1.02.0681.1.01.2	DE	0148-52-126	CLUTCH LEVER
1374	1.02.0682.1.01.3	DE	0148-52-127	BALL SEAT
1375	1.02.0683.1.01.4	DE	0148-52-128	BALL STUD
1376	1.02.0684.1.01.5	DE	0148-52-129	CONNECTING PLATE
1377	1.02.0685.1.01.6	DE	0148-52-132	ROT. SHAFT LIP SEAL
1378	1.02.0686.1.01.7	DE	0148-52-133	BALL BEARING
1379	1.02.0687.1.01.8	DE	0148-52-134	BELL HOUSING
1380	1.02.0688.1.01.9	DE	0148-52-136	HEXAGON BOLT
1381	1.02.0689.1.01.1	DE	0148-52-137	DRIVE SHAFT
1382	1.02.0690.1.01.2	DE	0148-52-139	POWER CYLINDER
1383	1.02.0691.1.01.3	DE	0148-52-141	HEXAGON BOLT
1384	1.02.0692.1.01.4	DE	0148-52-2480	HEXAGON BOLT
1385	1.02.0693.1.01.5	DE	0148-52-4843	O – SEAL
1386	1.02.0694.1.01.6	DE	0148-52-6312	BUSH
1387	1.02.0695.1.01.7	DE	0148-52-6345	COVER
1388	1.02.0696.1.01.8	DE	0148-52-6431	ROT. SHAFT LIP SEAL
1389	1.02.0697.1.01.9	DE	0148-52-6433	ROT. SHAFT LIP SEAL
1390	1.02.0698.1.01.1	DE	0148-56-001	BALL PIN
1391	1.02.0699.1.01.2	DE	0148-56-002	SEALING RING
1392	1.02.0700.1.01.3	DE	0148-56-003	YOKE
1393	1.02.0701.1.01.4	DE	0148-56-004	LINK
1394	1.02.0702.1.01.5	DE	0148-56-005	STOPPING LEVER
1395	1.02.0703.1.01.6	DE	0148-56-006	BUSH
1396	1.02.0704.1.01.7	DE	0148-56-007	BUSH
1397	1.02.0705.1.01.8	DE	0148-56-008	WASHER
1398	1.02.0706.1.01.9	DE	0148-56-009	BOLT
1399	1.02.0707.1.01.1	DE	0148-56-010	BALL SEAT
1400	1.02.0708.1.01.2	DE	0148-56-011	BOLT
1401	1.02.0709.1.01.3	DE	0148-56-012	PLAIN WASHER
1402	1.02.0710.1.01.4	DE	0148-56-013	BALL JOINT
1403	1.02.0711.1.01.5	DE	0148-56-014	CHEASE HEAD SCREW
1404	1.02.0712.1.01.6	DE	0148-56-015	PLAIN WASHER
1405	1.02.0713.1.01.7	DE	0148-56-016	CLAMPING RING
1406	1.02.0714.1.01.8	DE	0148-56-017	BOLT
1407	1.02.0715.1.01.9	DE	0148-56-018	SPACER
1408	1.02.0716.1.01.1	DE	0148-56-019	BRACKET
1409	1.02.0717.1.01.2	DE	0148-56-020	WASHER
1410	1.02.0718.1.01.3	DE	0148-56-022	NUT
1411	1.02.0719.1.01.4	DE	0148-56-023	BRACKET
1412	1.02.0720.1.01.5	DE	0148-56-024	WASHER
1413	1.02.0721.1.01.6	DE	0148-56-025	BELLOW
1414	1.02.0722.1.01.7	DE	0148-56-026	WASHER
1415	1.02.0723.1.01.8	DE	0148-56-027	SOLENOID
1416	1.02.0724.1.01.9	DE	0148-56-028	HOSE CLIP
1417	1.02.0725.1.01.1	DE	0148-56-030	SOCKET
1418	1.02.0726.1.01.2	DE	0148-56-031	SOLENOID SPRING
1419	1.02.0727.1.01.3	DE	0148-56-032	NUT
1420	1.02.0728.1.01.4	DE	0148-56-033	BELLOWS
1421	1.02.0729.1.01.5	DE	0148-58-001	HOSE CLIP
1422	1.02.0730.1.01.6	DE	0148-58-002	RUBBER SLEEVE
1423	1.02.0731.1.01.7	DE	0148-58-005	RUBBER STOP
1424	1.02.0732.1.01.8	DE	0148-58-008	GASKET
1425	1.02.0733.1.01.9	DE	0148-58-016	RUBBER SLEEVE
1426	1.02.0734.1.01.1	DE	0148-58-017	HOSE CLIP
1427	1.02.0735.1.01.2	DE	0148-61-028	SEALING SECTION
1428	1.02.0736.1.01.3	Shifted to Annexure II		
1429	1.02.0737.1.01.4	DE	0148-81-010	EXPANSION TANK
1430	1.02.0738.1.01.5	DE	0148-90-001	GASKET SET
1431	1.02.0739.1.01.6	DE	0165-01-013	Bearing Bush
1432	1.02.0740.1.01.7	DE	0165-01-014	Bearing Bush
1433	1.02.0741.1.01.8	DE	0165-01-016	Nozzle
1434	1.02.0742.1.01.9	DE	0165-01-017	Relief Valve
1435	1.02.0743.1.01.1	DE	0165-01-029	Rot. Shaft Lip Seal
1436	1.02.0744.1.01.2	DE	0165-01-030	Gasket
1437	1.02.0745.1.01.3	DE	0165-01-046	Dipstick
1438	1.02.0746.1.01.4	DE	0165-01-051	Oil Separator
1439	1.02.0747.1.01.5	DE	0165-01-052	O-Seal
1440	1.02.0748.1.01.6	DE	0165-01-053	Hose Clip
1441	1.02.0749.1.01.7	DE	0165-01-054	Rubber Sleeve
1442	1.02.0750.1.01.8	DE	0165-01-055	Breather Pipe
1443	1.02.0751.1.01.9	DE	0165-01-093	Rot. Shaft Lip Seal
1444	1.02.0752.1.01.1	DE	0165-01-101	Gasket

1445	1.02.0753.1.01.2	DE	0165-01-127	Sealing Ring
1446	1.02.0754.1.01.3	DE	0165-01-130	Packing Compound
1447	1.02.0755.1.01.4	DE	0165-01-161	Cylinder Liner
1448	1.02.0756.1.01.5	DE	0165-01-162	Oil Seal
1449	1.02.0757.1.01.6	DE	0165-02-001	Gasket
1450	1.02.0758.1.01.7	DE	0165-02-003	Screw Plug
1451	1.02.0759.1.01.8	DE	0165-02-004	Sealing Ring
1452	1.02.0760.1.01.9	DE	0165-05-004	Main Bearing (Std)
1453	1.02.0761.1.01.1	DE	0165-05-004/1	Main Bearing (1st U/S)
1454	1.02.0762.1.01.2	DE	0165-05-004/2	Main Bearing (2nd U/S)
1455	1.02.0763.1.01.3	DE	0165-05-004/3	Main Bearing (3rd U/S)
1456	1.02.0764.1.01.4	DE	0165-05-004/4	Main Bearing (4th U/S)
1457	1.02.0765.1.01.5	DE	0165-05-005	Thrust Washer
1458	1.02.0766.1.01.6	DE	0165-05-006	Big End Bearing (Std)
1459	1.02.0767.1.01.7	DE	0165-05-006/1	Big End Bearing (1st U/S)
1460	1.02.0768.1.01.8	DE	0165-05-006/2	Big End Bearing (2nd U/S)
1461	1.02.0769.1.01.9	DE	0165-05-006/3	Big End Bearing (3rd U/S)
1462	1.02.0770.1.01.1	DE	0165-05-047	Gear Rim
1463	1.02.0771.1.01.2	DE	0165-05-056	Ball Bearing
1464	1.02.0772.1.01.3	DE	0165-06-001	Connecting Rod
1465	1.02.0773.1.01.4	DE	0165-06-002	Big End Bolt
1466	1.02.0774.1.01.5	DE	0165-06-003	Big End Bush
1467	1.02.0775.1.01.6	DE	0165-07-001	Piston
1468	1.02.0776.1.01.7	DE	0165-07-007	Set of Piston Rings
1469	1.02.0777.1.01.8	DE	0165-08-001	Valve Collet
1470	1.02.0778.1.01.9	DE	0165-08-003	Valve Spring
1471	1.02.0779.1.01.1	DE	0165-08-004	Valve Stem Seal
1472	1.02.0780.1.01.2	DE	0165-08-005	Valve Guide
1473	1.02.0781.1.01.3	DE	0165-08-009	Inlet Valve Seat
1474	1.02.0782.1.01.4	DE	0165-08-010	Exhaust Valve Seat
1475	1.02.0783.1.01.5	DE	0165-08-011	Inlet Valve
1476	1.02.0784.1.01.6	DE	0165-08-012	Exhaust Valve
1477	1.02.0785.1.01.7	DE	0165-08-013	Cylinder Head
1478	1.02.0786.1.01.8	DE	0165-08-014	Safety/Lock. Agent
1479	1.02.0787.1.01.9	DE	0165-08-016	Cylinder Head Gasket (1Notch)
1480	1.02.0788.1.01.1	DE	0165-08-017	Cylinder Head Gasket (2Notch)
1481	1.02.0789.1.01.2	DE	0165-08-018	Cylinder Head Gasket (3Notch)
1482	1.02.0790.1.01.3	DE	0165-08-019	Cheese Head Screw
1483	1.02.0791.1.01.4	DE	0165-08-022	Valve Mechan. Cover
1484	1.02.0792.1.01.5	DE	0165-08-023	Gasket
1485	1.02.0793.1.01.6	DE	0165-08-024	Filler Cap
1486	1.02.0794.1.01.7	DE	0165-08-026	Profile Washer
1487	1.02.0795.1.01.8	DE	0165-08-028	Gasket
1488	1.02.0796.1.01.9	DE	0165-10-001	One-Piece Camshaft
1489	1.02.0797.1.01.1	DE	0165-10-002	Idle Gear
1490	1.02.0798.1.01.2	DE	0165-10-003	Toothed Gear
1491	1.02.0799.1.01.3	DE	0165-10-004	Parallel Pin
1492	1.02.0800.1.01.4	DE	0165-11-005	Hexagon Nut
1493	1.02.0801.1.01.5	DE	0165-11-006	Adjusting Screw
1494	1.02.0802.1.01.6	DE	0165-11-009	Push Rod
1495	1.02.0803.1.01.7	DE	0165-11-010	Valve Tappet
1496	1.02.0804.1.01.8	DE	0165-14-004	Oil Pressure Pump
1497	1.02.0805.1.01.9	DE	0165-15-001	Spin-On Oil Filter
1498	1.02.0806.1.01.1	DE	0165-15-041	Gasket
1499	1.02.0807.1.01.2	DE	0165-15-049	Lubricant Oil Cooler
1500	1.02.0808.1.01.3	DE	0165-16-043	Gasket
1501	1.02.0809.1.01.4	DE	0165-16-054	Gasket
1502	1.02.0810.1.01.5	DE	0165-16-073	Rubber Hose
1503	1.02.0811.1.01.6	DE	0165-16-074	Spring Band Clamp
1504	1.02.0812.1.01.7	DE	0165-17-001	Fuel Injection Pump
1505	1.02.0813.1.01.8	DE	0165-17-002	Supply Pump
1506	1.02.0814.1.01.9	DE	0165-17-012	Supply Pump
1507	1.02.0815.1.01.1	DE	0165-19-002	Nozzle
1508	1.02.0816.1.01.2	DE	0165-19-003	Sealing Ring
1509	1.02.0817.1.01.3	DE	0165-19-004	Fuel Injector
1510	1.02.0818.1.01.4	DE	0165-19-006	Union Screw
1511	1.02.0819.1.01.5	DE	0165-20-010	Spin-On Fuel Filter
1512	1.02.0820.1.01.6	DE	0165-20-017	Filter Cartridge
1513	1.02.0821.1.01.7	DE	0165-21-001	High Pressure Pipe
1514	1.02.0822.1.01.8	DE	0165-21-002	High Pressure Pipe
1515	1.02.0823.1.01.9	DE	0165-21-003	High Pressure Pipe
1516	1.02.0824.1.01.1	DE	0165-21-004	High Pressure Pipe
1517	1.02.0825.1.01.2	DE	0165-21-005	High Pressure Pipe
1518	1.02.0826.1.01.3	DE	0165-21-006	High Pressure Pipe
1519	1.02.0827.1.01.4	DE	0165-22-046	Gasket
1520	1.02.0828.1.01.5	DE	0165-22-054	Hose Clip
1521	1.02.0829.1.01.6	DE	0165-22-055	Rubber Sleeve

1522	1.02.0830.1.01.7	DE	0165-22-059	Stud
1523	1.02.0831.1.01.8	DE	0165-22-060	Plain Washer
1524	1.02.0832.1.01.9	DE	0165-22-061	Hexagon Nut
1525	1.02.0833.1.01.1	DE	0165-22-081	Hose Clip
1526	1.02.0834.1.01.2	DE	0165-22-082	Rubber Dust Exclud
1527	1.02.0835.1.01.3	DE	0165-22-084	O-Seal
1528	1.02.0836.1.01.4	DE	0165-22-085	Plug
1529	1.02.0837.1.01.5	DE	0165-22-090	Intake Elbow
1530	1.02.0838.1.01.6	DE	0165-22-091	Hose Clip
1531	1.02.0839.1.01.7	DE	0165-22-092	Rubber Sleeve
1532	1.02.0840.1.01.8	Shifted to Annexure II		
1533	1.02.0841.1.01.9	Shifted to Annexure II		
1534	1.02.0842.1.01.1	DE	0165-27-016	Control Unit
1535	1.02.0843.1.01.2	DE	0165-29-007	Tension Spring
1536	1.02.0844.1.01.3	DE	0165-33-001	Air Compressor
1537	1.02.0845.1.01.4	DE	0165-33-003	Toothed Gear
1538	1.02.0846.1.01.5	DE	0165-33-004	O-Seal
1539	1.02.0847.1.01.6	DE	0165-36-001	Cooling System
1540	1.02.0848.1.01.7	DE	0165-36-002	Rubber Mounting
1541	1.02.0849.1.01.8	DE	0165-36-003	Filler Cap
1542	1.02.0850.1.01.9	DE	0165-36-014	Rubber Sleeve
1543	1.02.0851.1.01.1	DE	0165-36-019	Rubber Dust Exclud
1544	1.02.0852.1.01.2	DE	0165-37-001	Gasket
1545	1.02.0853.1.01.3	DE	0165-37-002	O-Seal
1546	1.02.0854.1.01.4	DE	0165-37-003	O-Seal
1547	1.02.0855.1.01.5	DE	0165-37-006	Gasket
1548	1.02.0856.1.01.6	DE	0165-37-025	Repair Kit
1549	1.02.0857.1.01.7	DE	0165-38-009	Gasket
1550	1.02.0858.1.01.8	DE	0165-38-010	Sealing Ring
1551	1.02.0859.1.01.9	DE	0165-38-011	Thermostat
1552	1.02.0860.1.01.1	DE	0165-38-019	Rubber Sleeve
1553	1.02.0861.1.01.2	DE	0165-38-034	Thermostat
1554	1.02.0862.1.01.3	DE	0165-39-003	Suction Fan
1555	1.02.0863.1.01.4	DE	0165-39-043	Rot. Shaft Lip Seal
1556	1.02.0864.1.01.5	DE	0165-41-001	Exhaust Manifold
1557	1.02.0865.1.01.6	DE	0165-41-002	Gasket
1558	1.02.0866.1.01.7	DE	0165-41-003	Hexagon Bolt
1559	1.02.0867.1.01.8	DE	0165-41-006	Hexagon Nut
1560	1.02.0868.1.01.9	DE	0165-41-007	Plain Washer
1561	1.02.0869.1.01.1	DE	0165-41-008	Hexagon Bolt
1562	1.02.0870.1.01.2	DE	0165-41-014	Exhaust Manifold
1563	1.02.0871.1.01.3	DE	0165-41-049	Compensator
1564	1.02.0872.1.01.4	DE	0165-43-001	Turbocharger
1565	1.02.0873.1.01.5	DE	0165-43-002	Hexagon Bolt
1566	1.02.0874.1.01.6	DE	0165-43-005	Core Assembly
1567	1.02.0875.1.01.7	DE	0165-43-008	Repair Kit
1568	1.02.0876.1.01.8	DE	0165-43-043	Stud
1569	1.02.0877.1.01.9	DE	0165-43-045	Hexagon Nut
1570	1.02.0878.1.01.1	DE	0165-44-001	Alternator
1571	1.02.0879.1.01.2	DE	0165-44-010	Narrow V-Belt
1572	1.02.0880.1.01.3	DE	0165-44-041	Self Starter
1573	1.02.0881.1.01.4	DE	0165-44-044	Stud
1574	1.02.0882.1.01.5	DE	0165-44-129	Set Narrow V-Belts
1575	1.02.0883.1.01.6	DE	0165-46-001	Mounting Foot
1576	1.02.0884.1.01.7	DE	0165-46-004	Mounting Foot
1577	1.02.0885.1.01.8	DE	0165-48-025	Impulse Transmitter
1578	1.02.0886.1.01.9	DE	0165-48-041	Interconnect Cable
1579	1.02.0887.1.01.1	DE	0165-48-043	Cable Harness
1580	1.02.0888.1.01.2	DE	0165-51-002	Level Switch
1581	1.02.0889.1.01.3	DE	0165-51-015	Temperature Transmitter
1582	1.02.0890.1.01.4	DE	0165-51-023	Pressure Pickup
1583	1.02.0891.1.01.5	DE	0165-51-025	Temperature Transmitter
1584	1.02.0892.1.01.6	DE	0165-51-026	Temperature Transmitter
1585	1.02.0893.1.01.7	DE	0165-51-029	Pressure Sensor
1586	1.02.0894.1.01.8	DE	0165-51-032	Pressure Sensor
1587	1.02.0895.1.01.9	DE	0165-52-001	Cheese Head Screw
1588	1.02.0896.1.01.1	DE	0165-52-002	Cheese Head Screw
1589	1.02.0897.1.01.2	DE	0165-52-005	Blanking Parts
1590	1.02.0898.1.01.3	DE	0165-52-5070	Rot. Shaft Lip Seal
1591	1.02.0899.1.01.4	DE	0165-52-6916	Cylinder Roller Bearing
1592	1.02.0900.1.01.5	DE	0165-52-6928	Rot. Shaft Lip Seal
1593	1.02.0901.1.01.6	DE	0165-56-021	Solenoid
1594	1.02.0902.1.01.7	DE	0165-56-023	Ball Joint
1595	1.02.0903.1.01.8	DE	0165-90-001	Gasket Set
1596	1.02.0904.1.01.9	DE	0165-90-6336	DEUTZ OIL (20 LTR) (DQC-III)
1597	1.02.0905.1.01.1	DE	0165-90-6337	DEUTZ OIL (208 LTR) (DQC-III)
1598	1.02.0906.1.01.2	DE	0165-90-7991	COOLANT (20 LTR.)

1599	1.02.0907.1.01.3	DE	0165-90-7992	COOLANT (208 LTR.)
1600	1.02.0908.1.01.4	DE	1 120 033 009	COVER PLATE
1601	1.02.0909.1.01.5	DE	1 120 283 000	RADIAL SEAL
1602	1.02.0910.1.01.6	DE	1 120 300 018	EXPANSION BUSHING
1603	1.02.0911.1.01.7	DE	1 120 322 003	STOP BUSHING
1604	1.02.0912.1.01.8	DE	1 120 905 039/533	BEARING
1605	1.02.0913.1.01.9	DE	1 120 905 525	BEARING
1606	1.02.0914.1.01.1	DE	1 124 035 177	ROTOR
1607	1.02.0915.1.01.2	DE	1 124 037 001	ROTOR
1608	1.02.0916.1.01.3	DE	1 124 037 002	ROTOR
1609	1.02.0917.1.01.4	DE	1 125 045 107	STATOR
1610	1.02.0918.1.01.5	DE	1 125 047 005	STATOR
1611	1.02.0919.1.01.6	DE	1 125 825 043	DRIVE END SHIELD
1612	1.02.0920.1.01.7	DE	1 125 827 006	DRIVE END SHIELD
1613	1.02.0921.1.01.8	DE	1 125 827 021	DRIVE END SHIELD
1614	1.02.0922.1.01.9	DE	9 451 037 406	FILTER
1615	1.02.0923.1.01.1	DE	1 127 011 016	PARTS SET
1616	1.02.0924.1.01.2	DE	1 127 011 020	PARTS SET ROTOR
1617	1.02.0925.1.01.3	DE	1 127 011 064	PARTS SET ROTOR
1618	1.02.0926.1.01.4	DE	1 127 011 071	PARTS SET
1619	1.02.0927.1.01.5	DE	1 127 011 072	PARTS SET
1620	1.02.0928.1.01.6	DE	1 127 011 083	PARTS SET CLAMP
1621	1.02.0929.1.01.7	DE	1 127 011 171	PARTS SET ROTOR
1622	1.02.0930.1.01.8	DE	1 127 014 021	CARBON
1623	1.02.0931.1.01.9	DE	1 127 014 030/022	CARBON BRUSH SET
1624	1.02.0932.1.01.1	DE	9 451 037 404	FILTER
1625	1.02.0933.1.01.2	DE	1 127 320 316	RECTIFIER
1626	1.02.0934.1.01.3	DE	1 127 320 550/973	RECTIFIER
1627	1.02.0935.1.01.4	DE	1 127 320 973	RECTIFIER
1628	1.02.0936.1.01.5	DE	1 127 320 976	RECTIFIER
1629	1.02.0937.1.01.6	DE	1 197 311 304	REGULATOR
1630	1.02.0938.1.01.7	DE	1 197 311 315	TRANSISTOR REGULATOR
1631	1.02.0939.1.01.8	DE	1 197 311 317	REGULATOR
1632	1.02.0940.1.01.9	DE	1 197 311 320	REGULATOR
1633	1.02.0941.1.01.1	DE	1 414 612 020	DV SPRING
1634	1.02.0942.1.01.2	DE	1 457 431 003	FILTER
1635	1.02.0943.1.01.3	DE	1 464 612 512	DV SPRING
1636	1.02.0944.1.01.4	DE	1 466 100 312	SHAFT
1637	1.02.0945.1.01.5	DE	9 430 034 293	NOZZLE
1638	1.02.0946.1.01.6	DE	1 466 111 361	CAMPLATE
1639	1.02.0947.1.01.7	DE	1 467 010 059	GASKET KIT
1640	1.02.0948.1.01.8	DE	1 467 030 304	FEED PUMP
1641	1.02.0949.1.01.9	DE	2 418 552 035	DELIVERY VALVE
1642	1.02.0950.1.01.1	DE	1 468 336 480	DISTRIBUTOR HEAD
1643	1.02.0951.1.01.2	DE	2 418 552 003	DELIVERY VALVE
1644	1.02.0952.1.01.3	DE	2 418 552 027	DELIVERY VALVE
1645	1.02.0953.1.01.4	DE	1 468 532 247	DELIVERY VALVE
1646	1.02.0954.1.01.5	DE	1 900 900 361	BEARING
1647	1.02.0955.1.01.6	DE	1 900 900 602	BEARING
1648	1.02.0956.1.01.7	DE	1 900 905 167	BEARING
1649	1.02.0957.1.01.8	DE	1 900 910 024	BEARING
1650	1.02.0958.1.01.9	DE	1 900 910 240	BEARING
1651	1.02.0959.1.01.1	DE	2 418 455 045	ELEMENT
1652	1.02.0960.1.01.2	DE	1 900 910 241	BEARING
1653	1.02.0961.1.01.3	DE	1120905031/107/105	BEARING
1654	1.02.0962.1.01.4	DE	2 000 212 000	RADIAL SEAL
1655	1.02.0963.1.01.5	DE	2 000 220 080	STOP BUSHING
1656	1.02.0964.1.01.6	DE	2 418 455 030	ELEMENT
1657	1.02.0965.1.01.7	DE	2 000 301 015	BUSHING
1658	1.02.0966.1.01.8	DE	2 000 301 016	BUSH
1659	1.02.0967.1.01.9	DE	2 000 328 021	STOP BUSHING
1660	1.02.0968.1.01.1	DE	2 000 910 002	BEARING
1661	1.02.0969.1.01.2	DE	2 000 910 005	BEARING
1662	1.02.0970.1.01.3	DE	2 418 455 026	ELEMENT
1663	1.02.0971.1.01.4	DE	2 004 005 023/024	ARMATURE
1664	1.02.0972.1.01.5	DE	2 004 125 083	EXCITATION WINDING
1665	1.02.0973.1.01.6	DE	2 005 825 087	DRIVE END SHAFT
1666	1.02.0974.1.01.7	DE	2 005 825 242	DRIVE END SHAFT
1667	1.02.0975.1.01.8	DE	2 417 010 027	GASKET KIT
1668	1.02.0976.1.01.9	DE	2 006 209 492	PINION
1669	1.02.0977.1.01.1	DE	2 006 382 018	PINION
1670	1.02.0978.1.01.2	DE	2 006 401 527	MULTIPLATE CLUTCH
1671	1.02.0979.1.01.3	DE	2 007 010 032	PARTS SET
1672	1.02.0980.1.01.4	DE	2 007 011 029	TERMINAL PARTS SET
1673	1.02.0981.1.01.5	DE	2 007 011 069	PARTS SET
1674	1.02.0982.1.01.6	DE	2 007 011 070	TERMINAL PARTS SET
1675	1.02.0983.1.01.7	DE	2 007 014 063	CARBON

1676	1.02.0984.1.01.8	DE	2 007 014 070	CARBON
1677	1.02.0985.1.01.9		Repeated item	
1678	1.02.0986.1.01.1	DE	2 120 905 000	DEEP-GROOVE BALL BEARING
1679	1.02.0987.1.01.2	DE	2 120 910 001	CYL. ROLLER BEARING
1680	1.02.0988.1.01.3	DE	2 414 614 002	DV SPRING
1681	1.02.0989.1.01.4	DE	2 417 010 023	GASKET KIT
1682	1.02.0990.1.01.5			Repeated item
1683	1.02.0991.1.01.6	DE	9 451 037 407	FILTER
1684	1.02.0992.1.01.7	DE	9 451 037 409	FILTER
1685	1.02.0993.1.01.8	DE	2102211	REDUCTION
1686	1.02.0994.1.01.9	DE	ABA-50-65/12	HOSE CLIP
1687	1.02.0995.1.01.1	DE	NW110X6MM-90LG	HOSE
1688	1.02.0996.1.01.2	DE	0148-44-24	self starter for BCM
1689	1.02.0997.1.01.3	DE	0148-38-295	SOLENOID VALVE
1690	1.02.0998.1.01.4	DE	0148-16-168/10	PIPE LINE
1691	1.02.0999.1.01.5	DE	0165-20-029	FILTER ELEMENT
1692	1.02.1000.1.01.6	DE	0165-20-030	GASKET SET
1693	1.02.1001.1.01.7	DE	0165-44-131	EYE Bolt(V-belt Tensioning bolts)
1694	1.02.1002.1.01.8	DE	0148-48-017 (0.5BAR)	PRESSURE SWITCH (0.5BAR)
1695	1.02.1003.1.01.9	DE	0148-48-017 (2.5BAR)	PRESSURE SWITCH(2.5BAR)
1696	1.02.1004.1.01.1	DE	0150A-22-043 (01319258)	AIR FILTER CATRIDGE
1697	1.02.1005.1.01.2	DE	0150A-22-044 (118 0871)	AIR FILTER CATRIDGE
1698	1.02.1006.1.01.3	DE	0148-22-3903	AIR FILTER INNER
1699	1.02.1007.1.01.4	DE	0148-22-2303	AIR FILTER OUTER
1700	1.02.1008.1.01.5	DE	0150A-15-009/ 1183574	SPIN ON OIL FILTER
1701	1.02.1009.1.01.6	DE	0150A-20-007/ 1181917	SPIN ON FUEL FILTER
1702	1.02.1010.1.01.7	DE	0150A-22-043 /0131-9258	AIR FILTER CATRIDGE
1703	1.02.1011.1.01.8	DE	0150A-22-044/0118- 0871	AIR FILTER CATRIDGE
1704	1.02.1012.1.01.9	DE	0150A-44-105/40169990	NARROW V BELT
1705	1.02.1013.1.01.1	DE	0150A-39-147/40169990	NARROW V BELT
1706	1.02.1014.1.01.2	DE	0150A-01-095	TENSION PULLEY
1707	1.02.1015.1.01.3	DE	0165-33-012	VACCUM/COMPRESSOR HOSE
1708	1.02.1016.1.01.4	DE	0165-20-010-V08	Spin-On Fuel Filter
1709	1.02.1017.1.01.5	DE	0165-15-001-V08	Spin-On Oil Filter
1710	1.02.1018.1.01.6	DE	0165-20-075-V08	Filter Cartridge
1711	1.02.1019.1.01.7	DE	0165-22-248-V08	Filter Insert
1712	1.02.1020.1.01.8	DE	0165-22-249-V08	Safety Cartridge
1713	1.02.1021.1.01.9	DE	0148-22-013	SEALING NUT
1714	1.02.1022.1.01.1	PH	UTVI 06 38/00	RELIEF VALVE
1715	1.02.1023.1.01.2	DE	0165-33-001-V08-U	AIR COMPRESSOR
1716	1.02.1024.1.01.3	DEUTZ	0165-36-046	RADIATOR
1717	1.02.1025.1.01.4	DEUTZ	0164-01-018	Hexagonal bolt
1718	1.02.1026.1.01.5	DEUTZ	0165-16-001	FILLER PIPE GASKET
1719	1.02.1027.1.01.6	DEUTZ	0165-16-138	GASKET
1720	1.02.1028.1.01.7	DEUTZ	0165-16-135	RUBBER HOSE
1721	1.02.1029.1.01.8	DEUTZ	0165-16-131	GASKET
1722	1.02.1030.1.01.9	DEUTZ	0165-17-022	O-SEAL
1723	1.02.1031.1.01.1	DEUTZ	0165-17-18	SEALING RING
1724	1.02.1032.1.01.2	DEUTZ	0165-17-043	SEALING PLATE
1725	1.02.1033.1.01.3	DEUTZ	0165-33-000	STOP RING
1726	1.02.1034.1.01.4	DEUTZ	0165-01-132	SPECIAL GASKET
1727	1.02.1035.1.01.5	DEUTZ	0165-133-9590	GASKET
1728	1.02.1036.1.01.6	DEUTZ	0150A-39-150	V-BELT
1729	1.02.1037.1.01.7	DEUTZ	0150-21-042	FUEL LINE
1730	1.02.1038.1.01.8	DEUTZ	0150A-21-044	FUEL LINE
1731	1.02.1039.1.01.9	DEUTZ	0150A-20-051	FILTER ELEMENT
1732	1.02.1040.1.01.1	DEUTZ	0150A-22-040	AIR CLEANER
1733	1.02.1041.1.01.2	DEUTZ	0150A-20-007	Spin -On Fuel Filter
1734	1.02.1042.1.01.3	DEUTZ	0148-01-098	Rubber steeve
1735	1.02.1043.1.01.4	DEUTZ	0148-44-041	Alternator
1736	1.02.1044.1.01.5	DEUTZ	0148-22-122	Thrust plate
1737	1.02.1045.1.01.6	DEUTZ	0165-33-8475	Gasket
1738	1.02.1046.1.01.7	DEUTZ	0165-36-086	Hose
1739	1.02.1047.1.01.8	DEUTZ	0150-44-001	Alternator
1740	1.03.0001.1.01.7	GR	123209450107	NON MARINE AFTER COOLER
1741	1.03.0002.1.01.8	GR	1200240183	DB FILTER 028
1742	1.03.0003.1.01.9	GR	1200240911	FILT. ELEMENT WITH O RING
1743	1.03.0004.1.01.1	GR	1200240912	FLTR INSRT WITH O RING
1744	1.03.0005.1.01.2	GR	1707230112	RUBER SEAL INJECTOR
1745	1.03.0006.1.01.3	GR	103460221016	COGGED BELT BX40
1746	1.03.0007.1.01.4	GR	105292001442	TC .K27.2-2967 MXA 13.2 TBD2V6
1747	1.03.0008.1.01.5	GR	123200190258	SET OF HOSES * TBD V12 RC
1748	1.03.0009.1.01.6	GR	123200190268	SET OF HOSECLIPS TBDV12RC
1749	1.03.0010.1.01.7	GR	123200190278	SET OF O RINGS TBDV12 RC
1750	1.03.0011.1.01.8	GR	123200190448	SET-SEALING RINGS TBDV12
1751	1.03.0012.1.01.9	GR	123200193557	SET OF GASKET-TBDV12 RC

1752	1.03.0013.1.01.1	GR	123200194357	SET-FLEX F/PIPE TBDV12-II
1753	1.03.0014.1.01.2	GR	123201400507	CR-SHFT ASSY-TBD/V12 SPL
1754	1.03.0015.1.01.3	GR	123201700094	CAMSHAFT V12 FINISHED
1755	1.03.0016.1.01.4	GR	123203100184	DOWEL PIN TBD/V12-10X95
1756	1.03.0017.1.01.5	GR	123203210034	PUSH ROD - D2/D4/DL4
1757	1.03.0018.1.01.6	GR	123203410096	TENSION ROLLER-1B GROOVE
1758	1.03.0019.1.01.7	GR	123203410166	TENSION ROLLER ASSY TISCO
1759	1.03.0020.1.01.8	GR	123206230014	BRKT FUEL FILTER
1760	1.03.0021.1.01.9	GR	123207110036	FUEL INJ. PUMP DRIVE
1761	1.03.0022.1.01.1	GR	123207311106	FW PUMP 3-GR WITH 35.4PULLEY
1762	1.03.0023.1.01.2	GR	123207319217	SECONDARY WATER PUMP ASSY
1763	1.03.0024.1.01.3	GR	123207400517	LUBOIL CENTRFG. FILTR ASY
1764	1.03.0025.1.01.4	GR	123209123025	Pipe Aft Clr inlet from Sec water pump
1765	1.03.0026.1.01.5	GR	123209302566	EXHAUST MANIFOLD LAGGED
1766	1.03.0027.1.01.6	GR	123209302576	EXHAUST MANIFOLD LAGGED
1767	1.03.0028.1.01.7	GR	123209311126	EXHAUST ELBOW B-BANK LAGD
1768	1.03.0029.1.01.8	GR	123209311136	EXHAUST ELBOW LAGGED
1769	1.03.0030.1.01.9	GR	123209423905	PIPE-OIL COOLER TO SECON.
1770	1.03.0031.1.01.1	GR	123209424474	Pipe Sec water pump to Aft Clr
1771	1.03.0032.1.01.2	GR	123406520015	FLANG BELLOW
1772	1.03.0033.1.01.3	GR	602001016401	BOLT M16X1.5X75 CL 10.9 B-FORM
1773	1.03.0034.1.01.4	GR	602360102206	LOCKING RING A/4
1774	1.03.0035.1.01.5	GR	604960650901	OILSEAL=110X90X12 MM THK
1775	1.03.0036.1.01.6	GR	604960651332	OIL SEAL (FLYWHEEL SIDE)
1776	1.03.0037.1.01.7	GR	604962000002	VALVE STEAM SEAL
1777	1.03.0038.1.01.8	GR	605411880008	LUB OIL FILTER(232V12)
1778	1.03.0039.1.01.9	GR	606500100006	A V MOUNTG-A2T/4030B
1779	1.03.0040.1.01.1	GR	623200197227	PISTON RINGS SET * TD/TBD
1780	1.03.0041.1.01.2	GR	623201320044	CYLINDER LINER
1781	1.03.0042.1.01.3	GR	623203100104	DOWEL PIN 10X40
1782	1.03.0043.1.01.4	GR	623203250044	TAPPET
1783	1.03.0044.1.01.5	GR	623203300144	BRASS SLEEVE
1784	1.03.0045.1.01.6	GR	623203300154	CU.SLEEVE
1785	1.03.0046.1.01.7	GR	623203320034	VALVE GUIDE D2
1786	1.03.0047.1.01.8	GR	623203450032	INSERTS V S INL/EXH
1787	1.03.0048.1.01.9	GR	623203510034	BOLT M B M18X2.5X135
1788	1.03.0049.1.01.1	GR	623203580024	ADJ.SCREW=M10X1.5X39 LG.
1789	1.03.0050.1.01.2	GR	623204600024	VALVE EX D2 KV 2994
1790	1.03.0051.1.01.3	GR	623204650015	PISTON COOLING NOZZLE STD
1791	1.03.0052.1.01.4	GR	623207030164	VIBRATION DAMPER TBD V12
1792	1.03.0053.1.01.5	GR	623284300037	MAIN-BRG 0.010" U/S(0.25)
1793	1.03.0054.1.01.6	GR	623284306027	BRG CON-ROD LE 0.010"/.25
1794	1.03.0055.1.01.7	GR	623407300046	LUB OIL PUMP ASSY (MAIN)
1795	1.03.0056.1.01.8	GR	100099390664	Flexible Pipe Pressure Guage
1796	1.03.0057.1.01.9	GR	100099391384	Flexible Pipe IOF
1797	1.03.0058.1.01.1	GR	105413100062	Diesel Pre- Filter
1798	1.03.0059.1.01.2	GR	105612412501	Lub. Oil Pressure Gauge
1799	1.03.0060.1.01.3	GR	105652090146	Tachometer Meter
1800	1.03.0061.1.01.4	GR	105685000621	Water Temperature Gauge
1801	1.03.0062.1.01.5	GR	105685090027	HCT Switch
1802	1.03.0063.1.01.6	GR	105782010008	L.L.O.P. Switch
1803	1.03.0064.1.01.7	GR	106900000014	Air Filter Element (Outer)
1804	1.03.0065.1.01.8	GR	106900000015	Air Filter Element (Inner)
1805	1.03.0066.1.01.9	GR	106900000033	O' Ring Prefilter
1806	1.03.0067.1.01.1	GR	123206410094	Lever
1807	1.03.0068.1.01.2	GR	123206500174	Plate
1808	1.03.0069.1.01.3	GR	123299302755	Exhaust Junction
1809	1.03.0070.1.01.4	GR	123299330265	Exhaust Flex Pipe
1810	1.03.0071.1.01.5	GR	602000101065	Bolt for E/M
1811	1.03.0072.1.01.6	GR	602000501640	Hex Bolt
1812	1.03.0073.1.01.7	GR	602011081025	Stud
1813	1.03.0074.1.01.8	GR	602100540100	Lock Nut
1814	1.03.0075.1.01.9	GR	602100540160	Hex Nut
1815	1.03.0076.1.01.1	GR	602421102160	Spring Solenoid
1816	1.03.0077.1.01.2	GR	602701010010	Angular Joint (L)
1817	1.03.0078.1.01.3	GR	602701011010	Angular Joint (LH)
1818	1.03.0079.1.01.4	GR	604015120060	Hose Clip
1819	1.03.0080.1.01.5	GR	604015120072	Hose Clip
1820	1.03.0081.1.01.6	GR	604015301650	Hose Clip
1821	1.03.0082.1.01.7	GR	604015360380	Hose Clip
1822	1.03.0083.1.01.8	GR	604910121000	Gasket Silencer
1823	1.03.0084.1.01.9	GR	604920100814	Copper Washer
1824	1.03.0085.1.01.1	GR	604920101014	Copper Washer
1825	1.03.0086.1.01.2	GR	604920101418	Copper Washer
1826	1.03.0088.1.01.4	GR	607120130004	Lifting Magnet (24V)
1827	1.03.0089.1.01.5	GR	620708610104	Hose Bend
1828	1.03.0090.1.01.6	GR	623203200144	Rod Threaded 115mm

1829	1.03.0091.1.01.7	GR	623208610284	Hose
1830	1.03.0092.1.01.8	GR	623208610294	Hose
1831	1.03.0093.1.01.9	GR	623208610314	Hose
1832	1.03.0094.1.01.1	GR	623208610334	Hose
1833	1.03.0095.1.01.2	GR	623208610344	Hose Water M/F to H.E.
1834	1.03.0096.1.01.3	GR	623208610384	Hose
1835	1.03.0097.1.01.4	GR	E05302000040	INJ.CMPL F002C7Z116
1836	1.03.0098.1.01.5	GR	E23200192847	V12 F.I.PIPE SET-A TYPE
1837	1.03.0099.1.01.6	GR	E23201600106	PISTON(TBD2)+GPIN+CIRCLIP
1838	1.03.0100.1.01.7	GR	E23209390985	INJ O/FLOW PIPE V12-I
1839	1.03.0101.1.01.8	GR	E23209391275	INJ.OVER FLOW PIPE (EMI)D2V12
1840	1.03.0102.1.01.9	GR	P23408550024	CYL HEAD GASKET 132 MM
1841	1.03.0103.1.01.1	GR	TBD232 V12	Engine complete
1842	1.03.0103.1.01.2	GR	2202-0160A	INJECTOR GASKET
1843	1.04.0001.1.01.8	KI	06.001.20.0	CRANK CASE ASSEMBLY
1844	1.04.0002.1.01.9	KI	C-075600003	CAM SHAFT BUSH
1845	1.04.0003.1.01.1	KI	W-075500003	THRUST EASHER SET
1846	1.04.0004.1.01.2	KI	02.002.10.0	OIL SPRAY NOZZLE ASSY
1847	1.04.0005.1.01.3	KI	03.007.01.0	OIL SEAL HOUSING(FEW)
1848	1.04.0006.1.01.4	KI	03.007.06.0	OIL SEAL (115 X 140 X 16 mm)
1849	1.04.0007.1.01.5	KI	03.007.04.0	JOINT FOR OIL SEAL HOUSING
1850	1.04.0008.1.01.6	KI	03.008.10.0	INTERMEDIATE GEAR WITH BUSH
1851	1.04.0009.1.01.7	KI	G-075500003	BUSH FOR INTERMEDIATE GEAR
1852	1.04.0010.1.01.8	KI	03.008.03.0	GEAR SUPPORT
1853	1.04.0011.1.01.9	KI	03.008.04.0	SPLIT BUSH FOR GEAR SUPPORT
1854	1.04.0012.1.01.1	KI	M-075400003	MAIN BEARING SET STD
1855	1.04.0013.1.01.2	KI	M-075400013	MAIN BEARING SET 0.25 U/S
1856	1.04.0014.1.01.3	KI	M-075400023	MAIN BEARING SET 0.50 U/S
1857	1.04.0015.1.01.4	KI	06.073.20.0	CRANK SHAFT ASSEMBLY
1858	1.04.0016.1.01.5	KI	06.017.10.0	CRANK SHAFT PULLEY
1859	1.04.0017.1.01.6	KI	03.016.02.0	BOLT
1860	1.04.0018.1.01.7	KI	03.016.03.0	WASHER
1861	1.04.0019.1.01.8	KI	06.005.10.0	CAM SHAFT ASSEMBLY
1862	1.04.0020.1.01.9	KI	03.006.04.0	CAM SHAFT GEAR
1863	1.04.0021.1.01.1	KI	03.006.02.0	THRUST WAHER
1864	1.04.0022.1.01.2	KI	03.006.03.0	BUSH FOR TACHOMETER
1865	1.04.0023.1.01.3	KI	02.024.01.0	VALVE TAPPET
1866	1.04.0024.1.01.4	KI	02.024.10.0	PUSH ROD
1867	1.04.0025.1.01.5	KI	02.024.33.0	PUSH ROD COVER TUBE
1868	1.04.0026.1.01.6	KI	02.024.04.0	SPRING
1869	1.04.0027.1.01.7	KI	02.024.03.0	SEALING RING CAP
1870	1.04.0028.1.01.8	KI	02.021.30.0	CONNECTING ROD ASSY
1871	1.04.0029.1.01.9	KI	S-075500003	SMALL END BUSH
1872	1.04.0030.1.01.1	KI	B-075400003	L.E. BEARING SET STD
1873	1.04.0031.1.01.2	KI	B-075400013	L.E. BEARING SET 0.25 U/S
1874	1.04.0032.1.01.3	KI	B-075400023	L.E. BEARING SET 0.50 U/S
1875	1.04.0033.1.01.4	KI	02.020.01.0	PISTON ASSY
1876	1.04.0034.1.01.5	KI	02.020.98.0	PISTON RING SET STD
1877	1.04.0035.1.01.6	KI	02.019.01.0	CYLINDER LINER STD
1878	1.04.0036.1.01.7	KI	02.019.03.0	SHIM RING
1879	1.04.0037.1.01.8	KI	02.022.20.0	CYLINDER HEAD ASSY COMPLETE
1880	1.04.0038.1.01.9	KI	02.022.17.0	VALVE GUIDE
1881	1.04.0039.1.01.1	KI	02.022.18.0	WIRE SNAP RING
1882	1.04.0040.1.01.2	KI	02.022.22.0	INLET VALVE
1883	1.04.0041.1.01.3	KI	02.022.08.0	EXHAUST VALVE
1884	1.04.0042.1.01.4	KI	02.022.21.0	SPRING CUP
1885	1.04.0043.1.01.5	KI	02.022.13.0	VALVE SPRING
1886	1.04.0044.1.01.6	KI	02.022.12.0	VALVE COLLECT
1887	1.04.0045.1.01.7	KI	02.022.11.0	VALVE CUP
1888	1.04.0046.1.01.8	KI	02.093.02.0	CYLINDER HEAD BOLT
1889	1.04.0047.1.01.9	KI	02.022.04.0	WASHER
1890	1.04.0048.1.01.1	KI	02.024.50.0	ROCKER PEDASTEL ASSY
1891	1.04.0049.1.01.2	KI	02.024.20.0	VALVE ROCKER ASSY
1892	1.04.0050.1.01.3	KI	02.024.32.0	ROCKER COVER
1893	1.04.0051.1.01.4	KI	02.024.21.0	SEALING WASHER(ROCKER COVER GASKET)
1894	1.04.0052.1.01.5	KI	06.013.01.0	FRONT COVER
1895	1.04.0053.1.01.6	KI	03.013.06.0	OIL SEAL (65 X 85 X 13)
1896	1.04.0054.1.01.7	KI	03.013.05.0	JOINT FOR FRONT COVER
1897	1.04.0055.1.01.8	KI	03.014.20.0	SUB ASSY OF TACHOMETER PLUG
1898	1.04.0056.1.01.9	KI	34.036.60.0	OIL FILLER CAP
1899	1.04.0057.1.01.1	KI	06.010.20.0	LUB OIL PUMP ASSY
1900	1.04.0058.1.01.2	KI	06.008.20.0	SUCTION TUBE ASSY
1901	1.04.0059.1.01.3	KI	03.012.10.0	DELIVERY TUBE WITH 'O' RING
1902	1.04.0060.1.01.4	KI	06.020.01.0	LUB OIL COOLER
1903	1.04.0061.1.01.5	KI	06.075.01.0	OIL SUMP
1904	1.04.0062.1.01.6	KI	06.015.02.0	JOINT FOR OIL SUMP

1905	1.04.0063.1.01.7	KI	06.040.10.0	LUB OIL FILTER ASSY
1906	1.04.0064.1.01.8	KI	06.040.01.0	LUB OIL FILTER ELEMENT
1907	1.04.0065.1.01.9	KI	34.032.30.0	FUEL FILTER ASSY
1908	1.04.0066.1.01.1	KI	34.032.02.0	PRE FILTER ELEMENT
1909	1.04.0067.1.01.2	KI	34.032.03.0	MICRO FILTER ELEMENT
1910	1.04.0068.1.01.3	KI	25.040.01.0	FUEL PIPE (FEED PUMP TO FILTER)
1911	1.04.0069.1.01.4	KI	34.151.04.0	FUEL PIPE (FILTER TO PUMP)
1912	1.04.0070.1.01.5	KI	06.003.10.0	FUEL PUMP ASSY
1913	1.04.0071.1.01.6	KI	02.035.30.0	FUEL INJECTOR ASSY
1914	1.04.0072.1.01.7	KI	42.005.10.0	NOZZLE
1915	1.04.0073.1.01.8	KI	02.035.07.0	BUSH FOR INJECTOR
1916	1.04.0074.1.01.9	KI	06.026.90.0	SET OF HIGH PRESSURE PIPE
1917	1.04.0075.1.01.1	KI	06.027.10.0	LEAK OFF PIPE
1918	1.04.0076.1.01.2	KI	06.085.40.0	COOLING AIR BLOWER ASSY
1919	1.04.0077.1.01.3	KI	06.085.20.0	IMPELLER WITH BUSH
1920	1.04.0078.1.01.4	KI	06.085.20.1	FLY WHEEL WITH STARTER RING
1921	1.04.0079.1.01.5	KI	06.048.10.0	AIR CLEANER ASSY
1922	1.04.0080.1.01.6	KI	06.046.01.0	EXHAUST MAIN FOLD CUM SILENCER
1923	1.04.0081.1.01.7	KI	06.065.20.0	SUB ASSY OF BEND & RAIN CAP ASSY
1924	1.04.0082.1.01.8	KI	06.050.10.0	SET OF JOINT
1925	1.04.0083.1.01.9	KI	06.051.10.0	SET OF 'O' RINGS
1926	1.04.0084.1.01.1	KI	2130-2341F	FUEL RETURN PIPE(INJECTOR)
1927	1.04.0085.1.01.2	KI	46.252.05.0.00	LUB OIL PRESSURE SENSER WITH SWTICH 3POINT
1928	1.04.0086.1.01.3	KI	03.061.70.0.00	OIL BATH FILTER
1929	1.04.0087.1.01.4	KI	06.436.01.0.00	SPIN ON LUBE OIL FILTER
1930	1.04.0088.1.01.5	KI	48.117.04.0.00	FUEL FILTER ELEMENT PRE
1931	1.04.0089.1.01.6	KI	48.117.05.0.00	FUEL FILTER ELEMENT MICRO
1932	1.04.0090.1.01.7	KI	48.145.02.0.00	AIR CLEANER ELEMENT OUTER
1933	1.04.0091.1.01.8	KI	48.145.03.0.00	AIR CLEANER ELEMENT INNER
1934	1.04.0092.1.01.9	KI	06.793.01.0.00	Engine shut down coil
1935	1.04.0093.1.01.1	KI	1.457.431.003	FUEL FILTER ELEMENT PRE
1936	1.04.0094.1.01.2	KI	9.451.037.409	FUEL FILTER ELEMENT MICO
1937	1.04.0095.1.01.3	KI	34.174.02.0.00	fuel pipe connect with benzo pipe(filter to pipe)
1938	1.04.0096.1.01.4	KI	34.035.03.0.00	fuel pipe connect with benzo pipe(feed pump to filter)
1939	1.05.0001.1.01.9	SU	4202-0007A	COPPER WASHER
1940	1.05.0002.1.01.1	SU	4202-0008A	COPPER WASHER
1941	1.05.0003.1.01.2	SU	4202-0012A	COPPER WASHER
1942	1.05.0004.1.01.3	SU	4161-0008A	CLAMP
1943	1.05.0005.1.01.4	SU	2067-0002A	FLY WHEEL RING
1944	1.05.0006.1.01.5	SU	2203-0455A	PACKING RUBBER
1945	1.05.0007.1.01.6	SU	2203-0436A	TAPPET COVER GASKET
1946	1.05.0008.1.01.7	SU	4632-0505A	O RING
1947	1.05.0009.1.01.8	SU	4632-0018A	WASHER
1948	1.05.0010.1.01.9	SU	2181-2031G	WASHER
1949	1.05.0011.1.01.1	SU	2203-2126F (New Part No. 2203- 2262F)	WASHER
1950	1.05.0012.1.01.2	SU	2181-0060A	WASHER
1951	1.05.0013.1.01.3	SU	2039-0018A	SPACER
1952	1.05.0014.1.01.4	SU	2040-0002A	COLLET
1953	1.05.0015.1.01.5	SU	2202-0162A	WASHER (0.10)
1954	1.05.0016.1.01.6	SU	2202-0163A	WASHER (0.20)
1955	1.05.0017.1.01.7	SU	2202-0164A	WASHER (0.30)
1956	1.05.0018.1.01.8	SU	2202-0158F	GASKET CYLINDER HEAD
1957	1.05.0019.1.01.9	SU	2038-0016A (New Part No. 2038- 2013F)	VALVE GUIDE
1958	1.05.0020.1.01.1	SU	4203-2003A	GASKET
1959	1.05.0021.1.01.2	SU	2044-0026C (New Part No. 2044- 2013F)	VALVE INSERT
1960	1.05.0022.1.01.3	SU	2036-2005F	VALVE CONE(INLET)
1961	1.05.0023.1.01.4	SU	2044-0025A	VALVE INSERT (EX)
1962	1.05.0024.1.01.5	SU	2037-0024A	VALVE CONE (EX)
1963	1.05.0025.1.01.6	SU	1025-2048F	PISTON COMPLETE
1964	1.05.0026.1.01.7	SU	1027-0073A	PISTON RINGS
1965	1.05.0027.1.01.8	SU	2203-2181F	GASKET
1966	1.05.0028.1.01.9	SU	2203-2182F	GASKET (OIL PAN)
1967	1.05.0029.1.01.1	SU	4632-0034A	O RING
1968	1.05.0030.1.01.2	SU	2202-2066F	GASKET
1969	1.05.0031.1.01.3	SU	2203-2179F	GASKET
1970	1.05.0032.1.01.4	SU	2042-0012A	PUSH ROD
1971	1.05.0033.1.01.5	SU	1030-2012F	BEARING MAIN STD
1972	1.05.0034.1.01.6	SU	1030-2013F	BEARING MAIN 0.25
1973	1.05.0035.1.01.7	SU	1030-0033S (New Part No.1030- 2034F)	MAIN BEARING STD

1974	1.05.0036.1.01.8	SU	1030-0033S (New Part No.1030-2035F)	MAIN BEARING 0.25
1975	1.05.0037.1.01.9	SU	2165-0005A	THRUST RING STD
1976	1.05.0038.1.01.1	SU	4637-0215A	BEARING BALL
1977	1.05.0039.1.01.2	SU	4637-0185A	BEARING BALL
1978	1.05.0040.1.01.3	SU	4637-0379A	BEARING BALL
1979	1.05.0041.1.01.4	SU	4627-0045A	CIRCLIP
1980	1.05.0042.1.01.5	SU	4626-0047A	CIRCLIP
1981	1.05.0043.1.01.6	SU	NA	BOLT CON.ROD
1982	1.05.0044.1.01.7	SU	1030-0087A	CON.ROD BEARING STD
1983	1.05.0045.1.01.8	SU	1030-0089A	CON.ROD BEARING 0.25
1984	1.05.0046.1.01.9	SU	2202-0052A	O RING
1985	1.05.0047.1.01.1	SU	4632-0072A	OIL SEAL
1986	1.05.0048.1.01.2	SU	4115-0030A	L.O FILTER
1987	1.05.0049.1.01.3	SU	2203-2189F	GASKET
1988	1.05.0050.1.01.4	SU	4027-0002A	RING(EX.MFLD)
1989	1.05.0051.1.01.5	SU	4113-2011A	AIR CLEANER
1990	1.05.0052.1.01.6	SU	4161-0041A	CLAMP
1991	1.05.0053.1.01.7	SU	4634-0250A	BALL BEARING (BLOWER)
1992	1.05.0054.1.01.8	SU	4651-0554A	V BELT
1993	1.05.0055.1.01.9	SU	3130-0030A	HOSE (TURBO)
1994	1.05.0056.1.01.1	SU	4161-0043A	CLAMP (TURBO)
1995	1.05.0057.1.01.2	SU	2202-2058F	GASKET (TURBO)
1996	1.05.0058.1.01.3	SU	2203-2162F	GASKET (TURBO)
1997	1.05.0059.1.01.4	SU	2203-2190F	GASKET (TURBO)
1998	1.05.0060.1.01.5	SU	2202-2059F	GASKET (TURBO)
1999	1.05.0061.1.01.6	SU	2130-0127A	HOSE (TURBO)
2000	1.05.0062.1.01.7	SU	4161-0034A	CLAMP (TURBO) New Part No.4161
2001	1.05.0063.1.01.8	SU	4632-0135A	O RING
2002	1.05.0064.1.01.9	SU	4202-0014A	WASHER
2003	1.05.0065.1.01.1	SU	4202-0022A	WASHER
2004	1.05.0066.1.01.2	SU	1203-2137G/2270F	SET OF ENGINE GASKET SET
2005	1.05.0067.1.01.3	SU	1203-2135F	SET OF CYLINDER HEAD GASKET
2006	1.05.0068.1.01.4	SU	4531-0059A	FUEL FILTER
2007	1.05.0069.1.01.5	SU	4502-2012F	STOP SOLENOID- 24V
2008	1.05.0070.1.01.6	SU	4502-2011F	STOP SOLENOID- 12V
2009	1.05.0071.1.01.7	SU	3524-2046F	TURBO CHARGER
2010	1.05.0072.1.01.8	SU	4506-2015A	NOZZLE
2011	1.05.0073.1.01.9	SU	4518-0005A	DIAPHRAM LIFT PUMP
2012	1.05.0074.1.01.1	SU	4634-0451A	SEAL RING
2013	1.05.0075.1.01.2	SU	1035-2036	CYLINDER HEAD ENGINE NEW PART NO.1035-2097F
2014	1.05.0076.1.01.3	SU	1115-0016B	OIL FILTER ASSY.NEW PART NO.115-2005F
2015	1.05.0077.1.01.4	SU	1120-0027A	OIL RADIATOR
2016	1.05.0078.1.01.5	SU	1506-2010F	INJECTOR
2017	1.05.0079.1.01.6	SU	1518-0017A	FUEL FEED PUMP
2018	1.05.0080.1.01.7	SU	3502-2034F	FUEL FEED PUMP (B&S)
2019	1.05.0081.1.01.8	SU	2017-0060F	CRANK SHAFT
2020	1.05.0082.1.01.9	SU	2018-2036F	CAM SHAFT
2021	1.05.0083.1.01.1	SU	1129-2055F	INJECTOR PIPE
2022	1.05.0084.1.01.2	SU	4637-0250A	BLOWER BEARING
2023	1.05.0085.1.01.3	SU	2163-0290A	SPACER
2024	1.05.0086.1.01.4	SU	4626-0062A	CIRCLIP
2025	1.05.0087.1.01.5	SU	4606-0008A	LUB OIL SENSOR/OIL TEMP.SWITCH
2026	1.05.0088.1.01.6	SU	4161.0034 (New Part No.4161-2143F)	HOSE
2027	1.05.0089.1.01.7	SU	2012-0030A	FLY WHEEL HOUSING
2028	1.05.0090.1.01.8	SU	4561-0026A	ANTI VIBRATION MOUNTING
2029	1.05.0091.1.01.9	SU	3553-0060A	STARTER
2030	1.05.0092.1.01.1		Shifted to Annexure-II	
2031	1.05.0093.1.01.2		Shifted to Annexure-II	
2032	1.05.0094.1.01.3		Shifted to Annexure-II	
2033	1.05.0095.1.01.4	SU	1521-0036A	OIL PUMP
2034	1.05.0096.1.01.5	SU	3531-0032A	FUEL FILTER
2035	1.05.0097.1.01.6	SU	2130-2350G	PIPE
2036	1.05.0098.1.01.7	SU	2203-0230A	GASKET
2037	1.05.0099.1.01.8	SU	2203-0231A	GASKET
2038	1.05.0100.1.01.9	SU	2097-2213G	COVER
2039	1.05.0101.1.01.1	SU	3203-0017A	GASKET
2040	1.05.0102.1.01.2	SU	2202-2046A	GASKET
2041	1.05.0103.1.01.3	SU	2097-2174A	OIL RADIATOR SHEET
2042	1.05.0104.1.01.4	SU	2130-2312F	PIPE
2043	1.05.0105.1.01.5	SU	2130-2313F	PIPE
2044	1.05.0106.1.01.6	SU	2561-0003A	SHOCK ABSORBER
2045	1.05.0107.1.01.7	SU	2060-0253A	PULLEY
2046	1.05.0108.1.01.8	SU	4176-3533F	SCREW

2047	1.05.0109.1.01.9	SU	2052-2033G	FRONT SUPPORT ASSEMBLY
2048	1.05.0110.1.01.1	SU	2177-0063A	CAP
2049	1.05.0111.1.01.2	SU	1177-2003F	OIL FILLER.PLUG
2050	1.05.0112.1.01.3	SU	2130-2502F	PIPE FROM THE TANK T
2051	1.05.0113.1.01.4	SU	2130-2016A	TUBE
2052	1.05.0114.1.01.5	SU	2104-0113G	INTAKE MANIFOLD
2053	1.05.0115.1.01.6	SU	2013-0289A	COVER
2054	1.05.0116.1.01.7	SU	2013-0267F	COVER
2055	1.05.0117.1.01.8	SU	2054-0001A	BRACKET
2056	1.05.0118.1.01.9	SU	2024-0063A	CYLINDER
2057	1.05.0119.1.01.1	DE	21202009G	RADITOR
2058	1.05.0120.1.01.2		Repeated item	
2059	1.05.0121.1.01.3		Repeated item	
2060	1.05.0122.1.01.4	SU	35242047F	Turbo charger
2061	1.05.0123.1.01.5	SU	3524-2021A	TURBO ASSY
2062	1.05.0124.1.01.6	SU	4175-0381A	STUD
2063	1.05.0125.1.01.7	SU	4175-0897A	STUD
2064	1.05.0126.1.01.8	SU	2203-2220	GASKET
2065	1.08.0001.1.01.3	CA	1063969	Air Cleaner outer (C-18)
2066	1.08.0002.1.01.4	CA	1063973	Air Cleaner inner (C-18)
2067	1.08.0003.1.01.5	CA	1327167	Air Cleaner outer (C-9)
2068	1.08.0004.1.01.6	CA	1R-0749	FUEL FILTER (C-9)
2069	1.08.0005.1.01.7	CA	AVX13-925LA	V-BELT
2070	1.08.0006.1.01.8	CA	1R-0751	FUEL FILTER (C-9)
2071	1.08.0007.1.01.9	CA	1R-1808	Engine oil Filter (C-9 & C-18)
2072	1.08.0008.1.01.1	CA	275-2096	Lub. Oil Pressure gauge
2073	1.08.0009.1.01.2	CA	326-1643	FUEL FILTER WATER SEPARATOR
2074	1.08.0010.1.01.3	CA	612510	Air Cleaner inner (C-9)
2075	1.08.0011.1.01.4	CA	6N-7054 CAT F 5211F5	V-belt (C-18) for radiator fan
2076	1.08.0012.1.01.5	CA	A-4896	V-belt (C-9) for water pump
2077	1.08.0013.1.01.6	CA	B 1080 B41	V-belt (C-9) for alternator
2078	1.08.0014.1.01.7	CA	C 1610 C61	V-belt (C-9) for radiator fan
2079	1.08.0015.1.01.8	CA	XPB 1500	V-belt (C-18) for alternator
2080	1.08.0016.1.01.9		Shifted to Ann-II	
2081	1.08.0017.1.01.1		Repeated	
2082	1.08.0018.1.01.2	CA	1W3636	ELEMENT AS
2083	1.08.0019.1.01.3	CA	2515886	ELEMENT AS
2084	1.08.0020.1.01.4	CA	4401616	AIR COMPRESSOR
2085	1.08.0021.1.01.5	CA	1W4150	SPIDER A
2086	1.08.0022.1.01.6	CA	2969799	TUBE AS
2087	1.08.0023.1.01.7	CA	1R-0755	FUEL FILTER
2088	1.08.0024.1.01.8	CA	423-8521	FUEL/WATER SEPARATOR
2089	1.08.0025.1.01.9	CA	246-5010	ELEMENT SEC (INNER AIR FILTER)
2090	1.08.0026.1.01.1	CA	246-5009	ELEMENT AS (OUTER AIR FILTER)
2091	1.08.0027.1.01.2	CA	1R-1804	FUEL FILTER
2092	1.08.0028.1.01.3	CA	441-5111	FUEL/WATER SEPARATOR
2093	1.08.0029.1.01.4	CA	7W-2326	OIL FILTER
2094	1.08.0030.1.01.5	CA	110-6326	AIR FILTER
2095	1.08.0031.1.01.6	CA	197-8820 (95A,24V)	Engine 1&2 Alternator
2096	1.08.0032.1.01.7	CA	339-7767 (65A,12V)	Genset alternator
2097	1.08.0033.1.01.8	CA	338-3454(24V)	ENGINE self starter
2098	1.08.0034.1.01.9	CA	3575202 (12V,3.2KW)	GENSET SELF STARTER
2099	1.08.0035.1.01.1	CA	CAT-1W1456	pully
2100	1.08.0036.1.01.2	CA	CAT-2429537	Seal
2101	1.08.0037.1.01.3	CA	CAT-2761806	Element-fuel
2102	1.08.0038.1.01.4	CA	CAT-0676987	Element-fuel
2103	1.08.0039.1.01.5	CA	CAT-2201523	Filter Oil
2104	1.08.0040.1.01.6	CA	CAT-5516183	Element-Prim
2105	1.08.0041.1.01.7	CA	IML-3E9848	CAT DEO C14 15W40 PAIL20L:IN
2106	1.08.0042.1.01.8	CA	1295429	CORE AS
2107	1.08.0043.1.01.9	CA	1365017	BASE AS
2108	1.08.0044.1.01.1	CA	1375541	PUMP AS
2109	1.08.0045.1.01.2	CA	1614113	PUMP GP-EO 1
2110	1.08.0046.1.01.3	CA	1678130	DAMPER AS
2111	1.08.0047.1.01.4	CA	1977348	TACHOMETER-E
2112	1.08.0048.1.01.5	CA	2336742	VALVE-CHECK
2113	1.08.0049.1.01.6	CA	2345013/2566453	SENSOR GP TEMPERATURE
2114	1.08.0050.1.01.7	CA	2350183	HOSE AS
2115	1.08.0051.1.01.8	CA	2350313	HOSE AIR COM
2116	1.08.0052.1.01.9	CA	2374305	HARNESS AS
2117	1.08.0053.1.01.1	CA	2433820-10/2395025	DRIVING PANEL DISPLAY
2118	1.08.0054.1.01.2	CA	2477133	REGULATOR WATER TEMP
2119	1.08.0055.1.01.3	CA	2661473	ENGINE SPEED SENSOR/SENSOR GP
2120	1.08.0056.1.01.4	CA	2746719/2746718	OIL PRESSURE SENSOR
2121	1.08.0057.1.01.5	CA	3520211	WATER PUMP
2122	1.08.0058.1.01.6	CA	3540049	HARNESS AS

2123	1.08.0059.1.01.7	CA	3584926	TURBO CATRIDGE
2124	1.08.0060.1.01.8	CA	3595392	TURBO GP-BAS
2125	1.08.0061.1.01.9	CA	3848612	PUMP GP-F XF
2126	1.08.0062.1.01.1	CA	4787933	CONT GP-E
2127	1.08.0063.1.01.2	CA	3L1425	BALL BEARING
2128	1.08.0064.1.01.3	CA	4W2683	WATER PRESSURE GAUGE/INDICATOR
2129	1.08.0065.1.01.4	CA	6N0598	PULLEY FAN DRIVE(GROVE)/PULLEY
2130	1.08.0066.1.01.5	CA	6N6490	BRACKET A
2131	1.08.0067.1.01.6	CA	6N7053	VEE BELT SET
2132	1.08.0068.1.01.7	CA	6N7054	VEE BELT
2133	1.08.0069.1.01.8	CA	6N7135	VEE BELT
2134	1.08.0070.1.01.9	CA	7W8132/1182018	VEE BELT
2135	1.08.0071.1.01.1	CA	7C0145	CORE A
2136	1.08.0072.1.01.2	CA	8H9789	BALL BEARING
2137	1.08.0073.1.01.3	CA	1918303	SENSOR
2138	1.08.0074.1.01.4	CA	2746717	SENSOR
2139	1.08.0075.1.01.5	CA	2799830	SENSOR
2140	1.08.0076.1.01.6	CA	3888890	SENSOR
2141	1.08.0077.1.01.7	CA	2399957/4309449	COOLANT LEVEL SENSOR
2142	1.08.0078.1.01.8	CA	1396873	VALVE GP
2143	1.08.0079.1.01.9	CA	1666693	OIL PRESSURE SENSOR
2144	1.08.0080.1.01.1	CA	2201206	HOSE AIR COM
2145	1.08.0081.1.01.2	CA	2284381	TUBE
2146	1.08.0082.1.01.3	CA	2601553	HOSE AS FUEL
2147	1.08.0083.1.01.4	CA	2745013	OIL PRESSURE SENSOR
2148	1.08.0084.1.01.5	CA	2752096	INDICATOR
2149	1.08.0085.1.01.6	CA	2915911	INJECTOR GP FUEL
2150	1.08.0086.1.01.7	CA	3169819	HOSE AS FUEL
2151	1.08.0087.1.01.8	CA	3595393	TURBO CHARGER
2152	1.08.0088.1.01.9	CA	39173990	HOSE HUMP
2153	1.08.0089.1.01.1	CA	4W0506	LUB OIL PRESSURE GAUGE
2154	1.08.0090.1.01.2	CA	4W6841	HOSE AS FUEL
2155	1.08.0091.1.01.3	CA	5S2106	SEAL LIP
2156	1.08.0092.1.01.4	CA	6L4854	HOSE
2157	1.08.0093.1.01.5	CA	7E8630	HOSE AIR INLET
2158	1.08.0094.1.01.6	CA	9N5613	HOSE AS FUEL
2159	1.08.0095.1.01.7	CA	343-5527	WATER SEPERATOR BOWL
2160	1.08.0096.1.01.8	CA	4N-9680	AIR COMPRESSOR GOVERNOR KIT
2161	1.08.0097.1.01.9	CA	3589226/0676987	Engine fuel filter
2162	1.08.0098.1.01.1	CA	2485513	Regulator-TE(C-27)
2163	1.08.0099.1.01.2	CA	2542267	Temperature Regulator for genset
2164	1.08.0100.1.01.3	CA	2256451	Gasket-V Cov(C4.4)
2165	1.08.0101.1.01.4	CA	4415108	Filter GP Fuel(C4.4)
2166	1.08.0102.1.01.5	CA	1454212	Vacuum Indicator(C-27)
2167	1.08.0103.1.01.6	CA	2969800	Radiator
2168	1.08.0104.1.01.7	CA	2071556:AA	Self starter
2169	1.08.0105.1.01.8	CA	5N5692:AA	Alternator 24V 150A
2170	1.08.0106.1.01.9	CA	3595393:AA	Turbocharger RH
2171	1.08.0107.1.01.1	CA	2915911:AA	Injector GP
2172	1.08.0108.1.01.2	CA	7E8630:AA	Hose air inlet
2173	1.08.0109.1.01.3	CA	9X2201:AA	Clamp hose
2174	1.08.0110.1.01.4	CA	4V1878:AA	hose AS
2175	1.08.0111.1.01.5	CA	9N5613:AA	Hose as Fuel
2176	1.08.0112.1.01.6	CA	4W6841:AA	Hose as Fuel
2177	1.08.0113.1.01.7	CA	1940431:AA	Hose as Fuel
2178	1.08.0114.1.01.8	CA	3169819:AA	Hose as Fuel
2179	1.08.0115.1.01.9	CA	2858196:AA	Hose as Fuel
2180	1.08.0116.1.01.1	CA	2601553:AA	Hose as fuel
2181	1.08.0117.1.01.2	CA	2201206:AA	Hose as
2182	1.08.0118.1.01.3	CA	2435606:AA	Hose as
2183	1.08.0119.1.01.4	CA	2022173:AA	Hose as
2184	1.08.0120.1.01.5	CA	8T4988:AA	Clamps
2185	1.08.0121.1.01.6	CA	7L7099:AA	V-Belt Set
2186	1.08.0122.1.01.7	CA	4177614:AA	Hose as
2187	1.08.0123.1.01.8	CA	8T4985:AA	Clamp-Hose
2188	1.08.0124.1.01.9	CA	1440367:AA	Clamp-Hose
2189	1.08.0125.1.01.1	CA	2454630:AA	Sensor Gp - speed
2190	1.08.0126.1.01.2	CA	2482169:AA	Sensor Gp -Pressure
2191	1.08.0127.1.01.3	CA	2766793:AA	Sensor Gp -Pressure
2192	1.08.0128.1.01.4	CA	2968060:AA	Sensor Gp -Pressure
2193	1.08.0129.1.01.5	CA	9X2201	CLAMP HOSE
2194	1.08.0130.1.01.6	CA	2233505	AIR COMPRESSOR HOSE
2195	1.08.0131.1.01.7	CA	CAT-6I2508	AIR FILTER PRIMARY
2196	1.08.0132.1.01.8	CA	AVX131200LA Sub:CAT-3748470	ALTERNATOR V-BELT
2197	1.08.0133.1.01.9	CA	CAT-4381597	V-BELT
2198	1.08.0134.1.01.1	CA	CAT-4238524	OIL WATER SEPARATOR

2199	1.08.0135.1.01.2	CA	105-5080(C18)	Self-starter
2200	1.08.0136.1.01.3	CA	435-1240	Self-starter
2201	1.08.0137.1.01.4	CA	81769643	Alternator(C-9)
2202	1.08.0138.1.01.5	CA	81769643	Alternator(C-18)
2203	1.08.0139.1.01.6	CA	81852021	Alternator(Power Pack)
2204	1.08.0140.1.01.7	CA	2925863/572-5184	AIR ELEMENT OUTER
2205	1.08.0141.1.01.8	CA	4238524	Oil water seperator
2206	1.08.0142.1.01.9	CA	6I-2509	Cartridge of Air Filter
2207	1.09.0001.1.01.4	AS	F0W02200	AIR CLEANER ELEMENT(Element primary)
2208	1.09.0002.1.01.5	AS	F0W02300	AIR CLEANER ELEMENT (Element safety)
2209	1.09.0003.1.01.6	AS	Gulf Ley power cool 40	Coolant
2210	1.09.0004.1.01.7	AS	X8820800	MAIN FUEL FILTER CRS
2211	1.09.0005.1.01.8	AS	X8800700	WATER FILTER N4
2212	1.09.0006.1.01.9	AS	F7A04800	SPIN ON OIL FILTER N6
2213	1.09.0007.1.01.1	AS	F7B02900	SPIN ON PRE FUEL FILTER
2214	1.09.0008.1.01.2	AS	X7487500	ENGINE SPEED SENSOR
2215	1.09.0009.1.01.3	AS	X7472800	WATER TEMPERATURE SENSOR
2216	1.09.0010.1.01.4	AS	X8820700	TURBO CHARGER
2217	1.09.0011.1.01.5	AS	F7A04700	PRE FUEL FILTER ASSY
2218	1.09.0012.1.01.6	AS	11292055	INJECTOR PIPE
2219	1.09.0013.1.01.7	AS	X3409522	CYLINDER LINER N4&N6
2220	1.09.0014.1.01.8	AS	HAEPR38/1	ASSEMBLY OF PISTON AND RINGS
2221	1.09.0015.1.01.9	AS	B9803503	CONNECTING ROD SUB ASSY
2222	1.09.0016.1.01.1	AS	X0200140	BEARING, CONROD UPPER SHELL
2223	1.09.0017.1.01.2	AS	X2708200	TIMING OIL SEAL H N4/N6
2224	1.09.0018.1.01.3	AS	P5104225	MAIN BEARING SET - STD
2225	1.09.0019.1.01.4	AS	X3401010	SLEEVE INJECTOR
2226	1.09.0020.1.01.5	AS	B4P00109	ROCKER SHAFT 1 EBS ASSY (SL.NOs.11,12,14,15,16,17,18,36,37,39,40,41,42,43)
2227	1.09.0021.1.01.6	AS	B4P00106	ROCKER ARM EXHAUST ASSEMBLY EBS (SL.NOs.11,12,14,15,16,17,18,36,37,39,40,41,42,43)
2228	1.09.0022.1.01.7	AS	B6C00501	S/A OF INJECTOR - 630HTF BASELINE (SL.NOs.2,3,4,5) (12)
2229	1.09.0023.1.01.8	AS	XB500100	NOZZLE 630HTF - BASELINE INJECTOR 1NSS
2230	1.09.0024.1.01.9	AS	X0801511	CLAMP - INJECTOR
2231	1.09.0025.1.01.1	AS	B9800901	OIL PUMP SUB ASSY
2232	1.09.0026.1.01.2	AS	B9800604	COMMON RAIL PUMP ASSY
2233	1.09.0027.1.01.3	AS	X3M04800	R WITH WASTE GATE
2234	1.09.0028.1.01.4	AS	X2009600	BOOST PRESSURE SENSOR
2235	1.09.0029.1.01.5	AS	X0675700	INTERNAL WIRING HARNESS
2236	1.09.0030.1.01.6	AS	X0300100	BELT TENSIONER
2237	1.09.0031.1.01.7	AS	F0Y00311	GEAR AIR COMPRESSOR Z=32
2238	1.09.0032.1.01.8	AS	10011475	WIRING HARNESS_9m_ N6_CRS ENG UTV UTS
2239	1.09.0033.1.01.9	AS	10008217	ECU INTERFACE ENG.SAFETYUNIT IP67
2240	1.09.0034.1.01.1	AS	10004232	EXHAUST BELLOW N6 ENG
2241	1.09.0035.1.01.2	AS	F7474000	AIR COMPRESSOR
2242	1.09.0036.1.01.3	AS	B9801102	WATER PUMP
2243	1.09.0037.1.01.4	AS	F7V033900	PT PUMP
2244	1.09.0038.1.01.5			
2245	1.09.0039.1.01.6			
2246	1.09.0040.1.01.7			
2247	2.01.0001.1.01.6	KA	310.3.112.03.06. T1	HYDRAULIC PUMP
2248	2.01.0002.1.01.7	KA	310.3.112.04.06. T1	HYDRAULIC PUMP
2249	2.01.0003.1.01.8	KA	310.3.160.03.06 T1	HYDRAULIC PUMP
2250	2.01.0004.1.01.9	KA	310.3.160.04.06 T1	HYDRAULIC PUMP
2251	2.01.0005.1.01.1	KA	310.3.56.03.06 T1	HYDRAULIC PUMP
2252	2.01.0006.1.01.2	KA	310.4.112.03.06	HYDRAULIC PUMP
2253	2.01.0007.1.01.3	KA	310.4.112.04.06	HYDRAULIC PUMP
2254	2.01.0008.1.01.4	KA	310.4.160.03.06	HYDRAULIC PUMP
2255	2.01.0009.1.01.5	KA	310.4.160.04.06	HYDRAULIC PUMP
2256	2.01.0010.1.01.6	KA	310.4.56.03.06 T1	HYDRAULIC PUMP
2257	2.01.0011.1.01.7	KA	6.04.02.620	HYDRAULIC PUMP FOR TRANSMISSION GB
2258	2.01.0012.1.01.8	PL	M6PV82.820142AL3V	HYDRAULIC PUMP
2259	2.01.0013.1.01.9	PL	62.05.4000.325	HYDRAULIC PUMP
2260	2.01.0014.1.01.1	PL	64.04.3000.86	HYDRAULIC PUMP
2261	2.01.0015.1.01.2	PL	229055	HYD.PROPEL DOUBLE PUMP FOR BRM
2262	2.01.0016.1.01.3	KE	733626	EMERGEINCY PUMP

2263	2.01.0017.1.01.4	HA	D-434622	HYD PUMP FOR TRT
2264	2.01.0018.1.01.5		Shifted to Ann II	
2265	2.01.0019.1.01.6	LO	106504	PUMP HYDR PC C4 FLNG/14T SPLN/4.5 IN3
2266	2.01.0020.1.01.7	LO	B68693	PUMP VAN VARIABLE VOL
2267	2.01.0021.1.01.8	PH	4P22	EMERGENCY HYDRAULIC PUMP ASSEMBLY
2268	2.01.0022.1.01.9	PL	62.05.2000.144	PUMP
2269	2.01.0023.1.01.1	PL	HY 709 X 71L/DFR + 28L/DFR	PUMP
2270	2.01.0024.1.01.2		Repeated item	
2271	2.01.0025.1.01.3	CR	H1-P-210-L-A-A-A5-C1-N-D8-C-G2-H5-L-35-L-35-W-P-24- PN-NNN-NNN	HYDRAULIC VARIABLE PISTON PUMP
2272	2.01.0026.1.01.4	CR	H1-P-130-L-B-A-A5-C1-N-D8-G-G2-H6-L-25-L-25-L-P-24- PN-NNN-NNN	HYDRAULIC PUMP-1
2273	2.01.0027.1.01.5	CR	ER-L-130B-LS-25-20-NN-N- 3-S1NP-A1N-AAA-NNN-NNN	HYDRAULIC PUMP-2
2274	2.01.0028.1.01.6	CR	D1P-130-L-A-NPSN-S-D4-N1-C5-NNN-320-20-NN-FS- FS-NNN-NNN	HYDRAULIC PUMP-4
2275	2.01.0029.1.01.7	CR	PRR 048-/044-L-N-07-SS-P1-A4-A3-NN-A4-A3-NN-D- N-/NNN-N-N	DOUBLE GEAR PUMP-1
2276	2.01.0030.1.01.8	CR	PRR 048-/026-L-N-07-SS-P1-A4-A3-NN-A4-A3-NN-D- N-/NNN-N-N	DOUBLE GEAR PUMP-2
2277	2.01.0031.1.01.9	CR	DE2R-25SH-BB-104-25- N104-NNN-000-AX-AN-NNN	GEAR PUMP
2278	2.01.0032.1.01.1	CR	DB9513-20A-00	EMERGENCY BACKUP SYSYTEM HYDRAULIC PUMP
2279	2.01.0033.1.01.2	GE	T6DCC-B14-B12-B12-3L02- A100	Triple vane pumps-1
2280	2.01.0034.1.01.3	GE	T67DCC-050-012-008-3R03-B1-M1	Triple vane pumps-2
2281	2.01.0035.1.01.4	GE	T6DCC-B20-B12-B12-3L02-A100	Triple vane pumps-3
2282	2.01.0036.1.01.5	PL	VT11118-1X	AMPLIFIER DRIVE PUMP
2283	2.01.0037.1.01.6		Shifted to Ann II	
2284	2.01.0038.1.01.7		Shifted to Ann II	
2285	2.01.0039.1.01.8		Shifted to Ann II	
2286	2.01.0040.1.01.9		Shifted to Ann II	
2287	2.01.0041.1.01.1		Shifted to Ann II	
2288	2.01.0042.1.01.2		Shifted to Ann II	
2289	2.01.0043.1.01.3		Shifted to Ann II	
2290	2.01.0044.1.01.4		Shifted to Ann II	
2291	2.01.0045.1.01.5		Shifted to Ann II	
2292	2.01.0046.1.01.6		Shifted to Ann II	
2293	2.01.0047.1.01.7	PL	HY712x60L/HD1/D350+60L/HD1/D	DOUBLE VARIABLE DISPLACEMENT PUMP
2294	2.01.0048.1.01.8	PL	HY716x95R/HD1D-315/60	DUAL PUMP
2295	2.01.0049.1.01.9	PL	HY720x280L/EP4/38A+22L	VARIABLE DISPLACEMENT PUMP
2296	2.01.0050.1.01.1		Shifted to Ann II	
2297	2.01.0051.1.01.2		Shifted to Ann II	
2298	2.01.0052.1.01.3	PL	HY712x130L/DRS	VARIABLE DISPLACEMENT PUMP
2299	2.01.0053.1.01.4	PL	HY709x100L/DFR1	VARIABLE DISPLACEMENT PUMP
2300	2.01.0054.1.01.5	PL	SU1401.414.1.102.1	HYDRAULIC EMERGENCY PUMP REAR
2301	2.01.0055.1.01.6	PL	18049	HYDRAULIC EMERGENCY PUMP FRONT(380V M302G, 7L/MIN, 1500U/ MIN,4KW)
2302	2.01.0056.1.01.7	PL	HY721X165LE8/38A-SAEB	HYD PUMP
2303	2.01.0057.1.01.8	KE	729346	DOBLE PUMP DRIVE
2304	2.01.0058.1.01.9	LO	160241	MOTOR PUMP ASSEMBLY 30HP 74CC PUMP 71CC PUMP
2305	2.01.0059.1.01.1	LO	247922	PUMP GEAR TANDEM .87+.87; B2 13T CCW SAE ORB PORTS
2306	2.01.0060.1.01.2	LO	248126	PUMP HYD GEAR FIX 3.94CIR; B2 13T CCW SAE 61 PORTS
2307	2.01.0061.1.01.3	LO	247633	PUMP DRIVE 3 PAD W/RTD; 2XSAE D4/1XSAE B2/1.596RT
2308	2.01.0062.1.01.4	LO	156949	PUMP WATER 400GPM 96PSI NEEDS 30HP MOTOR
2309	2.01.0063.1.01.5	CR	40089350	Electric emergency pump
2310	2.01.0064.1.01.6	CR	40101322	Hydraulic Tripple pump
2311	2.01.0065.1.01.7	CR	5005833	PUMP HIGH PRESSURE/OT PICKUP (PUMP)
2312	2.01.0066.1.01.8	CR	C5912Y01	LOW PRESSURE CIRCUIT (PUMP)
2313	2.01.0067.1.01.9	CR	D4346Y22	DRIVING (2pad)
2314	2.01.0068.1.01.1	CR	5131774	PUMP
2315	2.01.0069.1.01.2	CR	5131780	VEN PUMP
2316	2.01.0070.1.01.3	PL	WN80.2600F/1.040	PUMP GEAR
2317	2.01.0071.1.01.4	PL	HY718X180R/EP4/35A	VARIABLE DISPLACEMENT PUMP
2318	2.01.0072.1.01.5	PL	HY936 N5.5	EMERGENCY PUMP
2319	2.01.0073.1.01.6	PL	HY704X180L/EP4/A380BAR+SAEB	PUMP

2320	2.01.0074.1.01.7	HA	200-FZ-002250	Hyd PUMP for FASSI Crane
2321	2.02.0001.1.01.7	PL	62.05.4000.24	HYDRAULIC MOTOR FOR BCM
2322	2.02.0002.1.01.8	PL	HY935.N10-P	MOTOR
2323	2.02.0003.1.01.9	PL	SU 126-5011-1-1/A	MOTOR
2324	2.02.0004.1.01.1	KA	210.12.01.03 T1	MOTOR
2325	2.02.0005.1.01.2	KA	310.2.28.01.03	MOTOR
2326	2.02.0006.1.01.3	KA	410.0.107W A4F10/A2FM107/61WXAB010J-S	MOTOR
2327	2.02.0007.1.01.4		Shifted to Ann II	
2328	2.02.0008.1.01.5	PL	HY935.N10	MOTOR
2329	2.02.0009.1.01.6	PL	62.05.1000.339	MOTOR
2330	2.02.0010.1.01.7	PL	62.05.4000.34	HYD MOTOR
2331	2.02.0011.1.01.8	KA	HYS909X160HA1T/50/280BAR	DRIVE MOTOR
2332	2.02.0012.1.01.9	GE	A0350003	Emergency oil pump ass.
2333	2.02.0013.1.01.1	GE	BS550(IND)-22-10-11-00	HYDRAULIC MOTOR ASSEMBLY- DRIVING
2334	2.02.0014.1.01.2	GE	BS550(IND)-22-11-15-00	HYDRAULIC MOTOR ASSEMBLY - WORKING
2335	2.02.0015.1.01.3	CR	H1-B-210-A-A-TA-DAN-A-TB- DN-LN-N-A-30-NN-080-Z-29- NNN	HYDRAULIC MOTOR-2
2336	2.02.0016.1.01.4	CR	CA50	HYDRAULIC MOTOR
2337	2.02.0017.1.01.5	CR	11160334(TMT315EMD)	HYDRAULIC MOTOR-4
2338	2.02.0018.1.01.6	CR	151Z3264(TMT315)	HYDRAULIC MOTOR-5
2339	2.02.0019.1.01.7	CR	TMT470EMD	HYDRAULIC MOTOR-6
2340	2.02.0020.1.01.8	CR	11119830(TMT250EMD)	HYDRAULIC MOTOR-7
2341	2.02.0021.1.01.9	CR	MSE082 115 F09 2A50 BE	HYDRAULIC MOTOR-8
2342	2.02.0022.1.01.1	CR	A2FM63/61W-VAB027H	HYDRAULIC MOTOR-9
2343	2.02.0023.1.01.2	CR	TMT400EMD	HYDRAULIC MOTOR-10
2344	2.02.0024.1.01.3	CR	M5AS 016 ZN24 A1Y 00000 42	HYDRAULIC MOTOR-11
2345	2.02.0025.1.01.4	CR	MOTO4A01B0000AOA	HYDRAULIC MOTOR-12
2346	2.02.0026.1.01.5	CR	1303111	HYDRAULIC MOTOR-13
2347	2.02.0027.1.01.6	CR	BS550(IND)-22-14-13-00	HYDRAULIC MOTOR ASSEMBLY
2348	2.02.0028.1.01.7	CR	BS550(IND)-22-13-10-00	HYDRAULIC MOTOR ASSEMBLY
2349	2.02.0029.1.01.8	CR	BS550(IND)-22-15-11-00	HYDRAULIC MOTOR ASSEMBLY
2350	2.02.0030.1.01.9	CR	40103552	VARIABLE PLUNGER MOTOR
2351	2.02.0031.1.01.1		Shifted to Ann II	
2352	2.02.0032.1.01.2		Shifted to Ann II	
2353	2.02.0033.1.01.3		Shifted to Ann II	
2354	2.02.0034.1.01.4		Shifted to Ann II	
2355	2.02.0035.1.01.5		Shifted to Ann II	
2356	2.02.0036.1.01.6	PL	HY701X12LI	HYD MOTOR
2357	2.02.0037.1.01.7	PL	HY701X12RE	HYD MOTOR
2358	2.02.0038.1.01.8	PL	HY949x170HA1TU-60/230	VARIABLE DISPLACEMENT MOTOR
2359	2.02.0039.1.01.9	PL	HY938x55/MS/FS	HYDRAULIC MOTOR (DTS Motor)
2360	2.02.0040.1.01.1	PL	HY910x32/VBB040	HYDRAULIC MOTOR
2361	2.02.0041.1.01.2	PL	HY952x160E2AA/107/30L	VARIABLE DISPLACEMENT MOTOR (Cutter chain)
2362	2.02.0042.1.01.3	PL	HYS909x107HA1TF/QMAX98CM3	VARIABLE DISPLACEMENT MOTOR (Screen motor)
2363	2.02.0043.1.01.4	PL	HY940x490	HYDRAULIC MOTOR
2364	2.02.0044.1.01.5	PL	HY940x390	HYDRAULIC MOTOR
2365	2.02.0045.1.01.6		Shifted to Ann II	
2366	2.02.0046.1.01.7	PL	HY910x90/61W-VAB010	PISTON MOTOR
2367	2.02.0047.1.01.8	PL	HYS909x55HA1T/40/200BAR	VARIABLE DISPLACEMENT MOTOR
2368	2.02.0048.1.01.9	PL	HY925N32	Hydraulic motor (Chord tensioning)
2369	2.02.0049.1.01.1	PL	HY.701.N08.L	Hydraulic Motor
2370	2.02.0050.1.01.2		Shifted to Ann II	
2371	2.02.0051.1.01.3	PL	HY944N50	MOTOR
2372	2.02.0052.1.01.4	LO	152547	MOTOR HYD GEAR FX 1.37CIR; A2 KEY BI 12FORB
2373	2.02.0053.1.01.5	LO	247647	MOTOR HYD HST VAR 250CC; 15T PROP CNTRL
2374	2.02.0054.1.01.6	PL	62. 05.4000.422	MOTOR
2375	2.02.0055.1.01.7	PL	HY938X55/MS	HYD MOTOR
2376	2.02.0056.1.01.8	PL	HY943X107HAIT-40/280BAR/10L	HYD MOTOR
2377	2.02.0057.1.01.9	CR	0-3321014-0-05	TRACTION MOTOR
2378	2.02.0058.1.01.1	CR	0-3324001-0-01	OT2 , OT1,NT1,NT2&NT3 CONVEYOR (MOTOR)
2379	2.02.0059.1.01.2	CR	OEPLGM1	DRIVING MOTOR (Gantry)
2380	2.02.0060.1.01.3	CR	5138480	MOTOR
2381	2.02.0061.1.01.4	LO	247352	PUMP HYD PIST VAR 10.07CIR; D4 13T CCW AUX B2 13T
2382	2.02.0062.1.01.5	PL	HY943X250HA1T-10/280	HYDRAULIC MOTOR
2383	2.02.0063.1.01.6	PL	HY953N185-A	HYDRAULIC MOTOR
2384	2.02.0064.1.01.7	PL	HY925X12.5 (151G004) sub HY925 N12.5D	HYDRAULIC MOTOR
2385	2.02.0065.1.01.8	LO	112800	MOTOR VERTICAL SHAFT 2.25 DIA X 26.94

2386	2.02.0066.1.01.9	LO	156949-SP	PUMP WATER 400GPM 96PSI (NO MOTOR)
2387	2.02.0067.1.01.1	PL	HY90.N43	Hydraulic Motor (for hydraulic oil cooler)
2388	2.02.0068.1.01.2	PL	HY72SX35 L	Vibration motor for Tamping unit
2389	2.03.0001.1.01.8	PL	HY940X200-SO SUBSTITUTE HY940X200	MOTOR
2390	2.03.0002.1.01.9			
2391	2.03.0003.1.01.1	PL	62.05.1000.350	STOP VALVE
2392	2.03.0004.1.01.2			Shifted to Ann II
2393	2.03.0005.1.01.3			Shifted to Ann II
2394	2.03.0006.1.01.4			Shifted to Ann II
2395	2.03.0007.1.01.5			Shifted to Ann II
2396	2.03.0008.1.01.6	PL	62.05.3000.378	HYDRAULIC VALVE
2397	2.03.0009.1.01.7			Repeated item
2398	2.03.0010.1.01.8	PL	62.05.3000.516	HYD.CONTROL VALVE
2399	2.03.0011.1.01.9	PL	62.05.3000.575	CONTROL VALVE
2400	2.03.0012.1.01.1			Shifted to Ann II
2401	2.03.0013.1.01.2			Shifted to Ann II
2402	2.03.0014.1.01.3			Shifted to Ann II
2403	2.03.0015.1.01.4	PL	62.05.3000.713	HYDRAULIC VALVE
2404	2.03.0016.1.01.5	PL	62.05.4000.266	PRESSURE VALVE
2405	2.03.0017.1.01.6			
2406	2.03.0018.1.01.7	PL	62.05.4000.385	HYDRAULIC VALVE
2407	2.03.0019.1.01.8	PL	62.05.4000.386	CONTROL VALVE
2408	2.03.0020.1.01.9	PL	62-05-2000-138	CONTROL VALVE
2409	2.03.0021.1.01.1	PL	62.05.2000.109	VALVE
2410	2.03.0022.1.01.2	PL	79965/2105	SAFETY VALVE
2411	2.03.0023.1.01.3	PL	79965/2120	SAFETY VALVE
2412	2.03.0024.1.01.4	PL	HY.151.204	VALVE BLOCK WITH PROPORTIONAL VALVE FEEDER FOR 09-3X
2413	2.03.0025.1.01.5			Repeated item
2414	2.03.0026.1.01.6	PL	HY.511.38.160 BAR	PRESSURE RELIEF VALVE / SATELLITE BY PASS VALVE
2415	2.03.0027.1.01.7	PL	HY-06-RSM	DC VALVE FOR LOGIC VALVE
2416	2.03.0028.1.01.8	PL	HY151.13/3	CHECK VALVE
2417	2.03.0029.1.01.9	PL	HY151.13/5	CHECK VALVE
2418	2.03.0030.1.01.1	PL	HY151.187/75 BAR	PROP. CONTROL VALVE
2419	2.03.0031.1.01.2	PL	HY151.188/5	RADIATOR SAFETY VALVE
2420	2.03.0032.1.01.3	PL	62.05.3000.235	THREE-WAY COCK
2421	2.03.0033.1.01.4			Shifted to Annexure II
2422	2.03.0034.1.01.5	PL	HY151.190	SAFETY VALVE
2423	2.03.0035.1.01.6	PL	HY151.215	SAFETY VALVE
2424	2.03.0036.1.01.7	PL	HY151.217/5BAR	CHECK VALVE
2425	2.03.0037.1.01.8	PL	HY151.33/0,5BAR06	CHECK VALVE
2426	2.03.0038.1.01.9	PL	HY151.33/0,5BAR12	CHECK VALVE
2427	2.03.0039.1.01.1	PL	HY151.33/5BAR16	CHECK VALVE
2428	2.03.0040.1.01.2	PL	HY151.33/5BAR24	CHECK VALVE
2429	2.03.0041.1.01.3	PL	HY-151-172A WITH HY-511-38/160 BAR	SATELLITE BYPASS VALVE
2430	2.03.0042.1.01.4	PL	HY155.11	LOCKING BLOCK
2431	2.03.0043.1.01.5	PL	HY157.103 SUB. HY157.80	CURRENT REGULATION VALVE
2432	2.03.0044.1.01.6	PL	HY157.106/270	FLOW CONTROL VALVE
2433	2.03.0045.1.01.7	PL	HY-157-27-160 BAR	HYD SAFTY VLAVE
2434	2.03.0046.1.01.8			Shifted to Annexure II
2435	2.03.0047.1.01.9	PL	HY511.50/350 SUB. HY511.50/315	SAFETY VALVE
2436	2.03.0048.1.01.1			Shifted to Annexure II
2437	2.03.0049.1.01.2	PL	HY511.52/60LT SUB. 62.05.3000.568	VALVE BLOCK
2438	2.03.0050.1.01.3	PL	HY6RSU-SRP	HYDRALIC VALVE
2439	2.03.0051.1.01.4	PL	HYA10-RPE50.D	PROP. CONTROL VALVE
2440	2.03.0052.1.01.5			Shifted to Annexure II
2441	2.03.0053.1.01.6	PL	HY-M10RMEEJ	CONTROL VALVE BLOCK
2442	2.03.0054.1.01.7	PL	HY-M10RMJ	CONTROL VALVE BLOCK
2443	2.03.0055.1.01.8	PL	HY-M10RMJJ	CONTROL VALVE BLOCK
2444	2.03.0056.1.01.9	PL	HYN.25-RPE2-325.TDSO151	PROPORTIONAL VALVE
2445	2.03.0057.1.01.1			Shifted to Annexure II
2446	2.03.0058.1.01.2	PL	I79965/2080 SUB. I79965/1080	SAFETY VALVE
2447	2.03.0059.1.01.3	PL	167507	VENTED RELIEF VALVE
2448	2.03.0060.1.01.4	KE	187898	VALVE BANK SOL TYPE BRM
2449	2.03.0061.1.01.5	KE	729345	CONTROL VALVE BANK FOR BRM
2450	2.03.0062.1.01.6	KE	732159	VALVE BRM
2451	2.03.0063.1.01.7	KE	733668	VALVE LOCK FOR BRM
2452	2.03.0064.1.01.8	KE	735893	VALVE BANK MANUAL 5 SELECTION
2453	2.03.0065.1.01.9	KE	4107030	ELECTRO VALVE (24V)
2454	2.03.0066.1.01.1			Shifted to Ann II
2455	2.03.0067.1.01.2			Shifted to Ann II
2456	2.03.0068.1.01.3			Shifted to Ann II

2457	2.03.0069.1.01.4			Shifted to Ann II
2458	2.03.0070.1.01.5			Shifted to Ann II
2459	2.03.0071.1.01.6			Shifted to Ann II
2460	2.03.0072.1.01.7			Shifted to Ann II
2461	2.03.0073.1.01.8			Shifted to Ann II
2462	2.03.0074.1.01.9			Shifted to Ann II
2463	2.03.0075.1.01.1			Shifted to Ann II
2464	2.03.0076.1.01.2			Shifted to Ann II
2465	2.03.0077.1.01.3	AM	00L06G001	T.C VALVE T 28
2466	2.03.0078.1.01.4	AM	00LO554001	TV VALVE T-28
2467	2.03.0079.1.01.5			Shifted to Ann II
2468	2.03.0080.1.01.6			Shifted to Ann II
2469	2.03.0081.1.01.7	PH	4P11	PILOT OPERATED CHECK VALVE
2470	2.03.0082.1.01.8	PH	4P15	3/4" CHECK VALVE
2471	2.03.0083.1.01.9	PH	4P17	1/2" CHECK VALVE
2472	2.03.0084.1.01.1	PH	4P31	SHUT OFF VALVE
2473	2.03.0085.1.01.2	PH	4P41	VALVE BRAKE (4 SIGMENT)
2474	2.03.0086.1.01.3	PH	5P11	SECONDARY RELIEF VALVE
2475	2.03.0087.1.01.4	PH	8P18	OVER CENTRE VALVE
2476	2.03.0088.1.01.5	PH	0017159 C	RAIL WHEEL/CRAWLER DRIVE SELECTING (COMMANDO CYL.)
2477	2.03.0089.1.01.6	PH	6100046	SELECTOR VDM 07D-V-1-G (EMERGENCY WORKING)
2478	2.03.0090.1.01.7	PH	101011	VALVE CHK 5000PSI 160GPM; HYD 3PSI CRACK 32 SLIPIN
2479	2.03.0091.1.01.8	LO	100563	VALVE DRIVER CARD
2480	2.03.0092.1.01.9	LO	101481	NOZZLE-125GPM 1-1/2 NH MOUNT
2481	2.03.0093.1.01.1	LO	107697	SOLENOID VALVE .38 24VDC
2482	2.03.0094.1.01.2	LO	118547	VALVE ASSY DIRECTION CTRL SIZE 10 5000PSI 20GPM
2483	2.03.0095.1.01.3			Shifted to Ann II
2484	2.03.0096.1.01.4	LO	165583	VALVE CHK 5000P 15GPM HYD D03 PILOT A B FROM P
2485	2.03.0097.1.01.5	LO	166225	SUBPLATE VALVE DO5 OFFSET; 1.50 THK 1.25 OFFSET
2486	2.03.0098.1.01.6	LO	3 RD	PRESSURE REGULATOR
2487	2.03.0099.1.01.7	KA	D-633 R16KA-MONSM2	SERVO VALVE
2488	2.03.0100.1.01.8	KA	K/V 4/3 5KO.6.G.6	HYD CONTROL VALVE
2489	2.03.0101.1.01.9	KA	KV 4/2 5KO-10-G6/KV4/3-5KO-10G6	HYD.CONTROL VALVE
2490	2.03.0102.1.01.1	KA	KV4/2.5KO.6.G.51A	HYD.CONTROL VALVE
2491	2.03.0103.1.01.2	KA	KV4/3 5KO 10 G2	HYD. CONTROL VALVE
2492	2.03.0104.1.01.3	KA	MPKV 10/3MP 204	REDUCING VALVE
2493	2.03.0105.1.01.4	KA	MPKV 16/3 F3R22404	SAFETY VALVE
2494	2.03.0106.1.01.5	KA	MPKV 25/3 FIV204/MKPV25/3FIV2	SAFETY VALVE
2495	2.03.0107.1.01.6	PL	HY152.03	STOPCOCK
2496	2.03.0108.1.01.7	PL	II50172/2A1L+A66269 SUBSTITUTE I26684	STOP COCK
2497	2.03.0109.1.01.8			Shifted to Ann II
2498	2.03.0110.1.01.9			Shifted to Ann II
2499	2.03.0111.1.01.1			Repeated item
2500	2.03.0112.1.01.2			Shifted to Ann II
2501	2.03.0113.1.01.3			Repeated item
2502	2.03.0114.1.01.4	PL	HY.511.39.A	pressure reducing valve
2503	2.03.0115.1.01.5			Repeated item
2504	2.03.0116.1.01.6	PL	62.05.3000.379-STKL SUBSTITUTE 62.05.3000.379	CONTROL VALVE
2505	2.03.0117.1.01.7	KA	DPZO-A37-LD/DE18	Proportional Valve
2506	2.03.0118.1.01.8	GE	CDC16A-23-09-01-00	Servo valve bank
2507	2.03.0119.1.01.9	GE	496A0600DWG/08	Valve bank
2508	2.03.0120.1.01.1	GE	WXB-T-20A	Single-way valve
2509	2.03.0121.1.01.2	GE	WZT-DN20-3/4-087	Safety valve
2510	2.03.0122.1.01.3	GE	SC3/4	Shutter valve
2511	2.03.0123.1.01.4	GE	EQT4-62-07-500-1	Reversing valve
2512	2.03.0124.1.01.5	GE	PA12679-02-33	Two-posi. five-way solenoid valve
2513	2.03.0125.1.01.6	GE	PA12706-02-33	Three-posi. five-way solenoid valve (intermediate unloading)
2514	2.03.0126.1.01.7	GE	PA12705-02-33	Three-posi. five-way solenoid valve
2515	2.03.0127.1.01.8	GE	RFU 444-1/4	Flow control valve
2516	2.03.0128.1.01.9	CR	SV13-10-0-0-00	Solenoid Operated Di- rectional Manifold
2517	2.03.0129.1.01.1	CR	DG4V-3-2C-M-U-H7-60	Solenoid Operated Di- rectional Manifold-1
2518	2.03.0130.1.01.2	CR	DG4V-3-6C-M-U-H5-60	Solenoid Operated Di- rectional Manifold-2

2519	2.03.0131.1.01.3	CR	SV3-10-0-0-00	Solenoid Operated Di- Rectional Manifold-6
2520	2.03.0132.1.01.4	CR	SVJO.S08.03.00	Solenoid Operated Di- Rectional Manifold-8
2521	2.03.0133.1.01.5	CR	1800575	Solenoid Operated Di- Rectional Manifold-9
2522	2.03.0134.1.01.6	CR	HIC00419	Solenoid Operated Di- Rectional Manifold-10
2523	2.03.0135.1.01.7	CR	1800573	Solenoid Operated Di- Rectional Manifold-11
2524	2.03.0136.1.01.8	CR	1800572	Solenoid Operated Di- Rectional Manifold-12
2525	2.03.0137.1.01.9	CR	1800580	Solenoid Operated Di- Rectional Manifold-13
2526	2.03.0138.1.01.1	CR	1800574	Solenoid Operated Di- Rectional Manifold-14
2527	2.03.0139.1.01.2	CR	PKS9581RF-1/4-4633	Two-position and five- port solenoid valve-1
2528	2.03.0140.1.01.3	CR	PKS9581RF-1/2-4633	Two-position and five- port solenoid valve-9
2529	2.03.0141.1.01.4	CR	PKS9581RFE-1/4-24 VDC	Three-position and five- port valve-1
2530	2.03.0142.1.01.5	CR	40101858	THREE WAY VALVE OF WIPER
2531	2.03.0143.1.01.6		Shifted to Ann II	
2532	2.03.0144.1.01.7	PL	HY153.02	Four Way Valve
2533	2.03.0145.1.01.8		Shifted to Ann II	
2534	2.03.0146.1.01.9		Shifted to Ann II	
2535	2.03.0147.1.01.1		Shifted to Ann II	
2536	2.03.0148.1.01.2		Shifted to Ann II	
2537	2.03.0149.1.01.3		Shifted to Ann II	
2538	2.03.0150.1.01.4		Shifted to Ann II	
2539	2.03.0151.1.01.5		Shifted to Ann II	
2540	2.03.0152.1.01.6		Shifted to Ann II	
2541	2.03.0153.1.01.7		Shifted to Ann II	
2542	2.03.0154.1.01.8		Shifted to Ann II	
2543	2.03.0155.1.01.9	PL	PVG32/159U8169(4FACH)	PROP. CONTROL VALVE
2544	2.03.0156.1.01.1	PL	PVG32/159U8167(3FACH)	PROP. CONTROL VALVE
2545	2.03.0157.1.01.2	PL	PVG32/159U8168(3FACH)	PROP. CONTROL VALVE
2546	2.03.0158.1.01.3	PL	DV16-1.1/5-P-S	VALVE
2547	2.03.0159.1.01.4	PL	HY151.03/1,5KPL.	CHECK VALVE
2548	2.03.0160.1.01.5	PL	HY151.34	CHECK VALVE
2549	2.03.0161.1.01.6	PL	HY155.10-A	CHECK VALVE
2550	2.03.0162.1.01.7	PL	HY100.07	CHECK THROTTLE
2551	2.03.0163.1.01.8	PL	HY157.96	CURRENT REGULATION VALVE
2552	2.03.0164.1.01.9	PL	HY157.109	CURRENT REGULATION VALVE
2553	2.03.0165.1.01.1.	PL	HY152.04	STOPCOCK
2554	2.03.0166.1.01.2	PL	HY151.177-00/SAE	Changeover valve
2555	2.03.0167.1.01.3	SI	237-6500POS-06	THROTTLE CUM CHECK VALVE
2556	2.03.0168.1.01.4	SI	237-6500POS-13	BRIDGE LIFTING DIRECTION CONTROL VALVE
2557	2.03.0169.1.01.5	SI	237-6500POS-14	LETTERAL MOVEMENT DIRECTION CONTROL VALVE
2558	2.03.0170.1.01.6	LO	103776	VALVE BALL 3000PSI 57 GPM HYD 2061 2061C HANDLE
2559	2.03.0171.1.01.7	LO	111701	VALVE CHECK 0.38 NPT
2560	2.03.0172.1.01.8	LO	125910	VALVE SOL 1.50 NPT N CLSD 24 VDC
2561	2.03.0173.1.01.9	PL	HY151.172A	HYD VALVE (SATELLITE BYPASS VALVE)
2562	2.03.0174.1.01.1	PL	HY151.103A	HYD Servo Block without Valve
2563	2.03.0175.1.01.2	PL	HY157.48-A OR Sub Part no. HY157.17	RADIATOR
2564	2.03.0176.1.01.3	LO	B78865	Valve C3W Distribution
2565	2.03.0177.1.01.4	LO	A65990	Valve Ball 2.50 NPT Bronze 600#WOG
2566	2.03.0178.1.01.5	Colmar	H5535300	HYD SERVO CONTROL
2567	2.03.0179.1.01.6	KE	142862	CONTROL THROTTLE
2568	2.03.0180.1.01.7	KE	148607	MOTION CONTROL VALVE
2569	2.03.0181.1.01.8	KE	228104	VALVE BANK MANUAL
2570	2.03.0182.1.01.9	KE	228105	VALVE BANK MANUAL
2571	2.03.0183.1.01.1	KE	230153	MAXIMUM TORQUE VALVE
2572	2.03.0184.1.01.2	LO	236366	DIVIDER FLOW 2 SECT GEAR; 5.1-14.9 GPM PER SECTION
2573	2.03.0185.1.01.3	LO	101010	HOUSING CHECK VALVE 2461C SLIPIN SIZE 32 VALVE
2574	2.03.0186.1.01.4	LO	239282	VALVE CRTG PO CHECK; T11A PO OPEN
2575	2.03.0187.1.01.5	LO	173050	VALVE DIAPHRAGM 1.50 SPRINGLESS
2576	2.03.0188.1.01.6	LO	179684	VALVE REPAIR KIT 1.50; DIAPHRAGM BUNA N

2577	2.03.0189.1.01.7	LO	161649	HOUSING CHECK VALVE 2461C; SLIPIN SIZE 32 VALVE ALUM
2578	2.03.0190.1.01.8	LO	A32718	VALVE BALL 1.00 NPT BRONZE 600#WOG W/LOCK
2579	2.03.0191.1.01.9	LO	A64284	VALVE BALL 0.50 NPT BRONZE
2580	2.03.0192.1.01.1	LO	A65037	VALVE BALL .75 NPT BRONZE 600#WOG W/LOCK
2581	2.03.0193.1.01.2	LO	231298	VALVE BALL 32 FNPT; BRONZE 600PSI CWP W/LOCK
2582	2.03.0194.1.01.3	LO	209733	VALVE BALL REMOTE OPER NC; 16FBSPP 04BSPP 24VDC
2583	2.03.0195.1.01.4	LO	101682	BALL VALVE 32-61 MODIFIED
2584	2.03.0196.1.01.5	LO	A28748	VALVE SHUTTLE .50 FNPT
2585	2.03.0197.1.01.6	PL	HY511.54	Pressure limiting valve
2586	2.03.0198.1.01.7	PL	62.05.4000.372 SUB:HY511. 71/ W/ 15/ 42	Hydraulic Valves
2587	2.03.0199.1.01.8	PH	UTVI 06 16/00	TIME DELAY VALVE
2588	2.03.0200.1.01.9	LO	A115390	VALVE DRCT 125PSI 5GPM H2O 12FNPT NO SOL 24V DC
2589	2.03.0201.1.01.1	PL	HY-M10RMEJJE	HYD VALVE
2590	2.03.0202.1.01.2	KA	530.25.00 /TU22-1.020-102-95	Check valves
2591	2.03.0203.1.01.3	KA	KBMK 25 G1.1 /TU2-053-1753-85E	Throttle with check valve
2592	2.03.0204.1.01.4	KA	KBMK10 G1.1 / TU2-053-1753-85	Throttle with check valve
2593	2.03.0205.1.01.5	CR	40095830	Electro-hydraulic directional valve
2594	2.03.0206.1.01.6	CR	40095831	Electromagnetic directional valve
2595	2.03.0207.1.01.7	CR	40095832	Electromagnetic directional valve
2596	2.03.0208.1.01.8	CR	40096170	Electromagnetic directional valve
2597	2.03.0209.1.01.9	CR	40096171	Electromagnetic directional valve
2598	2.03.0210.1.01.1	CR	40096172	Electromagnetic directional valve
2599	2.03.0211.1.01.2	CR	40100404	Proportional pressure-reducing valve
2600	2.03.0212.1.01.3	CR	40100405	Proportional directional valve
2601	2.03.0213.1.01.4	CR	40102064	Electromagnetic directional valve
2602	2.03.0214.1.01.5	CR	40102065	Electromagnetic directional valve
2603	2.03.0215.1.01.6	CR	40102066	Electromagnetic directional valve
2604	2.03.0216.1.01.7	CR	40102068	Electromagnetic directional valve
2605	2.03.0217.1.01.8	CR	40102069	Unidirection pressure-reducing valve
2606	2.03.0218.1.01.9	CR	0-3333030-0-04	Lever assly
2607	2.03.0219.1.01.1	CR	L426165	WKG Section
2608	2.03.0220.1.01.2	CR	0-3334012-0-01	VALVE
2609	2.03.0221.1.01.3	CR	0-3333003-0-04	VALVE
2610	2.03.0222.1.01.4	CR	0-3335030-0-03	FLOW CONTROL VALVE
2611	2.03.0223.1.01.5	CR	C0613Y03	RELIEF VALVE
2612	2.03.0224.1.01.6	CR	0-3334013-0-02	REDUCING VALVE
2613	2.03.0225.1.01.7	CR	150358-1	PUMP LOAD VALVE
2614	2.03.0226.1.01.8	CR	0-3333003-0-27	DC Valve
2615	2.03.0227.1.01.9	CR	0-3333003-0-25	DC Valve
2616	2.03.0228.1.01.1	CR	0-3333010-0-53	DC Valve
2617	2.03.0229.1.01.2	CR	02-360717	DC Valve
2618	2.03.0230.1.01.3	CR	A1215Y15	DC Valve
2619	2.03.0231.1.01.4	CR	0-3333039-0-28	DC Valve
2620	2.03.0232.1.01.5	CR	0-3333010-055	DC Valve
2621	2.03.0233.1.01.6	CR	5138469	REXROTH PRESSURE RELIEF VALVE
2622	2.03.0234.1.01.7	CR	5123565	FORWARD SOLENOID VALVE
2623	2.03.0235.1.01.8	CR	5131584	REVERSE SOLENOID VALVE
2624	2.03.0236.1.01.9	PL	I12546	Check valve
2625	2.03.0237.1.01.1	PL	HY16RSH-B-350	VALVE
2626	2.03.0238.1.01.2	PL	62.05.1000.382/A-450BAR	CHECK VALVE
2627	2.03.0239.1.01.3	PL	HY511.54	PRESSURE LIMITING VALVE
2628	2.03.0240.1.01.4	PL	HY511.39-A	Prop. reducing valve
2629	2.03.0241.1.01.5	PL	HY16RSJ-B	VALVE
2630	2.03.0242.1.01.6	PL	HY100.16	CHECK THROTTLE
2631	2.03.0243.1.01.7	PL	HY157.71	BRAKE VALVE
2632	2.03.0244.1.01.8	PL	HY511.58	DOUBLE SHOCK VALVE
2633	2.03.0245.1.01.9	PL	HY157.95/16	FLUSHING VALVE
2634	2.03.0246.1.01.1	PL	HY511.26/75Y	REDUCING VALVE
2635	2.03.0247.1.01.2	PL	HY151.183A	SUCTION VALVE
2636	2.03.0248.1.01.3	LO	210895	VALVE FLOW 3000PSI 26GPM; HYD THROTTLE CHECK D05
2637	2.03.0249.1.01.4	LO	237834	VALVE CHK 3000P 15GPM; HYD D03 PILOT A FROM B
2638	2.03.0250.1.01.5	PL	HY-E6RSD-B	Hydraulic VALVE
2639	2.03.0251.1.01.6	PL	HY151.184	SUCTION VALVE
2640	2.03.0252.1.01.7	PL	HY157.89	FLOW CONTROL VALVE
2641	2.03.0253.1.01.8	PL	HY511.11	Safety valve (for unloader)
2642	2.03.0254.1.01.9	PL	HY511.12	Safety valve(for unloader)
2643	2.03.0255.1.01.1	PL	HY157.27-160bar	Double shock valve(for work drive)
2644	2.03.0256.1.01.2	PL	HY151.15	Non return valve
2645	2.03.0257.1.01.3	PL	EL-T76.00 MO	Servo valve for lifting and lining
2646	2.03.0258.1.01.4	PL	HY155.12	Check Valve
2647	2.03.0259.1.01.5	PL	HY16RSD-ET	4 Way valve (for T/U) tilting

2648	2.04.0001.1.01.9	PL	61.02.235	PUMP CYL.
2649	2.04.0002.1.01.1	PL	62.05.2000.184	CYL ROLLER CLAMP BCM
2650	2.04.0003.1.01.2	PL	62.05.3000.300	CYLINDER
2651	2.04.0004.1.01.3	PL	62.05.3000.353	HYD CYLINDER FOR BCM
2652	2.04.0005.1.01.4	PL	62.05.3000.60PL	CYLINDER ASCENDING SIDE FOR BCM
2653	2.04.0006.1.01.5	PL	62.05.3000.61PL	CYLINDER DESCENDING SIDE
2654	2.04.0007.1.01.6	PL	62.05.3000.63PL	HYD. CYLINDER FOR BCM
2655	2.04.0008.1.01.7	PL	62.05.3000.69PL	CYLINDER
2656	2.04.0009.1.01.8	PL	62.05.3204	PISTON ROD WITH PISTON
2657	2.04.0010.1.01.9	PL	62.11.305	HYD CYLINDER
2658	2.04.0011.1.01.1	PL	64.14.1055	PISTON
2659	2.04.0012.1.01.2	PL	64.14.1058	LIFTING CLAMP CYLINDER
2660	2.04.0013.1.01.3	PL	64.14.1059	LIFTING CLAMP CYLINDER
2661	2.04.0014.1.01.4	PL	CU 311-3007A LI	HOOK UP DOWN CYLINDER
2662	2.04.0015.1.01.5	PL	CU 311-3007A RE	HOOK UP DOWN CYLINDER
2663	2.04.0016.1.01.6	PL	EL-T2111.G4	CYLINDER BLOCK
2664	2.04.0017.1.01.7	SI	F1666	BRIDGE LIFTING CYLINDER
2665	2.04.0018.1.01.8	SI	F1667	BRAKE CYLINDER
2666	2.04.0019.1.01.9	SI	F1668	EXTRA LIFTING LOWERING CYLINDER
2667	2.04.0020.1.01.1	SI	F1669	RAIL CLAMP CYLINDER
2668	2.04.0021.1.01.2	PL	HY600.05A(A)	DAMPER CYLINDER
2669	2.04.0022.1.01.3	PL	HZD06.080.040.003 SUB. HZD06.080.040.001	GUIDE BUSH
2670	2.04.0023.1.01.4	PL	HZD10.080.040.0710.010 SUB. HZD10.080.040.0710.1.001	PISTON ROD WITH PISTON
2671	2.04.0024.1.01.5	PL	HZD10.080.040.0760.001	PISTON ROD WITH PISTON
2672	2.04.0025.1.01.6	PL	HZD10.080.040.0760.010	PISTON ROD WITH PISTON
2673	2.04.0026.1.01.7	PL	HZD10.080.040.0835.010	PISTON ROD WITH PISTON
2674	2.04.0027.1.01.8	PL	HZDGB.063.036.0765.1.010	CYLINDER
2675	2.04.0028.1.01.9	PL	HZDGB.080.040.0760.1.001	TAMPING UNIT LIFTING LOWRING [UP/DOWN] CYL
2676	2.04.0029.1.01.1	PL	HZDPA.063.036.0715.1.001	CYLINDER
2677	2.04.0030.1.01.2	PL	HZDPA.080.040.0710.1.002	CYLINDER
2678	2.04.0031.1.01.3	PL	HZDPA.080.040.0760.1.001	CYLINDER
2679	2.04.0032.1.01.4	PL	HZDPA.080.040.0835.01.001	HYD CYLINDER FOR TAMPING UNIT UP / DOWN [IMPORTED] own PLASSER INDIA
2680	2.04.0033.1.01.5	PL	HZDQB.080.040.0600.1.001	CYLINDER
2681	2.04.0034.1.01.6	PL	HZGB.040.025.0130.1	BRAKE CYLINDER
2682	2.04.0035.1.01.7	PL	HZGB.040.025.0170.1	LOCKING CYLINDER
2683	2.04.0036.1.01.8	PL	HZGB.050.036.0080.001	CYLINDER
2684	2.04.0037.1.01.9	PL	HZGB.063.036.0100.1	CLAMP CYLINDER
2685	2.04.0038.1.01.1	PL	HZGB.063.036.0190.1	HYD CYLINDER FOR FRM
2686	2.04.0039.1.01.2	PL	HZGB.063.036.0400.1	HYD CYLINDER FOR FRM
2687	2.04.0040.1.01.3	PL	HZGB.063.036.0775.1	HYD CYLINDER FOR FRM
2688	2.04.0041.1.01.4	PL	HZGB.063.36.0190.1	HYD. CYLINDER FOR BCM
2689	2.04.0042.1.01.5	PL	HZGB.063.36.0425.1	CYLINDER
2690	2.04.0043.1.01.6	PL	HZGB.080.036.0180.2	SATELLITE SUPPORT CYLINDER
2691	2.04.0044.1.01.7	PL	HZGB.080.036.0305.1	CYLINDER
2692	2.04.0045.1.01.8	PL	HZGB.080.036.1000.1	CYLINDER
2693	2.04.0046.1.01.9	PL	HZGB.080.045.0200.2 Sub. HZGB.080.045.0200.1	HYD. CYLINDER
2694	2.04.0047.1.01.1	PL	HZGB.080.050.0900.1	CYLINDER
2695	2.04.0048.1.01.2	PL	HZGB.100.063.0200.1	CYLINDER
2696	2.04.0049.1.01.3	PL	HZGB.100.063.1000.1	CYLINDER
2697	2.04.0050.1.01.4	PL	HZGB.125.063.0250.1	CYLINDER
2698	2.04.0051.1.01.5	PL	HZGB.125.063.0950.1	CYLINDER
2699	2.04.0052.1.01.6	PL	HZGB.125.090.1000.1	CYLINDER
2700	2.04.0053.1.01.7	PL	HZMB.080.045.0160.2	CYLINDER
2701	2.04.0054.1.01.8	PL	HZMB.100.045.0120.2	CYLINDER
2702	2.04.0055.1.01.9	PL	HZMB.100.063.0600.2.041	HYD CYLINDER FOR BCM
2703	2.04.0056.1.01.1	PL	HZMB.100.063.1400.2.040	HYD CYLINDER FOR BCM
2704	2.04.0057.1.01.2	PL	HZMB.100.063.1600.2.001	HYD CYLINDER FOR BCM
2705	2.04.0058.1.01.3	PL	HZMB.125.063.2100.1.001	HYD CYLINDER FOR BCM
2706	2.04.0059.1.01.4	PL	HZMBV.100.063.1170.2	HYD CYLINDER FORFRM
2707	2.04.0060.1.01.5	PL	HZMBV.125.090.2250.1	HYD CYLINDER FOR BCM
2708	2.04.0061.1.01.6	PL	HZPA.050.036.0800.1.001+ yoke HZ 60.01.2	CYLINDER
2709	2.04.0062.1.01.7	PL	HZQB.080.050.0800.1.003	BOOSTING CYLINDER
2710	2.04.0063.1.01.8	PL	HZQk.125.050.0410.2.001	HYD CYLINDER FOR BCM
2711	2.04.0064.1.01.9	PL	HZSA 163.153N	T/U LOCK CYLINDER
2712	2.04.0065.1.01.1	PL	HZSI-G.50.429	FORK CYLINDER
2713	2.04.0066.1.01.2	PL	NZGB.080.045.0200.2	HYD CYLINDER FORFRM
2714	2.04.0067.1.01.3	PL	NZGB.100.045.0300.1.001	LINING CYLINDER
2715	2.04.0068.1.01.4	PL	NZGB.100.050.0400.1	LATERAL CONTROL CYLINDER
2716	2.04.0069.1.01.5	PL	NZGB.125.050.0450.1.002	TRACK LIFTING CYLINDER

2717	2.04.0070.1.01.6	PL	RM08A.27.0130	CYLINDER
2718	2.04.0071.1.01.7	PL	UD 50.1900	SUPPORT CYLINDER
2719	2.04.0072.1.01.8	PL	UD 50.200	SUPPORT CYL
2720	2.04.0073.1.01.9	PL	UD 50.2200	SUPPORT CYLINDER
2721	2.04.0074.1.01.1	PL	UD 65.1177	NUT FOR T.UNIT LIFT CYL
2722	2.04.0075.1.01.2	PL	UD160.50-DG	BRAKE CYLINDER
2723	2.04.0076.1.01.3	PL	UD313.3305LI	HOOK UP DOWN CYLINDER WITH YOKE
2724	2.04.0077.1.01.4	PL	UD313.3305RE	HOOK UP DOWN CYLINDER WITH YOKE
2725	2.04.0078.1.01.5	PL	UD50.100	CYLINDER
2726	2.04.0079.1.01.6	PL	UD50.1950-A WITHOUT ROLLER	CYLINDER
2727	2.04.0080.1.01.7	PL	UD50.2800	CYLINDER
2728	2.04.0081.1.01.8	PL	UD50.3100	SUPPORT CYLINDER
2729	2.04.0082.1.01.9	PL	UD50.3700	SUPPORT CYLINDER
2730	2.04.0083.1.01.1	PL	UD50.3900(A)	WHEEL SUPPORT CYLINDER
2731	2.04.0084.1.01.2	KE	174977 / 781965	WING IN AND OUTER CYL
2732	2.04.0085.1.01.3	KE	184092	WING TEMP. I/O CYLINDER
2733	2.04.0086.1.01.4	KE	218527	WING TILTING CYLINDER
2734	2.04.0087.1.01.5	KE	662984	ASSEMBLY PISTON ROD
2735	2.04.0088.1.01.6	KE	707917	PLOW BROOM U/D CYLINDER
2736	2.04.0089.1.01.7	KE	730563	PLOW I/O CYLINDER
2737	2.04.0090.1.01.8	KE	781967	WING TILT CYLINDER
2738	2.04.0091.1.01.9	KE	781970	HYD. CYLINDER
2739	2.04.0092.1.01.1	KE	1260637	WORKING CYLINDER
2740	2.04.0093.1.01.2	AM	0017311 C	CLAMP LIFT CYLINDER
2741	2.04.0094.1.01.3		Shifted to Ann-II	
2742	2.04.0095.1.01.4	PH	1P3	PISTON HAFT I
2743	2.04.0096.1.01.5	PH	1P6	PISTON HAFT II
2744	2.04.0097.1.01.6	PH	5P10	SLEW CYLINDER
2745	2.04.0098.1.01.7	LO	113604	CYLINDER HYD 2.00BX1.50R 6.00S HEAD MT THD ROD
2746	2.04.0099.1.01.8	LO	117534	CYLINDER HYD 3.50BX1.50RX14.00S
2747	2.04.0100.1.01.9	LO	119467	CYLINDER HYD 1.50BX1.00RX7.00S
2748	2.04.0101.1.01.1	LO	124422	CYLINDER HYD 1.50B 1.00R 07.00S PORTS AT ROD END
2749	2.04.0102.1.01.2	LO	159321	AXLE SUPPORT WELDT
2750	2.04.0103.1.01.3	LO	159322	AXLE SUPPORT ASSY
2751	2.04.0104.1.01.4	KA	1023.48.65.000	HYD CYL for LIFTING THE RAISING & LINING DEVICEFOR TRACK LIFTING WITH YOKE
2752	2.04.0105.1.01.5	PL	HZDGB.080.040.0710.1.001WITHUD6 7.1400.11	CYLINDER+GUIDE BUSH
2753	2.04.0106.1.01.6	PL	HZDGB.080.040.0760.1.001WITH UD67.1400.11	CYLINDER+GUIDE BUSH
2754	2.04.0107.1.01.7	PL	HZQB.050.036.0600.1.002	CYLINDER WITHOUT PRESSURE HEAD
2755	2.04.0108.1.01.8		Repeated item	
2756	2.04.0109.1.01.9	PL	HZMBV.080.050.0400.2.001	CYLINDER
2757	2.04.0110.1.01.1	PL	HZPA.050.036.0800.1.001	CYLINDER
2758	2.04.0111.1.01.2	PL	HZMB.080.045.0120.2	CYLINDER
2759	2.04.0112.1.01.3	PL	HZGB.063.036.0190.1.001	CYLINDER
2760	2.04.0113.1.01.4	PL	HZGB.063.036.0200.1	CYLINDER
2761	2.04.0114.1.01.5	PL	HZPB.040.025.0220.2.001	CYLINDER
2762	2.04.0115.1.01.6	PL	HZMB.063.040.0600.1.009	CYLINDER
2763	2.04.0116.1.01.7	PL	62.05.3000.63PL.S20	CYLINDER
2764	2.04.0117.1.01.8	PL	HZMB.050.025.0300.1	CYLINDER
2765	2.04.0118.1.01.9	PL	HZMB.080.050.1780.1.001	CYLINDER
2766	2.04.0119.1.01.1	PL	HZMB.063.036.0250.2	CYLINDER
2767	2.04.0120.1.01.2	PL	HZMB.063.025.0365.2	CYLINDER
2768	2.04.0121.1.01.3	PL	HZPK.063.036.0560.1.005	CYLINDER
2769	2.04.0122.1.01.4		Repeated item	
2770	2.04.0123.1.01.5	PL	NZGB.080.036.0950.1	CYLINDER
2771	2.04.0124.1.01.6	PL	19X1200	S.S.STRIP
2772	2.04.0125.1.01.7	PL	2013-08-00.85 SUBSTITUTE 1620-M	NUT
2773	2.04.0126.1.01.8	PL	2020-01-00.31 SUBSTITUTE NW2-400BAR	HOSE
2774	2.04.0127.1.01.9		Shifted to Annexure II	
2775	2.04.0128.1.01.1		Shifted to Annexure II	
2776	2.04.0129.1.01.2	PL	404-23034-1	RING
2777	2.04.0130.1.01.3		Shifted to Annexure II	
2778	2.04.0131.1.01.4	PL	62.14.2182	NUT
2779	2.04.0132.1.01.5	PL	HZGB.063.040.0320.1.043	Hydraulic Cylinder
2780	2.04.0133.1.01.6	PL	HZGB.063.036.0050.1.001	Hydraulic Cylinder
2781	2.04.0134.1.01.7	PL	HZDGB.080.040.0760.1.010	PISTON ROD
2782	2.04.0135.1.01.8	GE	CDCK16A-56-02-03-00	Traversing cylinder inst.

2783	2.04.0136.1.01.9	PL	HZDGB.063.036.0800.1.001HW	TAMPING UNIT LIFTING CYL
2784	2.04.0137.1.01.1	PL	HZDPA.080.040.0810.1.002	Hydraulic Cylinder
2785	2.04.0138.1.01.2	PL	HZDPA.080.040.0810.1.002PA	Hydraulic Cylinder
2786	2.04.0139.1.01.3	PL	HZDPA.080.040.0835.1.001PA	TAMPING UP/DN CYLINDER
2787	2.04.0140.1.01.4	AM	17311	Extra Lifting Cylinder (Grips lift cylinder)
2788	2.04.0141.1.01.5	CR	40105638	HOOK LIFTING CYLINDER
2789	2.04.0142.1.01.6		Shifted to Annexure II	
2790	2.04.0143.1.01.7	GE	CDCK16A-56-09	Lining cylinder
2791	2.04.0144.1.01.8	GE	TE03-80.01.001.00	Left lifting cylinder
2792	2.04.0145.1.01.9	GE	TE03-80.01.001.00Re	Right lifting cylinder
2793	2.04.0146.1.01.1	GE	CDCK16A-50(I)-02-0 9-01	Unit traversing cylinder
2794	2.04.0147.1.01.2	GE	YD432D-02(II)-01-02	Car body support cylinder
2795	2.04.0148.1.01.3	GE	DCL32-02(I)-07-04	Axle box support cylinder
2796	2.04.0149.1.01.4	GE	CDCK16A-50(I)-02-0 8-01	Frame traversing cylinder
2797	2.04.0150.1.01.5	GE	CDC16A-50(II)-10-05	Pressing cylinder
2798	2.04.0151.1.01.6	CR	Φ110/80-1620.2040_BS550 (IND)-07	HYDRAULIC CYLINDER- 1-1
2799	2.04.0152.1.01.7	CR	Φ80/45-120.380_BS550(IND)-07	HYDRAULIC CYLINDER- 2-1
2800	2.04.0153.1.01.8	CR	Φ80/40-150.60_BS550 (IND)-07	HYDRAULIC CYLINDER- 3-1
2801	2.04.0154.1.01.9	CR	Φ63/36-120.460_BS550(IND)-07	HYDRAULIC CYLINDER- 4-1
2802	2.04.0155.1.01.1	CR	Φ100/70-830.1200_BS550(IND)-07	HYDRAULIC CYLINDER- 5-1
2803	2.04.0156.1.01.2	CR	Φ63/45-1020.1340_BS500W (IND)-08	HYDRAULIC CYLINDER- 7-1
2804	2.04.0157.1.01.3	CR	Ø80/40-880.1110_BS550(IND)-10	HYDRAULIC CYLINDER-8-1
2805	2.04.0158.1.01.4	CR	Φ80/45-300.600_BS550(IND)-11	HYDRAULIC CYLINDER-9-1
2806	2.04.0159.1.01.5	CR	Φ50/36-212.495_BS550(IND)-11	HYDRAULIC CYLINDER-10
2807	2.04.0160.1.01.6	CR	Φ90/50-305.617_BS550(IND)-13	HYDRAULIC CYLINDER-11-1
2808	2.04.0161.1.01.7	CR	Φ90/45-1100.1597_BS500W (IND)-13	HYDRAULIC CYLINDER- 12-1
2809	2.04.0162.1.01.8	CR	Φ80/45-130.265_BS500W(IND)-13	HYDRAULIC CYLINDER-13-1
2810	2.04.0163.1.01.9	CR	Φ90/45-600.947_BS500W(IND)-13	HYDRAULIC CYLINDER-14-1
2811	2.04.0164.1.01.1	CR	Φ110/80-170.1350_BS500W(IND)-13	HYDRAULIC CYLINDER- 15-1
2812	2.04.0165.1.01.2	CR	Φ63/32-325.570_BS500W(IND)-13	HYDRAULIC CYLINDER-16-1
2813	2.04.0166.1.01.3	CR	Φ63/45-210.455_BS500W(IND)-13	HYDRAULIC CYLINDER-17-1
2814	2.04.0167.1.01.4	CR	Φ110/80-1620.2040_BS550(IND)-07	HYDRAULIC CYLINDER-1
2815	2.04.0168.1.01.5	CR	Φ80/45-120.380_BS550(IND)-07	HYDRAULIC CYLINDER-2
2816	2.04.0169.1.01.6	CR	JB/T7940.2-M10X1(GB/T1153)	ANGLE HYDRAULIC GREASE NIPPLE
2817	2.04.0170.1.01.7	CR	Φ80/40-150.600_BS550(IND)-07	HYDRAULIC CYLINDER-1
2818	2.04.0171.1.01.8	CR	Φ63/36-120.460_BS550(IND)-07	HYDRAULIC CYLINDER-2
2819	2.04.0172.1.01.9	CR	Ø80/40-880.1110_BS550(IND)-10	HYDRAULIC CYLINDER
2820	2.04.0173.1.01.1	CR	Φ90/50-305.617_BS550	CYLINDER
2821	2.04.0174.1.01.2	CR	BS500W(IND)-13-01-17-00	CYLINDER BASE
2822	2.04.0175.1.01.3	CR	Φ90/45- 1100.1597_BS500W(IND)-13	CYLINDER-1
2823	2.04.0176.1.01.4	CR	Φ80/45-130.265_BS500W(IND)-13	CYLINDER-2
2824	2.04.0177.1.01.5	CR	Φ90/45-600.947_BS500W(IND)-13	CYLINDER-3
2825	2.04.0178.1.01.6	CR	Φ110/80- 170.1350_BS500W(IND)-13	CYLINDER-4
2826	2.04.0179.1.01.7	CR	Φ63/32-325.570_BS500W(IND)-13	CYLINDER-1
2827	2.04.0180.1.01.8	CR	Φ63/45-210.455_BS500W(IND)-13	CYLINDER-2
2828	2.04.0181.1.01.9	CR	23085460	CYLINDER(HOOK IN/OUT)
2829	2.04.0182.1.01.1	CR	40105431	CYLINDER(FOR CLAMP ROLLER)
2830	2.04.0183.1.01.2	CR	40102431	CYLINDER (BIG CYL.)LIFTING UNIT UP/DOWN
2831	2.04.0184.1.01.3	CR	40102430	CYLINDER(LIFTING UNIT LEFT/RIGHT)
2832	2.04.0185.1.01.4	CR	40105368	CYLINDER(HOOK UP/DOWN)
2833	2.04.0186.1.01.5	CR	40103578/40095751	Hydraulic cylinder sealing ring (full set)
2834	2.04.0187.1.01.6	CR	40103558/40095762	Hydraulic cylinder sealingring (full set)
2835	2.04.0188.1.01.7	CR	40104985	HYDRAULIC CYL.(TAMPING FRAME AND RATOARY EQUIP)
2836	2.04.0189.1.01.8	CR	40102642	HYDRAULIC CYL(ROTARY CYL. ASSEMBLY)
2837	2.04.0190.1.01.9	CR	40102640	LIFTING OIL CYL.
2838	2.04.0191.1.01.1	CR	40104956	CYLINDER(LIFTING UNIT LIFTING CYL.)
2839	2.04.0192.1.01.2	CR	40106838	CYLINDER(FRONT CLAMP ROLLER)
2840	2.04.0193.1.01.3	CR	23077185	CYLINDER(INSTALLATIO N OF FORWARD/BACKWARD CYL)

2841	2.04.0194.1.01.4	CR	40102433	CYLINDER(INSTALLATION OF FORWARD/BACKWARD CYL.)
2842	2.04.0195.1.01.5	CR	40106876	LIFTING HYD. CYL.
2843	2.04.0196.1.01.6	PL	NZGB.100.050.0100.2.001	AHM INCLINATION CYLINDER
2844	2.04.0197.1.01.7	PL	HZMB.050.036.0125.2.001	AHM INCLINATION LOCKING CYLINDER
2845	2.04.0198.1.01.8	PL	UD50.3900/HUB40MM	AXLE SUPPORT CYLINDER
2846	2.04.0199.1.01.9	PL	HZMB.100.063.0350.1.002	DTS LIFTING CYLINDER
2847	2.04.0200.1.01.1	PL	NZGB.080.036.0360.1	DTS LATERAL SHIFTING CYLINDER
2848	2.04.0201.1.01.2	PL	NZMBV.125.063.0645.2.001	CHAIN TENSION CYLINDER
2849	2.04.0202.1.01.3	PL	HZGB.150.090.1250.1.001	TROUGH LIFTING CYLINDER
2850	2.04.0203.1.01.4	PL	HZGB.100.063.1200.1.001	TROUGH LATERAL SHIFTING CYLINDER
2851	2.04.0204.1.01.5	PL	RE08.03.719	CUTTER BAR ELBOW LOCKING CYLINDER
2852	2.04.0205.1.01.6	PL	NZGB.100.050.0700.1	CLAMP 1 LIFTING CYLINDER
2853	2.04.0206.1.01.7	PL	NZGB.063.040.0540.1	CLAMP1 EXTENDED CYLINDER
2854	2.04.0207.1.01.8	PL	NZMBV.080.045.0900.1	CLAMP1 LINING CYLINDER
2855	2.04.0208.1.01.9	PL	HZMB.048.025.0110.2.001	CLAMP1 CLAMPS OPEN/CLOSE CYLINDER
2856	2.04.0209.1.01.1	PL	HZGB.050.036.0100.1.001	CLAMP2 CLAMPS OPEN/CLOSE CYLINDER
2857	2.04.0210.1.01.2	PL	HZMBV.080.036.0580.1.001	CLAMP2 LIFTING CYLINDER
2858	2.04.0211.1.01.3	PL	NZGB.080.045.0800.1	CLAMP2 LINING CYLINDER
2859	2.04.0212.1.01.4	PL	NZGB.100.050.0135.1	CLAMP2 INCLINATION CYLINDER
2860	2.04.0213.1.01.5	PL	HZGB.050.036.0160.2.001	PLOUGH PLATE OPEN/CLOSE CYLINDER
2861	2.04.0214.1.01.6	PL	NZGB.040.025.0670.1	CUTTER BAR LIFT CYLINDER
2862	2.04.0215.1.01.7	PL	RE11.00.500	A1 BELT CLAMPING CYL(TENSION)
2863	2.04.0216.1.01.8	PL	W33.200E	BALLAST DISTRIBUTING CYLINDER
2864	2.04.0217.1.01.9	PL	NZMBV.125.063.0150.2	CLAMP1 INCLINATION CYLINDER
2865	2.04.0218.1.01.1	PL	SU1600.502.3.11.19	DTS HYDRAULIC LOCK CYLINDER
2866	2.04.0219.1.01.2	PL	NZGB.080.050.0255.1	Troughs feeder plate in/out cylinder
2867	2.04.0220.1.01.3	PL	NZMBV.080.036.0170.001	FRAME INCLINATION ADJUSTMENT
2868	2.04.0221.1.01.4	PL	HZMBV.063.036.0350.1	A2 BELT SUSPENSION CYLINDER
2869	2.04.0222.1.01.5	PL	NZGB.063.036.0400.1	A3 BELT SUSPENSION CYLINDER
2870	2.04.0223.1.01.6	PL	HZMBV.050.025.0450.1	TOTAL EXCAVATION CHUTE ADJUSTMENT CYLINDER
2871	2.04.0224.1.01.7	PL	RE 150.3.002-1 and Sub Part no. 64.14.1119 or 64.14.1120	HYD CYLINDER
2872	2.04.0225.1.01.8	PL	UD50.550	HYD CYLINDER
2873	2.04.0226.1.01.9	PL	HZ60.01-2.001	FORK HEAD
2874	2.04.0227.1.01.1	PL	HZ60.01-2.005	FORK HEAD
2875	2.04.0228.1.01.2	PL	HZ60.01-2.007	FORK HEAD
2876	2.04.0229.1.01.3	PL	HZ60.01-2.014	FORK HEAD
2877	2.04.0230.1.01.4	PL	HZ60-30H8.38.50-1	YOKE
2878	2.04.0231.1.01.5	PL	HZ70.01-2.001	ROD END
2879	2.04.0232.1.01.6	PL	HZ70.01-2.002	ROD END
2880	2.04.0233.1.01.7	PL	HZ70.01-2.003	ROD END
2881	2.04.0234.1.01.8	PL	HZ70.01-5.001	JOINT HEAD
2882	2.04.0235.1.01.9	PL	HZ80.01-1	ROD END
2883	2.04.0236.1.01.1	PL	HZ80.01-2	ROD END
2884	2.04.0237.1.01.2	PL	HZ80.01-2.001	JOINT HEAD
2885	2.04.0238.1.01.3	PL	HZ80.01-3	ROD END
2886	2.04.0239.1.01.4	PL	HZ80.01-3.002	ROD END
2887	2.04.0240.1.01.5	LO	241420	CYLINDER HYD 2.50BX1.50R; 17.56S
2888	2.04.0241.1.01.6	LO	209554	CYLINDER HYD 2.00BX1.25R; 2.25S CLVS
2889	2.04.0242.1.01.7	LO	210333	CYLINDER HYD 1.50BX1.00R; 2.62S EYE X CLEVIS
2890	2.04.0243.1.01.8	LO	206799	CYL HYD 2.00B X 1.25R; 10.00S MTS FEEDBACK
2891	2.04.0244.1.01.9	LO	211893	CYL HYD 1.50B X .75R; 8.00S TRUNNION MOUNT
2892	2.04.0245.1.01.1	LO	252351-26	CYLINDER BUSHING KIT #2
2893	2.04.0246.1.01.2	LO	242914	BLOCK CYLINDER MOUNT
2894	2.04.0247.1.01.3	PL	HZGB.100.045.0300.1	CYLINDER
2895	2.04.0248.1.01.4	PL	6408.400004	Chain Tension Cylinder
2896	2.04.0249.1.01.5	PL	62.05.3000.486	HYD CYLINDER
2897	2.04.0250.1.01.6	PL	64.08.4000.04	HYD CYLINDER
2898	2.04.0251.1.01.7	PL	HZ050.025.0280/0100.01	HYD CYLINDER
2899	2.04.0252.1.01.8	PL	HZ063.040.0105.1/0105.2.001	LIFTING UNIT LONGITUDINAL DOUBLE ACTING CYLINDER
2900	2.04.0253.1.01.9	PL	HZDBQ.080.040.0600.1.001	CYLINDER
2901	2.04.0254.1.01.1	PL	HZGB.040.025.0160.1	HYD CYLINDER
2902	2.04.0255.1.01.2	PL	HZGB.050.025.0120.1	HYD CYLINDER
2903	2.04.0256.1.01.3	PL	HZGB.050.025.0170.1	DGS CENTERING HYD CYLINDER
2904	2.04.0257.1.01.4	PL	HZGB.050.025.0750.1.001	HYD CYLINDER
2905	2.04.0258.1.01.5	PL	HZGB.063.036.240.2.003	HYD CYLINDER
2906	2.04.0259.1.01.6	PL	HZGB.063.036.0440.1	HYD CYLINDER

2907	2.04.0260.1.01.7	PL	HZGB.063.040.0685.2	HYD CYLINDER
2908	2.04.0261.1.01.8	PL	HZGB.063.040.2000.2.002	HYD CYLINDER
2909	2.04.0262.1.01.9	PL	HZGB.100.045.0790.1	HYD CYLINDER
2910	2.04.0263.1.01.1	PL	HZGB.125.050.0435.1.014	HYD CYLINDER
2911	2.04.0264.1.01.2	PL	HZMB.040.025.0180.2	HYD CYLINDER
2912	2.04.0265.1.01.3	PL	HZMB.063.040.0710.1.001	HYD CYLINDER
2913	2.04.0266.1.01.4	PL	HZMB.063.040.0780.1.017	HYD CYLINDER
2914	2.04.0267.1.01.5	PL	HZMB.080.050.0170.2	HYD CYLINDER
2915	2.04.0268.1.01.6	PL	HZMB.080.050.0185.2	CYLINDER
2916	2.04.0269.1.01.7	PL	HZMB.100.045.0605.2.001	HYD CYLINDER
2917	2.04.0270.1.01.8	PL	HZMB.125.063.2100.1.002	HYD CYLINDER
2918	2.04.0271.1.01.9	PL	HZMBV.080.045.0600.1	HYD CYLINDER
2919	2.04.0272.1.01.1	PL	HZPA.100.050.1500.1.001	HYD CYLINDER
2920	2.04.0273.1.01.2	PL	NZGB.063.036.1030.1	HYD CYLINDER
2921	2.04.0274.1.01.3	PL	NZGB.063.040.0280.1	HYD CYLINDER
2922	2.04.0275.1.01.4	PL	NZGB.080.045.0150.1.001	HYD CYLINDER
2923	2.04.0276.1.01.5	PL	NZMBV.100.050.0100.2	SWIVEL BLOCKING DEVICE HYD CYLINDER
2924	2.04.0277.1.01.6	PL	NZMBV.063.036.0200.1	CYLINDER
2925	2.04.0278.1.01.7	PL	NZMBV.080.045.0215.1.001	CYLINDER
2926	2.04.0279.1.01.8	PL	UD66.3260/198	CYLINDER
2927	2.04.0280.1.01.9	CR	40101877	Hydraulic cylinder
2928	2.04.0281.1.01.1	CR	40102354	Hydraulic cylinder
2929	2.04.0282.1.01.2	CR	40102372	Hydraulic cylinder
2930	2.04.0283.1.01.3	CR	40102373	Hydraulic cylinder
2931	2.04.0284.1.01.4	CR	40102374	Hydraulic cylinder
2932	2.04.0285.1.01.5	CR	40102375	Hydraulic cylinder
2933	2.04.0286.1.01.6	CR	40102426	Hydraulic cylinder
2934	2.04.0287.1.01.7	CR	40102637	Hydraulic cylinder
2935	2.04.0288.1.01.8	CR	40102639	Hydraulic cylinder
2936	2.04.0289.1.01.9	CR	40102641	Hydraulic cylinder
2937	2.04.0290.1.01.1	CR	40102829	Hydraulic cylinder
2938	2.04.0291.1.01.2	CR	40106794	Hydraulic cylinder
2939	2.04.0292.1.01.3	CR	40106875	Hydraulic cylinder
2940	2.04.0293.1.01.4	CR	40107602	Hydraulic cylinder
2941	2.04.0294.1.01.5	CR	40107603	Hydraulic cylinder
2942	2.04.0295.1.01.6	CR	5030785	MAIN FRAME FRONT
2943	2.04.0296.1.01.7	CR	B6423XAA	ACCUMULATOR PLATFORM UP/DN
2944	2.04.0297.1.01.8	CR	0-3371047-0-01	CYLINDER (REVERCE FIRWARD)
2945	2.04.0298.1.01.9	CR	5131772	HYD CYLINDER (3" BORE X 6" STROCK)
2946	2.04.0299.1.01.1	CR	5131777	CLAMP/UNCLAMP CYLINDER
2947	2.04.0300.1.01.2	PL	NZGB.080.045.0260.1	HYD CYLINDER
2948	2.04.0301.1.01.3	PL	HZ10.150.090.1250.001	PISTON ROD COMPLETE
2949	2.04.0302.1.01.4	PL	HZ08.080.045.0247.1.001	PISTON ROD COMPLETE
2950	2.04.0303.1.01.5	PL	HZ10.080.036.0580.1	PISTON ROD COMPLETE
2951	2.04.0304.1.01.6	PL	W33.202B	PISTON ROD
2952	2.04.0305.1.01.7	PL	HZ10.063.036.0350.1	PISTON ROD COMPLETE
2953	2.04.0306.1.01.8	PL	NZ10.063.036.0400.1	PISTON ROD COMPLETE
2954	2.04.0307.1.01.9	PL	HZ10.050.036.0115.2	PISTON ROD COMPLETE
2955	2.04.0308.1.01.1	PL	NZ10.100.050.0700.1	PISTON ROD COMPLETE
2956	2.04.0309.1.01.2	PL	NZ10.063.040.0540.1	PISTON ROD COMPLETE
2957	2.04.0310.1.01.3	PL	HZ10.050.036.0100.1	PISTON ROD COMPLETE
2958	2.04.0311.1.01.4	PL	NZ10.100.050.0135.1	PISTON ROD COMPLETE
2959	2.04.0312.1.01.5	PL	NZ10.125.063.0150.2	PISTON ROD COMPLETE
2960	2.04.0313.1.01.6	PL	HZ10.100.063.0050.1.001	PISTON ROD COMPLETE
2961	2.04.0314.1.01.7	PL	HZ10.063.036.0315.1	PISTON ROD COMPLETE
2962	2.04.0315.1.01.8	PL	RE151.102-2	Clamp1 extra lifting cylinder piston
2963	2.04.0316.1.01.9	LO	209934	CYLINDER HYD 2.50BX1.50R; 4.00S .75 CLVS X .75 CLVS
2964	2.04.0317.1.01.1	PL	HZ70.01.5	JOINT HEAD
2965	2.04.0318.1.01.2	PL	UD50.2400	SUPPORT CYLINDER
2966	2.04.0319.1.01.3	PL	CU311.1017	HYD CYLINDER
2967	2.04.0320.1.01.4	PL	HZGB.125.050.0365.1.004	HYD CYLINDER
2968	2.04.0321.1.01.5	PL	HZ10.063.040.410.1	Piston rod
2969	2.04.0322.1.01.6	PL	HZ10.100.045.0300.1.001	Piston rod
2970	2.04.0323.1.01.7	PL	HZ10.125.050.0500.1	Piston rod
2971	2.04.0324.1.01.8	PL	HZSA-K.150.272	Piston rod
2972	2.04.0325.1.01.9	PL	HZ10.125.050.0330.1	Piston rod
2973	2.04.0326.1.01.1	PL	HZ10.125.050.0365.1	Piston rod
2974	2.04.0327.1.01.2	PL	HZ10.063.036.0765.004	Piston rod
2975	2.04.0328.1.01.3	PL	HZ10.100.045.0520.1	Piston rod
2976	2.04.0329.1.01.4	PL	HZ10.080.040.0810.1.002	Piston rod
2977	2.04.0330.1.01.5	LO	170406-NI	CYLINDER HYDRAULIC 2.50B X1.50R; 12.00S EYE CLEVIS MAGNET
2978	2.04.0331.1.01.6	LO	206370	CYLINDER HYD 2.50BX1.50R 12.00S EYE CLVS MAGNET
2979	2.04.0332.1.01.7	PL	HZDGB.125.050.0365.1-004	Hyd. Cylinder (hook on/off)
2980	2.04.0333.1.01.8	PL	HZS-A.201.134/HZS-G.201.135	Hyd. Cylinder for tamping unit vibration
2981	2.04.0334.1.01.9	PL	HZDPA.080.040.0801.1.002(V1)	Tamping unit Up/Down Cylinder
2982	2.04.0335.1.01.1	PL	W33.200C	Cylinder

2983	2.04.0336.1.01.2	PL	HZGB.040.025.0360.1	Cylinder
2984	2.04.0337.1.01.3	PL	NZGB063.036.0580.1	Hyd. Cylinder (for T/U Displacing)
2985	2.04.0338.1.01.4	PL	UD.313.1017	Hook lateral movement cylinder
2986	2.04.0339.1.01.5	SR	HSL01-90/50E-2611-320X650	Oil Cylinder
2987	2.04.0340.1.01.6	SR	SPZ-270-79-00-34	Oil Cylinder
2988	2.04.0341.1.01.7	SR	HSL01-63/35E-2801-370X640	Oil Cylinder
2989	2.04.0342.1.01.8	PL	HZGB.100.045.0400.1.015	HYD CYLINDER (LINING)
2990	2.04.0343.1.01.9	PL	UD50.2600.A	SUPPORT CYLINDER
2991	2.04.0344.1.01.1	PL	CA311.1017	HYD CYLINDER
2992	2.04.0345.1.01.2	PL	NZGB.100.045.0580.2	HYD CYLINDER
2993	2.04.0346.1.01.3	PL	UD50.2204	BUSH
2994	2.04.0347.1.01.4	PL	HZSI.A.36.426	HYDRAULIC CYLINDER
2995	2.04.0348.1.01.5	PL	HZGB.100.045.0580.2.002	HYD. CYLINDER
2996	2.04.0349.1.01.6	PL	HZGB.050.025.0540.1.001	CYLINDER
2997	2.04.0350.1.01.7	PL	HZPK.063.040.0320.1	SLIDE CYLINDER
2998	2.04.0351.1.01.8	PL	JT30.150B	FLAP (CLAPPER) CYLINDER
2999	2.04.0352.1.01.9	PL	HZGB.100.046.0400.1.015	HYD. CYLINDER
3000	2.04.0353.1.01.1	PL	NZGB.063.025.0430.2	CONVEYOR BELT SUPPORT CYLINDER
3001	2.04.0354.1.01.2	PL	HZGB.080.036.0160.2	HYDRAULIC CYLINDER
3002	2.04.0355.1.01.3	PL	HZGB.80.040.0600.1.001	HYDRAULIC CYLINDER
3003	2.04.0356.1.01.4	PL	NZGB.0100.050.0400.1	HYDRAULIC CYLINDER
3004	2.04.0357.1.01.5	PL	HZGB.063.036.010.1	HYDRAULIC CYLINDER
3005	2.04.0358.1.01.6	PL	NZGB.125.050.0435.1	HYDRAULIC CYLINDER
3006	2.04.0359.1.01.7	PL	NZGB.100.045.0300.1.001PA	Lifting unit cylinder
3007	2.06.0001.1.01.2	LO	114722-0011.13	HOSE ASSEMBLY 06 08FORFS STR 5300P; 08FORFS STR
3008	2.06.0002.1.01.3	LO	130805-0112.00	HOSE ASSEMBLY 04 04FORFS STR 6500P; 04FORFS EL90
3009	2.06.0003.1.01.4	LO	114722-0011.63	HOSE ASSEMBLY 06 08FORFS STR 5300P; 08FORFS STR
3010	2.06.0004.1.01.5	LO	229107	HOSE CLAMP T-BOLT; 5.28 - 5.59
3011	2.06.0005.1.01.6	LO	252351-208	HOSE REPAIR KIT - SMALL
3012	2.06.0006.1.01.7	LO	H18527	FLANGE SPLIT CLAMP HALF 1.50 3000 PSI CODE 61
3013	2.06.0007.1.01.8	LO	H18528	FLANGE SPLIT CLAMP HALF 2.00 3000 PSI CODE 61
3014	2.06.0008.1.01.9	CR	82008020880	BREATHER
3015	2.06.0009.1.01.1	CR	HF-S36/40102117	AIR FILTER
3016	2.06.0010.1.01.2	CR	HF-O-0015G/40102116	AIR FILTER
3017	2.06.0011.1.01.3	CR	PD55349-001	WATER COLLECTION CUP
3018	2.06.0012.1.01.4	CR	40097601	Air intake filter
3019	2.07.0001.1.01.3		Shifted to Ann -II	
3020	2.07.0002.1.01.4	LO	2023251 SUBSTITUTE BEF-WN-OBW	MOUNTING BRACKET
3021	2.07.0003.1.01.5	LO	HY157.100	OIL COOLER
3022	2.07.0004.1.01.6	PL	HY.157.39	Hyd cooler
3023	2.07.0005.1.01.7	GE	20L	Accumulator-1
3024	2.07.0006.1.01.8	GE	SB330H-32A1/112A9- 330A	Accumulator-2
3025	2.07.0007.1.01.9	GE	CDCM 16A-23-01-01-00	Hydraulic oil tank body
3026	2.07.0008.1.01.1	LO	252351-156	HYDRAULIC POWER MAINTENANCE KIT, SMALL
3027	2.07.0009.1.01.2	LO	252351-157	HYDRAULIC POWER MAINTENANCE KIT, LARGE
3028	2.07.0010.1.01.3	LO	252351-158	HYDRAULIC POWER REPAIR KIT, SMALL
3029	2.07.0011.1.01.4	LO	252351-159	HYDRAULIC POWER REPAIR KIT, LARGE
3030	2.07.0012.1.01.5	LO	252351-160	HYDRAULIC POWER OVERHAUL KIT
3031	2.07.0013.1.01.6	LO	252351-161	HYDRAULIC BUGGY SYSTEM AINTENANCE KIT, SMALL
3032	2.07.0014.1.01.7	LO	252351-162	HYDRAULIC BUGGY SYSTEM AINTENANCE KIT, LARGE
3033	2.07.0015.1.01.8	LO	252351-163	HYDRAULIC BUGGY SYSTEM REPAIR KIT, SMALL
3034	2.07.0016.1.01.9	LO	252351-164	HYDRAULIC BUGGY SYSTEM REPAIR KIT, LARGE
3035	2.07.0017.1.01.1	LO	252351-165	HYDRAULIC BUGGY SYSTEM OVERHAUL KIT
3036	2.07.0018.1.01.2	LO	151959	COOLER OIL 250PSI 200GPM; 4861C 12FORB 2000PSI
3037	2.07.0019.1.01.3	LO	247736	COOLER OIL 250PSI 150GPM; 4061C 12FORB 1650PSI
3038	2.07.0020.1.01.4	LO	114901	CLAMP ACCUMULATOR HD; 9.1 IN DIA BLADDER STYLE
3039	2.07.0021.1.01.5	LO	125684	BREATHER TANK KLEENVENT 10 GALLON NOMINAL SIZE
3040	2.07.0022.1.01.6	LO	161652	MANIFOLD MACH 5000P 160G; HYD SLIPIN SIZE 32 2461C
3041	2.07.0023.1.01.7	LO	A24453	BREATHER

3042	2.07.0024.1.01.8	LO	252351-205	HYDRAULIC REPAIR KIT - SMALL
3043	2.07.0025.1.01.9	LO	H17401	FLANGE SPLIT CLAMP HALF 1.00 3000 PSI CODE 61
3044	2.07.0026.1.01.1	LO	252351-195	WATER SYSTEM MAINTENANCE KIT, SMALL
3045	2.07.0027.1.01.2	LO	252351-196	WATER SYSTEM MAINTENANCE KIT, LARGE
3046	2.07.0028.1.01.3	LO	252351-197	WATER SYSTEM REPAIR KIT, SMALL
3047	2.07.0029.1.01.4	LO	252351-198	WATER SYSTEM REPAIR KIT, LARGE
3048	2.07.0030.1.01.5	LO	252351-126	WATER SYSTEM MAINTENANCE KIT, SMALL
3049	2.07.0031.1.01.6	LO	252351-127	WATER SYSTEM MAINTENANCE KIT, LARGE
3050	2.07.0032.1.01.7	LO	252351-128	WATER SYSTEM REPAIR KIT, SMALL
3051	2.07.0033.1.01.8	LO	252351-129	WATER SYSTEM REPAIR KIT, LARGE
3052	2.07.0034.1.01.9	LO	252351-10	WATER SYSTEM KIT #1
3053	2.07.0035.1.01.1	LO	111540	WATER PUMP REPAIR KIT
3054	2.07.0036.1.01.2	LO	252351-56	WATER SYSTEM KIT #2
3055	2.07.0037.1.01.3	LO	214604	NOZZLE FIRE HOSE; 16FBSPP 8/15/30 GPM
3056	2.07.0038.1.01.4	LO	252351-218	WATER SYSTEM KIT
3057	2.07.0039.1.01.5	LO	156658	FAN OILER COOLER
3058	2.07.0040.1.01.6	LO	252351-214	OIL COOLER KIT
3059	2.07.0041.1.01.7	PL	62.05.6000.11	COOLING UNIT
3060	2.07.0042.1.01.8	PL	HY155.13 (SUB HY155.01)	LOCKING BLOCK
3061	2.07.0043.1.01.9	CR	5031130	HYD OIL COOLER
3062	2.07.0044.1.01.1	PL	HY-A.44.028-01	Brake slide mounting
3063	2.07.0045.1.01.2	PL	HY151.202	Hub regulator
3064	2.07.0046.1.01.3	PL	NSE-4 INCH	HYRAULIC COUPLING
3065	2.07.0047.1.01.4	PL	HY157.105/SILENCE	HYD OIL COOLER
3066	2.07.0048.1.01.5	PL	HY-M10RMJJJ	Mono CONTROL BLOCK
3067	2.07.0049.1.01.6	PL	HY-M10RMJE	Mono CONTROL BLOCK
3068	2.07.0050.1.01.7	PL	HY157.99	EMERGENCY OPERATOR KNOB
3069	2.08.0001.1.01.4	PL	455800001	BREATHER
3070	2.08.0002.1.01.5	PL	1181061 SUB. 1175893	FILTER ELEMENT
3071	2.08.0003.1.01.6	PL	2040SM	FILTER ELEMENT
3072	2.08.0004.1.01.7	PL	62.05.1000.113 ES	FILTER ELEMENT
3073	2.08.0005.1.01.8	PL	62.05.1000.187	FILTER ELEMENT
3074	2.08.0006.1.01.9	PL	62.05.1000.256	FILTER ELEMENT
3075	2.08.0007.1.01.1	PL	62.05.1000.270	FILTER ELEMENT
3076	2.08.0008.1.01.2	PL	62.05.1000.271	FILTER COMPLETE WITH ELEMENT
3077	2.08.0009.1.01.3	PL	62.05.1000.272	FILTER ELEMENT OF CONTROL PRESSURE FOR BCM
3078	2.08.0010.1.01.4	PL	62.05.1000.273	FILTER ELEMENT
3079	2.08.0011.1.01.5	PL	62.05.1000.293	FILTER ELEMENT
3080	2.08.0012.1.01.6	PL	62.05.1000.296	FILTER ELEMENT
3081	2.08.0013.1.01.7	PL	62.05.1000.424	FILTER ELEMENT
3082	2.08.0014.1.01.8	PL	62.05.1000.424/KOPF	FILTER HEAD
3083	2.08.0015.1.01.9	PL	62.05.1000.471	FILTER ELEMENT
3084	2.08.0016.1.01.1	PL	62.05.2000.95	HYDRAULIC FILTER
3085	2.08.0017.1.01.2	PL	62.05.2000.95ES	FILTER ELEMENT
3086	2.08.0018.1.01.3	PL	62.05.2000.96	FILTER ELEMENT
3087	2.08.0019.1.01.4	PL	62.05.4000.247	MAIN GEAR LUB FILTER FOR BCM
3088	2.08.0020.1.01.5	PL	62.05.4000.247ES	FILTER ELEMENT
3089	2.08.0021.1.01.6	PL	62.05.4000.274 ES	FILTER ELEMENT
3090	2.08.0022.1.01.7		Repeated item	
3091	2.08.0023.1.01.8	PL	64.04.3000.87	FILTER ELEMENT
3092	2.08.0024.1.01.9		Repeated item	
3093	2.08.0025.1.01.1	KA	CCH-802-FUI	SUCTION FILTER
3094	2.08.0026.1.01.2	KA	CRC4-10FUI	RETURN FILTER
3095	2.08.0027.1.01.3	PL	DL.40.60.3E	FILTER ELEMENT FOR SERVO VALVE
3096	2.08.0028.1.01.4	PL	DL.40.60.H	SERVO FILTER COMPLETE
3097	2.08.0029.1.01.5	PL	EA1392	FILTER ELEMENT
3098	2.08.0030.1.01.6	PL	HYS.501.90.10 ES	FILTER ELEMENT FOR HYD VARIABLE PUMP
3099	2.08.0031.1.01.7	PL	HYR.501.330.25ES	RETURN FILTER
3100	2.08.0032.1.01.8	PL	HY151.187ES	FILTER ELEMENT
3101	2.08.0033.1.01.9	PL	HY-501.03.05/ES	FILTER ELEMENT
3102	2.08.0034.1.01.1	PL	HYD 501.225.10 / ES	FILTER ELEMENT
3103	2.08.0035.1.01.2	PL	HYD.501.1	PROPORTIONALE FILTER HOUSING BODY
3104	2.08.0036.1.01.3	PL	HY-D501.10.10/H300W/ES FILTEREINSATZ	FILTER ELEMENT
3105	2.08.0037.1.01.4	PL	HY-D501.225.25DS	SEAL KIT
3106	2.08.0038.1.01.5	PL	HY-D501.225.25ES	FILTER ELEMENT
3107	2.08.0039.1.01.6	PL	HY-D501.32.10/DS	SEAL KIT
3108	2.08.0040.1.01.7	PL	HY-D501.32.10/ES	FILTER
3109	2.08.0041.1.01.8	PL	HY-D501.5.10ES	FILTER ELEMENT

3110	2.08.0042.1.01.9	PL	HY-D501.60.10	FILTER
3111	2.08.0043.1.01.1	PL	HYD-501-225-25H	FILTER BODY
3112	2.08.0044.1.01.2	PL	HYD-501-32-10H	FILTER
3113	2.08.0045.1.01.3	PL	HY-D506.10.30	FILTER
3114	2.08.0046.1.01.4	PL	HY-D506.10.30ES	FILTER ELEMENT
3115	2.08.0047.1.01.5	PL	HY-D507.140.10/ES	FILTER CARTRIDGE
3116	2.08.0048.1.01.6	PL	HY-E507.800.03 SUB. ELFL3-10-1.0	FILTER
3117	2.08.0049.1.01.7	PL	HY-L507.1600.3 SUB. 62.05.1000.425	VENTILATOR FILTER
3118	2.08.0050.1.01.8	PL	HY-R501.330.10	RETURN FLOW FILTER COMPLETE
3119	2.08.0051.1.01.9	PL	HY-R501.330.10A/ES	FILTER ELEMENT
3120	2.08.0052.1.01.1	PL	HY-R501.330.10ES	FILTER ELEMENT
3121	2.08.0053.1.01.2	PL	HY-R501.330.25	RETURN FLOW FILTER COMPLETE
3122	2.08.0054.1.01.3		Repeated item	
3123	2.08.0055.1.01.4	PL	HY-R507.05.01H SUB. HY-R508.05.01	FILTER
3124	2.08.0056.1.01.5		Repeated item	
3125	2.08.0057.1.01.6	PL	HY-R508.05.01DS	SEAL KIT
3126	2.08.0058.1.01.7	PL	HY-S501.160.P10ES	FILTER ELEMENT
3127	2.08.0059.1.01.8	PL	HY-S501.160.P10H	FILTER
3128	2.08.0060.1.01.9	PL	HY-S501.180.10ES	FILTER ELEMENT
3129	2.08.0061.1.01.1	PL	HY-S501.300.P10H	FILTER
3130	2.08.0062.1.01.2	PL	HY-S501.300.P10H/ES	FILTER ELEMENT
3131	2.08.0063.1.01.3	PL	HY-S501.350.200ES	FILTER ELEMENT
3132	2.08.0064.1.01.4	PL	HY-S501.360.150	SUCTION FILTER COMPLETE
3133	2.08.0065.1.01.5	PL	HY-S501.360.150ES	FILTER ELEMENT
3134	2.08.0066.1.01.6	PL	HY-S501.460.150	SUCTION FILTER COMPLETE
3135	2.08.0067.1.01.7	PL	HY-S501.460.150/DS	SEAL KIT
3136	2.08.0068.1.01.8	PL	HY-S501.460.150ES	FILTER
3137	2.08.0069.1.01.9	PL	HY-S501.560.150ES	FILTER ELEMENT
3138	2.08.0070.1.01.1		Repeated item	
3139	2.08.0071.1.01.2	PL	HYS-501-160-P10	FILTER BODY
3140	2.08.0072.1.01.3	KE	140732	BRM FILTER
3141	2.08.0073.1.01.4	KE	126664	SUCTION STRAINER ELEMENT
3142	2.08.0074.1.01.5	KE	176664	SUCTION FILTER FOR BRM
3143	2.08.0075.1.01.6	KE	735438	CORE CIRCUIT FILTER CHOKE
3144	2.08.0076.1.01.7	AM	F1030/6	HYD FILTER ASSY FOR TROLLEY T28
3145	2.08.0077.1.01.8		Shifted to Annexure-II	
3146	2.08.0078.1.01.9		Shifted to Annexure-II	
3147	2.08.0079.1.01.1	AM	FBD CA-30/6	HYD. FILTER FOR T-28
3148	2.08.0080.1.01.2		Shifted to Annexure-II	
3149	2.08.0081.1.01.3	PH	81400750	FILTER ELEMENT FOR CRT-5633 (STAINER)
3150	2.08.0082.1.01.4	PH	4P1	FILTER BREATHER
3151	2.08.0083.1.01.5	PH	4P2	RETURN FILTER ASSEMBLY
3152	2.08.0084.1.01.6	PH	91550014 (6884505)	DDGB FILTER ASSEMBLY
3153	2.08.0085.1.01.7	LO	100550	CARTR RELIEF 100-3000 SUN T3A CAVITY 50 GPM
3154	2.08.0086.1.01.8	LO	106021	BREATHER PRESS/VAC; 5 PSI/0.3PSI/.75 MNPT
3155	2.08.0087.1.01.9	LO	124239	FILTER HYD 100PSI 100GPM 2461C TANK BPS VIS GA
3156	2.08.0088.1.01.1	LO	132615	FILTER ASSY COOLING FAN
3157	2.08.0089.1.01.2	LO	142988	FILTER HYD 3000PSI 100GPM; 2461C BYP SWITCH
3158	2.08.0090.1.01.3	LO	A44044	STRAINER Y-TYPE 1.50 NPT 20 MESH SS SCREEN
3159	2.08.0091.1.01.4	PL	BF8X-F00-3MY SUBSTITUTE FLE.001/4"ZG.1234D	FILTER
3160	2.08.0092.1.01.5	PL	62.05.1000.427	FILTER
3161	2.08.0093.1.01.6	PL	62.05.1000.428	FILTER ELEMENT
3162	2.08.0094.1.01.7		Repeated item	
3163	2.08.0095.1.01.8		Repeated item	
3164	2.08.0096.1.01.9		Repeated item	
3165	2.08.0097.1.01.1	PL	75250/597/MUL	VENTILATOR
3166	2.08.0098.1.01.2	PL	HY-D501.225.25H	Z.F.FILTER COMPLETE
3167	2.08.0099.1.01.3	PL	HY-D501.225.10A-B/ES	FILTER ELEMENT
3168	2.08.0100.1.01.4		Repeated item	
3169	2.08.0101.1.01.5		Shifted to Ann II	
3170	2.08.0102.1.01.6		Repeated item	
3171	2.08.0103.1.01.7		Repeated item	
3172	2.08.0104.1.01.8		Repeated item	
3173	2.08.0105.1.01.9	PL	SFS330	Filter Element
3174	2.08.0106.1.01.1	PL	ELFP4F3W1.0/-03061632 or ELFP4F10W1.0/3061632-MS	FILTER ELEMENT
3175	2.08.0107.1.01.2	PL	HY721X78/SPEISEFILTER/ES	FILTER ELEMENT (VARIABLE PUMP)
3176	2.08.0108.1.01.3	PL	HY-D501.10.30/H300W	FILTER ELEMENT COMPLETE

3177	2.08.0109.1.01.4	PL	HY-D507.140.10	FILTER ELEMENT COMPLETE
3178	2.08.0110.1.01.5	PL	HY-S501.560.150H and Sub part no. HY-S501.560.150H	SUCTION FILTER COMPLETE
3179	2.08.0111.1.01.6	PL	S80/120 Sub.S80/150	FILTER ELEMENT
3180	2.08.0112.1.01.7	PL	628-36724-1	FILTER
3181	2.08.0113.1.01.8		Shifted to Ann II	
3182	2.08.0114.1.01.9	PL	HY.L501.6000.10	Aeration filter
3183	2.08.0115.1.01.1	GE	DFBN/HC330TF5D1.0-L24	High pressure filter
3184	2.08.0116.1.01.2	GE	DFBN/HC60G10D1.1- L24	High pressure filter-2
3185	2.08.0117.1.01.3	GE	GE770017	Oil suction filter-1
3186	2.08.0118.1.01.4	GE	GE770020	Oil suction filter-2
3187	2.08.0119.1.01.5	GE	GE770012	Oil return filter
3188	2.08.0120.1.01.6	GE	BD-YS-20	Piping filter-1
3189	2.08.0121.1.01.7	GE	BD-YS-25	Piping filter-2
3190	2.08.0122.1.01.8	CR	0240 D 010 ON	FILTER CARTRIDGE-1-1
3191	2.08.0123.1.01.9	CR	0330R025W	FILTER CARTRIDGE-2
3192	2.08.0124.1.01.1	CR	0160 D 010 ON	FILTER CARTRIDGE-3
3193	2.08.0125.1.01.2	CR	AND95G10B	FILTER CARTRIDGE-4-1
3194	2.08.0126.1.01.3	CR	0950 R 010 ON	FILTER CARTRIDGE-5-1
3195	2.08.0127.1.01.4	CR	0500 D 010 ON	FILTER CARTRIDGE-6
3196	2.08.0128.1.01.5	CR	ELFL P 3 F 03 W 1.0	FILTER CARTRIDGE-9
3197	2.08.0129.1.01.6	CR	QUQ2.5-20X3.0	FILTER-1
3198	2.08.0130.1.01.7	CR	1340130	FILTER-2
3199	2.08.0131.1.01.8	CR	2201523	FILTER-3
3200	2.08.0132.1.01.9	AM	60700001	Hydraulic Filter (CA160/3)
3201	2.08.0133.1.01.1	AM	60701005	Hydraulic Filter (CA500/3)
3202	2.08.0134.1.01.2	PH	4P33	Return Filter element
3203	2.08.0135.1.01.3	CR	40093869	ZF oil filter
3204	2.08.0136.1.01.4	CR	40091493	Suction filter
3205	2.08.0137.1.01.5	CR	40091492	Suction filter
3206	2.08.0138.1.01.6	CR	40095474	Return filter
3207	2.08.0139.1.01.7	CR	40095613	Servo filter
3208	2.08.0140.1.01.8	CR	40093909	Proportional filter
3209	2.08.0141.1.01.9	CR	YB-31 338001	ZF FILTER
3210	2.08.0142.1.01.1	CR	80242980176	Online filtration
3211	2.08.0143.1.01.2	PL	0501.333.764	ZF FILTER ELEMENT
3212	2.08.0144.1.01.3		Shifted to Ann -II	
3213	2.08.0145.1.01.4		Shifted to Ann -II	
3214	2.08.0146.1.01.5	PL	HY-R507.05.01HES	Hydraulic Superfine Filter
3215	2.08.0147.1.01.6	PL	OF5S10P6N2B05ES	Filtering unit
3216	2.08.0148.1.01.7	PL	1300 R 005 ON/-KB-387 or 1300R005BN3HC/-KB-SO387	Filtration unit filter cartridge
3217	2.08.0149.1.01.8	PL	HY-D507.140.10	Filter complete
3218	2.08.0150.1.01.9	PL	HY-D501.32.10H	Filter complete
3219	2.08.0151.1.01.1	PL	HY-D501.225.10A-B	Filter complete
3220	2.08.0152.1.01.2	PL	HY-D506.10.30H-300W OR HY- D506.10.30H-350W OR HY157.87	FILTER ELEMENT COMPLETE
3221	2.08.0153.1.01.3	PL	62.05.1000.113	Filter
3222	2.08.0154.1.01.4	PL	501333764	Pressure Filter
3223	2.08.0155.1.01.5	PL	62.05.1000.269A	FILTER ELEMENT (DUCT) COMPLETE
3224	2.08.0156.1.01.6	PL	62.05.1000.470A	FILTER ELEMENT COMPLETE
3225	2.08.0157.1.01.7	PL	HY501.03.05	OIL FILTER UNIT
3226	2.08.0158.1.01.8	PL	HY-D501.10.30/H300W/ES	FILTER ELEMENT
3227	2.08.0159.1.01.9	CRCC HTEC	SE360.130.F0	Suction filter
3228	2.08.0160.1.01.1	CRCC HTEC	SE460.130.S0	Suction filter
3229	2.08.0161.1.01.2	CRCC HTEC	RF ON 330D L 10FD 1.X/-2M0	Return filter
3230	2.08.0162.1.01.3	CRCC HTEC	DF ON 60 T C 10 CD 1.1/-2M0	Propotional filter
3231	2.08.0163.1.01.4	CRCC HTEC	DF ON 240 T E 10 CD 1.1/-2M0	Servo Filter
3232	2.08.0164.1.01.5	CRCC HTEC	OF5M30V1U2N5DM005E	Emergency back up oil filter
3233	2.08.0165.1.01.6	CRCC HTEC	0060 D 010 ON	Propotional filter element
3234	2.08.0166.1.01.7	CRCC HTEC	0240 D 010 ON	Servo Filter element
3235	2.08.0167.1.01.8	CRCC HTEC	N5DM005	Emergency back up oil filter element
3236	2.08.0168.1.01.9	KE	733692	FILTER (CASE DRAIN) ASSY
3237	2.08.0169.1.01.1	KE	714374	FILTER (CHARGE FLOW) ASSY
3238	2.08.0170.1.01.2	LO	252351-81	FILTER KIT #1
3239	2.08.0171.1.01.3	LO	A93360	ELEMENT FILTER KW WATER REMOVAL
3240	2.08.0172.1.01.4	PL	62.05.1000.269	DUCT FILTER
3241	2.08.0173.1.01.5	PL	62.05.1000.292	FILTER
3242	2.08.0174.1.01.6	HA	0-3351002-0-05	SUCTION FILTER IN TANK
3243	2.08.0175.1.01.7	PL	64.05.1000.141	FILTER ASSY
3244	2.08.0176.1.01.8	KA	RSC 410FVIFS/RSC 410FVIFS SUB RKT 0800 UMC 020 VXBB LXN VVXX1	FILTER ELEMENT (RETURN VPR)
3245	2.08.0177.1.01.9	CR	YB31 338 001	ZF Filter
3246	2.08.0178.1.01.1	CR	N5DM005	Filter element(Emergency back up)

3247	2.08.0179.1.01.2	CR	0-3353001-0-04	HYDRAULIC FILTER PRESSURE Assly
3248	2.08.0180.1.01.3	PL	HY-D501.225.10A-B/ES	FILTER ELEMENT
3249	2.08.0181.1.01.4	PL	HY-S501.300.P10H	Filter complete
3250	2.08.0182.1.01.5	CR	40097603	Oil filter
3251	2.08.0183.1.01.6	CR	40102325	Deoiling unit
3252	2.08.0184.1.01.7	CR	40103002	Drying agent
3253	2.08.0185.1.01.8	CR	40103007	Filter cartridge
3254	2.08.0186.1.01.9	CR	40103008	Filter cartridge
3255	2.08.0187.1.01.1	CR	40103009	Filter cartridge
3256	2.08.0188.1.01.2	CR	40103013	Filter cartridge
3257	2.08.0189.1.01.3	HA	F-I-871	Hyd Filter Crane (FASSI Make)
3258	2.08.0190.1.01.4	SI	C100000113-01-09-01	Hyd Return filter element
3259	2.08.0191.1.01.5	COLMAR	H3019090	Hydraulic Suction Filter
3260	2.09.0001.1.01.5	PL	100,97X5,33-N-DIN-3371-NBR90	SEAL SET EXTRA LIFTING CYL. O,RING
3261	2.09.0002.1.01.6	PL	62.05.1000.338DS	SEAL KIT (FOR BCM ONLY)
3262	2.09.0003.1.01.7	PL	62.05.1000.374/DS	SEAL KIT (FOR BCM ONLY)
3263	2.09.0004.1.01.8	PL	62.05.2000.111/DS	SEAL KIT (FOR BCM ONLY)
3264	2.09.0005.1.01.9	PL	62.05.3000.300DS	SEAL KIT (FOR BCM ONLY)
3265	2.09.0006.1.01.1	PL	62.05.4000.241/DS	SEAL KIT (FOR BCM ONLY)
3266	2.09.0007.1.01.2	PL	62.05.4000.254/DS	SEAL KIT (FOR BCM ONLY)
3267	2.09.0008.1.01.3	PL	64.03.4000.114/DS	SEAL KIT (FOR BCM ONLY)
3268	2.09.0009.1.01.4		Shifted to Ann II	
3269	2.09.0010.1.01.5	PL	EL-T76.10MO	REPAIR SET
3270	2.09.0011.1.01.6	PL	HY155.11DS	SEAL KIT
3271	2.09.0012.1.01.7	PL	HY156.09DS	SEAL KIT
3272	2.09.0013.1.01.8	PL	HY72SX/DS	SEAL KIT
3273	2.09.0014.1.01.9	PL	HY916N/DS	SEAL KIT
3274	2.09.0015.1.01.1	PL	HY925N12.5/D-DS	SEAL KIT
3275	2.09.0016.1.01.2	PL	HY938X55/MS-DS	SEAL KIT
3276	2.09.0017.1.01.3	PL	HZ02.080.050.001	SEAL KIT (FOR BCM ONLY)
3277	2.09.0018.1.01.4	PL	HZ02.040.025	SEAL KIT (FOR BCM ONLY)
3278	2.09.0019.1.01.5	PL	HZ02.063.036	SEAL KIT (FOR BCM ONLY)
3279	2.09.0020.1.01.6	PL	HZ02.080.036	SEAL KIT (FOR BCM ONLY)
3280	2.09.0021.1.01.7	PL	HZ02.100.045	SEAL KIT (FOR BCM ONLY)
3281	2.09.0022.1.01.8	PL	HZ02.100.050	SEAL KIT (FOR BCM ONLY)
3282	2.09.0023.1.01.9	PL	HZ02.125.050	SEAL KIT (FOR BCM ONLY)
3283	2.09.0024.1.01.1	PL	NZ01.050	SEAL KIT (FOR BCM ONLY)
3284	2.09.0025.1.01.2	PL	NZ01.063	SEAL KIT (FOR BCM ONLY)
3285	2.09.0026.1.01.3	PL	NZ01.080	SEAL KIT (FOR BCM ONLY)
3286	2.09.0027.1.01.4	PL	NZ01.100	SEAL KIT (FOR BCM ONLY)
3287	2.09.0028.1.01.5	PL	NZ01.125	SEAL KIT (FOR BCM ONLY)
3288	2.09.0029.1.01.6	AM	ORL050005 &6S	SEAL KIT CHAIN TENSION CYL EURO TRACK
3289	2.09.0030.1.01.7	PL	S14-09944	SEAL KIT (FOR BCM ONLY)
3290	2.09.0031.1.01.8	PL	UD 50-3200 DS	SEAL KIT(FOR TAMPERS)
3291	2.09.0032.1.01.9	PL	UD50.100 DS	SEAL KIT(FOR TAMPERS)
3292	2.09.0033.1.01.1	PL	UD50.1900 DS	SEAL SET FOR SATELLITE AXLE SUPPORT CYL.
3293	2.09.0034.1.01.2	PL	UD50.1950 ADS	SEAL SET FOR MACHINE SUPPORT CYL.
3294	2.09.0035.1.01.3	PL	UD50.200 DS	SEAL KIT(FOR TAMPERS)
3295	2.09.0036.1.01.4	PL	UD50.2200 DS	SEAL SET FOR WHEEL SUPPORT CYL.
3296	2.09.0037.1.01.5	PL	UD50.2800 DS	SEAL SET FOR AXLE SUPPORT CYL.
3297	2.09.0038.1.01.6	PL	UD50.550 DS	SEAL KIT(FOR TAMPERS)
3298	2.09.0039.1.01.7	KE	80829	SEAL SET FOR BRM
3299	2.09.0040.1.01.8	KE	174975	SEAL SET(FOR BRM)
3300	2.09.0041.1.01.9	KE	218537	SEAL KIT BRM
3301	2.09.0042.1.01.1	KE	350644	OIL SEAL
3302	2.09.0043.1.01.2	KE	657884	OIL SEAL
3303	2.09.0044.1.01.3	KE	660167	SEAL KIT
3304	2.09.0045.1.01.4	KE	663059	SEAL SHAFT FOR BRM
3305	2.09.0046.1.01.5	AM	0016057S	SEAL SET FOR WHEEL CYL
3306	2.09.0047.1.01.6	AM	0017012S	SEAL SET VERTICAL / HORIZONTAL CYL. FOR T28
3307	2.09.0048.1.01.7	AM	0017018S	SEAL SET FOR VERTICAL CYL T 28
3308	2.09.0049.1.01.8	AM	0017159 S	SEAL SET FOR COMMANDO CYL T 28
3309	2.09.0050.1.01.9	AM	0017311 S	SEAL SET FOR CLAMP LIFTING CYL T28
3310	2.09.0051.1.01.1	AM	0021013/0170125	SEAL SET FOR TROLLEY LILFT T 28
3311	2.09.0052.1.01.2	AM	160575	SEAL SET WHEEL CYL T28
3312	2.09.0053.1.01.3	AM	90179016	SEAL SET FOR WHEEL CYLINDER
3313	2.09.0054.1.01.4	AM	90179023	SEAL SET
3314	2.09.0055.1.01.5	PH	30211015	RETAINER OIL SEAL
3315	2.09.0056.1.01.6	PH	30212012	SPACER SEAL

3316	2.09.0057.1.01.7	PH	1P15	SEAL SET FOR SLEW CYL
3317	2.09.0058.1.01.8	PH	1P4	SEAL SET FOR SLEWING CYLINDER
3318	2.09.0059.1.01.9	PH	2P12	SEAL SET FOR COLUMN CYL UTV CRANE
3319	2.09.0060.1.01.1	PH	2P12S	SEAL SET FOR UTV COLUMN CYL
3320	2.09.0061.1.01.2	PH	3P19	SEAL FOR 3RD EXT BOOM CYL UTV
3321	2.09.0062.1.01.3	PH	3P19S	SEAL SET FOR 3RD EXTENSION CYLINDER
3322	2.09.0063.1.01.4	PH	3P20	SEAL FRO 2ND EXT BOOM CYL UTV
3323	2.09.0064.1.01.5	PH	3P20-S	SEAL SET FOR 2ND EXTENSION CYLINDER
3324	2.09.0065.1.01.6	PH	3P27	SEAL FOR 1ST EXT BOOM CYL UTV
3325	2.09.0066.1.01.7	PH	3P27S	SEAL SET FOR 1ST EXTENSION CYLINDER
3326	2.09.0067.1.01.8	PH	3P28S	SEAL SET FOR BOOM CYL UTV
3327	2.09.0068.1.01.9	PH	5P10S	SEAL SET FOR SLEW CYLINDER
3328	2.09.0069.1.01.1	PH	8P13	SEAL SET FOR 1ST BOOM CYL
3329	2.09.0070.1.01.2	PH	8P5	SEAL SET FOR 3RD BOOM CYL
3330	2.09.0071.1.01.3	PH	8P8	SEAL SET FOR 2ND BOOM CYL
3331	2.09.0072.1.01.4	LO	124942	SEAL KIT CYLINDER HYTREL GLYCOL COMPATABLE
3332	2.09.0073.1.01.5	LO	124943	SEAL KIT CYLINDER HYTREL GLYCOL COMPATABLE
3333	2.09.0074.1.01.6	LO	124945	SEAL KIT CYLINDER HYTREL GLYCOL COMPATABLE
3334	2.09.0075.1.01.7	PL	62.05.2000.43DS	SEAL KIT
3335	2.09.0076.1.01.8	PL	62.05.3000.184DS	SEAL KIT
3336	2.09.0077.1.01.9	PL	90X75X1.6B1MS	SHIM
3337	2.09.0078.1.01.1	PL	A2/100X112X12/7-PU	WIPER
3338	2.09.0079.1.01.2	PL	A60X68X2DIN76030CU	SEAL RING
3339	2.09.0080.1.01.3	PL	HZ02.080.040	SEAL SET
3340	2.09.0081.1.01.4	PL	HZ05.050.025	PISTON
3341	2.09.0082.1.01.5	PL	HZ05.080.045	PISTON
3342	2.09.0083.1.01.6	PL	HZ05.125.050	PISTON
3343	2.09.0084.1.01.7	KA	GC1023.07.62.000	Seal For Hydraulic Cylinder
3344	2.09.0085.1.01.8	KA	1023.41.08.000-01	Seal For Hydraulic Cylinder
3345	2.09.0086.1.01.9	KA	1023.41.10.000.01	Seal For Hydraulic Cylinder
3346	2.09.0087.1.01.1	CR	FA80.92.2.7.2/12	Scrapper seal-7
3347	2.09.0088.1.01.2	CR	GS80.95.1.6.3	Stern Seal-8
3348	2.09.0089.1.01.3	CR	TPM110.85.22.4.6.35	Combined Seal-5
3349	2.09.0090.1.01.4	CR	FA40.48.6.5/7	Scrapper seal-5
3350	2.09.0091.1.01.5	CR	GS40.50.7.4.2	Stern seal-6
3351	2.09.0092.1.01.6	CR	FA36.44.6.5/7	Scrapper seal-6
3352	2.09.0093.1.01.7	CR	TPM63.47.18.4.6.35	Combined Seal-4
3353	2.09.0094.1.01.8	CR	GS36.46.7.4.2	Stern Seal-7
3354	2.09.0095.1.01.9	CR	FA70.80.6.5.3/7	Scrapper seal-8
3355	2.09.0096.1.01.1	CR	GS70.85.1.6.3	Stern Seal-9
3356	2.09.0097.1.01.2	CR	TPM100.75.22.4.6.35	Combined Seal-6
3357	2.09.0098.1.01.3	CR	GS45.60.1.6.3	STERN SEAL-1
3358	2.09.0099.1.01.4	CR	TPM80.60.22.4.6.35	COMBINED SEAL-1
3359	2.09.0100.1.01.5	CR	FK45.56.8.5/9	SCRAPPER SEAL-2
3360	2.09.0101.1.01.6	CR	TPM50.40.12.5.4	Combined Seal-2
3361	2.09.0102.1.01.7	CR	TPM90.70.22.4.6.35	Combined Seal-12
3362	2.09.0103.1.01.8	CR	FA50.60.5/7	Scrapper Seal-15
3363	2.09.0104.1.01.9	CR	GS45.55.7.4.2	Stern Seal-12
3364	2.09.0105.1.01.1	CR	FA45.55.5/7	Scrapper Seal-12
3365	2.09.0106.1.01.2	CR	FA32.40.5/7	Scrapper seal-9
3366	2.09.0107.1.01.3	CR	GS32.42.7.4.2	Stern Seal-10
3367	2.09.0108.1.01.4	CR	TPM63.48.20.5	Combined Seal-7
3368	2.09.0109.1.01.5	GE	CDCK16A-56-02-07	Gasket-1
3369	2.09.0110.1.01.6	GE	GB/T97.3 36	Gasket-2
3370	2.09.0111.1.01.7	GE	HZ01.063(HD01.063)+HZD02.063.036	Lifting cylinder seal
3371	2.09.0112.1.01.8	CR	40100378-048	SEAL, OIL
3372	2.09.0113.1.01.9	CR	40100378-052	SEAL, OIL-2
3373	2.09.0114.1.01.1	CR	82008021478	piston seal
3374	2.09.0115.1.01.2	CR	82008021479	cylinder head seal
3375	2.09.0116.1.01.3	CR	82008021488	piston seal
3376	2.09.0117.1.01.4	CR	82008021489	cylinder head seal
3377	2.09.0118.1.01.5	CR	82008021504	piston seal
3378	2.09.0119.1.01.6	CR	82008021505	cylinder head seal
3379	2.09.0120.1.01.7	CR	82010040052	piston seal
3380	2.09.0121.1.01.8	CR	82010040053	cylinder head seal
3381	2.09.0122.1.01.9	CR	40095761	LIFTING/LINING CYLINDER SEAL
3382	2.09.0123.1.01.1	CR	40095751	CLAMP OIL CYLINDER SEAL
3383	2.09.0124.1.01.2	CR	40095760	LIFTING CYLINDER SEAL
3384	2.09.0125.1.01.3	CR	40095762	LINING CYLINDER SEAL
3385	2.09.0126.1.01.4	CR	40095753	LIFTING HOOK SIDEWAYS SEAL

3386	2.09.0127.1.01.5	CR	40095752	TOOL TILTING CYLINDER SEAL
3387	2.09.0128.1.01.6	CR	40095754	TAMPING BAT OIL SEAL
3388	2.09.0129.1.01.7	CR	40095755	OIL CYLINDER SEALING ELEMENT
3389	2.09.0130.1.01.8	CR	40095759	OIL CYLINDER SEALING ELEMENT
3390	2.09.0131.1.01.9	CR	40095758	OIL CYLINDER SEALING ELEMENT
3391	2.09.0132.1.01.1	CR	40095757	OIL CYLINDER SEALING ELEMENT
3392	2.09.0133.1.01.2	CR	40095756	OIL CYLINDER SEALING ELEMENT
3393	2.09.0134.1.01.3	CR	41028010	SQUEEZING CYLINDER SEAL
3394	2.09.0135.1.01.4	CR	57.15.3.53	O ring-13
3395	2.09.0136.1.01.5	CR	60318	O ring-14
3396	2.09.0137.1.01.6	CR	20261425	Plate
3397	2.09.0138.1.01.7	PL	HY-S501.300.P10/DS	Seal kit
3398	2.09.0139.1.01.8	PL	HY-R507.05.01H/DS	seal kit
3399	2.09.0140.1.01.9	PL	HY-D507.140.10/DS	seal kit
3400	2.09.0141.1.01.1	PL	HY-D506.10.30/DS	Seal kit
3401	2.09.0142.1.01.2	Colmar	112500015	KIT SEAL 70/35
3402	2.09.0143.1.01.3	Colmar	112500016	KIT SEAL 70/40
3403	2.09.0144.1.01.4	Colmar	112500017	KIT SEAL 80/60
3404	2.09.0145.1.01.5	Colmar	112500018	KIT SEAL 100/60
3405	2.09.0146.1.01.6	Colmar	112500019	KIT SEAL 140/90
3406	2.09.0147.1.01.7	Colmar	112500020	KIT SEAL 85/70
3407	2.09.0148.1.01.8	Colmar	112500021	KIT SEAL 100/60
3408	2.09.0149.1.01.9	LO	101173	SEAL KIT FOR T-3 AND T-5 CAV BUNA N (FOR VALVES 100506 & 100550)
3409	2.09.0150.1.01.1	LO	140479	SEAL KIT D05 SEAL PLATE WITH O- RINGS
3410	2.09.0151.1.01.2	LO	252351-80	HYDRAULIC VALVE KIT #4
3411	2.09.0152.1.01.3	LO	246599	SEAL KIT D03 BUNA-N
3412	2.09.0153.1.01.4	LO	H100120	O-RING 2.675ID X .103CS AS568-147 70DURO BUNA-N
3413	2.09.0154.1.01.5	LO	H100719	PLUG O-RING BOSS #3 SOCKET HD
3414	2.09.0155.1.01.6	LO	H17527	O-RING 1.296ID X .139CS AS568-219 90DURO BUNA-N
3415	2.09.0156.1.01.7	LO	H18533	O-RING 1.859ID X .139CS AS568-225 90DURO BUNA-N
3416	2.09.0157.1.01.8	LO	H18534	O-RING 2.234ID X .139CS AS568-228 90DURO BUNA-N (O-RING FOR 101683)
3417	2.09.0158.1.01.9	LO	H20942	O-RING .924ID X .116CS AS568-912 90DURO BUNA-N
3418	2.09.0159.1.01.1	LO	H22082	O-RING .239ID X .070CS; AS568-010 70DURO BUNA-N
3419	2.09.0160.1.01.2	LO	H22084	O-RING .364ID X .070CS AS568-012 70DURO BUNA-N
3420	2.09.0161.1.01.3	LO	H22086	O-RING .489ID X .070CS AS568-014 70DURO BUNA-N
3421	2.09.0162.1.01.4	LO	H22104	O-RING .612ID X .103CS AS568-114 70DURO BUNA-N (MIN QTY 10)
3422	2.09.0163.1.01.5	LO	H22149	O-RING 4.484ID X .139CS AS568-246 70DURO BUNA-N
3423	2.09.0164.1.01.6	LO	H22150	O-RING 4.609ID X .139CS AS568-247 70DURO BUNA-N
3424	2.09.0165.1.01.7	LO	H22153	O-RING 4.984ID X .139CS AS568-250 70DURO BUNA-N
3425	2.09.0166.1.01.8	LO	H26773	GROMMET FILTER
3426	2.09.0167.1.01.9	LO	H26776	O-RING 5.234ID X .139CS AS568-252 70DURO BUNA-N
3427	2.09.0168.1.01.1	LO	H79238	O-RING .489ID X .070CS AS568-014 75DURO VITON
3428	2.09.0169.1.01.2	LO	H90932	O-RING .426ID X .070CS AS568-013 70DURO VITON
3429	2.09.0170.1.01.3	LO	H91095	O-RING .364ID X .070CS AS568-012 75DURO VITON
3430	2.09.0171.1.01.4	LO	H22089	O-RING .614ID X .070CS AS568-016 70DURO BUNA-N
3431	2.09.0172.1.01.5	LO	H94205	O-RING 3.359ID X .139CS AS568-237 90DURO BUNA-N
3432	2.09.0173.1.01.6	LO	H30261	O-RING .799ID X .103CS AS568-117 70DURO BUNA-N
3433	2.09.0174.1.01.7	COLMAR	6040464	WRI 215 SEAL RING
3434	2.09.0175.1.01.8	PL	0150A-44-100/01183626	ALTERNATOR 28V, 55A
	2.09.0176.1.01.9	SI	C100000113-01-02-01B	Suction strainer for axial piston pump
3435	2.09.0177.1.01.1	PL	62.05.1000.309DS	SEAL KIT
3436	2.09.0178.1.01.2	PL	62.05.1000.333/DS	SEAL KIT
3437	2.09.0179.1.01.3	PL	62.05.1000.350/DS	SEAL KIT
3438	2.09.0180.1.01.4	PL	62.05.1000.366/DS	SEAL KIT
3439	2.09.0181.1.01.5	PL	62.05.2000.44DS	SEAL KIT
3440	2.09.0182.1.01.6	PL	62.05.3000.486DS	HYD SEAL SET

3441	2.09.0183.1.01.7	PL	62.05.3000.489/DS	SEAL KIT
3442	2.09.0184.1.01.8	PL	62.05.3000.504DS	SEAL KIT
3443	2.09.0185.1.01.9	PL	62.05.4000.301/DS	SEAL KIT
3444	2.09.0186.1.01.1	PL	HY10RSD-DS	HYD SEAL SET
3445	2.09.0187.1.01.2	PL	HY56 R/DS	HYD SEAL SET
3446	2.09.0188.1.01.3	PL	HY155.19DS	HYD SEAL SET
3447	2.09.0189.1.01.4	PL	HY156.06/DS	HYD SEAL SET
3448	2.09.0190.1.01.5	PL	HY156.08H/DS OR HY156.03H/DS	HYD SEAL SET
3449	2.09.0191.1.01.6	PL	HY935.N10P/DS	HYD SEAL SET
3450	2.09.0192.1.01.7	PL	HY953N185-A/DS	HYD SEAL SET
3451	2.09.0193.1.01.8	PL	HY-R501.330.10DS	HYD SEAL SET
3452	2.09.0194.1.01.9	PL	HYS501.360.150DS	HYD SEAL SET
3453	2.09.0195.1.01.1	PL	HYS501.560.150DS	HYD SEAL SET
3454	2.09.0196.1.01.2	PL	HZD02.063.036HW	HYD SEAL SET
3455	2.09.0197.1.01.3	PL	UD50.3900DS	HYD SEAL SET
3456	2.09.0198.1.01.4	PL	64.08.1991DS	SEAL KIT
3457	2.09.0199.1.01.5	PL	HY16RSD-DS	BYPASS FORWARD VALVE (SATELLITE) SEAL KIT
3458	2.09.0200.1.01.6	PL	HY24RSH-DS	SEAL KIT
3459	2.09.0201.1.01.7	PL	HY151.18DS	SEAL KIT
3460	2.09.0202.1.01.8	PL	HY151.19DS	SEAL KIT
3461	2.09.0203.1.01.9	PL	HY157.106/270 DS	SEAL KIT
3462	2.09.0204.1.01.1	PL	HY.511.31DS	HYDRAULIC BRAKE VALVE SEAL SET
3463	2.09.0205.1.01.2	PL	HY511.46 DS	PROPORTIONAL PRESSURE RELIEF VALVE SEAL KIT
3464	2.09.0206.1.01.3	PL	HYA25RPE/DS	PROPORTIONAL CONTROL VALVE (SATELLITE) SEAL KIT
3465	2.09.0207.1.01.4	PH	5577310	O-RING
3466	2.09.0208.1.01.5	PH	30516003	Gasket 0.8TH
3467	2.09.0209.1.01.6	PH	30516017	Gasket
3468	2.09.0210.1.01.7	PH	92000087	Oil Seal ID-100 X OD-120X12
3469	2.09.0211.1.01.8	SI	C100000113-01-02-01B/ SE6352-01-02-01B	SEAL KIT FOR BRIDGE LIFTING CYLINDER
3470	2.09.0212.1.01.9	SI	C100000113-01-03-01B/SE6352-01-03-01B	Seal kit for extra lifting cylinder
3471	2.09.0213.1.01.1	SI	C100000113-01-05-01B/SE6352-01-05-01B	Seal kit for rail clamp cylinder
3472	2.09.0214.1.01.2	SI	C100000113-01-04-01B/SE6352-01-04-01B	Seal kit for brake cylinder
3473	2.09.0215.1.01.3	SI	C100000113-01-11-01	Seal kit for Load holding valve
3474	2.09.0216.1.01.4	PL	BA70-100-10DIN3760-NB	SEAL RING
3475	2.09.0217.1.01.5	PL	BA70-90-10DIN3760-NB	SEAL RING
3476	2.09.0218.1.01.6	PL	NZGB.080.050.0255.1DS	Seal kit
3477	2.09.0219.1.01.7	PL	NZ01.040	Seal kit
3478	2.09.0220.1.01.8	LO	153877	SEAL KIT FOR 124422 NO DWG
3479	2.09.0221.1.01.9	PL	HY600.05DS	Seal kit for Damper Cylinder
3480	2.09.0222.1.01.1	PL	W.33 200ADS	Seal Set (tool tilting)
3481	2.09.0223.1.01.2	PL	HY55R/DS	Seal Kit for tamping unit UP/DN cylinder
3482	2.09.0224.1.01.3	PL	E-150-180DS	Seal kit rail clamp cylinder
3483	2.09.0225.1.01.4	PL	HY56R/DS	Seal kit
3484	2.09.0226.1.01.5	PL	HY152.01DS	Seal kit
3485	2.09.0227.1.01.6	PL	HY-V10/DS	Seal kit
3486	2.09.0228.1.01.7	PL	HYA16-RPE/DS	Seal kit proportional control valve
3487	2.09.0229.1.01.8	PL	HY6RSD-DS	Seal kit valve
3488	2.09.0230.1.01.9	PL	HY511.12DS	Seal kit
	2.09.0231.1.01.1	SI	C100000113-01-02-01	Seal Kit
3489	2.10.0001.1.01.6	PL	5140-20-03.00	PRESSURE GAUGE CONNECTION
3490	2.10.0002.1.01.7	CR	JB/T7940.1-M10X1	STRAIGHT HYDRAULIC GREASE NIPPLE
3491	2.10.0003.1.01.8	CR	30031100	GREASE NIPPLE
3492	2.10.0004.1.01.9	LO	H114571	ADAPTER ELBOW 45 8 MOR/8 MORFS
3493	2.10.0005.1.01.1	LO	H19724	ADAPTER PLUG SAE 04 MOR HEX HEAD
3494	2.10.0006.1.01.2	LO	H19725	ADAPTER PLUG 08MORB
3495	2.10.0007.1.01.3	LO	H20463	ADAPTER STRAIGHT 32 MP/32 MJC
3496	2.10.0008.1.01.4	LO	H33007	ADAPTER PLUG 12 MOR
3497	2.10.0009.1.01.5	LO	H94167	ADAPTER STRAIGHT 08MORB 12MORFS
3498	2.10.0010.1.01.6	LO	H94198	ADAPTER TEE ORFS 8MORFS/8MORFS/8MOR
3499	2.10.0011.1.01.7	LO	A64687	COUPLING SOCKET 2 NPT
3500	2.11.0001.1.01.7	PL	1Z-MS	DIRT COLLECTOR
3501	2.11.0002.1.01.8	PL	62.05.3000.83	DIRT INDICATOR

3502	2.11.0003.1.01.9	PL	64.07.1000.201-A SUBST 64.07.1000.41	DIRT INDICATOR
3503	2.11.0004.1.01.1	PL	64.07.1000.202-A	DIRT INDICATOR
3504	2.11.0005.1.01.2	PL	64.07.1000.269	DIRT INDICATOR
3505	2.11.0006.1.01.3	PL	64.07.1000.270	MANOMETER O.CHROMRS.
3506	2.11.0007.1.01.4	PL	HY151.192	PRESSURE GAUGE PILOT VALVE
3507	2.11.0008.1.01.5	PL	HY154.27 SUB. G/63.250-1/4/B	MONOMETER SWITCH
3508	2.11.0009.1.01.6	PL	HY-154-05H	PRESSURE GAUGE ISOLATOR
3509	2.11.0010.1.01.7	KE	762684	BROOM MOTOR PRESSURE GAUGE
3510	2.11.0011.1.01.8	AM	60720004	PRESSURE GAUGE T-28
3511	2.11.0012.1.01.9	LO	A91362	SIGHT GAUGE ASSY 12 INCH FRT MTG SEALS THERM
3512	2.11.0013.1.01.1	GE	YY224B	Torque Converter oil Pressure gauge
3513	2.11.0014.1.01.2	GE	GE500108	Pressure gauge
3514	2.11.0015.1.01.3	GE	YCS100- II	Duplex pressure gauge
3515	2.11.0016.1.01.4	GE	FLG250YMM10	Liquid level and temperature gauge
3516	2.11.0017.1.01.5	LO	244174	GAUGE, DIFFERENTIAL PRESSURE
3517	2.11.0018.1.01.6	LO	124337	GAUGE PRESS 0-3000 BOTT -4 MOR BRASS W/SILICONE
3518	2.11.0019.1.01.7	LO	125545	GAUGE PRESS 30HG-15 BOTT .25 NPT BRASS
3519	2.11.0020.1.01.8	LO	252351-49	GAUGE REPAIR KIT #3
3520	2.11.0021.1.01.9	PL	PQ72-250/0-10V/0-500BAR	GAUGE
3521	2.11.0022.1.01.1	PL	PQ48-250/0-10V/0-25BAR	GAUGE
3522	2.11.0023.1.01.2	KA	PVA20-A-100-CB	Oil pressure indicator
3523	2.11.0024.1.01.3	KA	PVA20-B-120C-CB	Coolant Temp.indicator
3524	2.11.0025.1.01.4	PL	OVZ-30-5-N5-N-L343	Oval wheel flow meter
3525	2.11.0026.1.01.5	PL	SK28L/G11/4Z	OIL LEVEL SIGHT
3526	2.11.0027.1.01.6	PL	UD64.1350	OIL LEVEL INDICATOR
3527	2.11.0028.1.01.7	PL	WN71.185/190	Oil Level Gauge
3528	2.11.0029.1.01.8	PL	Hy154.23	PRESSURE GAUGE (0-100)
3529	2.11.0030.1.01.9	PL	HY154.28 SUB. G/63.600-1/4/B	PRESSURE GAUGE (0-600)
3530	3.01.0001.1.01.7			Shifted to Ann-II
3531	3.01.0002.1.01.8			Shifted to Ann-II
3532	3.01.0003.1.01.9			Shifted to Ann-II
3533	3.01.0004.1.01.1			Shifted to Ann-II
3534	3.01.0005.1.01.2			Shifted to Ann-II
3535	3.01.0006.1.01.3	PL	90250	VALVE
3536	3.01.0007.1.01.4	PL	90294	VALVE
3537	3.01.0008.1.01.5	PL	90295	VALVE
3538	3.01.0009.1.01.6	PL	275200	PRESSURE REGULATOR
3539	3.01.0010.1.01.7	PL	501313375	SOLENOID VALVE
3540	3.01.0011.1.01.8	PL	185095/024 SUB. NO.170897/024	IDLER VALVE
3541	3.01.0012.1.01.9	PL	90187 DS, 90187 ES, 4324-069-202	KIT FOR AIR DRYER
3542	3.01.0013.1.01.1	PL	90245-A SUB. 90245	OVER FLOW VALVE
3543	3.01.0014.1.01.2	PL	90251-52	VALVE
3544	3.01.0015.1.01.3			Item shifted to Ann II
3545	3.01.0016.1.01.4			Item shifted to Ann II
3546	3.01.0017.1.01.5			Item shifted to Ann II
3547	3.01.0018.1.01.6			Item shifted to Ann II
3548	3.01.0019.1.01.7	PL	I12556	SOLENOID VALVE
3549	3.01.0020.1.01.8	PL	I28456/0500	UNLOADER VALVE
3550	3.01.0021.1.01.9	PL	I28473/0380	VALVE
3551	3.01.0022.1.01.1	PL	I69500/00024	VALVE
3552	3.01.0023.1.01.2	PL	I82555/024	VALVE
3553	3.01.0024.1.01.3	PL	I85095/024	VALVE
3554	3.01.0025.1.01.4	PL	I39387	COCK
3555	3.01.0026.1.01.5	KE	I38038	BROOM LOCK / UNLOCK VALVE
3556	3.01.0027.1.01.6	KE	37022	BALL VALVE 2 WAY
3557	3.01.0028.1.01.7	KE	280033	VALVE SAFETY
3558	3.01.0029.1.01.8			Shifted to Ann-II
3559	3.01.0030.1.01.9	PH	UTVI-06 50/00	SHUT OFF WITH VENT
3560	3.01.0031.1.01.1			Shifted to Ann-II
3561	3.01.0032.1.01.2	LO	158626	MOISTURE SEPARATOR W/ AUTO DRAIN
3562	3.01.0033.1.01.3	LO	162301	VALVE CHECK 200PSI CV6 AIR 16FNPT 5PSI CRCK BUNA
3563	3.01.0034.1.01.4	LO	162700	VALVE DRCT 200PSI AIR 2W2P 20FNPT SOL NO
3564	3.01.0035.1.01.5	LO	A22010	VALVE DRCT 150 PSI CV7 AIR 04MNPT MAN DRAW COCK
3565	3.01.0036.1.01.6	LO	A66642	VALVE AIR SOLENOID
3566	3.01.0037.1.01.7	LO	A70947	VALVE BRONZE CHECK .75
3567	3.01.0038.1.01.8	KA	V71-22A	PNEUMATIC DITRIBUTOR
3568	3.01.0039.1.01.9	KA	VV-32SH 24 V / TU 4151-001- 20725946-97	ELECTRO-PNEUMATIC VALVE

3569	3.01.0040.1.01.1		Shifted to Ann II	
3570	3.01.0041.1.01.2	PL	90189-A SUBSTITUTE 90188	PRESSURE REGULATOR
3571	3.01.0042.1.01.3	PL	90190-A SUBSTITUTE 90184	PRESSURE REGULATOR
3572	3.01.0043.1.01.4		Shifted to Ann-II	
3573	3.01.0044.1.01.5		Shifted to Ann-II	
3574	3.01.0045.1.01.6	PL	90323	STOP COCK
3575	3.01.0046.1.01.7		Shifted to Ann-II	
3576	3.01.0047.1.01.8		Repeated item	
3577	3.01.0048.1.01.9		Repeated item	
3578	3.01.0049.1.01.1	PL	90386	VALVE
3579	3.01.0050.1.01.2		Shifted to Ann II	
3580	3.01.0051.1.01.3		Shifted to Ann-II	
3581	3.01.0052.1.01.4	PL	90343 SUBSTITUTE 90339	VALVE
3582	3.01.0053.1.01.5		Shifted to Ann-II	
3583	3.01.0054.1.01.6		Shifted to Ann-II	
3584	3.01.0055.1.01.7	PL	90384TR	SUPPORT FOR VALVE
3585	3.01.0056.1.01.8		Shifted to Ann-II	
3586	3.01.0057.1.01.9		Shifted to Ann-II	
3587	3.01.0058.1.01.1		Shifted to Ann-II	
3588	3.01.0059.1.01.2	PL	90361	NON-RETURN VALVE
3589	3.01.0060.1.01.3	PL	90418	Non Return Valve
3590	3.01.0061.1.01.4		Repeated item	
3591	3.01.0062.1.01.5	PL	169500/00024	Magnetic Valve
3592	3.01.0063.1.01.6	PL	204069	EMERGENCY BRAKE VALVE KEY
3593	3.01.0064.1.01.7		Shifted to Ann-II	
3594	3.01.0065.1.01.8		Shifted to Ann-II	
3595	3.01.0066.1.01.9	PL	90359-IND	CUTT OFF ANGLE COCK VALVE
3596	3.01.0067.1.01.1		Shifted to Ann II	
3597	3.01.0068.1.01.2	PL	Plasser Part no. 90183	Pneumatic Pressure Reducing Valve 1/2"
3598	3.01.0069.1.01.3		Shifted to Ann II	
3599	3.01.0070.1.01.4	ZF	4420191151	VALVE
3600	3.01.0071.1.01.5	GE	TB/T1041	Dust filter check valve
3601	3.01.0072.1.01.6	CR	I799652090	HIGH PRESSURE SAFETY VALVE
3602	3.01.0073.1.01.7	CR	VCHC40-06G	ONE-WAY VALVE-1
3603	3.01.0074.1.01.8	CR	E321K10-2995-481865C2	SOLENOID VALVE-1
3604	3.01.0075.1.01.9	CR	PKPD36335	ONE-WAY VALVE-2
3605	3.01.0076.1.01.1	CR	4690713	EXHAUST GAS STOP VALVE-1
3606	3.01.0077.1.01.2	CR	VNA301A-20A-B	PNEUMATIC VENT VALVE
3607	3.01.0078.1.01.3	CR	KPS35(060-3105)	PRESSURE REGULATOR
3608	3.01.0079.1.01.4	CR	PK04021321	BALL VALVE-1
3609	3.01.0080.1.01.5	CR	KR014658-DR4263	SEQUENCE VALVE
3610	3.01.0081.1.01.6	CR	K-631.561AZ	BRAKE VALVE
3611	3.01.0082.1.01.7	CR	PK04022027	BALL VALVE-2
3612	3.01.0083.1.01.8	CR	4691321	EXHAUST GAS STOP VALVE-2
3613	3.01.0084.1.01.9	CR	I17154-AE4103	SHUTTLE VALVE
3614	3.01.0085.1.01.1	CR	PKS9561RF-1/2	PNEUMATIC CONTROL VALVE-1
3615	3.01.0086.1.01.2	CR	PD55649-000	PRESS. REDUCE VALVE
3616	3.01.0087.1.01.3	CR	K-665.631B	DRIVING SAFETY VALVE
3617	3.01.0088.1.01.4	CR	PKVBA10-02/04	PRESSURIZING VALVE
3618	3.01.0089.1.01.5	CR	PKS9561RF-1/4	PNEUMATIC CONTROL VALVE-2
3619	3.01.0090.1.01.6	CR	RV-08	ONE-WAY VALVE-3
3620	3.01.0091.1.01.7	CR	K-703.701R	BRAKE CONTROL VALVE
3621	3.01.0092.1.01.8	CR	K-665.181	BRAKE CONTROLLER
3622	3.01.0093.1.01.9	CR	SV-3-1/8-B-SA	VALVE
3623	3.01.0094.1.01.1	CR	40079276	SOLENOID VALVE(AIR BRAKING SYSTEM)
3624	3.01.0095.1.01.2	CR	40090981	SOLENOID NON RETURN VALVE
3625	3.01.0096.1.01.3	CR	40079232	PNEUMATIC PRESSURE REGULATING VALVE
3626	3.01.0097.1.01.4	GE	ZTFD-01	Double-pipe electric control air horn assembly
3627	3.01.0098.1.01.5	PL	I191917/02120 and Sub Part no. I79965/2120	safety valve(12.0 Bar)
3628	3.01.0099.1.01.6	PL	I191917/02105	safety valve(10.5 Bar)
3629	3.01.0100.1.01.7	PL	9753035040/DR	Pressure regulator
3630	3.01.0101.1.01.8	PL	86704NC.8301.02400	valve(for 10 secs)
3631	3.01.0102.1.01.9	PL	90105EW	automatic drain valve

3632	3.01.0103.1.01.1	PL	90357	pressure reducing valve
3633	3.01.0104.1.01.2	PL	I152077	Drivers brake valve FB-11S
3634	3.01.0105.1.01.3	PL	90372	Auxiliary brake unit(KR-5)
3635	3.01.0106.1.01.4	PL	I89454	BRAKE LOAD VALVE (FLOW DIVIDER)
3636	3.01.0107.1.01.5	PL	90354	ON-OFF BRAKE CHANGE OVER DEVICE
3637	3.01.0108.1.01.6	LO	A86731	REGULATOR AIR
3638	3.01.0109.1.01.7	LO	229955	GAS SPRING ASSY 250LB; 18.07 RET 13.77 STROKE
3639	3.01.0110.1.01.8	LO	A37072	EVACUATOR VALVE
3640	3.01.0111.1.01.9	PL	90390	VALVE
3641	3.01.0112.1.01.1	PL	90420E-A/90420E	VALVE
3642	3.01.0113.1.01.2	PL	90421	VALVE
3643	3.01.0114.1.01.3	PL	90423	SOLENOID VALVE
3644	3.01.0115.1.01.4	PL	90424-SKTL	VALVE
3645	3.01.0116.1.01.5	PL	90489	REDUCTION VALVE
3646	3.01.0117.1.01.6	PL	9753034740/DR	PRESSURE REGULATOR
3647	3.01.0118.1.01.7	PL	90359LI /ESCORT	STOP COCK LHS
3648	3.01.0119.1.01.8	PL	90359 RE/ ESCORT	STOP COCK LHS
3649	3.01.0120.1.01.9	HA	G2243Y02	Air Valve 24 v dc solenoide
3650	3.01.0121.1.01.1	HA	D4741Y01	Air Valve 2/4 way
3651	3.01.0122.1.01.2	HA	5131786	INCHING VALVE
3652	3.01.0123.1.01.3	PH	UTVI 06 19/00	EMERGENCY BRAKE VALVE
3653	3.01.0124.1.01.4	PH	D08EAB010000	D1 EMERGENCY BRAKE VALVE
3654	3.01.0125.1.01.5	OEPL	P1459	VALVE
3655	3.01.0126.1.01.6	PL	90271	Valve
3656	3.01.0127.1.01.7	PL	3A98760/3,8 BAR	KE VALVE
3657	3.01.0128.1.01.8	PL	90186	Pressure regulator
3658	3.01.0129.1.01.9	PH	UTVI-06 20/00	Single Solenoid valve MFH-1/4"
3659	3.01.0130.1.01.1	KA	TU3184.071.057.56760.200	Pneumatic check valve
3660	3.02.0001.1.01.8			Shifted to Ann-II
3661	3.02.0002.1.01.9			Shifted to Ann-II
3662	3.02.0003.1.01.1			Shifted to Ann-II
3663	3.02.0004.1.01.2	PL	90374/A-DB	AUTOMATIC TRAIN STOP VALVE
3664	3.02.0005.1.01.3	PL	90375	TWO-WAY COCK
3665	3.02.0006.1.01.4			Repeated item
3666	3.02.0007.1.01.5			Shifted to Ann-II
3667	3.02.0008.1.01.6	PL	1154444/5852 SUB:128577/585	AIR BRAKE CYLINDER 10"
3668	3.02.0009.1.01.7	PL	90205/52803	PNEUMATIC BRAKE CYLINDER 8"
3669	3.02.0010.1.01.8	PL	90217/370	PNEU. BRAKE CYLINDER-6"
3670	3.02.0011.1.01.9	PL	90218DS-10"	BRAKE CYL SEAL 10"
3671	3.02.0012.1.01.1	PL	90226 , BGS-12"	PNEUMATIC BRAKE CYLINDER
3672	3.02.0013.1.01.2	PL	90227/37002	PNEUMATIC BRAKE CYLINDER 8"
3673	3.02.0014.1.01.3	PL	90227DS	BRAKE CYLINDER SEAL KIT-6"
3674	3.02.0015.1.01.4	PL	90291-500 LG	HOSE
3675	3.02.0016.1.01.5			Repeated item
3676	3.02.0017.1.01.6	PL	90364 DS	SEAL KIT
3677	3.02.0018.1.01.7	PL	I26964 SUB. 90227-8"	PISTON RUBBER PACKING
3678	3.02.0019.1.01.8	PL	I154444/5852 SUB. I28577/585	BRAKE CYLINDER
3679	3.02.0020.1.01.9	PL	IRFD110	DUAL POWER DRIVER
3680	3.02.0021.1.01.1	PL	UD 67-1802	BRACKET UNIMAT SUSPENSION
3681	3.02.0022.1.01.2	PL	UD210.29	BRAKE BLOCK
3682	3.02.0023.1.01.3	PL	UD210.42-DB	KEY
3683	3.02.0024.1.01.4	PL	UD214.5700BLI	BRAKE ASSEMBLY REAR
3684	3.02.0025.1.01.5	KE	115880	BRAKE CHAMBER
3685	3.02.0026.1.01.6	KE	197535	VALVE PARKING BRAKE 197535
3686	3.02.0027.1.01.7	KE	197536	SERVICE BRAKE VALVE
3687	3.02.0028.1.01.8	KE	229080	BRAKE CYLINDER
3688	3.02.0029.1.01.9	KE	662983	BRAKE CHAMBER DIAPHRAGM
3689	3.02.0030.1.01.1	KE	720921	BRAKE VALVE
3690	3.02.0031.1.01.2	PH	UTV1-06/10/00	SHUT OFF COCK 3/4"
3691	3.02.0032.1.01.3	PH	UTV1-06/17/00	THROTTLE LEVER VALVE
3692	3.02.0033.1.01.4	PH	UTV1-06/22/00	REDUCING VALVE
3693	3.02.0034.1.01.5			Shifted to Ann II
3694	3.02.0035.1.01.6	PH	UTV1-06/35/00	RELAY VALVE
3695	3.02.0036.1.01.7			Shifted to Ann II
3696	3.02.0037.1.01.8	PH	UTVI-06/02/00	AFTER COOLER
3697	3.02.0038.1.01.9			Shifted to Ann II
3698	3.02.0039.1.01.1	PH	UTVI-06/09/00	J-1 SAFETY VALVE
3699	3.02.0040.1.01.2	PH	UTVI-06/15/00	PARKING BRAKE VALVE
3700	3.02.0041.1.01.3	PH	UTVI-06/47/00	BRAKE CYLINDER WITHOUT TRUNION
3701	3.02.0042.1.01.4	PH	UTVI-06-14/00	D CHECK VALVE
3702	3.02.0043.1.01.5	LO	A28749	VALVE RELAY J-1 SUSPENSION MOUNTED

3703	3.02.0044.1.01.6	LO	A48635	VALVE RELAY J-1.6-16 SUSPENSION MOUNTED
3704	3.02.0045.1.01.7	LO	A75396	VALVE RELAY J1.6-16 FLOOR MOUNTED
3705	3.02.0046.1.01.8	LO	B23652	VALVE AIR BREAK AUTOMATIC A-9
3706	3.02.0047.1.01.9	LO	B37308	VALVE DIFF CONTROL
3707	3.02.0048.1.01.1	LO	D28747	VALVE BRAKE INDEPENDENT H-2-FX 0-65 PSI
3708	3.02.0049.1.01.2	PL	90218/58502	PNEUMATIC BRAKE CYLINDER 10"
3709	3.02.0050.1.01.3	PL	90235	PILOT VALVE
3710	3.02.0051.1.01.4	PL	90319-IND	BRAKE HOSE ASSY.
3711	3.02.0052.1.01.5	CR	K-679.507	ANGLE COCK (LEFT)
3712	3.02.0053.1.01.6	CR	K-679.520	ANGLE COCK (RIGHT)
3713	3.02.0054.1.01.7	CR	HU20051	TREAD BRAKE UNIT(WITH PARKING BRAKE)
3714	3.02.0055.1.01.8	PL	CA215.3723	Pneumatic brake cylinder
3715	3.02.0056.1.01.9	CR	40086032	AIR CYLINDER
3716	3.02.0057.1.01.1	HA	P1443	SERVICE BRAKE CYLINDER
3717	3.02.0058.1.01.2	PH	UTVI 06 34/00	CHECK VALVE
3718	3.02.0059.1.01.3	OEPL	P1444	AIR DRYER WITH UNLODER
3719	3.02.0060.1.01.4	PL	UD214.6601	LEVER
3720	3.02.0061.1.01.5	PL	UD214.6602	BRAKE LEVER
3721	3.02.0062.1.01.6	KA	NO.483M TU24.05.10.062-98	Air Distributor (KE Valve)
3722	3.02.0063.1.01.7	KA	GOST P52392-2005	Pnumatic brake cylinder
3723	3.03.0001.1.01.9	PL	2E34.150B	PNUE. CYLINDER
3724	3.03.0002.1.01.1		Shifted to Ann-II	
3725	3.03.0003.1.01.2	PL	64.03.4000.62	PNUE. CYLINDER
3726	3.03.0004.1.01.3		Shifted to Ann-II	
3727	3.03.0005.1.01.4	PL	PN1Z-0.25/10/30	PN. CYLINDER WORK MODE THROTTLE
3728	3.03.0006.1.01.5		Shifted to Ann-II	
3729	3.03.0007.1.01.6	PL	PN2Z.KF.50/18/88-50/18/44	PNE. CYLINDER
3730	3.03.0008.1.01.7	PL	PN2Z-KF.35/18/102UB	PNEUMATIC CYLINDER
3731	3.03.0009.1.01.8	PL	PN2Z-KF.50/18/28	PNEUMATIC CYLINDER
3732	3.03.0010.1.01.9		Shifted to Ann-II	
3733	3.03.0011.1.01.1	PL	PN4Z-70/20x200x200	PNEUMATIC CYLINDER (4-POSITION)
3734	3.03.0012.1.01.2	PL	UD150.2312	FORK HEAD
3735	3.03.0013.1.01.3	KE	191243	FLOW LOCK CYLINDER
3736	3.03.0014.1.01.4	PH	UTV1.06.40.00	CYLINDER PNEUMATIC
3737	3.03.0015.1.01.5	PL	40.400-1.37	PNEUMATIC CYLINDER
3738	3.03.0016.1.01.6		Shifted to Ann-II	
3739	3.03.0017.1.01.7	PL	PN4Z-70/20X230X230	4-POSITION CYLINDER
3740	3.03.0018.1.01.8	PL	6009720 SUBSTITUTE DOS-1205-W	FEMALE CONNECTOR
3741	3.03.0019.1.01.9	PL	C10-L	ADAPTOR
3742	3.03.0020.1.01.1	PL	C15-L	ADAPTOR
3743	3.03.0021.1.01.2	PL	C38-S	ADAPTOR
3744	3.03.0022.1.01.3	PL	CP15LR1/2BSP	ADAPTOR
3745	3.03.0023.1.01.4	PL	CP18-LR1/2BSP	ADAPTOR
3746	3.03.0024.1.01.5	PL	CV15-L	ADAPTOR
3747	3.03.0025.1.01.6	PL	CX-18LN1/2NPTF	ADAPTOR
3748	3.03.0026.1.01.7	PL	ES141	QUICK RELEASE COUPLING
3749	3.03.0027.1.01.8	PL	SFP38SN-1.1/2NPTF	ADAPTOR
3750	3.03.0028.1.01.9	GE	DCM32A-06-02-01	Brake cylinder
3751	3.03.0029.1.01.1	CR	CP95SF40-80	PNEUMATIC CYLINDER
3752	3.03.0030.1.01.2	CR	SMB-10075-6318-4500	PNEUMATIC CYLINDER-9
3753	3.03.0031.1.01.3	CR	AZ5035-50-00	PNEUMATIC CYLINDER-11
3754	3.03.0032.1.01.4	CR	40105548	PN. CYLINDER(SWING ARM ASSEMBLY)
3755	3.03.0033.1.01.5	PL	PN-Z02/ 50/ 900	Pneumatic Cylinder
3756	3.03.0034.1.01.6	PL	90415/3702	PNEUMATIC BRAKE CYLINDER BG7
3757	3.03.0035.1.01.7	PL	PN2Z-0.25/10/30/RZF	PNEUMATIC CYLINDER
3758	3.03.0036.1.01.8	PL	PN2Z-0.25/10/40/RZF	PNEUMATIC CYLINDER
3759	3.03.0037.1.01.9	PL	PN90.374	PNEUMATIC CYLINDER
3760	3.03.0038.1.01.1	PL	PN90.382	PNEUMATIC CYLINDER
3761	3.03.0039.1.01.2	PL	PN90.384	PNEUMATIC CYLINDER
3762	3.03.0040.1.01.3	PL	PN90.386	PNEUMATIC CYLINDER
3763	3.03.0041.1.01.4	PL	PN90.390	PNEUMATIC CYLINDER
3764	3.03.0042.1.01.5	PL	WN100.129.05	PNEUMATIC CYLINDER
3765	3.03.0043.1.01.6	PL	WN100.184-3	PNEUMATIC CYLINDER
3766	3.03.0044.1.01.7	CR	40072070	Air cylinder
3767	3.03.0045.1.01.8	CR	40072150	Air cylinder
3768	3.03.0046.1.01.9	CR	40072170	Air cylinder
3769	3.03.0047.1.01.1	CR	40072180	Air cylinder
3770	3.03.0048.1.01.2	CR	40072190	Air cylinder
3771	3.03.0049.1.01.3	CR	40079623	Brake Cylinder
3772	3.03.0050.1.01.4	HA	5138418	LOCK CYLINDER
3773	3.03.0051.1.01.5	PH	UTVI 06 18/00	THROTTLE CYL
3774	3.03.0052.1.01.6	PL	PN2Z-G.50/16/160	PNEUMATIC CYLINDER

3775	3.03.0053.1.01.7	PL	PN4Z-100/25x230x100	PNEUMATIC CYLINDER (4-POSITION)
3776	3.03.0054.1.01.8	LO	A76179	CYLINDER BRAKE RH 9.00 DIA X 8.00 STROKE
3777	3.03.0055.1.01.9	LO	158533	CYLINDER BRAKE UAH LH 9.00 DIA X 8.00 STROKE
3778	3.03.0056.1.01.1	PL	PN2Z-G35/12/65	PNEUMATIC CYLINDER
3779	3.03.0057.1.01.2	PL	PN.2Z G.100/25/300	Pn. Cylinder
3780	3.03.0058.1.01.3	KA	1023.81.14.000.002	Pneumatic cylinder
3781	3.04.0001.1.01.1	CR	JRDG16-800	HIGH TEMP. HOSE 1
3782	3.04.0002.1.01.2	CR	K-301.091	BRAKE HOSE
3783	3.04.0003.1.01.3	PL	90291-S OR 90291-J	HOSE
3784	3.04.0004.1.01.4	PL	90433-A/600	HOSE
3785	3.04.0005.1.01.5	PL	90433-A/800	HOSE
3786	3.04.0006.1.01.6	PL	90291-S/90291/J	COMPRESSION HOSE
3787	3.04.0007.1.01.7	PL	90433-A/500	TEFLON CORRUGATED HOSE PIPE
3788	3.04.0008.1.01.8	PL	90287/700	PRESSURE GAUGE HOSE
3789	3.04.0009.1.01.9	PL	90286	BRAKE HOSE
3790	3.04.0010.1.01.1	PL	90267	HOSE
3791	3.05.0001.1.01.2	PL	ES12A	QUICK RELEASE COUPLNG
3792	3.06.0002.1.01.4	PL	64.03.4000.218-31RE	COILING COIL WITH FERRULE
3793	3.06.0003.1.01.5	PL	64.03.4000.278	PNEUMATIC COOLING SYSTEM
3794	3.06.0004.1.01.6	PL	64.03.4243	COOLING COIL
3795	3.06.0005.1.01.7	PL	64.03.4244	COOLING COIL
3796	3.06.0006.1.01.8	PL	64.03.4245	COOLING COIL
3797	3.06.0007.1.01.9	PL	64.03.4246	COOLING COIL
3798	3.06.0008.1.01.1	PL	DL.90.37A	COOLING COIL WITH FERRULE
3799	3.06.0009.1.01.2	PL	GP45-4-A19.50OHM/0.8A	COIL
3800	3.06.0010.1.01.3	KE	144216	AIR PRESSUR GAUGE
3801	3.06.0011.1.01.4	PH	UTV1-06/08/00	AIR STRAINER
3802	3.06.0012.1.01.5			Shifted to Ann II
3803	3.06.0013.1.01.6	PL	P 7-63	WIPER
3804	3.06.0014.1.01.7	LO	148464	ELEMENT AIR FILTER; PRIMARY
3805	3.06.0015.1.01.8	LO	A71633	VALVE CHECK CARTRIDGE T13A CAVITY 4 PSI
3806	3.06.0016.1.01.9	LO	B86483	FILTER ELEMENT KZ5; 5 MICRON 3.88D 9.06L
3807	3.06.0017.1.01.1			Shifted to Ann II
3808	3.06.0018.1.01.2	PL	453.58A	COLLECTOR DRIER
3809	3.06.0019.1.01.3	PL	677.80B	HOSE LINE
3810	3.06.0020.1.01.4	PL	90157-A	AIR TANK 100L
3811	3.06.0021.1.01.5	PL	90215(M22X1.5)	CONTAINER VENTILATION
3812	3.06.0022.1.01.6			Shifted to Ann II
3813	3.06.0023.1.01.7			Shifted to Ann II
3814	3.06.0024.1.01.8	PL	90358K	CHECKING CONNECTOR
3815	3.06.0025.1.01.9	PL	GIA 20EB	BRAKE PRESSUURE SWITCH
3816	3.06.0026.1.01.1	KA	U43102A-03 TS2010101044-95	Compressor
3817	3.06.0027.1.01.2	GE	BDE1000N2W2.0-RV 0.02	Air filter, dehumidification
3818	3.06.0028.1.01.3	CR	I34768	PNEUMATIC FILTER-1-1
3819	3.06.0029.1.01.4	CR	LCQ-1/2	PNEUMATIC FILTER-2
3820	3.06.0030.1.01.5	CR	LCQ-1/4	PNEUMATIC FILTER-3
3821	3.06.0031.1.01.6	CR	432 055-00	PNEUMATIC FILTER-4
3822	3.06.0032.1.01.7	CR	432 500-00	FILTER CARTRIDGE
3823	3.06.0033.1.01.8	CR	432 700-00	PNEUMATIC FILTER-5
3824	3.06.0034.1.01.9	CR	AF40-04D-A	PNEUMATIC FILTER-6
3825	3.06.0035.1.01.1	CR	890L/min	AIR COMPRESSOR
3826	3.06.0036.1.01.2	CR	RPO 600 LLA(H)	ROTARY COMPRESSOR (WITH HYDRAULIC MOTOR)
3827	3.06.0037.1.01.3	CR	TDS0550G/DH2.5/24VDC/PK -KM	DRYER AND CONTROL SYSTEM
3828	3.06.0038.1.01.4	CR	YYS1-100Z-DC24V-12bar	DUPLEX PRESSURE GAUGE
3829	3.06.0039.1.01.5	CR	YYD-100Z-DC24V-12bar	SINGLE NEEDLE PRESSURE GAUGE
3830	3.06.0040.1.01.6	CR	ZLS10/8-10bar-4-20mA	SINGLE NEEDLE ELECTRIC PRESSURE GAUGE
3831	3.06.0041.1.01.7	CR	GZD7053B1	HIGH TONE HORN
3832	3.06.0042.1.01.8	CR	GZD7053F1	LOW TONE HORN
3833	3.06.0043.1.01.9	CR	100L-Φ377	AIR RESERVOIR-1
3834	3.06.0044.1.01.1	CR	15L-φ203	AIR RESERVOIR-2
3835	3.06.0045.1.01.2	CR	200L-Φ508	AIR RESERVOIR-3
3836	3.06.0046.1.01.3	CR	57L-Φ300	AIR RESERVOIR-4
3837	3.06.0047.1.01.4	CR	SDB-121/2	Dehumidification air filter
3838	3.06.0048.1.01.5	CR	40079234	AIR OILER
3839	3.06.0049.1.01.6			Shifted to Ann II
3840	3.06.0050.1.01.7			Shifted to Ann II
3841	3.06.0051.1.01.8			Shifted to Ann II
3842	3.06.0052.1.01.9			Shifted to Ann II
3843	3.06.0053.1.01.1			Shifted to Ann II
3844	3.06.0054.1.01.2			Shifted to Ann II
3845	3.06.0055.1.01.3			Shifted to Ann II
3846	3.06.0056.1.01.4			Shifted to Ann II

3847	3.06.0057.1.01.5	PL	90157E	Pneumatic Tank-2 Nos.
3848	3.06.0058.1.01.6	PL	PN-LVE1000L	AIR SUPPLY UNIT
3849	3.06.0059.1.01.7	LO	163036-SP	Air compressor 50 HP
3850	3.06.0060.1.01.8	LO	153160	ELEMENT AIR FILTER; SECONDARY
3851	3.06.0061.1.01.9	LO	131585	PRE-CLEANER; AC/PRESSURISER
3852	3.06.0062.1.01.1	LO	C84385	RESERVOIR AUX 2500 CU IN 14.00 DIA X 20.25
3853	3.06.0063.1.01.2	LO	A65235	GAUGE PRESS 0-160 PSI BAR 04MNPT 2.5D BACK SIL
3854	3.06.0064.1.01.3	LO	118215	RESERVOIR AIR; 10 GAL
3855	3.06.0065.1.01.4	LO	163140	GAUGE PRESSURE PANEL 0-100 PSI/0-6.9 BAR
3856	3.06.0066.1.01.5	LO	252351-118	PNEUMATIC SYSTEM MAINTENANCE KIT, SMALL
3857	3.06.0067.1.01.6	LO	252351-119	PNEUMATIC SYSTEM MAINTENANCE KIT, MED
3858	3.06.0068.1.01.7	LO	252351-120	PNEUMATIC SYSTEM MAINTENANCE KIT, LARGE
3859	3.06.0069.1.01.8	LO	252351-130	AIR SYSTEM MAINTENANCE KIT, SMALL
3860	3.06.0070.1.01.9	LO	252351-131	AIR SYSTEM MAINTENANCE KIT, LARGE
3861	3.06.0071.1.01.1	LO	252351-132	AIR SYSTEM REPAIR KIT, SMALL
3862	3.06.0072.1.01.2	LO	252351-133	AIR SYSTEM REPAIR KIT, LARGE
3863	3.06.0073.1.01.3	LO	252351-154	PNEUMATIC SYSTEM MAINTENANCE KIT, MED
3864	3.06.0074.1.01.4	LO	252351-155	PNEUMATIC SYSTEM MAINTENANCE KIT, LARGE
3865	3.06.0075.1.01.5	LO	127532	DUPLEX GAUGE-AIR (BC-BP) DUAL SCALE PSI AND KPA
3866	3.06.0076.1.01.6	LO	158630	COALESCING PRE-FILTER .01 MICRON W/ AUTO DRAIN
3867	3.06.0077.1.01.7	LO	158635	DRAIN KIT
3868	3.06.0078.1.01.8	LO	A15560	HORN AIR
3869	3.06.0079.1.01.9	LO	A67604	AIR FILTER AND BRACKET
3870	3.06.0080.1.01.1	LO	D75161	AIR CHIME WHISTLE
3871	3.06.0081.1.01.2	HA	0-1100004-0-26	FILTER (PNEUMATIC)
3872	3.06.0082.1.01.3	HA	4011082	PRIMARY FILTER(CATRIDGE/PNEUMATIC)
3873	3.06.0083.1.01.4	HA	4011083	SECONDARY FILTER(CATRIDGE/PNEUMATIC)
3874	3.06.0084.1.01.5	HA	0-3350005-0-09	BREATHING VENT
3875	3.06.0085.1.01.6	HA	0-3436004-0-04	DESSICANT CART REFILL
3876	3.06.0086.1.01.7	KA	TU25-02.11.0331-84/	Pressure Gauge (1-15 kg/cm2 - 27SH)
3877	3.06.0087.1.01.8	PL	WN146-850.K-5	BRAKE BLOCK
3878	3.06.0088.1.01.9	PL	PN-A.40.131-00/EN	Cover
3879	3.06.0089.1.01.1	LO	162992	AIR HORN ASSY; CONTROL CAR
3880	3.06.0090.1.01.2	LO	124629	VALVE CHECK ON P OR T D03 SANDWICH
3881	3.06.0091.1.01.3	LO	A31585	FILTER AIR
3882	3.06.0092.1.01.4	PH	D08HRN020000	Air Horn low tone
3883	3.06.0093.1.01.5	PH	D08HRN010000	Air Horn high tone
3884	3.06.0094.1.01.6	PH	D08SFT010000	J-1 Safety Valve
3885	3.06.0095.1.01.7	KA	MC.202.D00	Filter Regulator
3886	3.06.0096.1.01.8	KA	UD-800 ID1-15kg/CM2-27SH TU U25-02.11.0331-84	Pressure Indicator(for Pressure Gauge)
3887	3.07.0001.1.01.4	PL	2E34.150BDS	SEAL KIT
3888	3.07.0002.1.01.5	PL	90201DS	SEAL KIT
3889	3.07.0003.1.01.6	PL	90202DS	SEAL KIT
3890	3.07.0004.1.01.7	PL	90217DS	BRAKE CYLINDER SEAL KIT-6"
3891	3.07.0005.1.01.8	Shifted to Ann II		
3892	3.07.0006.1.01.9	PL	S24-10352	SEAL KIT
3893	3.07.0007.1.01.1	PL	90345/46/DS SUBSTITUTE 90346DS	SEAL KIT
3894	3.07.0008.1.01.2	PL	90364DS	SEAL KIT
3895	3.07.0009.1.01.3	PL	90419DS	SEAL KIT
3896	3.07.0010.1.01.4	PL	90344DS	SEAL KIT
3897	3.07.0011.1.01.5	PL	611.2441.256	CABLE OPERATED SWITCH
3898	3.07.0012.1.01.6	PL	C-30850/2	AIR CLEANER ELEMENT
3899	3.07.0013.1.01.7	LO	252351-94	AIR VALVE KIT #4
3900	3.07.0014.1.01.8	PL	90415/3702/DS	SEAL KIT
3901	3.07.0015.1.01.9	PL	PZ02/50/900/DS	SEAL KIT
3902	3.07.0016.1.01.1	KA	Seal set for pneumatic breaking cylinder 507B	Seal set for pneumatic Brake cylinder
3903	3.07.0017.1.01.2	PL	90347-A/DS	SEAL KIT
3904	3.07.0018.1.01.3	PL	90372/DS	SEAL KIT
3905	3.07.0019.1.01.4	PL	90189DS	SEAL KIT
3906	3.07.0020.1.01.5	PL	90420-A/DS	SEAL KIT
3907	3.07.0021.1.01.6	PL	PNZ02/50/900DS	Seal kit
3908	3.07.0022.1.01.7	PL	12"	Seal set for m/c brake cylinder
3909	3.07.0023.1.01.8	PL	90356DS	Seal Kit

3910	3.07.0024.1.01.9	PL	90366DS	Seal Kit
3911	3.07.0025.1.01.1	PL	90247DS	Seal Kit
3912	3.07.0026.1.01.2	PL	90359LI/RE/DS	Seal Kit
3913	3.07.0027.1.01.3	PL	90344-A/DS	Seal Kit
3914	3.07.0028.1.01.4	PL	90246DS	Seal Kit
3915	4.01.0001.1.01.8	PL	24830	P C B
3916	4.01.0002.1.01.9	KE	733331	PCB
3917	4.01.0003.1.01.1	PL	942600	P C B
3918	4.01.0004.1.01.2	PL	6144217	JACK
3919	4.01.0005.1.01.3	PL	2-166010-1	P.C.B STRIP/48POL
3920	4.01.0006.1.01.4	PL	27128 SUB. 27C128	E-PROM-"HI" PROGRAMMED
3921	4.01.0007.1.01.5	PL	2764-A	EPROM-HI
3922	4.01.0008.1.01.6	PL	27C256-25	E-PROM-"HI" PROGRAMMED
3923	4.01.0009.1.01.7	PL	4214AP	MULTIPLICATOR
3924	4.01.0010.1.01.8	PL	64.07.1000.217	P C B
3925	4.01.0011.1.01.9	PL	64.07.5000.139	P C B
3926	4.01.0012.1.01.1	PL	64.07.5000.159	P C B
3927	4.01.0013.1.01.2	PL	82C55A-2*	PIO MODUL
3928	4.01.0014.1.01.3	PL	ADG508FBNZ SUB. HI1-0508-5	MULTIPLEXER
3929	4.01.0015.1.01.4	PL	BS62LV256PIP55 SUB. UPD43256BCZ-7OLL	RAM
3930	4.01.0016.1.01.5	PL	D27C512-200 SUB. 27C512	E-PROM-"HI" PROGRAMMED
3931	4.01.0017.1.01.6	PL	D580C320-MNL-25MHZ	MICRO CONTROLLER
3932	4.01.0018.1.01.7	PL	DS80C320-QNL-33MHZ/PLCC44 SUB. NB0C251SB12	MICRO CONTROLLER
3933	4.01.0019.1.01.8	PL	EK 207 V.00 B	PCB
3934	4.01.0020.1.01.9	PL	EK 430 DV	PCB
3935	4.01.0021.1.01.1	PL	EK-1.1/23LV1-00	PCB
3936	4.01.0022.1.01.2	PL	EK-100 V 00	PCB
3937	4.01.0023.1.01.3	PL	EK-104 V 00	PCB
3938	4.01.0024.1.01.4	PL	EK-1044V-00	PCB
3939	4.01.0025.1.01.5	PL	EK-1054V-00/1,5A	PCB
3940	4.01.0026.1.01.6	PL	EK-110-00A	P C B [MICRO CONTROLLER]
3941	4.01.0027.1.01.7	PL	EK-1116	P C B
3942	4.01.0028.1.01.8	PL	EK-120V-00	P C B
3943	4.01.0029.1.01.9	PL	EK-132-V-00	P C B
3944	4.01.0030.1.01.1	PL	EK-140V-00	P C B
3945	4.01.0031.1.01.2	PL	EK-144V-00	P C B
3946	4.01.0032.1.01.3	PL	EK-150V-00B	P C B
3947	4.01.0033.1.01.4	PL	EK-152 00	P C B
3948	4.01.0034.1.01.5	PL	EK16V-00	P C B
3949	4.01.0035.1.01.6	PL	EK-176V-00/1,5A-B	P C B
3950	4.01.0036.1.01.7	PL	EK-176V-00C	P C B
3951	4.01.0037.1.01.8	PL	EK-182V-00	P C B
3952	4.01.0038.1.01.9	PL	EK-193V.00	P C B
3953	4.01.0039.1.01.1	PL	EK-197-00A	P C B
3954	4.01.0040.1.01.2	PL	EK-1AP7-00B	P C B
3955	4.01.0041.1.01.3	PL	EK-202V-00B SUB. EK-202V.00A	P C B
3956	4.01.0042.1.01.4	PL	EK-2033LV-00	P C B
3957	4.01.0043.1.01.5	PL	EK-2038-LV-00	P C B
3958	4.01.0044.1.01.6	PL	EK-2039LV-00	P C B
3959	4.01.0045.1.01.7	PL	EK-2041LV-00A	P C B
3960	4.01.0046.1.01.8	PL	EK-2042LV-00A	P C B
3961	4.01.0047.1.01.9	PL	EK-2072LV-00	P C B
3962	4.01.0048.1.01.1	PL	EK-2140LV-00	P C B
3963	4.01.0049.1.01.2	PL	EK-2157LV-00	P C B
3964	4.01.0050.1.01.3	PL	EK-217	P C B
3965	4.01.0051.1.01.4	PL	EK-2173LV-00A	P C B
3966	4.01.0052.1.01.5	PL	EK-2186LV-00A	P C B
3967	4.01.0053.1.01.6	PL	EK-2187LV-00A	P C B
3968	4.01.0054.1.01.7	PL	EK-2188LV-00A	P C B
3969	4.01.0055.1.01.8	PL	EK-2195-LV-00	P C B
3970	4.01.0056.1.01.9	PL	EK-2255LV-00	P C B
3971	4.01.0057.1.01.1	PL	EK-2286LV-00	P C B
3972	4.01.0058.1.01.2	PL	EK-229-LV01	P C B
3973	4.01.0059.1.01.3	PL	EK-2324LV-00	P C B
3974	4.01.0060.1.01.4	PL	EK-2343LV-00A	P C B
3975	4.01.0061.1.01.5	PL	EK-2351LV-00	P C B
3976	4.01.0062.1.01.6	PL	EK-2360-LV-00	P C B
3977	4.01.0063.1.01.7	PL	EK-2433 LV-00 / EK 2039 LV-00	P C B
3978	4.01.0064.1.01.8	PL	EK-24V-00A	P C B
3979	4.01.0065.1.01.9	PL	EK-255-LV-00B	P C B
3980	4.01.0066.1.01.1	PL	EK-2684LV-00	P C B
3981	4.01.0067.1.01.2	PL	EK-275-LV-02	P C B
3982	4.01.0068.1.01.3	PL	EK-277LV-00	P C B
3983	4.01.0069.1.01.4	PL	EK-280-LV-00	P C B

3984	4.01.0070.1.01.5		Shifted to Ann-II	
3985	4.01.0071.1.01.6	PL	EK-290LV-00A	P C B
3986	4.01.0072.1.01.7	PL	EK-3045LV-00	P C B
3987	4.01.0073.1.01.8	PL	EK-3049LV-00	P C B
3988	4.01.0074.1.01.9	PL	EK-3069-LV-00	P C B
3989	4.01.0075.1.01.1	PL	EK-319-LV-00	P C B
3990	4.01.0076.1.01.2	PL	EK-335LV-00	P C B
3991	4.01.0077.1.01.3	PL	EK-345-LV-00	P C B
3992	4.01.0078.1.01.4	PL	EK-346LV-00	P C B
3993	4.01.0079.1.01.5	PL	EK-347-LV-00B	P C B
3994	4.01.0080.1.01.6	PL	EK-348LV-00	P C B
3995	4.01.0081.1.01.7	PL	EK-349-LV-00	P C B
3996	4.01.0082.1.01.8	PL	EK-429DV-00	P C B
3997	4.01.0083.1.01.9	PL	EK-430DV-00	P C B
3998	4.01.0084.1.01.1	PL	EK-501P.00 WITHOUT E-PROM	P C B
3999	4.01.0085.1.01.2	PL	EK-502-P-00A WITHOUT E-PROM	P C B
4000	4.01.0086.1.01.3	PL	EK-503P.00 WITHOUT E-PROM	P C B
4001	4.01.0087.1.01.4	PL	EK-552P-00	P C B
4002	4.01.0088.1.01.5	PL	EK-553P-00B	P C B
4003	4.01.0089.1.01.6	PL	EK-553P-04	FRONT PLATE
4004	4.01.0090.1.01.7	PL	EK-554P-00A	P C B
4005	4.01.0091.1.01.8	PL	EK-557P-00	P C B
4006	4.01.0092.1.01.9	PL	EK-602-E-00	P C B
4007	4.01.0093.1.01.1	PL	EK-603E-00	P C B
4008	4.01.0094.1.01.2	PL	EK-638MC-00C SUB. EK-638MC-00B	MICRO CONTROLLER
4009	4.01.0095.1.01.3	PL	EK-650-00	P C B
4010	4.01.0096.1.01.4	PL	EK-650P-00A WITHOUT E-PROM SUBST. EK-650P.00	P C B
4011	4.01.0097.1.01.5	PL	EK-650PX-00 WITHOUT E-PROM	P C B
4012	4.01.0098.1.01.6	PL	EK-651P-00-A	P C B
4013	4.01.0099.1.01.7	PL	EK-652P-00	P C B
4014	4.01.0100.1.01.8	PL	EK-653P/S-00B SUB. EK-653P.00	P C B
4015	4.01.0101.1.01.9	PL	EK-654E-00	P C B
4016	4.01.0102.1.01.1	PL	EK-657P-00A SUB. EK-657P.00	P C B
4017	4.01.0103.1.01.2	PL	EK-658P-00	P C B
4018	4.01.0104.1.01.3	PL	EK-662P-00A	P C B
4019	4.01.0105.1.01.4	PL	EK-664P-00D SUB. EK-664P-00 WITHOUT E-PROM	P C B
4020	4.01.0106.1.01.5	PL	EK727A.00	P C B
4021	4.01.0107.1.01.6	PL	EK-79V-00	P C B
4022	4.01.0108.1.01.7	PL	EK-805SV-00D SUB. EK-805SV-00C	POWER SUPPLY +5V
4023	4.01.0109.1.01.8	PL	EK-80V-00	PCB
4024	4.01.0110.1.01.9	PL	EK-812SV-00C SUB. EK-812SV-00A	PCB
4025	4.01.0111.1.01.1		Shifted to Ann-II	
4026	4.01.0112.1.01.2	PL	EK-816SV-00	PCB
4027	4.01.0113.1.01.3	PL	EK-819SV-00/GT	PCB
4028	4.01.0114.1.01.4	PL	EK-851SV-00	PCB
4029	4.01.0115.1.01.5	PL	EK-97V.00A	PCB
4030	4.01.0116.1.01.6	PL	EK-F3-00	PCB
4031	4.01.0117.1.01.7	PL	EL SUT 59	PCB
4032	4.01.0118.1.01.8	PL	EL-T 1116.00	PCB
4033	4.01.0119.1.01.9	PL	EL-T 1135-6428	POWER SUPPLY
4034	4.01.0120.1.01.1	PL	EL-T 1163	PCB
4035	4.01.0121.1.01.2	PL	EL-T 1340 00 A1	PCB
4036	4.01.0122.1.01.3	PL	EL-T 1442	PCB
4037	4.01.0123.1.01.4	PL	EL-T 156/5156	PCB
4038	4.01.0124.1.01.5	PL	EL-T 347-LV-00	PCB
4039	4.01.0125.1.01.6	PL	EL-T 442-00	PCB
4040	4.01.0126.1.01.7	PL	EL-T 5031 00	PCB
4041	4.01.0127.1.01.8	PL	EL-T 5096	PCB
4042	4.01.0128.1.01.9	PL	EL-T 5348.00B	PCB
4043	4.01.0129.1.01.1	PL	EL-T 5851.00B/ ULN 20617	PCB
4044	4.01.0130.1.01.2	PL	EL-T 631-01A	PCB
4045	4.01.0131.1.01.3	PL	EL-T 7050-200	POWER SUPPLY
4046	4.01.0132.1.01.4	PL	EL-T 998-00A	P C B
4047	4.01.0133.1.01.5	PL	EL-T-1190-00A	P C B
4048	4.01.0134.1.01.6	PL	EL-T-1318.00	P C B
4049	4.01.0135.1.01.7	PL	EL-T1340.00A	P C B
4050	4.01.0136.1.01.8	PL	EL-T1420.00	P C B
4051	4.01.0137.1.01.9	PL	EL-T-1442-00A	P C B
4052	4.01.0138.1.01.1	PL	EL-T-1807, EK-812	RACK WITH PCB EK-812
4053	4.01.0139.1.01.2	PL	EL-T406.00C	P C B
4054	4.01.0140.1.01.3	PL	EL-T4241.00	MOUNTING PLATE
4055	4.01.0141.1.01.4	PL	EL-T50058.00A	P C B

4056	4.01.0142.1.01.5	PL	EL-T-5024-00	P C B
4057	4.01.0143.1.01.6	PL	EL-T-5025-00A	P C B
4058	4.01.0144.1.01.7	PL	EL-T-5031-002	P C B
4059	4.01.0145.1.01.8	PL	EL-T-5034	P C B
4060	4.01.0146.1.01.9	PL	EL-T5034.00	P C B
4061	4.01.0147.1.01.1	PL	EL-T-5035-00	P C B
4062	4.01.0148.1.01.2	PL	EL-T5088.00	P C B
4063	4.01.0149.1.01.3	PL	EL-T5093.00A	P C B
4064	4.01.0150.1.01.4	PL	EL-T-5103	P C B
4065	4.01.0151.1.01.5	PL	ELT-5104.00	P C B
4066	4.01.0152.1.01.6	PL	EL-T5105.00	P C B
4067	4.01.0153.1.01.7	PL	EL-T-5131-00	P C B
4068	4.01.0154.1.01.8	PL	EL-T-5140-00	P C B
4069	4.01.0155.1.01.9	PL	EL-T5149.00	P C B
4070	4.01.0156.1.01.1	PL	EL-T-5156-00	P C B
4071	4.01.0157.1.01.2	PL	EL-T-5177-00	P C B
4072	4.01.0158.1.01.3	PL	ELT-5226-00A	P C B
4073	4.01.0159.1.01.4	PL	EL-T5227.00	PERIODS
4074	4.01.0160.1.01.5	PL	EL-T-5227-002	P C B
4075	4.01.0161.1.01.6	PL	EL-T-5231-00	P C B
4076	4.01.0162.1.01.7	PL	EL-T5234.00	P C B
4077	4.01.0163.1.01.8	PL	EL-T-5255-00A	P C B
4078	4.01.0164.1.01.9	PL	EL-T-5348-00	P C B
4079	4.01.0165.1.01.1	PL	EL-T-5352-00	P C B
4080	4.01.0166.1.01.2	PL	EL-T5354.00	P C B
4081	4.01.0167.1.01.3	PL	EL-T-5390-00	P C B
4082	4.01.0168.1.01.4	PL	EL-T-5391-00	P C B
4083	4.01.0169.1.01.5	PL	EL-T-5501-00	P C B
4084	4.01.0170.1.01.6	PL	EL-T-5507	P C B
4085	4.01.0171.1.01.7	PL	EL-T5529.00	P C B
4086	4.01.0172.1.01.8	PL	EL-T-5533-00A	P C B
4087	4.01.0173.1.01.9	PL	EL-T-5534-001 RE	P C B
4088	4.01.0174.1.01.1	PL	EL-T-5587.00	P C B
4089	4.01.0175.1.01.2	PL	EL-T-5592.00	P C B
4090	4.01.0176.1.01.3	PL	EL-T5593.00	P C B
4091	4.01.0177.1.01.4	PL	EL-T5596.00A	P C B
4092	4.01.0178.1.01.5	PL	EL-T-5598-00	P C B
4093	4.01.0179.1.01.6	PL	EL-T-5618	MICRO CONTROLLER X-LASER
4094	4.01.0180.1.01.7	PL	ELT-5621-00	PCB [LCD DISPLAY]
4095	4.01.0181.1.01.8	PL	ELT-5630-00C	P C B
4096	4.01.0182.1.01.9	PL	EL-T5672.00A	P C B
4097	4.01.0183.1.01.1	PL	EL-T-5721-00	P C B
4098	4.01.0184.1.01.2	PL	EL-T5735.00	P C B
4099	4.01.0185.1.01.3	PL	EL-T5851.00B SUB. ULN2061M	ADAPTOR PR.CIRCUIT BOARD
4100	4.01.0186.1.01.4	PL	EL-T5874.00A	P C B
4101	4.01.0187.1.01.5	PL	EL-T5898.00B	P C B
4102	4.01.0188.1.01.6	PL	EL-T5949.00	P C B
4103	4.01.0189.1.01.7	PL	EL-T5950.00A	P C B
4104	4.01.0190.1.01.8	PL	EL-T-6109-00	P C B
4105	4.01.0191.1.01.9	PL	ELT700-00030 SUB. EL-T7050.400-PE/A	POWER SUPPLY
4106	4.01.0192.1.01.1	PL	ELT700-00031 SUB. EL-T7050.200-PE/A	POWER SUPPLY
4107	4.01.0193.1.01.2	PL	ELT-701-00031 SUB. EL-T7050.200-PE/A	POWER SUPPLY
4108	4.01.0194.1.01.3	PL	EL-T-7050-400	POWER PACK
4109	4.01.0195.1.01.4	PL	EL-T-7155-00	P C B
4110	4.01.0196.1.01.5	PL	ELT-H00-00001	CONTROL DEVICE AIR DRYER
4111	4.01.0197.1.01.6	PL	EP910ILC-15(LP12.1)	PROGRAMME-E-PROME
4112	4.01.0198.1.01.7	PL	M27C64A-15FN SUB. 2764A	E-PROM-"HI" PROGRAMMED
4113	4.01.0199.1.01.8	PL	ST644/1H	TRANSFORMER
4114	4.01.0200.1.01.9	PL	VT 300 5G	AMPLIFIER CORD FOR REXROTH PUMP
4115	4.01.0201.1.01.1	PL	VT-3005-5032-A-822	P C B
4116	4.01.0202.1.01.2		Shifted to Ann-I	
4117	4.01.0203.1.01.3	PL	VT5036S1X/R5	AMPLIFIER
4118	4.01.0204.1.01.4	LO	110280	TRANSFORMER CT 1600:5
4119	4.01.0205.1.01.5	LO	114348	PLC MOD DIGITAL INPUT 16 INPUTS 24 VOLTS DC
4120	4.01.0206.1.01.6	LO	114351	PLC MOD DIGITAL OUTPUT 16 CONTACT OUTPUTS 2 AMPS
4121	4.01.0207.1.01.7	LO	114352	PLC 1756 INPUT ANALOG 16 SINGLE-END 8 DIFF
4122	4.01.0208.1.01.8	LO	114353	PLC MOD RTD INPUT 6 ISOLATED RTD INPUTS
4123	4.01.0209.1.01.9	LO	114354	PLC MOD ANALOG OUTPUT 8 VOLTAGE/CURRENT OUTPUTS

4124	4.01.0210.1.01.1	LO	114355	PLC MOD COUNTER 2 HIGH SPEED COUNTERS
4125	4.01.0211.1.01.2	LO	114357	PLC MOD CONTROL NET REDUNTANT COMM INTERFACE
4126	4.01.0212.1.01.3	LO	114358	PLC MOD DEVICE NET SCANNER INTERFACE
4127	4.01.0213.1.01.4	LO	114476	PLC MOD IFM DIN RAIL MOUNT
4128	4.01.0214.1.01.5	LO	114477	PLC MOD IFM DIN RAIL MOUNT
4129	4.01.0215.1.01.6	LO	114489	PLC MOD IFM DIN RAIL MOUNT
4130	4.01.0216.1.01.7	LO	123402	PLC POWER SUPPLY 24VDC 75W OUTPUT @ 60 DEG C
4131	4.01.0217.1.01.8	LO	123408	PLC MOD ETHERNET COMM INTERFACE
4132	4.01.0218.1.01.9	LO	124334	PLC 1756 COMM MODBUS INTERFACE
4133	4.01.0219.1.01.1	LO	126312	PCB ATTENUATOR VOLTAGE
4134	4.01.0220.1.01.2	LO	126629	PCB CALIBRATION SCR
4135	4.01.0221.1.01.3	LO	126632	PCB AMPLIFIER ISOLATION
4136	4.01.0222.1.01.4	LO	126645	PCB SCR DVDT AND FIRING BD
4137	4.01.0223.1.01.5	LO	128268	PLC 1794 CONTROL NET REDUNDANT COMM INTERFACE
4138	4.01.0224.1.01.6	LO	128269	PLC 1794 ANALOG I/O VOLTAGE/CURRENT 4IN 2OUT
4139	4.01.0225.1.01.7	LO	128270	PLC 1794 DIGITAL INPUT 16 24VDC INPUTS
4140	4.01.0226.1.01.8	LO	128271	PLC 1794 DIGITAL OUTPUT 8 RELAY CONTACT OUTPUTS
4141	4.01.0227.1.01.9	LO	156459	PLC 1756 CONTROLLER CONTROLLOGIX 8M RAM
4142	4.01.0228.1.01.1	KA	1023.14.21.230	PCB SEMI AUTO WORKING
4143	4.01.0229.1.01.2	KA	1023.14.22.220	PCB LINING
4144	4.01.0230.1.01.3	KA	1023.14.22.280	PCB ASSEMBLY
4145	4.01.0231.1.01.4	PL	EL-T5024.00A	P C B
4146	4.01.0232.1.01.5	PL	EL-T5025.00A	P C B
4147	4.01.0233.1.01.6	PL	EL-T5031.00	P C B
4148	4.01.0234.1.01.7	PL	EL-T5035.00	P C B
4149	4.01.0235.1.01.8	PL	1023.14.22.330	P C B
4150	4.01.0236.1.01.9	PL	EK-1.1/1LV1-00	P C B
4151	4.01.0237.1.01.1	PL	EK-100V.00	P C B
4152	4.01.0238.1.01.2	PL	EK-110MC-00B/3,84M SUBSTITUTE EK-110V.00A	P C B
4153	4.01.0239.1.01.3	PL	EK-16V-00B	P C B
4154	4.01.0240.1.01.4	PL	EK-197V-00B SUBSTITUTE EK-197V.00A	P C B
4155	4.01.0241.1.01.5	PL	EK-1AP13-00A	P C B
4156	4.01.0242.1.01.6	PL	EK-202V-00B SUBSTITUTE EK-202V.00A	P C B
4157	4.01.0243.1.01.7	PL	EK-2038LV-00	P C B
4158	4.01.0244.1.01.8	PL	EK-207V-00B SUBSTITUTE EK-207V-00A	P C B
4159	4.01.0245.1.01.9	PL	EK-2195LV-00	P C B
4160	4.01.0246.1.01.1	PL	EK-229LV-00	P C B
4161	4.01.0247.1.01.2	PL	EK-2360LV-00	P C B
4162	4.01.0248.1.01.3	PL	EK-275LV-00	P C B
4163	4.01.0249.1.01.4		Repeated item	
4164	4.01.0250.1.01.5	PL	EK-3069LV-00A	P C B
4165	4.01.0251.1.01.6	PL	EK-319LV-00C	P C B
4166	4.01.0252.1.01.7	PL	EK-345LV-00	P C B
4167	4.01.0253.1.01.8	PL	EK-347LV-00B	P C B
4168	4.01.0254.1.01.9	PL	EK-429DV-00D	P C B
4169	4.01.0255.1.01.1	PL	EK-430DV-00D	P C B
4170	4.01.0256.1.01.2	PL	EK-432DV-00	P C B
4171	4.01.0257.1.01.3	PL	EK-433DV-00	P C B
4172	4.01.0258.1.01.4	PL	EK-501P.00WITHOUTE-PROM	P C B
4173	4.01.0259.1.01.5	PL	EK-502P-00AWITHOUTE-PROM	P C B
4174	4.01.0260.1.01.6	PL	EK-503P.00WITHOUTE-PROM	P C B
4175	4.01.0261.1.01.7	PL	EK-520A-00C	P C B
4176	4.01.0262.1.01.8	PL	EK-520CA-00	P C B
4177	4.01.0263.1.01.9	PL	EK-522CA-00A	P C B
4178	4.01.0264.1.01.1	PL	EK-523CA-00C	P C B
4179	4.01.0265.1.01.2	PL	EK-602E-00	P C B
4180	4.01.0266.1.01.3	PL	EK-637MC-00D/185F	P C B
4181	4.01.0267.1.01.4	PL	EK-637MC-00D/186F	P C B
4182	4.01.0268.1.01.5	PL	EK-637MC-00D/235	P C B
4183	4.01.0269.1.01.6	PL	EK-638MC-00C SUBSTITUTE EK-638MC-00B	P C B
4184	4.01.0270.1.01.7	PL	EK-650P-00AWITHOUTE-PROM SUBSTITUTE EK-650P.00	P C B
4185	4.01.0271.1.01.8	PL	EK-650PX-00WITHOUTE-PROM	P C B

4186	4.01.0272.1.01.9	PL	EK-651P-00A	P C B
4187	4.01.0273.1.01.1	PL	EK-652P-00A SUBSTITUTE EK-652P.00	P C B
4188	4.01.0274.1.01.2	PL	EK-653P/S-00B SUBSTITUTE EK-653P.00	P C B
4189	4.01.0275.1.01.3	PL	EK-657P-00A SUBSTITUTE EK-657P.00	P C B
4190	4.01.0276.1.01.4	PL	EK-664P-00D SUBSTITUTE EK-554P-00A	P C B
4191	4.01.0277.1.01.5	PL	EK-664P-00D SUBSTITUTE EK-664P-00	P C B
4192	4.01.0278.1.01.6	PL	EK-706AR-00A	P C B
4193	4.01.0279.1.01.7	PL	EK-727A-00	P C B
4194	4.01.0280.1.01.8	PL	EK-754P-00D/195	P C B
4195	4.01.0281.1.01.9	PL	EK-754P-00D/253	P C B
4196	4.01.0282.1.01.1	PL	EK-758P-00	P C B
4197	4.01.0283.1.01.2	PL	EK-805SV-00/GT	P C B
4198	4.01.0284.1.01.3	PL	EK-805SV-00D SUBSTITUTE EK-805SV-00C	P C B
4199	4.01.0285.1.01.4	PL	EK-812SV-00	P C B
4200	4.01.0286.1.01.5	PL	EK-812SV-00C SUBSTITUTE EK-812SV-00A	P C B
4201	4.01.0287.1.01.6	Repeated item		
4202	4.01.0288.1.01.7	PL	EK-821SV-00	P C B
4203	4.01.0289.1.01.8	PL	ELB-EP0-00A-MBI	P C B
4204	4.01.0290.1.01.9	PL	ELB-EP0-01-MBI	P C B
4205	4.01.0291.1.01.1	PL	ELB-EP0-01-TS	P C B
4206	4.01.0292.1.01.2	PL	ELB-KD0-01-MBI	P C B
4207	4.01.0293.1.01.3	PL	ELB-KN0-01	P C B
4208	4.01.0294.1.01.4	PL	ELB-KR0-25	P C B
4209	4.01.0295.1.01.5	PL	ELB-KV0-00-11	P C B
4210	4.01.0296.1.01.6	PL	ELB-SM0-05-MLC60	MICROCONTROLLER
4211	4.01.0297.1.01.7	PL	ELF3-40.1	FILTER
4212	4.01.0298.1.01.8	PL	EL-SU-T59.00	PR.CIRCUIT BOARD COMPLETE
4213	4.01.0299.1.01.9	PL	EL-T1157.00	P C B
4214	4.01.0300.1.01.1	PL	EK-819SV-00(02)	POWER SUPPLY
4215	4.01.0301.1.01.2	PL	ELB-EPO-00A-MBI	MICROPROCESSOR MODULE
4216	4.01.0302.1.01.3	PL	ELB-L00-10	P.C.B. MODULE
4217	4.01.0303.1.01.4	PL	EL-T1163.00	P C B
4218	4.01.0304.1.01.5	PL	EL-T50029.00	P C B
4219	4.01.0305.1.01.6	PL	EL-T50031.00A/100 SUBSTITUTE TRI-24V-100SEC	P C B
4220	4.01.0306.1.01.7	PL	EL-T5096.00	P C B
4221	4.01.0307.1.01.8	PL	EL-T5571.00B	PRINTED CIRCUIT BOARD F.PENDULUM
4222	4.01.0308.1.01.9	PL	EL-T5923.00	PCB
4223	4.01.0309.1.01.1	PL	EL-T5927.00A	P.C.B. MODULE
4224	4.01.0310.1.01.2	PL	PS-3-65-300	DC/AC CONVERTER
4225	4.01.0311.1.01.3	PL	1.50MM2/BANDWARE	JACKET
4226	4.01.0312.1.01.4	PL	7705	VOLTAGE STABILIZER
4227	4.01.0313.1.01.5	KA	161.14.22.220	Lifting PCB
4228	4.01.0314.1.01.6	KA	161.11.73.210	Lining PCB
4229	4.01.0315.1.01.7	KA	161.14.21.280	PCB Proportional Deepening
4230	4.01.0316.1.01.8	KA	HBE 440.24 & TP461340.000	Control Unit of Servo Valve
4231	4.01.0317.1.01.9	KA	TU25.7301-CC66-90 IEM 102-1-01-2 EM 102-1-05-2	Control Unit Servo Valve
4232	4.01.0318.1.01.1	KA	MCBP 461-161.432	Power Supply PCB
4233	4.01.0319.1.01.2	KA	161.14.22.330	Pendulum PCB
4234	4.01.0320.1.01.3	KA	461161420	Versine PCB
4235	4.01.0321.1.01.4	KA	461264547	Front Tower Lifting PCB
4236	4.01.0322.1.01.5	PL	EK-99V-00A	PCB Complete
4237	4.01.0323.1.01.6	PL	EL-T 5353.00	PCB
4238	4.01.0324.1.01.7	KA	1023.14.12.030	Pendulum PCB
4239	4.01.0325.1.01.8	KA	161.14.21.210	Tamping Unit PCB
4240	4.01.0326.1.01.9	KA	1023.14.12.020	PCB Lifting
4241	4.01.0327.1.01.1	KA	MCBP 461264.547	Front Tower Lifting PCB (Setting Device Lift/Slew)
4242	4.01.0328.1.01.2	PL	EK-855.SV	PCB
4243	4.01.0329.1.01.3	PL	64.07.5000.169	PCB
4244	4.01.0330.1.01.4	PL	EK29V.00	PRINTED CIRCUIT BOARD
4245	4.01.0331.1.01.5	PL	EK.152V.00	P.C.B (CPL)
4246	4.01.0332.1.01.6	PL	EL-T.5384.00	P.C.B (CPL)
4247	4.01.0333.1.01.7	PL	EK353 P/S-00B	PRINTED CIRCUIT BOARD
4248	4.01.0334.1.01.8	PL	EK664P.00B(EK654P.00IR)	P.C.B
4249	4.01.0335.1.01.9	CR	K-393.171	SEPERATE BRAKING MODULE
4250	4.01.0336.1.01.1	CR	6ES7155-6AU00-0CNO	INTERFACE MODULE

4251	4.01.0337.1.01.2	CR	MCR-VDC-UI-B-DC	VOLTAGE MEASURING MODULE
4252	4.01.0338.1.01.3	CR	6ES7138-6CG00-0BA0	TIME STAMP MODULE
4253	4.01.0339.1.01.4	CR	6ES7131-6BH01-0BA0	DIGITAL INPUT MODULE (16 digital input module)
4254	4.01.0340.1.01.5	CR	6ES7132-6BH01-0BA0	DIGITAL OUTPUT MODULE (16 digital output module)
4255	4.01.0341.1.01.6	CR	6ES7132-6BD20-0BA0	4 points digital output module
4256	4.01.0342.1.01.7	CR	6ES7134-6HD01-0BA1	analog input module
4257	4.01.0343.1.01.8	CR	6ES7135-6HD00-0BA1	analog output module
4258	4.01.0344.1.01.9	CR	QUINT-PS/24DC/24DC/10	DC/DC power supply
4259	4.01.0345.1.01.1	PL	64.07.5000.197	PRINTED CIRCUIT BOARD CPL
4260	4.01.0346.1.01.2	PL	64.07.5000.218	PRINTED CIRCUIT BOARD CPL
4261	4.01.0347.1.01.3	PL	EK-509CA-00B, SUB : EK-509CA-00A	PRINTED CIRCUIT BOARD POPULATED
4262	4.01.0348.1.01.4	PL	EK-513CA-00B	PRINTED CIRCUIT BOARD CPL
4263	4.01.0349.1.01.5	PL	64.07.5000.158	PRINTED CIRCUIT BOARD CPL
4264	4.01.0350.1.01.6	PL	EK-521CA-00	PRINTED CIRCUIT BOARD CPL
4265	4.01.0351.1.01.7	PL	EK-761P-00B	MICROPROCESSOR MODULE
4266	4.01.0352.1.01.8	PL	ELB-EPO-00A-SLAVE	MICRO PROCESSOR CARD FOR MBI
4267	4.01.0353.1.01.9	PL	EL-T3123LV-00B	PRINTED CIRCUIT BOARD CPL
4268	4.01.0354.1.01.1	PL	EL-T5115.00	PRINTED CIRCUIT BOARD CPL
4269	4.01.0355.1.01.2	PL	EL-T5843. 00A	PRINTED CIRCUIT BOARD CPL
4270	4.01.0356.1.01.3	PL	EL-T5847.00A	PRINTED CIRCUIT BOARD CPL
4271	4.01.0357.1.01.4	PL	EK-637MC-00D/187F	MICRO CONTROLLER FOR SQUEEZING
4272	4.01.0358.1.01.5	PL	ELB-EMO-03-EXTS/300F	MICRO CONTROLLER FOR AUTO POSITION
4273	4.01.0359.1.01.6	PL	EL-T5967.00	PRINTED CIRCUIT BOARD CPL
4274	4.01.0360.1.01.7	PL	ELB-SMO-37A-0006-MCL126	VALVE CARD
4275	4.01.0361.1.01.8	PL	ELB-M00-01-001MCL164	PRINTED CIRCUIT BOARD
4276	4.01.0362.1.01.9	PL	ELB-LAO-27	VOLTAGE STABILISER
4277	4.01.0363.1.01.1	PL	EL-AM30.00	EXTENSION 161N+OUTPUTS
4278	4.01.0364.1.01.2	PL	EL-AM30.03	EXTENSION 4IN+ 4OUT ANALOG
4279	4.01.0365.1.01.3	PL	EL-AM30.05	INPUT COUNTER MODULE
4280	4.01.0366.1.01.4	PL	EL-AM40.00/01	CONNECTING BLOCK FOR EL-AM30.00
4281	4.01.0367.1.01.5	PL	EL-AM40.03/01	CONNECTING BLOCK FOR EL-AM30.03
4282	4.01.0368.1.01.6	PL	EL-AM40.05/01	CONNECTING BLOCK FOR EL-AM30.05
4283	4.01.0369.1.01.7	PL	MINI-PS-12-24DC/5-15DC/2	POWER SUPPLY
4284	4.01.0370.1.01.8	PL	EL-AM60.00	POWER SUPPLY
4285	4.01.0371.1.01.9	PL	RPMD60-2415SG	POWER SUPPLY DC15V/4A
4286	4.01.0372.1.01.1	PL	EK-1AP4-00/1,5A	PCB
4287	4.01.0373.1.01.2	PL	EL-AM20.00	NODE MODULE,CANOPEN
4288	4.01.0374.1.01.3	PL	EL-AM30.01	EXTENSION/32 INPUTS
4289	4.01.0375.1.01.4	PL	EL-AM30.08	ANALOGUE 8 INPUT MODULE
4290	4.01.0376.1.01.5	PL	ELB-EMO-03-16	MICRO CONTROLLER
4291	4.01.0377.1.01.6	PL	ELB-EMO-03-08	MICRO CONTROLLER
4292	4.01.0378.1.01.7	PL	EK-532CA-00	PCB
4293	4.01.0379.1.01.8	PL	EL-T50059.002	PCB
4294	4.01.0380.1.01.9	PL	EK-1030V-00	PCB
4295	4.01.0381.1.01.1	PL	EK-2314LV.00	PCB
4296	4.01.0382.1.01.2	PL	EL-T7162.00	DC/DC CONVERTER
4297	4.01.0383.1.01.3	PL	EL-AM20.01	NODE MODULE,CANOPEN
4298	4.01.0384.1.01.4	PL	EL-T5058.00	PCB
4299	4.01.0385.1.01.5	PL	EK-2214LV.00a	PCB
4300	4.01.0386.1.01.6	PL	EL-T7219.00	DC/DC CONVERTER
4301	4.01.0387.1.01.7	PL	CPU/1-0076-1	CENTRAL CPU
4302	4.01.0388.1.01.8	PL	CPU/1-0076-2	CENTRAL CPU
4303	4.01.0389.1.01.9	PL	ERA-26.08	PR.CIRCUIT BOARD COMPLETE
4304	4.01.0390.1.01.1	PL	EK-761P-00-SPS	PCB
4305	4.01.0391.1.01.2	PL	ELB-SMO-05-MCL60	PCB
4306	4.01.0392.1.01.3	PL	EL-AM30.06	PWM module
4307	4.01.0393.1.01.4	PL	EL-AM40.01	FOR EL-AM30.01
4308	4.01.0394.1.01.5	PL	170-C23NKF10-A1G-TY-N	Star delta starter
4309	4.01.0395.1.01.6	PL	EK-513CA-00	PRINTED CIRCUIT BOARD CPL LINING ADAPTER
4310	4.01.0396.1.01.7	PL	EK-528CA-00A	PRINTED CIRCUIT BOARD CPL
4311	4.01.0397.1.01.8	PL	EK-638MC-00B/174-14F SUBSTITUTE EK-638MC-00C/174-14F or ELB-EMO-03-16/289F	PRINTED CIRCUIT BOARD CPL (LIFTING - U CONTROLLER)
4312	4.01.0398.1.01.9	PL	EK-638MC-00B/175-14F SUBSTITUTE EK-638MC-00C/175-14F or ELB-EMO-03-16/290F	PRINTED CIRCUIT BOARD CPL (LEVELLING - U CONTROLLER)

4313	4.01.0399.1.01.1	PL	EK-638MC-00B/176-14F SUBSTITUTE EK-638MC-00C/176-14F or ELB-EM0-03-16/291F	PRINTED CIRCUIT BOARD CPL (LINING - U CONTROLLER)
4314	4.01.0400.1.01.2	PL	EK-638MC-00B/211 OR EK-638MC-00C/211 OR ELB-EM0-03-16/307	PRINTED CIRCUIT BOARD CPL
4315	4.01.0401.1.01.3	PL	EK-3122LV-00C	PRINTED CIRCUIT BOARD CPL
4316	4.01.0402.1.01.4	PL	EK-3123V-00B, SUB : EK-3123V-00A	PRINTED CIRCUIT BOARD CPL
4317	4.01.0403.1.01.5	PL	ELB-EP0-01-SPS	PRINTED CIRCUIT BOARD CPL
4318	4.01.0404.1.01.6	PL	ELB-M00-01-001 MCL163	UNIVERSAL MODULE (DERAIL SAFETY)
4319	4.01.0405.1.01.7	PL	ELB-SM0-00	PRINTED CIRCUIT BOARD CPL
4320	4.01.0406.1.01.8	PL	ELB-SM0-19A-001-MCL120	PRINTED CIRCUIT BOARD CPL
4321	4.01.0407.1.01.9	PL	ELB-SM0-30-A-000-MCL123 OR ELB-SM0-30-000-MCL123	ALC ADAPTER BOARD
4322	4.01.0408.1.01.1	PL	ELB-SM0-37A-2008-MCL126	VALVE STAGE
4323	4.01.0409.1.01.2	PL	EL-T631.01-GT-A	PRINTED CIRCUIT BOARD CPL
4324	4.01.0410.1.01.3	PL	EL-T895.00	PRINTED CIRCUIT BOARD CPL
4325	4.01.0411.1.01.4	PL	EL-T5151.00	PRINTED CIRCUIT BOARD CPL
4326	4.01.0412.1.01.5	PL	EL-T5534.001R-C/ EL-T5534.001R-A	PRINTED CIRCUIT BOARD CPL
4327	4.01.0413.1.01.6	PL	EL-T5961.00	PRINTED CIRCUIT BOARD CPL
4328	4.01.0414.1.01.7	PL	EL-T50016.00	PRINTED CIRCUIT BOARD CPL
4329	4.01.0415.1.01.8	PL	EL-T50056.00/EL-T50056-MA.00	PRINTED CIRCUIT BOARD CPL
4330	4.01.0416.1.01.9	PL	EL-AM10.00	MODULE
4331	4.01.0417.1.01.1	PL	ELB-SA0-22-B OR ELB-SA0-22	DC DC FILTER
4332	4.01.0418.1.01.2	PL	ELB-SM0-01	TEMPERATURE DISPLAY UNIT
4333	4.01.0419.1.01.3	PL	ELB-SM0-01-UU2	DISPLAY UNIT
4334	4.01.0420.1.01.4	PL	ELB-SM0-01-UU4	DISPLAY UNIT
4335	4.01.0421.1.01.5	PL	ELB-SM0-03-MCL95	DIGITAL ANALOG MODUL
4336	4.01.0422.1.01.6	PL	ELB-SM0-07-102-MCL180	UNIVERSAL MODULE
4337	4.01.0423.1.01.7	PL	ELB-SM0-16-A-300-MCL148	MBI MDULE 16 O/P SIGNALS
4338	4.01.0424.1.01.8	PL	ELB-SM0-17-A-300-MCL124	MBI MDULE 16 DIN
4339	4.01.0425.1.01.9	PL	ELB-SM0-31-001-MCL142	DATA COLLECTOR
4340	4.01.0426.1.01.1	PL	ELB-SM0-32-A-001-MCL115	ON BOARD ELECTRICAL SYSTEM MONITORING MODULE
4341	4.01.0427.1.01.2	PL	ELB-SM0-32-MCL115 OR ELB-SM0-32-A-000-MCL115	ON BOARD ELECTRICAL SYSTEM MONITORING
4342	4.01.0428.1.01.3	PL	ELB-ES0-01-A-MCL140 OR ELB-ES0-01-MCL140 OR ELB-ES0-01-000-MCL140	POWER SUPPLY 170W
4343	4.01.0429.1.01.4	PL	EL-T5950.002A/EL-T5950.00-2K-A	FET PULSE AMPLIFIER
4344	4.01.0430.1.01.5	PL	EL-TH00-0000 and Sub Part no. PWD00A-400-19	AMPLIFIER MODULE
4345	4.01.0431.1.01.6	PL	ELB-M00-01-001-MCL168	UNIVERSAL MODULE
4346	4.01.0432.1.01.7	PL	ELB-M00-01-411-MCL162	MICROCONTROLLER
4347	4.01.0433.1.01.8	LO	A81904	Terminal Block Power
4348	4.01.0434.1.01.9	LO	173682	TRANS 480V 120V 750VA
4349	4.01.0435.1.01.1	LO	173729	TRANS 150A-5A 4VA CT
4350	4.01.0436.1.01.2	LO	134819	TIMER BOARD
4351	4.01.0437.1.01.3	LO	229492	Micro processor T1 69677-010
4352	4.01.0438.1.01.4	LO	114961	POWER SUPPLY 480/24 40A DIN RAIL MOUNT
4353	4.01.0439.1.01.5	LO	128272	PLC 1794 TERMINAL BASE
4354	4.01.0440.1.01.6	LO	128274	PLC 1794 TERMINAL BASE FUSED OUTPUTS
4355	4.01.0441.1.01.7	LO	116798	TRANSFORMER 10KVA 240X480-120/240VAC 1PHASE
4356	4.01.0442.1.01.8	LO	247861	GENERATOR; 900 KW
4357	4.01.0443.1.01.9	LO	108541	POWER SUPPLY (UPS) 120V 1500VA RACKMOUNT 6 OUTLET
4358	4.01.0444.1.01.1	LO	104243	TRANSFORMER 120/12VAC 50VA W/ FUSE CLIP
4359	4.01.0445.1.01.2	LO	A37756	TRANSFORMER 480-120V
4360	4.01.0446.1.01.3	LO	101440	POWER SUPPLY 12VDC 57AMP
4361	4.01.0447.1.01.4	LO	252351-39	POWER SUPPLY KIT #2
4362	4.01.0448.1.01.5	LO	252351-54	POWER SUPPLY KIT #3
4363	4.01.0449.1.01.6	LO	A47415	POWER SUPPLY 10 VDC
4364	4.01.0450.1.01.7	PL	EK-3112LV.00	PCB
4365	4.01.0451.1.01.8	PL	EK-2048LV. 00	PCB
4366	4.01.0452.1.01.9	PL	ELB-EM0-02	PCB
4367	4.01.0453.1.01.1	PL	ELB-EM0-01	PCB
4368	4.01.0454.1.01.2	PL	ELB-LOO.20	PCB
4369	4.01.0455.1.01.3	PL	EK-637MC-00C	MICROCONTROL LER
4370	4.01.0456.1.01.4	PL	ELW-SM0-05	UNIVERSAL MODULE
4371	4.01.0457.1.01.5	PL	EK-2683LV.00	VIBRATION CONTROL PCB
4372	4.01.0458.1.01.6	PL	EK-152MC-OOB /	PCB
4373	4.01.0459.1.01.7	PL	EL-T5033.00	PCB

4374	4.01.0460.1.01.8	PL	EL-T5100.00	PCB
4375	4.01.0461.1.01.9	PL	EL-T5895.00	PCB
4376	4.01.0462.1.01.1	PL	EK-1.1 / 2LV2.00	PCB
4377	4.01.0463.1.01.2	PL	EK-1.1/ 5LV2.00	PCB
4378	4.01.0464.1.01.3	PL	EL-T5258.00A	PCB
4379	4.01.0465.1.01.4	PL	EL-T5259.00A	PCB
4380	4.01.0466.1.01.5	PL	EL-T5271.00A	PCB
4381	4.01.0467.1.01.6	PL	EL-T5376.00A	PCB
4382	4.01.0468.1.01.7	PL	EL-T5825.00A	PCB
4383	4.01.0469.1.01.8	PL	EL-T5865.00A	PCB
4384	4.01.0470.1.01.9	PL	EK-526MC.00A	MICROCONTROL LER
4385	4.01.0471.1.01.1	PL	EK-2349 LV.00	PCB
4386	4.01.0472.1.01.2	PL	EL-T5686.00	PCB
4387	4.01.0473.1.01.3	PL	EL-T5722.00	PCB
4388	4.01.0474.1.01.4	PL	EL-T4S1.07B	PCB
4389	4.01.0475.1.01.5	PL	EL-T5586.00	PCB
4390	4.01.0476.1.01.6	PL	EK-528CA.00A	PCB
4391	4.01.0477.1.01.7	PL	EK-620MC.00	MICROCONTROL LER
4392	4.01.0478.1.01.8	PL	EK-2345LV.00	PCB
4393	4.01.0479.1.01.9	PL	EK-527CA.00	PCB
4394	4.01.0480.1.01.1	PL	62.07.1000.341	PCB
4395	4.01.0481.1.01.2	PL	ELB-SM0-04-MCL56	MICROCONTROLLER
4396	4.01.0482.1.01.3	PL	EK-517CA-00	PRINTED CIRCUIT BOARD CPL LINING ADAPTER
4397	4.01.0483.1.01.4	PL	EK-638MC-00B/179-14F Sub EK-638MC-00C/179-14F Sub ELB-EM0-03-16/294F	ANALOG DTS DRIVE CONTROLLER
4398	4.01.0484.1.01.5	PL	EK-638MC-00B/184F Sub EK-638MC-00C/184F Sub ELB-EM0-03-16/295F	ANALOG DRIVE CONTROL
4399	4.01.0485.1.01.6	PL	ELB-M00-01-411-MCL168	UNIVERSAL MODULE
4400	4.01.0486.1.01.7	PL	ELB-SM0-31-000-MCL142	DATA COLLECTOR
4401	4.01.0487.1.01.8	PL	ELB-SM0-37A-0001-MCL126	MODULE
4402	4.01.0488.1.01.9	PL	EL-T5832.00	PRINTED CIRCUIT BOARD CPL
4403	4.01.0489.1.01.1	PL	EL-T6109.002	PRINTED CIRCUIT BOARD CPL WITH STEP SWITCH
4404	4.01.0490.1.01.2	COLMAR	H8413070	PUMP ELECTRONIC PLC(16IN-16OUT)
4405	4.01.0491.1.01.3	CR	40082382	DC/DC power supply
4406	4.01.0492.1.01.4	CR	40089137	Anlog input module
4407	4.01.0493.1.01.5	CR	40089138	Anlog input module
4408	4.01.0494.1.01.6	CR	40099361	8-line PCB with capacitor
4409	4.01.0495.1.01.7	CR	40105559	frequency division plate
4410	4.01.0496.1.01.8	KA	MCBP 461161.402	Printed circuit assembly
4411	4.01.0497.1.01.9	HA	4019452	CAN MODULE
4412	4.01.0498.1.01.1	HA	4022695	J-42
4413	4.01.0499.1.01.2	HA	5131876	ENGINE CONTROLLER
4414	4.01.0500.1.01.3	LO	106494	PLC IFM 40P DIG; THRU
4415	4.01.0501.1.01.4	LO	114361	PLC RACK 17 SLOT; CONTROLLOGIX I/O CHASSIS
4416	4.01.0502.1.01.5	LO	160410	PLC MOD CONTROL NET RED; 100 CONNS
4417	4.01.0503.1.01.6	LO	148059	PLC 1756 DIGITAL OUTPUT; 32 OUTPUTS 10-31VDC
4418	4.01.0504.1.01.7	LO	236302	PLC MOD TEMP AI; 8 ISO INPUT RTD OR TC
4419	4.01.0505.1.01.8	LO	121997	PS 12VDC 2.5A; DIN RAIL MOUNT
4420	4.01.0506.1.01.9	LO	246277	H1 PUMP DRIVER CARD
4421	4.01.0507.1.01.1	LO	249024	H1 MOTOR DRIVER CARD
4422	4.01.0508.1.01.2	LO	249053	PROP VALVE DRIVER CARD
4423	4.01.0509.1.01.3	PL	ELB-EM0.04-MCL134	PCB
4424	4.01.0510.1.01.4	PL	EL-T5176	PCB
4425	4.01.0511.1.01.5	PL	ELB-SM0-37-A-2005-MCL126	MICROCONTROLLER
4426	4.01.0512.1.01.6	PL	S-8.61.5	DC/DC CONVERTER (24V -15V)
4427	4.01.0513.1.01.7	PL	EK-2416LV-00	PCB
4428	4.01.0514.1.01.8	PL	EK-508CA.00	PCB
4429	4.01.0515.1.01.9	PL	EL-T5187	PCB
4430	4.01.0516.1.01.1	PL	ELB-SA0-22	DC/DC CONVERTER
4431	4.01.0517.1.01.2	PL	ELB-SMO-03	PCB
4432	4.01.0518.1.01.3	PL	EK-2452LV-00	PCB
4433	4.01.0519.1.01.4	PL	EL-T50010.00	PCB
4434	4.01.0520.1.01.5	PL	EL-T5612	PCB
4435	4.01.0521.1.01.6	PL	EL-T5921	PCB
4436	4.01.0522.1.01.7	PL	EK-521CA-00	PCB
4437	4.01.0523.1.01.8	LO	159411	MODULE ASSY
4438	4.01.0524.1.01.9	PL	64.07.1000.341	PCB
4439	4.01.0525.1.01.1	PL	EK-103.00	PCB
4440	4.01.0526.1.01.2	GE	GE140195	Module
4441	4.01.0527.1.01.3	GE	GE149108	Module
4442	4.01.0528.1.01.4			

4443	4.01.0529.1.01.5	GE	GE149105	Module
4444	4.01.0530.1.01.6	GE	GE149106	Module
4445	4.01.0531.1.01.7	GE	GE149109	Module
4446	4.02.0001.1.01.9	PL	805468	TRANSISTOR
4447	4.02.0002.1.01.1	PL	100V/0,1MF	CAPACITOR
4448	4.02.0003.1.01.2	PL	100V/470/PF	CAPACITOR
4449	4.02.0004.1.01.3	PL	10MUEF50V/AXIAL	CAPACITOR
4450	4.02.0005.1.01.4	PL	10NF100V/VERTICAL/R=5MM SUB. 100V/10NF/R=5MM	CAPACITOR
4451	4.02.0006.1.01.5	PL	10UF/50V	CONDENSOR
4452	4.02.0007.1.01.6	PL	18PF	CAPACITOR
4453	4.02.0008.1.01.7	PL	1A600V1N4005	DIODE
4454	4.02.0009.1.01.8	PL	1MUEF50V-TA/R=2,5MM	CAPACITOR
4455	4.02.0010.1.01.9	PL	1N4148	DIODE
4456	4.02.0011.1.01.1	PL	1N5629A	ZENNER DIODE
4457	4.02.0012.1.01.2	PL	1N5637A	DIODE
4458	4.02.0013.1.01.3	PL	1N5642	DIODE
4459	4.02.0014.1.01.4	PL	1N5644A	DIODE
4460	4.02.0015.1.01.5	PL	2.2UF/50V	CONDENSOR
4461	4.02.0016.1.01.6	PL	2.2UF/63V	CONDENSOR
4462	4.02.0017.1.01.7	PL	255.36B	RELAY FOR KK2000 A/C WEBASTO
4463	4.02.0018.1.01.8	PL	2N2905A (BSV 15)	TRANSISTOR
4464	4.02.0019.1.01.9	PL	2N3019 SUB. BSW-67	TRANSISTOR
4465	4.02.0020.1.01.1	PL	2N3055	TRANSISTOR
4466	4.02.0021.1.01.2	PL	330PF100V/VERTICAL/R=5MM SUB. 100V/330PF/R=5MM	CAPACITOR
4467	4.02.0022.1.01.3	PL	35V/4.7MF	CAPACITOR
4468	4.02.0023.1.01.4	PL	3A1000VIN5408	DIODE
4469	4.02.0024.1.01.5	PL	4,7MUEF50V-TA/R=5MM	CAPACITOR
4470	4.02.0025.1.01.6	PL	4.7MF/10V	CONDENSOR
4471	4.02.0026.1.01.7	PL	40V/470MF	CAPACITOR
4472	4.02.0027.1.01.8	PL	40V4700MUEF/AXIAL	CAPACITOR
4473	4.02.0028.1.01.9	PL	40V47MUEF/TA/VERT	CAPACITOR
4474	4.02.0029.1.01.1	PL	50V/10MF	CAPACITOR
4475	4.02.0030.1.01.2	PL	50V1000MF	CAPACITOR
4476	4.02.0031.1.01.3	PL	50V22MUEF/AXIAL/BIPOL SUB. 63V22MUEF/AXIAL/BIPOL	CAPACITOR
4477	4.02.0032.1.01.4	PL	556/DIP14-POL	INTEGRATED CIRCUIT
4478	4.02.0033.1.01.5	PL	63V/0.22MUEF/AXIAL	CAPACITOR
4479	4.02.0034.1.01.6	PL	63V/10MF	CAPACITOR
4480	4.02.0035.1.01.7	PL	63V/1MF	CAPACITOR
4481	4.02.0036.1.01.8	PL	63V/220MUEF/AXIAL	CAPACITOR
4482	4.02.0037.1.01.9	PL	63V2.2MUEF/AXIAL	CONDENSOR
4483	4.02.0038.1.01.1	PL	68NF100V/VERTICAL/R=5MM SUB. 100V/68NF/R=5MM	CAPACITOR
4484	4.02.0039.1.01.2	PL	68NF100V/VERTIKAL/R=5MM	CAPACITOR
4485	4.02.0040.1.01.3	PL	68UF	CONDENSOR
4486	4.02.0041.1.01.4	PL	747DIP14-POL.	INTEGRATED CIRCUIT
4487	4.02.0042.1.01.5	PL	7805/TO220	VOLTAGE REGULATOR
4488	4.02.0043.1.01.6	PL	7805/TO3	VOLTAGE REGULATOR
4489	4.02.0044.1.01.7	PL	7812/TO220	VOLTAGE REGULATOR
4490	4.02.0045.1.01.8	PL	7812/TO3	VOLTAGE REGULATOR
4491	4.02.0046.1.01.9	PL	7815/TO220	VOLTAGE REGULATOR
4492	4.02.0047.1.01.1	PL	7824C/TO220AB	VOLTAGE REGULATOR
4493	4.02.0048.1.01.2	PL	BC182A	TRANSISTOR
4494	4.02.0049.1.01.3	PL	BC212A	TRANSISTOR
4495	4.02.0050.1.01.4	PL	BC546B	TRANSISTOR
4496	4.02.0051.1.01.5	PL	BC549B	TRANSISTOR
4497	4.02.0052.1.01.6	PL	BC556B	TRANSISTOR
4498	4.02.0053.1.01.7	PL	BD677	TRANSISTOR
4499	4.02.0054.1.01.8	PL	BD678	TRANSISTOR
4500	4.02.0055.1.01.9	PL	BD681	TRANSISTOR
4501	4.02.0056.1.01.1	PL	BDV64B	TRANSISTOR
4502	4.02.0057.1.01.2	PL	BDV65B	TRANSISTOR
4503	4.02.0058.1.01.3	PL	BSX46-10	TRANSISTOR
4504	4.02.0059.1.01.4	PL	BUF634	INTEGRATED CIRCUIT
4505	4.02.0060.1.01.5	PL	BUZ-20	TRANSISTOR
4506	4.02.0061.1.01.6	PL	C-MOS4001B	CIRCUIT
4507	4.02.0062.1.01.7	PL	C-MOS4014B	CIRCUIT
4508	4.02.0063.1.01.8	PL	C-MOS4023B	INTEGRATED CIRCUIT
4509	4.02.0064.1.01.9	PL	C-MOS4029B	INTEGRATED CIRCUIT
4510	4.02.0065.1.01.1	PL	C-MOS4040B	INTEGRATED CIRCUIT
4511	4.02.0066.1.01.2	PL	C-MOS4042B	INTEGRATED CIRCUIT
4512	4.02.0067.1.01.3	PL	C-MOS4049B	INTEGRATED CIRCUIT
4513	4.02.0068.1.01.4	PL	C-MOS4050B	INTEGRATED CIRCUIT
4514	4.02.0069.1.01.5	PL	C-MOS4059BPN	INTEGRATED CIRCUIT
4515	4.02.0070.1.01.6	PL	C-MOS4060B	CIRCUIT

4516	4.02.0071.1.01.7	PL	C-MOS4081B	INTEGRATED CIRCUIT
4517	4.02.0072.1.01.8	PL	C-MOS4082B	INTEGRATED CIRCUIT
4518	4.02.0073.1.01.9	PL	C-MOS4093B	INTEGRATED CIRCUIT
4519	4.02.0074.1.01.1	PL	C-MOS4094B	INTEGRATED CIRCUIT
4520	4.02.0075.1.01.2	PL	C-MOS4099B	INTEGRATED CIRCUIT
4521	4.02.0076.1.01.3	PL	C-MOS4500B	INTEGRATED CIRCUIT
4522	4.02.0077.1.01.4	PL	C-MOS4504B	INTEGRATED CIRCUIT
4523	4.02.0078.1.01.5	PL	C-MOS4512B	INTEGRATED CIRCUIT
4524	4.02.0079.1.01.6	PL	C-MOS4514B	INTEGRATED CIRCUIT
4525	4.02.0080.1.01.7	PL	C-MOS4555B	INTEGRATED CIRCUIT
4526	4.02.0081.1.01.8	PL	EL-T1218S	RELAY
4527	4.02.0082.1.01.9	PL	EL-T1501.00	INTEGRATED CIRCUIT
4528	4.02.0083.1.01.1	PL	EL-T295S	RELAY
4529	4.02.0084.1.01.2	PL	EL-T470S-T SUB. EL-T470S (GKLV-A/K/B)	RELAY
4530	4.02.0085.1.01.3	PL	EL-T470S-T SUB. EL-T470S	RELAY
4531	4.02.0086.1.01.4	PL	EL-T5610.00 SUB. FZH241	INTEGRATED CIRCUIT
4532	4.02.0087.1.01.5	PL	ELT7002/S2-L2	RELAY
4533	4.02.0088.1.01.6	PL	EL-T7003	RELAY SOCKET
4534	4.02.0089.1.01.7	PL	EL-T7011	RELAY
4535	4.02.0090.1.01.8	PL	EL-T7018	RELAY
4536	4.02.0091.1.01.9	PL	EL-T7045/12	RELAY
4537	4.02.0092.1.01.1	PL	EL-T7045/24V	RELAY
4538	4.02.0093.1.01.2	PL	EL-T7064/24	RELAY
4539	4.02.0094.1.01.3	PL	EL-T7068	DIODE
4540	4.02.0095.1.01.4	PL	EL-T7077.032 SUB. ZR012026	TIME RELAY
4541	4.02.0096.1.01.5	PL	EL-T7077.032 SUB. ZR012036	TIME RELAY
4542	4.02.0097.1.01.6	PL	EL-T7077.032 SUB. ZR012056	TIME RELAY
4543	4.02.0098.1.01.7	PL	EL-T7125	RELAY
4544	4.02.0099.1.01.8	PL	EL-T7125-NA	RELAY
4545	4.02.0100.1.01.9		Shifted to Ann-II	
4546	4.02.0101.1.01.1	PL	EL-T7284.00	RELAY
4547	4.02.0102.1.01.2	PL	FZK105	INTEGRATED CIRCUIT
4548	4.02.0103.1.01.3	PL	GAL16V8D-25NS/LP(LP14.1) SUB. GAL16V8D-25NS/LP(1.8.B.9)	INTEGRATED CIRCUIT WITH PROGRAMME
4549	4.02.0104.1.01.4	PL	GAL16V8D-25NS/LP(LP2.1) SUB. GAL16V8D-25NS/LP(2.5.4.6)	INTEGRATED CIRCUIT WITH PROGRAMME
4550	4.02.0105.1.01.5	PL	GAL16V8D-25NS/LP(LP3.1) SUB. GAL16V8D-25NS/LP(2.0.2.2)	INTEGRATED CIRCUIT WITH PROGRAMME
4551	4.02.0106.1.01.6	PL	HC-MOS74HC08AN	CIRCUIT
4552	4.02.0107.1.01.7	PL	HC-MOS74HC125N	CIRCUIT
4553	4.02.0108.1.01.8	PL	HC-MOS74HC132AN	CIRCUIT
4554	4.02.0109.1.01.9	PL	HC-MOS74HC161N	CIRCUIT
4555	4.02.0110.1.01.1	PL	HC-MOS74HC251N	CIRCUIT
4556	4.02.0111.1.01.2	PL	HC-MOS74HC259N	CIRCUIT
4557	4.02.0112.1.01.3	PL	HC-MOS74HC365N	CIRCUIT
4558	4.02.0113.1.01.4	PL	HC-MOS74HC366N	CIRCUIT
4559	4.02.0114.1.01.5	PL	HC-MOS74HC4514N	CIRCUIT
4560	4.02.0115.1.01.6	PL	HC-MOS74HC540N	CIRCUIT
4561	4.02.0116.1.01.7	PL	HC-MOS74HCT14	CIRCUIT
4562	4.02.0117.1.01.8	PL	HEF4731BP SUB. C-MOS4731B	INTEGRATED CIRCUIT
4563	4.02.0118.1.01.9	PL	ICL7660CPA	CIRCUIT
4564	4.02.0119.1.01.1	PL	IN4007	DIODE
4565	4.02.0120.1.01.2	PL	LM124J	INTEGRATED CIRCUIT
4566	4.02.0121.1.01.3	PL	LM139J	INTEGRATED CIRCUIT
4567	4.02.0122.1.01.4	PL	LT1001CN8 SUB. OP02C/DIP8-POL	INTEGRATED CIRCUIT
4568	4.02.0123.1.01.5	PL	MCT6 SUB. CNY74-2	INTEGRATED CIRCUIT
4569	4.02.0124.1.01.6	PL	MSK0041 SUB. LH0041CG	INTEGRATED CIRCUIT
4570	4.02.0125.1.01.7	PL	NE555P/DIP8-POL SUB. 555/DIP8-POL	CIRCUIT
4571	4.02.0126.1.01.8	PL	OP11EPZ SUB. OP11GP	INTEGRATED CIRCUIT
4572	4.02.0127.1.01.9	PL	PA-76A SUB. PA-25	AMPLIFIER
4573	4.02.0128.1.01.1	PL	PCF8574P	CIRCUIT
4574	4.02.0129.1.01.2	PL	REF-01-CPZ SUB. REF-01-CP	INTEGRATED CIRCUIT
4575	4.02.0130.1.01.3	PL	REL-26-01/24VAC, SUB GM10/24LQ203024	RELAY
4576	4.02.0131.1.01.4	PL	RM732024	RELAY
4577	4.02.0132.1.01.5	PL	RM738024	RELAY
4578	4.02.0133.1.01.6	PL	SAA1029	INTEGRATED CIRCUIT
4579	4.02.0134.1.01.7	PL	SN74F573	CIRCUIT
4580	4.02.0135.1.01.8	PL	SN74HC-125	INTEGRATED CIRCUIT
4581	4.02.0136.1.01.9	PL	SN74HC-355	INTEGRATED CIRCUIT
4582	4.02.0137.1.01.1	PL	SN74HC-366	INTEGRATED CIRCUIT
4583	4.02.0138.1.01.2	PL	TAA765A SUB. TAA765A/SMD-GESOCKELT	AMPLIFIER
4584	4.02.0139.1.01.3	PL	TCA2465	AMPLIFIER
4585	4.02.0140.1.01.4	PL	TL071ACP SUB. OPA131PA	AMPLIFIER

4586	4.02.0141.1.01.5	PL	TL084CDP	INTEGRATED CIRCUIT
4587	4.02.0142.1.01.6	PL	TN2-5V	RELAY
4588	4.02.0143.1.01.7	PL	UA741-CP/DIP8 SUB. 741DIP8-POL	INTEGRATED CIRCUIT
4589	4.02.0144.1.01.8	PL	ULN2803A	INTEGRATED CIRCUIT
4590	4.02.0145.1.01.9	PL	ULN2804A	TRANSISTOR
4591	4.02.0146.1.01.1	PL	ZPY10	DIODE
4592	4.02.0147.1.01.2	PL	ZR5MF025	TIME RELAY
4593	4.02.0148.1.01.3	KE	164032	RELAY
4594	4.02.0149.1.01.4	LO	100642	RELAY 24VDC 2P TIMER 0.1SEC - 600 HRS
4595	4.02.0150.1.01.5	LO	103482	CONTROL MODULE SCR-2
4596	4.02.0151.1.01.6	LO	103488	BRIDGE RECTIFIER
4597	4.02.0152.1.01.7	LO	114960	SURGE SUPPRESSOR 120V 20A DIN RAIL MOUNT
4598	4.02.0153.1.01.8	LO	116489	RELAY 2PDT 240VAC 10A
4599	4.02.0154.1.01.9	LO	117872	SOLENOID DRIVER CAMERA TILT SOLENOID
4600	4.02.0155.1.01.1	LO	119058	RELAY 3-NO, 1-NC 24VDC POSITIVE-GUIDED CONTACTS
4601	4.02.0156.1.01.2	LO	119705	RECTIFIER ASSY GENERATOR 900KW
4602	4.02.0157.1.01.3	LO	123703	RELAY 24VDC 1 DIN RAIL SPDT TERMINAL BLOCK RELAY
4603	4.02.0158.1.01.4	LO	126642	SURGE SUPPRESSOR 480V
4604	4.02.0159.1.01.5	LO	126994	RELAY 24VDC 10 AMP DPDT
4605	4.02.0160.1.01.6	LO	128988	FILTER HARMONIC SUPPRESSION FOR 480V 3P POWER SUPPLY
4606	4.02.0161.1.01.7	LO	130558	ROTOR EXCITER W/POWEREX DIODES
4607	4.02.0162.1.01.8	LO	131544	SURGE PROTECTOR
4608	4.02.0163.1.01.9	LO	144090	SOLENIOD 24V SERVO
4609	4.02.0164.1.01.1	LO	149424	RELAY 24VDC 4PDT BLADE WITH LIGHT AND SURGE SUPP
4610	4.02.0165.1.01.2	LO	149425	RELAY 24VDC DPDT BLADE WITH LIGHT AND SURGE SUPP
4611	4.02.0166.1.01.3	LO	149563	SOLENOID ASSY 24 VDC DIN COIL CORE TUBE NUT ORINGS
4612	4.02.0167.1.01.4	LO	152644	COIL STD 24V DC
4613	4.02.0168.1.01.5	LO	159508	FORWARD DIODE
4614	4.02.0169.1.01.6	LO	159509	REVERSE DIODE
4615	4.02.0170.1.01.7	LO	A79413	RELAY
4616	4.02.0171.1.01.8	LO	A91267	RELAY TIMER DPDT 100-240V; 0.1 SEC TO 600 HOURS
4617	4.02.0172.1.01.9	LO	B75057	ACTUATOR LINEAR 120VAC
4618	4.02.0173.1.01.1	KA	DEM 102.1.05.2 SETTING 1.5KGF/CM2	PRESSURE TRANSDUCER RELAY
4619	4.02.0174.1.01.2	KA	DEM102.1.01.2 SETTING 0 KGF/CM2	PRESSURE TRANSDUCER RELAY
4620	4.02.0175.1.01.3	KA	G2R.ISNDI 24 VDC	TIME RELAY
4621	4.02.0176.1.01.4	PL	ADC80AG-12	CONVERTER
4622	4.02.0177.1.01.5	PL	ADDAC80N-CBI-V SUBSTITUTE DAC80CBI-V	CONVERTER
4623	4.02.0178.1.01.6	PL	ADS574KP	CONVERTER
4624	4.02.0179.1.01.7	PL	AQW214J	RELAY
4625	4.02.0180.1.01.8	PL	AQW614J	RELAY
4626	4.02.0181.1.01.9	PL	ASL035.9214.1	DIODE
4627	4.02.0182.1.01.1	PL	EL-T5226.00	TIME RELAY
4628	4.02.0183.1.01.2	PL	ELT-700-00036	RELAY 300A 24V
4629	4.02.0184.1.01.3	PL	EL-T7002/S3	RELAY
4630	4.02.0185.1.01.4	PL	EL-T7077.032 SUBSTITUTE ZR012026	TIME RELAY
4631	4.02.0186.1.01.5	PL	EL-T7077.032 SUBSTITUTE ZR012036	TIME RELAY
4632	4.02.0187.1.01.6	PL	EL-T7077.032 SUBSTITUTE ZR012056	TIME RELAY
4633	4.02.0188.1.01.7	PL	SKR20/08	DIODE WITHOUT HEAT SINK
4634	4.02.0189.1.01.8	PL	H3T/24V/0.1-5SEC	TIME RELAY
4635	4.02.0190.1.01.9	PL	ELT-700-00017 SUBSTITUTE ZR4MF025-L	TIME RELAY
4636	4.02.0191.1.01.1	PL	H3FA-SB/12-24VDC	Time relay
4637	4.02.0192.1.01.2	PL	25536B SUBSTITUTE 255.36B	RELAY FOR KK2000 A/C WEBASTO
4638	4.02.0193.1.01.3	PL	ELT-700-00022	RELAY 50A 24V NC&NO
4639	4.02.0194.1.01.4	PL	33200220	RELAY
4640	4.02.0195.1.01.5	PL	332002250	RELAY
4641	4.02.0196.1.01.6	PL	332209203	RELAY
4642	4.02.0197.1.01.7	PL	335215143	RELAY
4643	4.02.0198.1.01.8	PL	EL-T470S-T SUBSTITUTE EL-T470S	RELAY

4644	4.02.0199.1.01.9	PL	EL-T7002/S2	RELAY
4645	4.02.0200.1.01.1	L	REL26.01/24VAC SUBSTITUTE GM10/24LQ203024	RELAY
4646	4.02.0201.1.01.2	PL	0331802100 SUBSTITUTE 0331801300	RELAY
4647	4.02.0202.1.01.3	PL	EL-T7002/L2	RELAY
4648	4.02.0203.1.01.4	PL	288-414 SUBSTITUTE EL-T7284.00	RELAY
4649	4.02.0204.1.01.5	PL	EL-T470S-T SUBSTITUTE EL- T470S(GKLV-A/K/B)	RELAY
4650	4.02.0205.1.01.6	PL	27128 SUBSTITUTE 27C128	E-PROM-"HI" PROGRAMMED
4651	4.02.0206.1.01.7	PL	EL-T 663	Relay
4652	4.02.0207.1.01.8	PL	EL-T 277	Relay
4653	4.02.0208.1.01.9	KA	PH-116 (For GP6.5)	Relay Controller
4654	4.02.0209.1.01.1	KA	TU16-523-583-80	Relay PHE-31G 24B Tropicalized Construction
4655	4.02.0210.1.01.2	KA	MY41N-D2,24VDC	Relay OMRAN MY41N-D2, 24VDC With Block
4656	4.02.0211.1.01.3	KA	G2R1-SNBI 24VDC	Electromagnetic Relay FA OMRAN With Block
4657	4.02.0212.1.01.4	KA	LG12DC4.521.901<0425.001TU	K2 Relay
4658	4.02.0213.1.01.5	Repeated item		
4659	4.02.0214.1.01.6	KA	PYF14A-E (OMRAN)	Relay
4660	4.02.0215.1.01.7	KA	GTL-1A-T 24VDC With Block PTLF-06	Relay
4661	4.02.0216.1.01.8	KA	LOGO 1.12/24 RCD.6EDI.052.2MDO-OBA6	Relay
4662	4.02.0217.1.01.9	KA	BK17-31-P-35-400-ind-38	Pressure Transducer Relay
4663	4.02.0218.1.01.1	Repeated item		
4664	4.02.0219.1.01.2	KA	BJ1-64B 2VV1-IOC	K2 Relay II 112 PC4.521
4665	4.02.0220.1.01.3	KA	RCO.6EDI.052.2MDOO-OBA6	Time Relay KT3
4666	4.02.0221.1.01.4	KA	BL-64, 24V, 3-3C. TU16-674.039- 86	Time Relay
4667	4.02.0222.1.01.5	KA	DP12 RS/PC 4521.901.Bgo.425.001TU	Relay K2
4668	4.02.0223.1.01.6	KA	VL-64, 24V, 1-10C, EXPORT TU16.674.039.86	Timer Relay
4669	4.02.0224.1.01.7	KA	VI-64, UHL4.1, 27V, 3-3C TU-16- 674.039.86	Time Relay
4670	4.02.0225.1.01.8	KA	P2RF-14/25-E	MV41 N-02, 24 VOC With Block
4671	4.02.0226.1.01.9	KA	PLTF-06	G2R-1 SNDI-24VOC With Block
4672	4.02.0227.1.01.1	KA	901.01.0425.001.TU	GTL-IA-T 24 VOC With Block
4673	4.02.0228.1.01.2	KA	LOGO/12/24RCD 6ED1052- 2MDOO-OBA6	Logic Module Siemens
4674	4.02.0229.1.01.3	KA	PC4.520.201.01 TTD.425.080 TU PC4.520.208-01 PC4.520.216-01	Relay PTC-32G Constr.
4675	4.02.0230.1.01.4	KA	PGC-32<PC4.520.201- 01ZKO.452.080 TU PC4. 520.208- 01 PC4.520.216-01	K9 Relay
4676	4.02.0231.1.01.5	KA	DEM102-1-02, Setting on 0Kg/Cm square TU25-73.01.0066-90	Pressure Transducer Relay
4677	4.02.0232.1.01.6	KA	PC4.520.201.01.TTD.452.080 TU PC4.520.208-01 PC4.520.216-01	Relay PTTC-32G Constr
4678	4.02.0233.1.01.7	GE	3062	Relay-1
4679	4.02.0234.1.01.8	GE	A0230002	Relay-2
4680	4.02.0235.1.01.9	GE	A0230001	Relay-3
4681	4.02.0236.1.01.1	CR	PLC-RSC-24DC/21HC	RELAY-1
4682	4.02.0237.1.01.2	CR	PLC-RSC-24DC/21	RELAY-2
4683	4.02.0238.1.01.3	CR	PLC-RSC-24DC/21-21	RELAY-3
4684	4.02.0239.1.01.4	CR	XPSAF5130	SAFETY RELAY-1
4685	4.02.0240.1.01.5	CR	SE-100C/SCHMERSAL	SAFETY RELAY-2
4686	4.02.0241.1.01.6	CR	TL-16A/1P-24VDC	PULSE RELAY
4687	4.02.0242.1.01.7	CR	40098525	POWER RELAY 120A
4688	4.02.0243.1.01.8	CR	40098529	POWER RELAY 60A
4689	4.02.0244.1.01.9	CR	40096416	SAFETY RELAY
4690	4.02.0245.1.01.1	PL	PNOZX2	Emergency -off relay
4691	4.02.0246.1.01.2	PL	ZR5MF0111	Multi function Timer relay
4692	4.02.0247.1.01.3	PL	LQ617048	impulse relay
4693	4.02.0248.1.01.4	PL	RIF-1-BPT/2X21	RELAY BASE
4694	4.02.0249.1.01.5	PL	PR1-BSC2/2X21	Relay base
4695	4.02.0250.1.01.6	PL	332002258	RELAY
4696	4.02.0251.1.01.7	PL	RIF-LDP-12-24DC	relay catridge
4697	4.02.0252.1.01.8	PL	0333002250	RELAY
4698	4.02.0253.1.01.9	PL	PP.BOP.0522	POWER RELAY 60A
4699	4.02.0254.1.01.1	PL	ELB-S00-01	DECOUPLING CAPACITOR
4700	4.02.0255.1.01.2	LO	173686	DB 0.10A 1P 277V EXCITATION
4701	4.02.0256.1.01.3	LO	125692	RECTIFIER ASSEMBLY
4702	4.02.0257.1.01.4	LO	215332	DIODE STANDARD POLARITY

4703	4.02.0258.1.01.5	LO	215333	DIODE REVERSE POLARITY
4704	4.02.0259.1.01.6	LO	107081	RELAY BASE
4705	4.02.0260.1.01.7	LO	205279	COIL 24VDC DIN;DO3 FITS REV C VALVE
4706	4.02.0261.1.01.8	LO	134829	RELAY BASE 8 PIN OCTAL
4707	4.02.0262.1.01.9	LO	A35629	RELAY STARTER (REPLACES A71826)
4708	4.02.0263.1.01.1	LO	A70104	RELAY BASE
4709	4.02.0264.1.01.2	LO	A84468	SOCKET RELAY 2 POLE
4710	4.02.0265.1.01.3	LO	246786	RELAY CLIP ASSEMBLY
4711	4.02.0266.1.01.4	LO	208622	COIL 24VDC DIN D05;FITS REV B VALVES
4712	4.02.0267.1.01.5	PL	ELW-LS0-01	DC/DC CONVERTER
4713	4.02.0268.1.01.6	PL	EL-T7154. 00	DC/ DC CONVERTER
4714	4.02.0269.1.01.7	PL	EL-T700-00020	RELAY, 50 A, 24 V NC & NO
4715	4.02.0270.1.01.8	PL	ZR03032090 20M	RELAY
4716	4.02.0271.1.01.9	PL	EL-T7046/24	RELAY
4717	4.02.0272.1.01.1	PL	EL-T521/6B	MAGNET COIL 24V DC
4718	4.02.0273.1.01.2	PL	EL-T521/10A	MAGNET COIL 24V DC
4719	4.02.0274.1.01.3	PL	EL-T521/10B	MAGNET COIL 24V DC
4720	4.02.0275.1.01.4	PL	EL-T522/90338H	MAGNET COIL 24V DC
4721	4.02.0276.1.01.5	PL	EL-T522/90254	MAGNET COIL 24V DC
4722	4.02.0277.1.01.6	PL	VT2000-5X	AMPLIFIER
4723	4.02.0278.1.01.7	PL	K9M6+1+SKR20/08	POWER DIODE
4724	4.02.0279.1.01.8	COLMAR	H3431060/C22-D12K1/10	SOLENOID
4725	4.02.0280.1.01.9	COLMAR	H3492520	Coil for solenoid
4726	4.02.0281.1.01.1	COLMAR	H8253110	General safety Relay
4727	4.02.0282.1.01.2	COLMAR	H8252690	RELAY
4728	4.02.0283.1.01.3	COLMAR	H8252640	TEMPERATURE REGULATOR RELAY
4729	4.02.0284.1.01.4	COLMAR	H9311120	SEALED RELAY
4730	4.02.0285.1.01.5	CR	40065770	Relay
4731	4.02.0286.1.01.6	CR	40065780	Relay
4732	4.02.0287.1.01.7	CR	40080668	Impulse Relay
4733	4.02.0288.1.01.8	CR	40082052	Relay
4734	4.02.0289.1.01.9	CR	40082330	Relay
4735	4.02.0290.1.01.1	CR	40100040	Relay
4736	4.02.0291.1.01.2	KA	PC4520.201-01	Relay 24V
4737	4.02.0292.1.01.3	HA	172164	RELAY [WORK, JUPITOR, COMPRESSOR]
4738	4.02.0293.1.01.4	HA	D0650Y14	PUMP VENT RELAY
4739	4.02.0294.1.01.5	HA	D0650Y18	TRACTION CONTROL RELAY
4740	4.02.0295.1.01.6	HA	D0650Y08	TRACTION STOP RELAY
4741	4.02.0296.1.01.7	HA	H710Y01	EMERGENCY STOP RELAY
4742	4.02.0297.1.01.8	PL	700-FEY2QU23	Timer relay (star delta circuit)
4743	4.02.0298.1.01.9	PL	S-8.62.1.B	Output amplifier
4744	4.02.0299.1.01.1	PL	193-KB40	Relay
4745	4.02.0300.1.01.2	PL	PR1-BSC2/2X21	Relay base
4746	4.02.0301.1.01.3	LO	215331	RECTIFIER ASSY
4747	4.02.0302.1.01.4	LO	106428	OVERLOAD IEC 4.0-6.3A; C2000 SERIES
4748	4.02.0303.1.01.5	LO	127066	SURGE SUPPRESSOR 250VDC
4749	4.02.0304.1.01.6	LO	252494	SOLENOID, COIL KIT; DANFOSS H1 PUMP 24V
4750	4.02.0305.1.01.7	PL	PNOZ-S4-COATED	RELAY
4751	4.02.0306.1.01.8	LO	B83480	RELAY-MECHANICAL LATCH 24VDC COIL 2 POLE
4752	4.02.0307.1.01.9	LO	128225	RELAY REPLACEMENT OUTPUT 24VDC SPDT
4753	4.02.0308.1.01.1	PL	EK-6530-00	Program control I/O card
4754	4.02.0309.1.01.2	PL	5A800V/BY500-800	Diode
4755	4.02.0310.1.01.1	KA	DPZO-A-371-L5/DE18	Proportional valve
4756	4.03.0001.1.01.1	PL	40001.01	CONTACT ELEMENT
4757	4.03.0002.1.01.2	PL	333009002	TEMPERATURE SWITCH
4758	4.03.0003.1.01.3	PL	341003004	BATTERY MAIN SWITCH
4759	4.03.0004.1.01.4		Shifted to Annx-II	
4760	4.03.0005.1.01.5	PL	344400008	OIL PRESSURE SWITCH
4761	4.03.0006.1.01.6	PL	352222006	SOCKET
4762	4.03.0007.1.01.7	PL	604145007	INDUCTIVE TRANSMETER
4763	4.03.0008.1.01.8	ZF	60412320196	MODULATOR
4764	4.03.0009.1.01.9	PL	0242-12	TEMPERATURE SWITCH
4765	4.03.0010.1.01.1	PL	1174555 SUB. 1182840	TEMPERATURE SWITCH
4766	4.03.0011.1.01.2	PL	1175981 / 1182841	TRANSDUCER / PRESSURE SWITCH
4767	4.03.0012.1.01.3	PL	1182708 SUB. 1178104	TEMPERATURE SWITCH
4768	4.03.0013.1.01.4	PL	230.112/005/011 SUB. 230.112/003/006	OIL PRESSURE SWITCH
4769	4.03.0014.1.01.5	PL	232.011/017/017	TEMPERATURE SWITCH
4770	4.03.0015.1.01.6	PL	232.011/017/032	TEMPERATURE SWITCH

4771	4.03.0016.1.01.7	PL	25436NHLD	SWITCH
4772	4.03.0017.1.01.8	PL	31-902-9	COVER (HOOD)
4773	4.03.0018.1.01.9	PL	323.803/001/006	TEMPERATURE SWITCH
4774	4.03.0019.1.01.1	PL	323.803/002/002	TEMPERATURE SWITCH
4775	4.03.0020.1.01.2		Shifted to Annx-II	
4776	4.03.0021.1.01.3	PL	452-K34FN2/100A	CIRCUIT BREAKER
4777	4.03.0022.1.01.4	PL	4609X-101/1KOHM SUB. 90-916870	RESISTOR CIRCUIT
4778	4.03.0023.1.01.5	PL	4880L / 2-166010-1	CONECTOR / PCB STRIP 48 PIN MALE / FEMALE
4779	4.03.0024.1.01.6	PL	5140-06-07-00	CONNECTION
4780	4.03.0025.1.01.7	PL	6041232018 / 0899202498	MODULE
4781	4.03.0026.1.01.8		Shifted to Annx-II	
4782	4.03.0027.1.01.9	PL	64-07-3000-1006	SWITCH BOX
4783	4.03.0028.1.01.1	PL	64-07-3000-1007	SWITCH BOX
4784	4.03.0029.1.01.2	PL	7101S/Z	TUMBLER SWITCH
4785	4.03.0030.1.01.3	PL	7103S/Z	SWITCH
4786	4.03.0031.1.01.4	PL	BX1/1X24V	EBE STEP SWITCH
4787	4.03.0032.1.01.5	PL	CHO-180	SWITCH COMPLETE
4788	4.03.0033.1.01.6		Shifted to Annx-II	
4789	4.03.0034.1.01.7		Shifted to Annx-II	
4790	4.03.0035.1.01.8	PL	EL-T 1301 4018	COLLETTE
4791	4.03.0036.1.01.9	PL	EL-T 1301-5601	SWITCH
4792	4.03.0037.1.01.1	PL	EL-T 1301-5602	PUSH BUTTON
4793	4.03.0038.1.01.2	PL	EL-T 1301-5604	KEY BUTTON
4794	4.03.0039.1.01.3	PL	EL-T 1301-5605	OPEL SQUARE SWITCH
4795	4.03.0040.1.01.4	PL	EL-T 455 C	CLUTCH FLANGE
4796	4.03.0041.1.01.5	PL	EL-T 455 F	RING
4797	4.03.0042.1.01.6	PL	EL-T 455 F KCLR	CAP
4798	4.03.0043.1.01.7	PL	EL-T 455 J	ENGINE BODY
4799	4.03.0044.1.01.8	PL	EL-T 455 T	FLANGE
4800	4.03.0045.1.01.9	PL	EL-T1301.1205	PUSH BUTTON
4801	4.03.0046.1.01.1	PL	EL-T1301.4013	BUTTON
4802	4.03.0047.1.01.2	PL	EL-T1301.4413	BUTTON
4803	4.03.0048.1.01.3	PL	EL-T2111.G6	SWITCH BOX
4804	4.03.0049.1.01.4	PL	EL-T5538.00	SWITCHING OF MEASUREMENT INPUTS
4805	4.03.0050.1.01.5	PL	EL-T5539.00	SWITCHING OF MEASUREMENT INPUTS
4806	4.03.0051.1.01.6	PL	EL-T-6446-00	L P MODULE
4807	4.03.0052.1.01.7	PL	EL-T7012	SWITCH
4808	4.03.0053.1.01.8	PL	EL-T7027	KNOB
4809	4.03.0054.1.01.9	PL	EL-T-7052	STEP SWITCH
4810	4.03.0055.1.01.1		Shifted to Annx-II	
4811	4.03.0056.1.01.2		Shifted to Annx-II	
4812	4.03.0057.1.01.3	PL	EL-T-7126/20 AMP.	CIRCUIT BREAKER
4813	4.03.0058.1.01.4		Shifted to Annx-II	
4814	4.03.0059.1.01.5		Shifted to Annx-II	
4815	4.03.0060.1.01.6		Shifted to Annx-II	
4816	4.03.0061.1.01.7		Shifted to Annx-II	
4817	4.03.0062.1.01.8		Shifted to Annx-II	
4818	4.03.0063.1.01.9		Shifted to Annx-II	
4819	4.03.0064.1.01.1		Shifted to Annx-II	
4820	4.03.0065.1.01.2		Shifted to Annx-II	
4821	4.03.0066.1.01.3		Shifted to Annx-II	
4822	4.03.0067.1.01.4		Shifted to Annx-II	
4823	4.03.0068.1.01.5		Shifted to Annx-II	
4824	4.03.0069.1.01.6		Shifted to Annx-II	
4825	4.03.0070.1.01.7		Shifted to Annx-II	
4826	4.03.0071.1.01.8		Shifted to Annx-II	
4827	4.03.0072.1.01.9		Shifted to Annx-II	
4828	4.03.0073.1.01.1		Shifted to Annx-II	
4829	4.03.0074.1.01.2		Shifted to Annx-II	
4830	4.03.0075.1.01.3		Shifted to Annx-II	
4831	4.03.0076.1.01.4	PL	EL-T7225.00 SUB. EL-T7157	CONVERTER
4832	4.03.0077.1.01.5	PL	G X 1/1 X 12V	SWITCH
4833	4.03.0078.1.01.6	PL	GA 10 BAR 2410203024	SWITCH
4834	4.03.0079.1.01.7	PL	IR6220	POWER SWITCH
4835	4.03.0080.1.01.8	PL	MR2-5	SWITCH
4836	4.03.0081.1.01.9	PL	MV-3	MICRO SWITCH
4837	4.03.0082.1.01.1	KE	182891	TOGGLE SWITCH
4838	4.03.0083.1.01.2	KE	182981	SWITCH TOGGLE-SPST
4839	4.03.0084.1.01.3	KE	182985	SWITCH TOGGLE-DPOT
4840	4.03.0085.1.01.4	KE	560507	PRESSURE SWITCH
4841	4.03.0086.1.01.5	PH	UTVI-07 25/00	BY PASS SWITCH
4842	4.03.0087.1.01.6	PH	UTVI-07 26/00	IGNITION S/W
4843	4.03.0088.1.01.7		Item shifted to Ann -II	

4844	4.03.0089.1.01.8	LO	102245	SWITCH SELECTOR KNOB 4W
4845	4.03.0090.1.01.9	LO	106223	SWITCH PB BLACK; SQUARE FLUSH MOUNT
4846	4.03.0091.1.01.1	LO	106354	SWITCH PB GREEN; SQUARE FLUSH MOUNT
4847	4.03.0092.1.01.2	LO	106357	SWITCH PB MUSHHEAD RED SQUARE PUSH/PULL MAINT
4848	4.03.0093.1.01.3	LO	106362	SWITCH PB ILLUM RED; SQUARE FLUSH MOUNT
4849	4.03.0094.1.01.4	LO	106365	SWITCH PB ILLUM GREEN; SQUARE EXTENDED MOUNT
4850	4.03.0095.1.01.5	LO	106368	SWITCH PB ILLUM ORANGE; SQUARE EXTENDED MOUNT
4851	4.03.0096.1.01.6	LO	106384	SWITCH SEL 3 POS MAINT; SQUARE BLACK
4852	4.03.0097.1.01.7	LO	107889	SWITCH TOGGLE DPDT 2POS
4853	4.03.0098.1.01.8	LO	108601	CONTACTOR REVERSE 15.0 HP 120VAC COIL 1NO/1NC SIDE
4854	4.03.0099.1.01.9	LO	112882	SWITCH SELECTOR 3 POS SPRG RTN BOTH SIDES
4855	4.03.0100.1.01.1	LO	112886	PUSH BUTTON FLUSH HEAD BLACK
4856	4.03.0101.1.01.2	LO	115390	VALVE DRCT 125PSI 5GPM H2O 12FNPT NO SOL 24V DC
4857	4.03.0102.1.01.3	LO	116863	SWITCH 22 TO 125-PSI -04 SAE BOSS
4858	4.03.0103.1.01.4	LO	119117	SWITCH PB MUSHHEAD RED; PUSH MAINT/TURN RELEASE
4859	4.03.0104.1.01.5	LO	126637	SWITCH PB 2POS 30.5MM E-STOP
4860	4.03.0105.1.01.6	LO	129420	CONT DS 480V 1NO AUX
4861	4.03.0106.1.01.7	LO	131682	SWITCH PSI 360 TO 1700 04MORB
4862	4.03.0107.1.01.8	LO	132107	SWITCH DS 600V 3P 16A; NON-FUSIBLE
4863	4.03.0108.1.01.9	LO	133029	SWITCH PRESSURE 5 PSI 1/4 MNPT/FORM C/INCREASE
4864	4.03.0109.1.01.1	LO	134816	CONT MS 23A 480V 3P; 120VAC COIL 1NO AUX
4865	4.03.0110.1.01.2	LO	134820	CONT PRESSURE DIGITAL
4866	4.03.0111.1.01.3	LO	135446	METER MULTI-FUNCTION POWER MONITOR
4867	4.03.0112.1.01.4	LO	136265	SWITCH PRESS DIRT ALARM FOR SCHROEDER RET FLTR
4868	4.03.0113.1.01.5	LO	146192	COMP SWITCH 8 PORT
4869	4.03.0114.1.01.6	LO	150561	SWITCH DIRT ALARM DIN 43650 CONN
4870	4.03.0115.1.01.7	LO	156468	HEAD ROTARY ACTUATED; LIMIT SWITCH
4871	4.03.0116.1.01.8	LO	159718	OBS-USE 134820; WAS PURGE CONTROL BOARD
4872	4.03.0117.1.01.9	LO	166964	SWITCH SEQUENTIAL CAMERA
4873	4.03.0118.1.01.1	LO	A34785	CONTACTOR - POWER; 1200 AMP.
4874	4.03.0119.1.01.2	LO	A36970	CONTACTOR FIELD
4875	4.03.0120.1.01.3	LO	A83596	CONTACTS-AUX 2NO 2NC
4876	4.03.0121.1.01.4	LO	B83382	CONTACT BLOCK 1-NO 1-NC
4877	4.03.0122.1.01.5	LO	B83383	KNOB-YELLOW MUSHROOM; ENGRAVED-PUSH HOT RAIL
4878	4.03.0123.1.01.6	LO	B85228	CONTACTOR DC 12VDC COIL
4879	4.03.0124.1.01.7	PL	2050205 SUBSTITUTE OBW-KHS-M02	WEATHER HOOD
4880	4.03.0125.1.01.8		Repeated item	
4881	4.03.0126.1.01.9	PL	437-K60-1-06-125A	BATTERY SAFETY SWITCH
4882	4.03.0127.1.01.1	PL	437-K60-1-06-160A	BATTERY SAFETY SWITCH
4883	4.03.0128.1.01.2	PL	7201S/Z	TUMBLER SWITCH
4884	4.03.0129.1.01.3	PL	7205S/Z	KEY BUTTON
4885	4.03.0130.1.01.4	PL	90450R2/20	PRESSURE SWITCH
4886	4.03.0131.1.01.5	PL	90451M2/20	PRESSURE SWITCH
4887	4.03.0132.1.01.6	PL	90451R0/2	PRESSURE SWITCH
4888	4.03.0133.1.01.7	PL	EL.T7190-S844	EMERGENCY BUTTON RED
4889	4.03.0134.1.01.8	PL	EL-T6684.00	SWITCH CABINET, POPULATED
4890	4.03.0135.1.01.9	PL	EL-T7052	STEP SWITCH
4891	4.03.0136.1.01.1	PL	EL-T7190-G0	KEY SWITCH
4892	4.03.0137.1.01.2		Shifted to Annx-II	
4893	4.03.0138.1.01.3		Shifted to Annx-II	
4894	4.03.0139.1.01.4		Shifted to Annx-II	
4895	4.03.0140.1.01.5		Shifted to Annx-II	
4896	4.03.0141.1.01.6		Shifted to Annx-II	
4897	4.03.0142.1.01.7	PL	EL-T1058-14	SWITCH
4898	4.03.0143.1.01.8		Shifted to Annx-II	
4899	4.03.0144.1.01.9		Shifted to Annx-II	

4900	4.03.0145.1.01.1	PL	EL-T7250-CF1B2 SUBSTITUTE EL-T1301.5605	PUSH BUTTON
4901	4.03.0146.1.01.2	PL	EL-T7250-CW4B2 SUBSTITUTE EL-T1301.5602	PUSH BUTTON
4902	4.03.0147.1.01.3	PL	EL-T7190-G2 SUBSTITUTE EL-T1050-G2	KEY SWITCH
4903	4.03.0148.1.01.4	PL	EL-T7250-CW8B2	ILLUMINATED PUSH-BUTTON
4904	4.03.0149.1.01.5	KA	1023.14.23.300	Joy Stick For Cross Level
4905	4.03.0150.1.01.6	KA	8P15K-218231-54U 2.8.3 Inputs	Limit Switch
4906	4.03.0151.1.01.7	CR	NI12U-EG18SK-AP6X	INDUCTIVE SWITCH
4907	4.03.0152.1.01.8	CR	BS500W(IND)-13-20-14	INDUCTIVE SWITCH PED
4908	4.03.0153.1.01.9	CR	3SE3-120/1JA(Short arm)	TRAVEL SWITCH
4909	4.03.0154.1.01.1	PL	EL-T700-00019-350A	RELAY 24V, 350A
4910	4.03.0155.1.01.2	PL	EL-T700-00018	RELAY 24V , 500A
4911	4.03.0156.1.01.3	PL	46.61.9.024.4000T	RELAY 24V, 16A
4912	4.03.0157.1.01.4	PL	4213436 and Sub :4194093	RELAY
4913	4.03.0158.1.01.5	PL	4219245 and Sub : 4213663	RELAY
4914	4.03.0159.1.01.6	PL	EL-T700-00050-5A	RELAY
4915	4.03.0160.1.01.7	PL	EL-T700-00050-7,5A/E.T.A	RELAY
4916	4.03.0161.1.01.8	PL	EL-T700-00050-10A	RELAY
4917	4.03.0162.1.01.9	PL	EL-T7274 SUBSTITUTE EMG10-REL/KSR-G24/21-LC	RELAY
4918	4.03.0163.1.01.1	PL	LQ612048/LQ252024/LQ229 024/D-MAT-400	IMPULSE RELAY
4919	4.03.0164.1.01.2	PL	REL-MR-24DC/21-21AU	RELAY 24V,8A
4920	4.03.0165.1.01.3	PL	REL-MR-24DC/21HCAU	RELAY 24V,16A
4921	4.03.0166.1.01.4	PL	ELT-700-00050-10A	POWER RELAY
4922	4.03.0167.1.01.5	PL	ELT-700-00050-5A	POWER RELAY
4923	4.03.0168.1.01.6	PL	232.011/017/033 and 232.011/017/011	TEMPERATURE SWITCH
4924	4.03.0169.1.01.7	PL	TWR3/4MO/40 GRAD C/AUS	TEMPERATURE SWITCH
4925	4.03.0170.1.01.8	GE	P56N-200KN14HR	Pressure switch
4926	4.03.0171.1.01.9	GE	YK-3	Liquid level switch
4927	4.03.0172.1.01.1	GE	XS218BLPAM12	Proximity switch-1
4928	4.03.0173.1.01.2	GE	XS630B4PAM12	Proximity switch-2
4929	4.03.0174.1.01.3	GE	GQ22-11/ self-reset	Red wave switch-1
4930	4.03.0175.1.01.4	GE	GQ22-11/self-locking	Red wave switch-2
4931	4.03.0176.1.01.5	CR	061B000066	PRESSURE SWITCH-1
4932	4.03.0177.1.01.6	CR	XB4-BS8445	40 ROTARY RESET RED BUTTON
4933	4.03.0178.1.01.7	CR	BAE311 301/BA303	EMERGENCY STOP BUTTON
4934	4.03.0179.1.01.8	CR	N-30-S-SA	SWITCH
4935	4.03.0180.1.01.9	CR	061B000966	PRESSURE SWITCH-2
4936	4.03.0181.1.01.1	CR	061B001066	PRESSURE SWITCH-3
4937	4.03.0182.1.01.2	CR	40077914	3 POSITION SWITCH
4938	4.03.0183.1.01.3	CR	40013840	PROXIMITY SWITCH
4939	4.03.0184.1.01.4	CR	40029740	LIMIT SWITCH
4940	4.03.0185.1.01.5	CR	80082411	PROXIMITY SWITCH
4941	4.03.0186.1.01.6	CR	40085400	PROXIMITY SWITCH
4942	4.03.0187.1.01.7	CR	40098624	PULL TYPE START BUTTON
4943	4.03.0188.1.01.8	CR	40082411	PROXIMITY SWITCH
4944	4.03.0189.1.01.9	CR	40091845	LIMIT SWITCH
4945	4.03.0190.1.01.1	CR	40082351	TWO WAY SWITCH
4946	4.03.0191.1.01.2	CR	40065040	TWO WAY SWITCH
4947	4.03.0192.1.01.3	CR	40069410	AIR BRAKING SYSTEM/PRESSURE SWITCH
4948	4.03.0193.1.01.4	PL	II50197/1	Indirect brake valve limit switch
4949	4.03.0194.1.01.5	PL	NI30U-M30-AP6X-H1141	Inductive switch
4950	4.03.0195.1.01.6	PL	S-8.70.1	Inductive switch
4951	4.03.0196.1.01.7	PL	PVD6/7/23/23-SH	5 POSITION TUMBLER SWITCH
4952	4.03.0197.1.01.8	PL	100-K09KF10	Contact
4953	4.03.0198.1.01.9	PL	100-K09ZJ400	Contact
4954	4.03.0199.1.01.1	PL	TWR3/4MO/90 GRAD C/AUS	TEMPERATURE SWITCH
4955	4.03.0200.1.01.2	PL	1695326	SWITCH
4956	4.03.0201.1.01.3	PL	EBC602.9E.904M	SWITCH
4957	4.03.0202.1.01.4	PL	PP7554/4,2-3,8	PRESSURE SWITCH
4958	4.03.0203.1.01.5	PL	EL-T1050-GO	SWITCH
4959	4.03.0204.1.01.6	PL	EL-T7123 and EL-T7123/85 GRAD	PROXIMITY SWITCH
4960	4.03.0205.1.01.7		Shifted to Annx-II	
4961	4.03.0206.1.01.8		Shifted to Annx-II	
4962	4.03.0207.1.01.9	LO	113882	LOCKING LEVER KIT ENGINE BATTERY SWITCH(KD SWITCHES)
4963	4.03.0208.1.01.1	LO	162552	SWITCH DISCONNECT 600V 3P 200A NON FUSIBLE
4964	4.03.0209.1.01.2	LO	173671	Cont MS 65A 120V 3ph
4965	4.03.0210.1.01.3	LO	173672	Cont 65A 120V 3P
4966	4.03.0211.1.01.4	LO	173673	Cont 50A 120V 3P

4967	4.03.0212.1.01.5	LO	153456	Cont OL 25-100A 1 NC 1 NO for S3 Contactor
4968	4.03.0213.1.01.6	LO	229549	Cont OL 1-4A 1 NC 1 NO for S00 Contactor
4969	4.03.0214.1.01.7	LO	229550	Cont MS 9A 480V 3P 120V Ac 50/60Hz Coil 1 No
4970	4.03.0215.1.01.8	LO	229551	Cont MS 80A 480V 3P 120V Ac 50/60Hz Coil 1 No
4971	4.03.0216.1.01.9	LO	103925	CB 25A 3P 480V
4972	4.03.0217.1.01.1	LO	118142	PS 12VDC 21A
4973	4.03.0218.1.01.2	LO	126450	CONT MS 480V 4 NO AUX FROUNT MOUNT
4974	4.03.0219.1.01.3	LO	126452	CONT CB 480V 1NO AUX
4975	4.03.0220.1.01.4	LO	127780	SWITCH DS 3P 600V 100A 1NO ENCLOSED NON FUSIBLE
4976	4.03.0221.1.01.5	LO	513882	Engine battery switch
4977	4.03.0222.1.01.6	LO	129422	SWITCH DS 600V 3P 100A NON-FUSIBLE
4978	4.03.0223.1.01.7	LO	245294	SWITCH SEQUENTIAL CAMERA; 4 IN 1 OUT BNC
4979	4.03.0224.1.01.8	LO	252351	ELECTRICAL SWITCHES KIT #4
4980	4.03.0225.1.01.9	LO	101439	CONTACTOR DC 24VDC NCNO
4981	4.03.0226.1.01.1	LO	252351-4	ELECTRICAL SWITCHES KIT #3
4982	4.03.0227.1.01.2	LO	245875	SWITCH PB 2POS MOM BLK; ROUND FLUSH MOUNT
4983	4.03.0228.1.01.3	LO	245932	CONTACT BLK 1NO-1NC; SCREW TERMINAL
4984	4.03.0229.1.01.4	LO	247927	CONTACT BLK 1 NO; SCREW TERMINAL
4985	4.03.0230.1.01.5	LO	247928	CONTACT BLK 1NC; SCREW TERMINAL
4986	4.03.0231.1.01.6	LO	252351-6	ELECTRICAL SWITCHES KIT #5
4987	4.03.0232.1.01.7	LO	245879	SWITCH PB 2POS MOM RED; ROUND FLUSH MOUNT ILLUM
4988	4.03.0233.1.01.8	LO	246517	SWITCH PB 2POS MOM ORG; 22MM ILLUM ROUND EXTENDED
4989	4.03.0234.1.01.9	LO	252351-7	ELECTRICAL SWITCHS KIT #6
4990	4.03.0235.1.01.1	LO	245899	SWITCH SS 3POS MTN BLK; 22MM ROUND KNOB
4991	4.03.0236.1.01.2	LO	252351-8	ELECTRICAL SWITCHES KIT #7
4992	4.03.0237.1.01.3	LO	245888	SWITCH SS 2POS MTN GRN; 22MM ILLUM ROUND KNOB
4993	4.03.0238.1.01.4	LO	252351-9	ELECTRICAL SWITCHES KIT #8
4994	4.03.0239.1.01.5	LO	109475	SWITCH TOGGLE 3 POS MOMEN BLACK NYLON
4995	4.03.0240.1.01.6	LO	247953	SWITCH SS 4POS MTN BLK; 22MM ROUND KNOB
4996	4.03.0241.1.01.7	LO	252351-15	LIGHT KIT #4
4997	4.03.0242.1.01.8	LO	242830	SWITCH PB MUSHHEAD RED; PUSH MAINT/TURN RELEASE
4998	4.03.0243.1.01.9	LO	252351-40	ELECTRICAL SWITCHES KIT #9
4999	4.03.0244.1.01.1	LO	252351-41	ELECTRICAL SWITCHES KIT #6
5000	4.03.0245.1.01.2	LO	126588	SWITCH TS 3POS MOM
5001	4.03.0246.1.01.3	LO	252351-47	ELECTRICAL SWITCHES KIT #10
5002	4.03.0247.1.01.4	LO	252351-62	ELECTRICAL SWITCHES #11
5003	4.03.0248.1.01.5	LO	A25902	COVER-SWITCH
5004	4.03.0249.1.01.6	LO	A38587	SWITCH 3-WAY 15A 120/277VAC
5005	4.03.0250.1.01.7	LO	252351-88	ELECTRICAL SWITCHES KIT #12
5006	4.03.0251.1.01.8	LO	252351-107	ELECTRICAL SWITCHES KIT #13
5007	4.03.0252.1.01.9	LO	175801	SWITCH LS 1NO 1NC TOP PLUNGER CONNECTOR
5008	4.03.0253.1.01.1	LO	148473	SWITCH PRESSURE ANTI-RESTART
5009	4.03.0254.1.01.2	PL	PVD6/ 7/ 16/23-	5-POSTION TUMBLER SWITCH
5010	4.03.0255.1.01.3	PL	ELT-700-00035-S	BATERY MAIN SWITCH
5011	4.03.0256.1.01.4	PL	HLU110-5KT	SELECTING SWITCH
5012	4.03.0257.1.01.5	PL	EL-T5589.00	SELECTOR FOR 5 MEASURING INPUTS
5013	4.03.0258.1.01.6	PL	TWR3/4MO/80 GRAD C/AUS	TEMPERATURE SWITCH
5014	4.03.0259.1.01.7	PL	EL-T7104.00	JOYSTICK PLUS PUSH BUTTON
5015	4.03.0260.1.01.8	PL	0342311007/0342311003	IGNITION LOCK
5016	4.03.0261.1.01.9	PL	EL-T 7190-DL3/GRUN	TOGGLE HEAD
5017	4.03.0262.1.01.1	PL	EL-T7190-DL8/GELB	TOGGLE HEAD
5018	4.03.0263.1.01.2	PL	EL-T7190-DL8/WEISS	TOGGLE HEAD
5019	4.03.0264.1.01.3	PL	EL-T7190-D8	TOGGLE HEAD
5020	4.03.0265.1.01.4	PL	EL-T7190-J5	TOGGLE HEAD
5021	4.03.0266.1.01.5	PL	EL-T1050-DL2	SWITCH
5022	4.03.0267.1.01.6	PL	EL-T1050-DL5/ORANGE	SWITCH
5023	4.03.0268.1.01.7	PL	EL-T1050-W37	PUSH BUTTON
5024	4.03.0269.1.01.8	PL	EL-T7190-A1	PUSH BUTTON, WHITE 1 445411

5025	4.03.0270.1.01.9	PL	EL-T7190-A2	PUSHBUTTON, BLACK
5026	4.03.0271.1.01.1	PL	EL-T7190-A3	BUTTO GREEN
5027	4.03.0272.1.01.2	PL	EL-T7190-A6	PUSH BUTTON, BLUE
5028	4.03.0273.1.01.3	PL	EL-T7190-418/SIR	Push button, white
5029	4.03.0274.1.01.4	PL	EL-T7190-W343	ILLUMINATED PUSH-BUTTON RED
5030	4.03.0275.1.01.5	PL	EL-T7250-CF5B2	ILLUMINATED PUSH BUTTON YELLOW
5031	4.03.0276.1.01.6	PL	EL-T7250-CF8B2	ILLUMINATED PUSH BUTTON ORANGE
5032	4.03.0277.1.01.7	PL	HD RAI-1823/24/24A	PUSH PULL SWITCH
5033	4.03.0278.1.01.8	PL	P1S5/5S826A/20-S2+S608B	FAULT SWITCH
5034	4.03.0279.1.01.9	PL	EL-T700-00035-GN	BATTERY SEPARATING SWITCH
5035	4.03.0280.1.01.1	PH	UTVI 07 11/00	PANEL MAIN SWITCH
5036	4.03.0281.1.01.2	PH	UTV1 07 24/00	ENGINE STOP SWITCH
5037	4.03.0282.1.01.3	CR	40065270	White button with light
5038	4.03.0283.1.01.4	CR	40077913	2 position selector switch with key
5039	4.03.0284.1.01.5	CR	40079237	Pressure switch
5040	4.03.0285.1.01.6	CR	40079238	Pressure switch
5041	4.03.0286.1.01.7	CR	40081943	White 2-position selection switch with light
5042	4.03.0287.1.01.8	CR	40082360	White 2-position selection switch with light
5043	4.03.0288.1.01.9	CR	40082365	Yellow 3-position reset selection switch with light
5044	4.03.0289.1.01.1	CR	40083283	Black 2-position selection switch
5045	4.03.0290.1.01.2	CR	40089205	8TX switch
5046	4.03.0291.1.01.3	CR	40095533	Pressure switch
5047	4.03.0292.1.01.4	CR	40102840	White 3-position reset selection switch with light
5048	4.03.0293.1.01.5	KA	BTT15K21	LIMIT SWITCH
5049	4.03.0294.1.01.6	KA	TTT 2-17-3TT 4H BK 0100.360.068 TU/PG2-17-3P4H BK	3 Position switch knob
5050	4.03.0295.1.01.7	KA	T3-CBAT 0-360.407TU/T3- CATO.360.407 TU	Toggle switch (2-way)
5051	4.03.0296.1.01.8	KA	T3-CBAT 0-360.406TU	Toggle switch (2-way)
5052	4.03.0297.1.01.9	KA	PK16-12Y4109T3/PK16-12U4109 T3-A , (TU3428-005-03965790-94)	Switch
5053	4.03.0298.1.01.1	KA	MT1B AG0.360.207TU	Toggle switch
5054	4.03.0299.1.01.2	KA	P2T-5 A G0.360.406TU	Toggle switch
5055	4.03.0300.1.01.3	KA	PT2-10B AG0.360.202TU/P2-10V	Toggle switch
5056	4.03.0301.1.01.4	KA	TU16.526.016-73/2PP-45	Switch (2PP-45)
5057	4.03.0302.1.01.5	KA	TU2-053-1707-84	pressure gauge switch
5058	4.03.0303.1.01.6	HA	0-3119006-0-01	LIMIT SWITCH
5059	4.03.0304.1.01.7	HA	5018833	Battery Cut-off Switch
5060	4.03.0305.1.01.8	HA	F013478K	PUSH TO START
5061	4.03.0306.1.01.9	HA	164824	IGNITION SW
5062	4.03.0307.1.01.1	HA	5138451	LIMIT SWITCH
5063	4.03.0308.1.01.2	HA	5131787	DIRECTION SELECTOR SWITCH
5064	4.03.0309.1.01.3	HA	5138428	BRAKE PRESSURE SWITCH
5065	4.03.0310.1.01.4	HA	5138442	AIR PRESSURE SWITCH
5066	4.03.0311.1.01.5	HA	5138433	BATTERY CUT OFF SWITCH
5067	4.03.0312.1.01.6	HA	447050010	JOY STICK LIFTING
5068	4.03.0313.1.01.7	HA	447040017	JOYSTICK CLAMPING/UNCLAMPING
5069	4.03.0314.1.01.8	PL	17PLUS-Q00-LR	Connection element /L-R
5070	4.03.0315.1.01.9	PL	FK20S-13v	Socket contact
5071	4.03.0316.1.01.1	PL	FK20P-13V	contact pin
5072	4.03.0317.1.01.2	PL	100-K05KF10	Contact/230V/50-60HZ
5073	4.03.0318.1.01.3	PL	PVD6/7/23/23-SH	5 POSITION TUMBLER SWITCH
5074	4.03.0319.1.01.4	PL	437-K60-1-06-200A	Battery Safety Switch
5075	4.03.0320.1.01.5	PL	FFA.2E.305.CLAC70ZN SUB:- FFA.2E.305.CLAC60ZN	5-PIN CONNECTOR
5076	4.03.0321.1.01.6	DE	0148-48-011	Temperature switch
5077	4.03.0322.1.01.7	PL	90257	PUSH BUTTON
5078	4.03.0323.1.01.8	LO	126999	SWITCH COOLANT LEVEL
5079	4.03.0324.1.01.9	LO	127000	SOLENOID FUEL SHUT OFF VALVE
5080	4.04.0001.1.01.2	PL	1801.1831	LED BLACK
5081	4.04.0002.1.01.3	PL	1178104	TEMPERATURE SWITCH
5082	4.04.0003.1.01.4	PL	3900062901	VACUUM SWITCH
5083	4.04.0004.1.01.5	PL	035-4210/ROT	LED RED
5084	4.04.0005.1.01.6	PL	035-4212/GRUEN	LED GREEN
5085	4.04.0006.1.01.7	PL	0868609/24VDC-8STELLING SUB. 0868165/24VDC-8ST	TAMPING ACTION COUNTER
5086	4.04.0007.1.01.8	PL	1032-04-01-0421	GEAR BOX
5087	4.04.0008.1.01.9	PL	1032-04-01-1309	GEAR BOX FOR CSM
5088	4.04.0009.1.01.1	PL	1181559 Sub.1180423/1182489	OIL PRESSURE SWITCH
5089	4.04.0010.1.01.2	PL	1413/ERSAT	INDICATOR
5090	4.04.0011.1.01.3	PL	323.801/028/001	TEMPERATURE SENSOR
5091	4.04.0012.1.01.4	PL	62.05.2000.43/A	PRESSURE SWITCH
5092	4.04.0013.1.01.5	PL	64.02.2182	DRIVE SHAFT
5093	4.04.0014.1.01.6		Shifted to Annx-II	

5094	4.04.0015.1.01.7	PL	64.07.1000.55	PRESSURE SWITCH
5095	4.04.0016.1.01.8		Shifted to Annx-II	
5096	4.04.0017.1.01.9	PL	811.65A SUB. 317.38A	TEMP.CONTROL
5097	4.04.0018.1.01.1	PL	EL-T7005.00E/B SUBSTITUTE EL-T7005.00E/A	VOLTMETER
5098	4.04.0019.1.01.2	PL	EL-T521/10B-SPULE	MAGNET
5099	4.04.0020.1.01.3	PL	90450-R0/2	PRESSURE SWITCH
5100	4.04.0021.1.01.4	PL	90451-R2/20	PRESSURE SWITCH
5101	4.04.0022.1.01.5	PL	9700511140 SUB. 1261885	WORKING CYLINDER
5102	4.04.0023.1.01.6	PL	A5500044	TEMPERATURE SENSOR
5103	4.04.0024.1.01.7	PL	AS10DIN71802/M6	ANGLE JOINT
5104	4.04.0025.1.01.8	PL	AS13DIN71802/M8	ANGLE JOINT
5105	4.04.0026.1.01.9	PL	AS16DIN71802/M10	ANGLE JOINT
5106	4.04.0027.1.01.1	PL	AS19DIN71802/M14X1,5	ANGLE JOINT
5107	4.04.0028.1.01.2	PL	DL-230-118/ELT-1004-800LG	FLEXIBLE SHAFT(IMPORTED) / RPM CABLE
5108	4.04.0029.1.01.3	PL	DZ 95/G 9300/HUB70	PULL CABLE
5109	4.04.0030.1.01.4	PL	DZ.60/G.1500/HUB 100	PULL CABLE
5110	4.04.0031.1.01.5	PL	DZ160/G=1500/HUB200	PULL CABLE
5111	4.04.0032.1.01.6	PL	EK-501CA-00B	U-ADAPTER FOR CMS SYSTEM
5112	4.04.0033.1.01.7	PL	EK-503CA-00B	N-ADAPTER FOR CMS SYSTEM
5113	4.04.0034.1.01.8	PL	EL-T 1064	INDICATOR
5114	4.04.0035.1.01.9	PL	ELT 1264.00W/B	REVOLUTION COUNTER
5115	4.04.0036.1.01.1	PL	EL-T 1473-10V	INDICATOR DIGITAL
5116	4.04.0037.1.01.2	PL	EL-T 1473-2V	INDICATOR
5117	4.04.0038.1.01.3	PL	EL-T 155-03-650LG	DRIVE SHAFT
5118	4.04.0039.1.01.4	PL	EL-T7004.00E/B SUBSTITUTE EL-T7004.00E/A	VOLTMETER
5119	4.04.0040.1.01.5	PL	EL-T 155-03-850LG	DRIVE SHAFT
5120	4.04.0041.1.01.6	PL	EL-T 336-00-E	MOVING COIL INSTRUMENT
5121	4.04.0042.1.01.7	PL	EL-T 439-00-E	VOLT METER
5122	4.04.0043.1.01.8	PL	EL-T 7004.00E/B SUB EL-T 7004.00E/A	VOLTMETER
5123	4.04.0044.1.01.9	PL	EL-T 7013-00	AMPERMETER
5124	4.04.0045.1.01.1	PL	EL-T 7036-00E	AMPERE METER
5125	4.04.0046.1.01.2	PL	EL-T 7055/700AF	ENCODER
5126	4.04.0047.1.01.3	PL	EL-T 7055/7F	ENCODER
5127	4.04.0048.1.01.4	PL	EL-T 7138-00A	PRESSURE GAUGE
5128	4.04.0049.1.01.5	PL	EL-T 790	INDICATOR (MEASURING DEVICE)
5129	4.04.0050.1.01.6	PL	EL-T 970-00A	INDICATOR
5130	4.04.0051.1.01.7	PL	EL-T-1001-00B Sub: EL-T 1001-001	PRESSURE GAUGE
5131	4.04.0052.1.01.8	PL	EL-T1022-01-00-142	ANGLE GEAR FOR CSM
5132	4.04.0053.1.01.9	PL	EL-T1199.00-BR/L-LINKS	DRIVE CONTROL LEVER
5133	4.04.0054.1.01.1	PL	EL-T1200.00A/ ERSATZ SUB. EL-T1200.00 /ERSATZ	THERMOMETER
5134	4.04.0055.1.01.2	PL	EL-T1200/100/A/ ERSATZ SUBSTITUTE EL-T1200/100/ERSATZ	THERMOMETER
5135	4.04.0056.1.01.3	PL	EL-T1200/100/B	THERMOMETER
5136	4.04.0057.1.01.4		Shifted to Annx-II	
5137	4.04.0058.1.01.5	PL	EL-T-1256-00A , EL-T-1001-00A /ERSATZ2	PRESSURE GAUGE
5138	4.04.0059.1.01.6	PL	EL-T1259.00/250/B	TEMPERATURE INDICATOR/THERMOMETER
5139	4.04.0060.1.01.7	PL	EL-T-1261-00	VOLT METER
5140	4.04.0061.1.01.8	PL	EL-T-1262-00	AMPERE METER
5141	4.04.0062.1.01.9	PL	EL-T1263.00 /120/ERSATZ SUB. EL-T1263.00/120	TACHOMETER
5142	4.04.0063.1.01.1	PL	EL-T1263.00/120/A	TACHOMETER
5143	4.04.0064.1.01.2	PL	EL-T1264.00W/ B/ ERSATZ SUB. EL-T1264.00W /ERSATZ	REVOLUTION COUNTER
5144	4.04.0065.1.01.3	PL	EL-T-1264-00B	RPM METER (REVOLUTION COUNTER)
5145	4.04.0066.1.01.4	PL	EL-T1343.11	VALVE CONTROL
5146	4.04.0067.1.01.5	PL	EL-T140.07	SHAFT
5147	4.04.0068.1.01.6	PL	EL-T1413/ ERSATZ/KM/H-LED	INDICATOR
5148	4.04.0069.1.01.7	PL	EL-T-1423-00	INDICATOR
5149	4.04.0070.1.01.8	PL	EL-T155.03-150LG	DRIVE SHAFT
5150	4.04.0071.1.01.9	PL	EL-T155.03-800LG	DRIVE SHAFT
5151	4.04.0072.1.01.1	PL	EL-T-1585/20V	DIGITAL DISPLAY
5152	4.04.0073.1.01.2	PL	EL-T-2060/125KM/II-WK/ERSATZ	TECHOGRAPH
5153	4.04.0074.1.01.3	PL	EL-T2078.17	GEAR WHEEL
5154	4.04.0075.1.01.4	PL	EL-T2113.00C	TACHOMETER
5155	4.04.0076.1.01.5	PL	EL-T2168.00	CAN BUS CONNECTOR
5156	4.04.0077.1.01.6	PL	EL-T4004.03	GUARD
5157	4.04.0078.1.01.7	PL	EL-T5690.00	DISPLAY

5158	4.04.0079.1.01.8	PL	EL-T7005.00E/B SUB. EL-T7005.00E/A	VOLTMETER
5159	4.04.0080.1.01.9	PL	EL-T-7009.00E/A	SERVO CURRENT MET/DRIV
5160	4.04.0081.1.01.1	PL	EL-T-7013-00 / ERSATZ	AMP METER
5161	4.04.0082.1.01.2	PL	EL-T7055/7AF	ROTARY ENCODER
5162	4.04.0083.1.01.3	PL	EL-T7066.00E/B SUB. EL-T7066.00E/A	VOLTMETER
5163	4.04.0084.1.01.4	PL	EL-T-7089.00/10V	DIGITAL DISPLAY
5164	4.04.0085.1.01.5	PL	EL-T-7093-00E	AMPERE METER
5165	4.04.0086.1.01.6	PL	EL-T-7097-00E	AMPERE METER
5166	4.04.0087.1.01.7	PL	EL-T7100.00E/B SUB. EL-T7100.00E/A	VOLTMETER
5167	4.04.0088.1.01.8	PL	EL-T7138.00A/ ERSATZ SUB. EL-T7138.00/ ERSATZ	PRESSURE GAUGE
5168	4.04.0089.1.01.9	PL	EL-T7164.00A	SIGNAL COLUMN
5169	4.04.0090.1.01.1	PL	EL-T-790-00E	DIGITAL DISPLAY
5170	4.04.0091.1.01.2	PL	EL-T80.00E/A SUB. EL-T80.00E	MOVING COIL INSTRUMENT
5171	4.04.0092.1.01.3	PL	EL-T-80-00	GALVANOMETER
5172	4.04.0093.1.01.4	PL	EL-T978.00E/B SUB. EL-T978.00E/A	AMPEREMETER
5173	4.04.0094.1.01.5	PL	EL-T-978-00	M A METER
5174	4.04.0095.1.01.6	PL	G 10700/HOB-70/D2/95/1	PULL CABLE
5175	4.04.0096.1.01.7	PL	G 11300/HOB-70/02/95	PULL CABLE
5176	4.04.0097.1.01.8	PL	GP-10S	PRESSURE GAUGE
5177	4.04.0098.1.01.9	PL	L06.125.05.100	TEMPERATURE CONTROL
5178	4.04.0099.1.01.1	PL	EL-T7130.02	RECORDING PAPER
5179	4.04.0100.1.01.2	PL	L6188A2002	FLUIDMETER
5180	4.04.0101.1.01.3	PL	PIS-3020	PRESSURE SWITCH
5181	4.04.0102.1.01.4	PL	PIS-3070	PRESSURE SWITCH
5182	4.04.0103.1.01.5	PL	SMD108214/ROT/GRUEN	LED RED & GREEN
5183	4.04.0104.1.01.6	PL	SMDD06004/ROT SUB. 035.4210/ROT	LED RED
5184	4.04.0105.1.01.7	PL	SMDD06104/GELB SUB. 035.4212/GELB	LED YELLOW
5185	4.04.0106.1.01.8	PL	SMDD08214/GRUEN SUB. .035.4214/YELLOW	LED GREEN
5186	4.04.0107.1.01.9	PL	VT17370-1X	AMPLIFIER M/C Dr. CSM
5187	4.04.0108.1.01.1		Shifted to Annexure-II	
5188	4.04.0109.1.01.2	KE	144211	WATER TEMP. GAUGE
5189	4.04.0110.1.01.3	KE	144224	SENDER AIR/OIL PRESSURE
5190	4.04.0111.1.01.4	KE	144225	SENDER WATER TEMPERATURE
5191	4.04.0112.1.01.5	KE	144230	OIL PRESSURE GAUGE
5192	4.04.0113.1.01.6	KE	181582	HOUR METER BRM
5193	4.04.0114.1.01.7	KE	182898	VOLTMETER
5194	4.04.0115.1.01.8	KE	716880	SENDER TACHOMETER
5195	4.04.0116.1.01.9	KE	719655	SPEEDOMETER
5196	4.04.0117.1.01.1	KE	729646	SENDER FUEL LEVEL GAUGE
5197	4.04.0118.1.01.2	KE	735100	TACHOMETER
5198	4.04.0119.1.01.3	KE	745359	SENDER OF SPEEDOMETER
5199	4.04.0120.1.01.4	AM	766689	SPEEDOMETER SENSOR
5200	4.04.0121.1.01.5	PH	UTVI-09 01/00	LUB OIL PRESSURE SENSOR
5201	4.04.0122.1.01.6	PH	UTVI-09 02/00	HIGH WATER TEMPERATURE SENSOR
5202	4.04.0123.1.01.7	LO	103485	HED SENSOR
5203	4.04.0124.1.01.8	LO	106333	SENSOR 0-50 AMP AC 4-20MA
5204	4.04.0125.1.01.9	LO	113622	MODULE OPTICAL ISOLATOR ENCODER INTERFACE
5205	4.04.0126.1.01.1	LO	117096	CYL ASSY DERRAIL DETECTION WITH PROXIMITY SWITCH
5206	4.04.0127.1.01.2	LO	118574	RTD SPRING LOADED
5207	4.04.0128.1.01.3	LO	126639	METER VDC 0-750
5208	4.04.0129.1.01.4	LO	126640	METER IDC 0-1500
5209	4.04.0130.1.01.5	LO	126643	SENSOR SW TEMP 85 DEG C SPDT
5210	4.04.0131.1.01.6	LO	131121	ENG/GEN CONTROLER INTEGRATED DISPLAY
5211	4.04.0132.1.01.7	LO	134828	CONV RTD TEMP 4-20MA
5212	4.04.0133.1.01.8	LO	143887	SENSOR FLUID LEVEL 4-20MA 24 LONG 3/4 MNPT
5213	4.04.0134.1.01.9	LO	160634	SENSOR HEAD FINAL ASSY UNIT 1
5214	4.04.0135.1.01.1	LO	160635	SENSOR HEAD FINAL ASSY UNIT 2
5215	4.04.0136.1.01.2	LO	12.3802	SPEEDOMETER INDICATOR
5216	4.04.0137.1.01.3	LO	E1622 IP 66	CURRENT CONTROL INDICATOR
5217	4.04.0138.1.01.4	LO	IP 4027.3	POSITION INDICATOR WITH KOG DOG
5218	4.04.0139.1.01.5	LO	IP 4027.4	POSITION INDICATOR WITH DOG
5219	4.04.0140.1.01.6	LO	IP 4027.5	POSITION INDICATOR WITH DOG
5220	4.04.0141.1.01.7	KA	IP 4027.9	POSITION INDICATOR WITH RETURNSPRING

5221	4.04.0142.1.01.8	PL	1047402 SUBSTITUTE DS50-P1112	DISTANCE SENSOR
5222	4.04.0143.1.01.9	PL	1174555 SUBSTITUTE 1182840	TEMPERATURE SWITCH
5223	4.04.0144.1.01.1	PL	1182484 SUBSTITUTE 1180418	OIL PRESSURE SWITCH
5224	4.04.0145.1.01.2	PL	1182485 SUBSTITUTE 1180419	OIL PRESSURE SWITCH
5225	4.04.0146.1.01.3		Repeated item	
5226	4.04.0147.1.01.4	PL	ATF-500PT SUBSTITUTE A5500044	SENSOR
5227	4.04.0148.1.01.5	PL	B28CP SUBSTITUTE B28DJ	INDICATION BULB
5228	4.04.0149.1.01.6	PL	EL-T1200.00/ERSATZ SUBSTITUTE EL-T1200.00/ERSATZ	THERMOMETER
5229	4.04.0150.1.01.7	PL	EL-T1200.00B	THERMOMETER
5230	4.04.0151.1.01.8	PL	EL-T1200/100/A/ERSATZ SUBSTITUTE EL-T1200/100/ERSATZ	THERMOMETER
5231	4.04.0152.1.01.9	PL	EL-T1259.00/185/B SUBSTITUTE EL-T1259.00/185/A	THERMOMETER
5232	4.04.0153.1.01.1	PL	EL-T1259.00/250/B SUBSTITUTE EL-T1259.00/250/A	THERMOMETER
5233	4.04.0154.1.01.2	PL	EL-T1263.00/120/B	SPEEDOMETER
5234	4.04.0155.1.01.3	PL	EL-T1263.00/120/ERSATZ SUBSTITUTE EL-T1263.00/120	TACHOMETER
5235	4.04.0156.1.01.4	PL	EL-T2105.00POS.4.16-39	DISTANCE TRANSDUCER
5236	4.04.0157.1.01.5	PL	EL-T2113.00C SUBSTITUTE EL-T2113.00	TACHOMETER
5237	4.04.0158.1.01.6	PL	EL-T273B SUBSTITUTE EL-T273A	CONNECTOR
5238	4.04.0159.1.01.7	PL	EL-T7089.00/10	INDICATOR
5239	4.04.0160.1.01.8	PL	EL-T7089.00/50	INDICATOR
5240	4.04.0161.1.01.9	PL	EL-T7100.00E/B SUBSTITUTE EL-T7100.00E/A	VOLTMETER
5241	4.04.0162.1.01.1	KA	PVA20-Y-3000-CB	Tachometer Indicator
5242	4.04.0163.1.01.2	KA	MCB11.461264.546	Depth Indicator Display (Setting Device)
5243	4.04.0164.1.01.3	KA	M42300.44.15-0-15B-15T	Volt Meter
5244	4.04.0165.1.01.4	KA	N16226TT A.700.815	Indicator for Current Checkout
5245	4.04.0166.1.01.5	KA	6251-AAAA-AZO (ELFA 36.885.22) With Cable Input (ELFA 55-023-72)	Galvanometer
5246	4.04.0167.1.01.6	KA	PVIOI-MD2	Display
5247	4.04.0168.1.01.7	KA	Display Logo TD/LOGO 6ED 10554MH00-0BAO	Tamping Cycle Display
5248	4.04.0169.1.01.8	KA	6ED1 055-4MH00-0BAO	Display Siemens Logo TD
5249	4.04.0170.1.01.9	PL	EL-T7197.00E	Amperemeter
5250	4.04.0171.1.01.1	ZF	065050178/0659050181	ZF LOCK UP SENSER
5251	4.04.0172.1.01.2	PL	EL-T596.00HG/B	ANGLE SENSOR
5252	4.04.0173.1.01.3	PL	EL-T970.00B	INDICATOR
5253	4.04.0174.1.01.4	GE	254-9175	Digital display gauge
5254	4.04.0175.1.01.5	GE	106-0031	Voltage gauge
5255	4.04.0176.1.01.6	GE	185-5980	Counter
5256	4.04.0177.1.01.7	PL	EL-T905-00002-I/70	ANGEL SENSOR
5257	4.04.0178.1.01.8	PL	ELT-200-00002-904-5-LI-U	ROTARY ENCODER
5258	4.04.0179.1.01.9	PL	ELT-200-00002-904-5-RE-U	ROTARY ENCODER
5259	4.04.0180.1.01.1	GE	TCT1000-202541C502-150C	Temperature sensor
5260	4.04.0181.1.01.2	GE	HDA 7446-A-400-000	Pressure sensor
5261	4.04.0182.1.01.3	CR	40108000	SENSOR, RPM
5262	4.04.0183.1.01.4	CR	SCP01-010-34-07(SCK-145)	PRESSURE SENSOR
5263	4.04.0184.1.01.5	CR	437-035-002C	SPEED ODOMETER
5264	4.04.0185.1.01.6	GE	750 type	Depth sensor
5265	4.04.0186.1.01.7		Shifted to Annexure-II	
5266	4.04.0187.1.01.8	PL	UM30-213113	Ultrasonic sensor
5267	4.04.0188.1.01.9	PL	UM30-214113	Ultrasonic sensor
5268	4.04.0189.1.01.1	PL	S-6.117.4	Brake pressure dector
5269	4.04.0190.1.01.2	PL	ETS7246-A-008	Temperature sensor
5270	4.04.0191.1.01.3	PL	AS1008-C-000	Aqua sensor
5271	4.04.0192.1.01.4	PL	HDD1L 16ND20	Pulse transducer (speed sensor)
5272	4.04.0193.1.01.5	PL	ELT-906-00001-I/800	measuring transducer
5273	4.04.0194.1.01.6	PL	ELT-906-00004-I/3500	measuring transducer
5274	4.04.0195.1.01.7	PL	ELT-906-00001-I/600	measuring transducer
5275	4.04.0196.1.01.8	PL	ELT-902-00002-I	Measures versine
5276	4.04.0197.1.01.9	PL	ELT-902-00001-I	Measures versine
5277	4.04.0198.1.01.1	PL	ELT-906-00001-I/3500	Transducer
5278	4.04.0199.1.01.2	PL	ELT-906-00007-I/800	Transducer
5279	4.04.0200.1.01.3	PL	ELT-906-00010-I/800	Transducer
5280	4.04.0201.1.01.4	PL	ELT-906-00001-I/400	Transducer
5281	4.04.0202.1.01.5	PL	EL-T9125.05	Carrier F tachom shaft (speedometer)

5282	4.04.0203.1.01.6	PL	NI75U-CP80-VP4X2	Clamp2 rail sensor
5283	4.04.0204.1.01.7	PL	S-8.72.2	Inductive sensor
5284	4.04.0205.1.01.8	PL	S-8.72.3	Inductive sensor
5285	4.04.0206.1.01.9	PL	EL-T2078.01	Wheel collar
5286	4.04.0207.1.01.1	PL	EL-T2105.03	Wheel
5287	4.04.0208.1.01.2	PL	ROTARY ENCODER	EL-T-200-00002-904-5-RE
5288	4.04.0209.1.01.3	PL	EL-T2170.G1	INDUCTIVE SENSOR
5289	4.04.0210.1.01.4	PL	KPPG166	SPEED SENSOR
5290	4.04.0211.1.01.5	LO	236305	PLC MOD TEMP AI KIT; 6 ISO INPUT RTD(replaces 114353)
5291	4.04.0212.1.01.6	LO	252351-220	SENSOR KIT
5292	4.04.0213.1.01.7	LO	252351-50	SENSOR KIT #2
5293	4.04.0214.1.01.8	LO	249182	SENSOR HEAD UNIT
5294	4.04.0215.1.01.9	LO	126571	THERMOWELL 12MOR 316SS .5 NPT 10.5 RELAXED
5295	4.04.0216.1.01.1	LO	248466	SENSOR TANK LEVEL; 1320 GAL
5296	4.04.0217.1.01.2	PL	EL-T7168. OOB	SPEEDOMETER/ 130KM/ H/ 24V -1
5297	4.04.0218.1.01.3	PL	676.38A	THERMOSTAT
5298	4.04.0219.1.01.4	PL	EL-T7159.00B	THERMOMETER/50-150DEGREES
5299	4.04.0220.1.01.5	PL	EL.T7190-V043	PILOT LAMP, RED
5300	4.04.0221.1.01.6	PL	EL-T7190-B1	LED-MODULE WHITE
5301	4.04.0222.1.01.7	PL	EL-T7190-B3	LED-MODULE GREEN
5302	4.04.0223.1.01.8	PL	EL-T7190-B4	LED-MODULE RED
5303	4.04.0224.1.01.9	PL	EL-T7190-B5	LED-MODULE YELLOW
5304	4.04.0225.1.01.1	PL	EL-T7250-CV1B	INDICATOR LIGHT WHITE
5305	4.04.0226.1.01.2	PL	EL-T7250-CV4B	INDICATOR LIGHT RED/18X18
5306	4.04.0227.1.01.3	PL	EL-T2083.02	WHEEL FLANGE
5307	4.04.0228.1.01.4	PL	B2N10H-Q20L60-2LU3-H1151	INCLINATION SENSOR
5308	4.04.0229.1.01.5	PH	UTV1-07-05/00	TRANSMISSION TEMP GAUGE
5309	4.04.0230.1.01.6	PH	UTV1-07-06/00	FUEL LEVEL GAUGE
5310	4.04.0231.1.01.7	PH	UTVI 07 08/00	TRANSMISSION PRESSURE GAUGE
5311	4.04.0232.1.01.8	PH	UTVI 07 09/00	AMPERE METER
5312	4.04.0233.1.01.9	PH	UTVI 07 10/00	RPM CUM HOUR METER
5313	4.04.0234.1.01.1	PH	UTVI 07 12/00	TECHOGRAPH
5314	4.04.0235.1.01.2	PH	UTVI 07 20/00	NEUTRAL TRANSMISSION INDICATOR
5315	4.04.0236.1.01.3	PH	UTVI 07 21/00	REVERSE TRANSMISSION INDICATOR
5316	4.04.0237.1.01.4	COLMAR	H5040530	THERMOSTAT
5317	4.04.0238.1.01.5	COLMAR	H8211100	CLAXON(BUZZER)
5318	4.04.0239.1.01.6	COLMAR	H8270020	Hydraulic pressure sensor
5319	4.04.0240.1.01.7	COLMAR	H8293920	BATTERY FOR RADIO CONTROL SENSOR
5320	4.04.0241.1.01.8	COLMAR	H8430090	PRESSURE SENSOR
5321	4.04.0242.1.01.9	COLMAR	H8467300	PRESSURE SENSOR
5322	4.04.0243.1.01.1	CR	40082234	Red LED
5323	4.04.0244.1.01.2	CR	40082235	Green LED
5324	4.04.0245.1.01.3	CR	40082663	Lining meter
5325	4.04.0246.1.01.4	CR	40084862	Pressure transmitter
5326	4.04.0247.1.01.5	CR	40098912	Pressure sensor
5327	4.04.0248.1.01.6	CR	40102519	Pressure sensor
5328	4.04.0249.1.01.7	CR	40109276	Super elevation meter
5329	4.04.0250.1.01.8	KA	E111622 6PA.700.815/EI1622 6PA.700.815	Galvanometers
5330	4.04.0251.1.01.9	KA	TU25.04.023-78	Voltammeter (BA-240 20-0-60amps) 0-30B
5331	4.04.0252.1.01.1	HA	413600	OT PAGE HORN
5332	4.04.0253.1.01.2	HA	5138450	PROXIMITY SENSOR / SWITCH
5333	4.04.0254.1.01.3	KA	TU37.003.615.79	Temp.indicator reciver
5334	4.04.0255.1.01.4	PL	HRL2B1TM18PP	MOUNTING CLIP 18MM for inductive sensor
5335	4.04.0256.1.01.5	PL	HRL4B1TM30PP	MOUNTING CLIP 30MM for inductive sensor
5336	4.04.0257.1.01.6	PL	EBC602-9E-904-M	Limit switch for brake air on
5337	4.04.0258.1.01.7	LO	211751	LEVEL/TEMP SWITCH, ACT
5338	4.04.0259.1.01.8	PL	DL242.02	Measuring Wheel (Encoder Wheel)
5339	4.04.0260.1.01.9	LO	111537	SENSOR WATER TEMP
5340	4.04.0261.1.01.1	LO	127009	SENSOR OIL PRESSURE
5341	4.04.0262.1.01.2	LO	127010	SENSOR TEMP INTAKE MANIFOLD
5342	4.04.0263.1.01.1	PL	SWBD08114/GELB	Led With Socket/20-28v/8mm
5343	4.04.0264.1.01.2	CU	216537	Switch magnetic
5344	4.04.0265.1.01.3	KA	12.3802/TU37.003.691-84	SPEEDOMETER INDICATOR
5345	4.04.0266.1.01.4	KA	24.3802/TU37.003.1189-83	SPEEDOMETER SENSOR
5346	4.04.0267.1.01.5	KA	OEM PART NO EI1622 6PA.700.815	Galvanometer
5347	4.04.0268.1.01.7	KA	6.61.12.000-01	FLOW CONTROL ASSEMBLY
5348	4.05.0001.1.01.3	PL	2155.01	TRANSDUCER
5349	4.05.0002.1.01.4	PL	501317159	TRANSDUCER
5350	4.05.0003.1.01.5	PL	750131053	FILTER ELEMENT
5351	4.05.0004.1.01.6	PL	0,1%0,25WTK25/1,2MOHM	RESISTANCE

5352	4.05.0005.1.01.7	PL	0,1%0,25WTK25/1,3KOHM	RESISTANCE
5353	4.05.0006.1.01.8	PL	0,1%0,25WTK25/1,5KOHM	RESISTANCE
5354	4.05.0007.1.01.9	PL	0,1%0,25WTK25/100KOHM	RESISTANCE
5355	4.05.0008.1.01.1	PL	0,1%0,25WTK25/10KOHM	RESISTANCE
5356	4.05.0009.1.01.2	PL	0,1%0,25WTK25/11KOHM	RESISTANCE
5357	4.05.0010.1.01.3	PL	0,1%0,25WTK25/12,1KOHM	RESISTANCE
5358	4.05.0011.1.01.4	PL	0,1%0,25WTK25/13KOHM	RESISTANCE
5359	4.05.0012.1.01.5	PL	0,1%0,25WTK25/14KOHM	RESISTANCE
5360	4.05.0013.1.01.6	PL	0,1%0,25WTK25/150KOHM	RESISTANCE
5361	4.05.0014.1.01.7	PL	0,1%0,25WTK25/15KOHM	RESISTANCE
5362	4.05.0015.1.01.8	PL	0,1%0,25WTK25/150HM	RESISTANCE
5363	4.05.0016.1.01.9	PL	0,1%0,25WTK25/16,3KOHM	RESISTANCE
5364	4.05.0017.1.01.1	PL	0,1%0,25WTK25/169KOHM	RESISTANCE
5365	4.05.0018.1.01.2	PL	0,1%0,25WTK25/18KOHM	RESISTANCE
5366	4.05.0019.1.01.3	PL	0,1%0,25WTK25/1KOHM	RESISTANCE
5367	4.05.0020.1.01.4	PL	0,1%0,25WTK25/1MOHM	RESISTANCE
5368	4.05.0021.1.01.5	PL	0,1%0,25WTK25/2,49KOHM	RESISTANCE
5369	4.05.0022.1.01.6	PL	0,1%0,25WTK25/200KOHM	RESISTANCE
5370	4.05.0023.1.01.7	PL	0,1%0,25WTK25/200-OHM	RESISTANCE
5371	4.05.0024.1.01.8	PL	0,1%0,25WTK25/20KOHM	RESISTANCE
5372	4.05.0025.1.01.9	PL	0,1%0,25WTK25/220-OHM	RESISTANCE
5373	4.05.0026.1.01.1	PL	0,1%0,25WTK25/24,3KOHM	RESISTANCE
5374	4.05.0027.1.01.2	PL	0,1%0,25WTK25/24,9KOHM	RESISTANCE
5375	4.05.0028.1.01.3	PL	0,1%0,25WTK25/255KOHM	RESISTANCE
5376	4.05.0029.1.01.4	PL	0,1%0,25WTK25/28KOHM	RESISTANCE
5377	4.05.0030.1.01.5	PL	0,1%0,25WTK25/2KOHM	RESISTANCE
5378	4.05.0031.1.01.6	PL	0,1%0,25WTK25/3,4KOHM	RESISTANCE
5379	4.05.0032.1.01.7	PL	0,1%0,25WTK25/3,92KOHM	RESISTANCE
5380	4.05.0033.1.01.8	PL	0,1%0,25WTK25/330OHM	RESISTANCE
5381	4.05.0034.1.01.9	PL	0,1%0,25WTK25/33KOHM	RESISTANCE
5382	4.05.0035.1.01.1	PL	0,1%0,25WTK25/36,5KOHM	RESISTANCE
5383	4.05.0036.1.01.2	PL	0,1%0,25WTK25/39KOHM	RESISTANCE
5384	4.05.0037.1.01.3	PL	0,1%0,25WTK25/4,22KOHM	RESISTANCE
5385	4.05.0038.1.01.4	PL	0,1%0,25WTK25/4,7KOHM	RESISTANCE
5386	4.05.0039.1.01.5	PL	0,1%0,25WTK25/4,99KOHM	RESISTANCE
5387	4.05.0040.1.01.6	PL	0,1%0,25WTK25/475OHM	RESISTANCE
5388	4.05.0041.1.01.7	PL	0,1%0,25WTK25/47OHM	RESISTANCE
5389	4.05.0042.1.01.8	PL	0,1%0,25WTK25/5,1KOHM	RESISTANCE
5390	4.05.0043.1.01.9	PL	0,1%0,25WTK25/5,9KOHM	RESISTANCE
5391	4.05.0044.1.01.1	PL	0,1%0,25WTK25/50KOHM	RESISTANCE
5392	4.05.0045.1.01.2	PL	0,1%0,25WTK25/51KOHM	RESISTANCE
5393	4.05.0046.1.01.3	PL	0,1%0,25WTK25/56,2KOHM	RESISTANCE
5394	4.05.0047.1.01.4	PL	0,1%0,25WTK25/560 OHM	RESISTANCE
5395	4.05.0048.1.01.5	PL	EL-T993.00-HG	TRANSDUCER
5396	4.05.0049.1.01.6	PL	0,1%0,25WTK25/6,49KOHM	RESISTANCE
5397	4.05.0050.1.01.7	PL	0,1%0,25WTK25/680OHM	RESISTANCE
5398	4.05.0051.1.01.8	PL	0,1%0,25WTK25/68KOHM	RESISTANCE
5399	4.05.0052.1.01.9	PL	0,1%0,25WTK25/7KOHM	RESISTANCE
5400	4.05.0053.1.01.1	PL	0,1%0,25WTK25/9,1KOHM	RESISTANCE
5401	4.05.0054.1.01.2	PL	0,5W1%15OHM	RESISTANCE
5402	4.05.0055.1.01.3	PL	0,5W1%3,3OHM	RESISTANCE
5403	4.05.0056.1.01.4	PL	0,5W1%33OHM	RESISTANCE
5404	4.05.0057.1.01.5	PL	0,5W1%47OHM	RESISTANCE
5405	4.05.0058.1.01.6	PL	100KOHM/T18	POTENTIOMETER
5406	4.05.0059.1.01.7	PL	100KOHM/T93YBQ	TRIMM POTENTIOMETER
5407	4.05.0060.1.01.8	PL	10KOHM	PRE-SET POTENTIOMETER
5408	4.05.0061.1.01.9	PL	10KOHM/PD2310/5A170MA	POTENTIOMETER
5409	4.05.0062.1.01.1	PL	10KOHM/T18	POTENTIOMETER
5410	4.05.0063.1.01.2	PL	10KOHM/T93YBQ	TRIMM POTENTIOMETER
5411	4.05.0064.1.01.3	PL	10KOHM0620017	POTENTIOMETER
5412	4.05.0065.1.01.4	PL	1183692 SUB. 1182841	TRANSDUCER
5413	4.05.0066.1.01.5	PL	1KOHM/T18	POTENTIOMETER
5414	4.05.0067.1.01.6	PL	1KOHM/T93YBQ	TRIMM POTENTIOMETER
5415	4.05.0068.1.01.7	PL	1W5%470OHM SUB. 1W10%470OHM	RESISTANCE
5416	4.05.0069.1.01.8	PL	2 MMD-BONDEZVG	CHORD WIRE 2 MM
5417	4.05.0070.1.01.9	PL	2.2KOHMT93YBQ	TRIMM POTENTIOMETER
5418	4.05.0071.1.01.1	PL	20 KSL=-/ - 5 SKLA	POTENTIOMETER
5419	4.05.0072.1.01.2	PL	20 KQ-10 SKALA/K-200G	POTENTIOMETER 20 K OHM
5420	4.05.0073.1.01.3	PL	200KOHM/T93YBQ	TRIMM POTENTIOMETER
5421	4.05.0074.1.01.4	PL	20K OHM-5-S KALA/K 200G	POTENTIOMETER
5422	4.05.0075.1.01.5	PL	20KOHM/T18	POTENTIOMETER
5423	4.05.0076.1.01.6	PL	20KOHM/T93YBQ	TRIMM POTENTIOMETER
5424	4.05.0077.1.01.7	PL	20KOHM+-5SKALA/K200-G	POTENTIOMETER
5425	4.05.0078.1.01.8	PL	210.033/041/001	ANGLE GEAR
5426	4.05.0079.1.01.9	PL	2155-0100-0002 Sub: 2155-01	TRANSDUCER
5427	4.05.0080.1.01.1	PL	220KOHM0620013	POTENTIOMETER

5428	4.05.0081.1.01.2	PL	22KOHM/T93YBQ	TRIMM POTENTIOMETER
5429	4.05.0082.1.01.3	PL	25W8.2OHM5%	RESISTANCE
5430	4.05.0083.1.01.4	PL	2KOHM/T18	POTENTIOMETER
5431	4.05.0084.1.01.5	PL	2OHM/2W	RESISTANCE
5432	4.05.0085.1.01.6	PL	2OHM/7W	RESISTANCE
5433	4.05.0086.1.01.7	PL	2OHM-1WATT	RESISTANCE
5434	4.05.0087.1.01.8	PL	323.801/003/001	TRANSDUCER
5435	4.05.0088.1.01.9	PL	323.801/004/002	TRANSDUCER
5436	4.05.0089.1.01.1	PL	323.805/001/001	TRANSDUCER
5437	4.05.0090.1.01.2	PL	340-807/001/100	TRANSDUCER
5438	4.05.0091.1.01.3	PL	4.7KOHMT93YBQ	TRIMM POTENTIOMETER
5439	4.05.0092.1.01.4	PL	47KOHM/T93YBQ	TRIMM POTENTIOMETER
5440	4.05.0093.1.01.5	PL	47KOHM0620017	POTENTIOMETER
5441	4.05.0094.1.01.6	PL	50W/1KOHM	RESISTANCE
5442	4.05.0095.1.01.7	PL	50W1OHM5%	RESISTANCE
5443	4.05.0096.1.01.8	PL	5KOHM/T18	POTENTIOMETER
5444	4.05.0097.1.01.9	PL	5W/470OHM	RESISTANCE
5445	4.05.0098.1.01.1	PL	5W/500OHM	RESISTANCE
5446	4.05.0099.1.01.2	PL	7W2% 2.2 OHM	RESISTANCE
5447	4.05.0100.1.01.3	PL	7W2%1OHM	RESISTANCE
5448	4.05.0101.1.01.4	PL	B380C1500M	RECTIFIER
5449	4.05.0102.1.01.5	PL	DF17/1S1.140BAD	PULSE GENERATOR
5450	4.05.0103.1.01.6	PL	EL-140-07	SHAFT
5451	4.05.0104.1.01.7	PL	EL-T 1041.01A	ROLLER
5452	4.05.0105.1.01.8		Shifted to Annexure-II	
5453	4.05.0106.1.01.9	PL	EL-T 1043	POTENTIOMETER
5454	4.05.0107.1.01.1	PL	EL-T 1062	POTENTIOMETER
5455	4.05.0108.1.01.2	PL	EL-T 2001-05	CHAIN BELT
5456	4.05.0109.1.01.3	PL	EL-T 213-06D	CARRIER
5457	4.05.0110.1.01.4	PL	EL-T 5112-00	POTENTIOMETER
5458	4.05.0111.1.01.5	PL	EL-T 576-0-80	CHORD WIRE
5459	4.05.0112.1.01.6	PL	EL-T 576-2.00	CHORD WIRE
5460	4.05.0113.1.01.7	PL	EL-T 928-01	ARM
5461	4.05.0114.1.01.8	PL	EL-T1041.12 (5X0.6)	SPRING
5462	4.05.0115.1.01.9	PL	EL-T1199.00-BR/L-RECHTS	TRANSDUCER
5463	4.05.0116.1.01.1	PL	EL-T1330.00LI	TRANSDUCER
5464	4.05.0117.1.01.2	PL	EL-T1330.00RE	TRANSDUCER
5465	4.05.0118.1.01.3	PL	EL-T1330.17	ROD
5466	4.05.0119.1.01.4	PL	EL-T152.04	CABLE PULLEY
5467	4.05.0120.1.01.5	PL	EL-T152.07	SHAFT
5468	4.05.0121.1.01.6	PL	EL-T152.161	STRIP
5469	4.05.0122.1.01.7	PL	EL-T2002.00/700	TRANSDUCER
5470	4.05.0123.1.01.8	PL	EL-T2007.00A	TRANSDUCER
5471	4.05.0124.1.01.9	PL	EL-T2013.04	SHAFT
5472	4.05.0125.1.01.1	PL	EL-T2013.17	LINING
5473	4.05.0126.1.01.2	PL	EL-T2013.23	STRIP
5474	4.05.0127.1.01.3	PL	EL-T2021.G1	SPIRIT LEVEL COMPLETE
5475	4.05.0128.1.01.4	PL	EL-T2036.43	LEVEL,SPIRIT MEASURING DEVICE
5476	4.05.0129.1.01.5	PL	EL-T2053.02	GEAR WHEEL
5477	4.05.0130.1.01.6	PL	EL-T2111.G3	LINEAR-WEGSENSOR.O.GRUNDPL.
5478	4.05.0131.1.01.7	PL	EL-T2117.00	PULSE DRIVE
5479	4.05.0132.1.01.8	PL	EL-T2118.00A-LINKS	TRANSDUCER
5480	4.05.0133.1.01.9	PL	EL-T-2118/4	TRANSDUCER
5481	4.05.0134.1.01.1	PL	EL-T213.01B	STRIP
5482	4.05.0135.1.01.2	PL	EL-T213.02B	ROD
5483	4.05.0136.1.01.3	PL	EL-T213.05	BUFFER STOP
5484	4.05.0137.1.01.4	PL	EL-T213.06G/1	CARRIER(BRASS)
5485	4.05.0138.1.01.5	PL	EL-T213.08	COVER
5486	4.05.0139.1.01.6	PL	EL-T213.28	SPRING
5487	4.05.0140.1.01.7	PL	EL-T213.33	BUSH
5488	4.05.0141.1.01.8	PL	EL-T213.34	PULLEY
5489	4.05.0142.1.01.9	PL	EL-T213.35	LEVER
5490	4.05.0143.1.01.1	PL	EL-T213.36	SPACER BUSH
5491	4.05.0144.1.01.2	PL	EL-T271SB SUB. EL-T271SA	CONNECTOR
5492	4.05.0145.1.01.3	PL	EL-T272SB SUB. EL-T272SA	CONNECTOR
5493	4.05.0146.1.01.4	PL	EL-T274B SUB. EL-T274A	CONNECTOR
5494	4.05.0147.1.01.5	PL	EL-T376.07	CABLE PULLEY
5495	4.05.0148.1.01.6	PL	EL-T376.15	COVER
5496	4.05.0149.1.01.7	PL	EL-T376.16	BEARING STAND
5497	4.05.0150.1.01.8	PL	EL-T376.283	ZERO-LIMIT
5498	4.05.0151.1.01.9	PL	EL-T376.284	SCREW
5499	4.05.0152.1.01.1	PL	EL-T376.285	BLOCK
5500	4.05.0153.1.01.2	PL	EL-T490.04	ROLLER
5501	4.05.0154.1.01.3	PL	EL-T490.10	SPRING
5502	4.05.0155.1.01.4	PL	EL-T5016.00A	POTENTIOMETER
5503	4.05.0156.1.01.5	PL	EL-T-5016-00	DEPTH INDICATOR (POTENOMETER)
5504	4.05.0157.1.01.6	PL	EL-T5112.00A	POTENTIOMETER

5505	4.05.0158.1.01.7	PL	EL-T566.01Z/S-5.14.1.2	COUPLING
5506	4.05.0159.1.01.8	PL	EL-T596.02A	CABLE PULLEY
5507	4.05.0160.1.01.9	PL	EL-T596.10	SPUR WHEEL
5508	4.05.0161.1.01.1	PL	EL-T596.11	GASKET
5509	4.05.0162.1.01.2	PL	EL-T609.29	SPRING
5510	4.05.0163.1.01.3	PL	EL-T609.32	ROD
5511	4.05.0164.1.01.4	PL	EL-T609.45	ROD
5512	4.05.0165.1.01.5	PL	EL-T7008/1100	DIGITAL POTENTIOMETER
5513	4.05.0166.1.01.6	PL	EL-T7033	POTENTIOMETER
5514	4.05.0167.1.01.7	PL	EL-T7072/100K	POTENTIOMETER
5515	4.05.0168.1.01.8	PL	EL-T7072/10K	POTENTIOMETER
5516	4.05.0169.1.01.9	PL	EL-T7072/1K	POTENTIOMETER
5517	4.05.0170.1.01.1	PL	EL-T7072/20K	POTENTIOMETER
5518	4.05.0171.1.01.2	PL	EL-T7072/2K	POTENTIOMETER
5519	4.05.0172.1.01.3	PL	EL-T7072/50K	POTENTIOMETER
5520	4.05.0173.1.01.4	PL	EL-T7072/5K	POTENTIOMETER
5521	4.05.0174.1.01.5	PL	EL-T7072C/200K	POTENTIOMETER
5522	4.05.0175.1.01.6	PL	EL-T7135.00B-JUSTIERT	TRANSDUCER
5523	4.05.0176.1.01.7	PL	EL-T750.00ES	TRANSDUCER
5524	4.05.0177.1.01.8		Shifted to Ann-II	
5525	4.05.0178.1.01.9	PL	EL-T750.15	ROPE CLAMP
5526	4.05.0179.1.01.1	PL	ELT902T1D-01	VERSINE TRANSDUCER
5527	4.05.0180.1.01.2	PL	ELT902T1F-01	TRANSDUCER
5528	4.05.0181.1.01.3	PL	ELT-903-00001-U/1000	ROLLER CHORD TRANSDUCER
5529	4.05.0182.1.01.4	PL	ELT-903-00001-U/2000	ROLLER CHORD TRANSDUCER
5530	4.05.0183.1.01.5	PL	ELT903T1A-01	ROLLER CHORD TRANSDUCER
5531	4.05.0184.1.01.6	PL	ELT904T1D-01A	PROPORTIONAL TRANSDUCER
5532	4.05.0185.1.01.7	PL	ELT904T1Q-01	LONGITUDINAL LEVEL TRANSDUCER
5533	4.05.0186.1.01.8	PL	EL-T920.04A	CARRIER
5534	4.05.0187.1.01.9	PL	EL-T920.14	DISC
5535	4.05.0188.1.01.1	PL	EL-T920.15	CABLE PULLY
5536	4.05.0189.1.01.2	PL	EL-T920.16	ROPE CLAMP
5537	4.05.0190.1.01.3	PL	III97105/1	SPRING
5538	4.05.0191.1.01.4	PL	MSW100-1101-06	ROD
5539	4.05.0192.1.01.5	PL	MSW100-1101-07	ROD
5540	4.05.0193.1.01.6	PL	N03330116	RESISTOR
5541	4.05.0194.1.01.7	PL	RM12-103J	RESISTOR NETWORK
5542	4.05.0195.1.01.8	PL	RM8-103J	RESISTOR NETWORK
5543	4.05.0196.1.01.9	PL	TQ441-01/01 YUER-1572	LIMIT INDICATOR
5544	4.05.0197.1.01.1	BH	4-20 MA DC SINGLE INPUT 0.5 OHM	CURRENT TRANSDUCER FOR DTS
5545	4.05.0198.1.01.2	LO	105055	SCR BRICK 800A 3000V
5546	4.05.0199.1.01.3	LO	126641	TRANS 117:36V 36VA CT 50/60 HZ, 1P
5547	4.05.0200.1.01.4	LO	126653	SCR TRACTION BRIDGE; 3 MODE DRIVE SYSTEM
5548	4.05.0201.1.01.5	LO	129527	TRANSDUCER PRESS 200PSI 04MORB 6-30VDC 4-20MA
5549	4.05.0202.1.01.6	LO	157290	TRANSDUCER PRESS 3000PSI 06MORB 7-35VDC 4-20MA
5550	4.05.0203.1.01.7	LO	A47129	POTENTIOMETER 5K SL
5551	4.05.0204.1.01.8	LO	C90410	REGULATOR VOLTAGE 63VDC 12 AMP CONTINUOUS
5552	4.05.0205.1.01.9	KA	TGU	LIAD SPEAKER DEVICE
5553	4.05.0206.1.01.1	PL	1183692 SUBSTITUTE 1182841	TRANSDUCER
5554	4.05.0207.1.01.2	PL	1W5%470OHM SUBSTITUTE 1W10%470OHM	RESISTANCE
5555	4.05.0208.1.01.3	PL	2155-01000002 SUBSTITUTE 2155-01	TRANSDUCER
5556	4.05.0209.1.01.4	PL	340.807/001/001	TRANSDUCER
5557	4.05.0210.1.01.5		Shifted to Ann II	
5558	4.05.0211.1.01.6		Shifted to Ann II	
5559	4.05.0212.1.01.7	PL	5W10%270OHM	RESISTANCE
5560	4.05.0213.1.01.8	PL	7W2%2.2OHM	RESISTANCE
5561	4.05.0214.1.01.9		Shifted to Ann II	
5562	4.05.0215.1.01.1	PL	EL-T1041.01A SUBSTITUTE EL-T1041.01AKPL	ROLLER
5563	4.05.0216.1.01.2	PL	EL-T1041.12(5X0.6)	SPRING
5564	4.05.0217.1.01.3	PL	EL-T1050-DL2/ BLAU	TOMMY HEAD
5565	4.05.0218.1.01.4	PL	EL-T1050-DL2/ROT	TOMMY HEAD
5566	4.05.0219.1.01.5	PL	EL-T1050-DL2/WEISS	TOMMY HEAD
5567	4.05.0220.1.01.6	PL	EL-T1050-DL3/BLAU	TOMMY HEAD
5568	4.05.0221.1.01.7	PL	EL-T1050-DL5/ GELB	TOMMY HEAD
5569	4.05.0222.1.01.8	PL	EL-T1062	POTENTIOMETER (10KOHM)
5570	4.05.0223.1.01.9		Shifted to Ann II	
5571	4.05.0224.1.01.1	PL	EL-T152.02	COVER
5572	4.05.0225.1.01.2	PL	EL-T2031.04	HOUSING
5573	4.05.0226.1.01.3	PL	EL-T2031.14	FITTING

5574	4.05.0227.1.01.4	PL	EL-T2070.00	CHORD GUIDANCE
5575	4.05.0228.1.01.5	PL	EL-T2070.01	SUPPORT
5576	4.05.0229.1.01.6	PL	EL-T4386.00	CHORD GUIDANCE
5577	4.05.0230.1.01.7	PL	EL-T576.10B	STEEL CHORD
5578	4.05.0231.1.01.8	PL	EL-T596.09	GEAR WHEEL
5579	4.05.0232.1.01.9	PL	EL-T67.02A	CARRIER
5580	4.05.0233.1.01.1	KA	6.54.00.008	Centimeter Transducer (Encoder)
5581	4.05.0234.1.01.2	KA	MGB115.461161.545	Potentiometer Setting Device
5582	4.05.0235.1.01.3	PL	EL-T200-00001-902-5-U	Absolute Valve Transducer
5583	4.05.0236.1.01.4	PL	EL-T200-00001-903-1-U-1000	Absolute Valve Transducer
5584	4.05.0237.1.01.5	CR	PD 210-10K/J 4BM	POTENTIOMETER
5585	4.05.0238.1.01.6	PL	ELT-908-00003-I	ACCELERATOR
5586	4.05.0239.1.01.7	PL	EL-T7287.00/ S-6.102/ISO	INCLINOMETER
5587	4.05.0240.1.01.8	PL	ELT-908-00001-I/L	ACCELERATOR
5588	4.05.0241.1.01.9	PL	EL-T700-00083-5/+5	POTENTIOMETER 20K - 5/+5 SKALA
5589	4.05.0242.1.01.1	PL	EL-T700-00083-0/10 sub 20KOHM0-10SKALA/K200-G	POTENTIOMETER
5590	4.05.0243.1.01.2	PL	EL-T7008/350 and 50KOHM2003	POTENTIOMETER
5591	4.05.0244.1.01.3	PL	ELB-LA0-25-10KOHM/10KOHM0620017	POTENTIOMETER
5592	4.05.0245.1.01.4	PL	ELB-LA0-26-22KOHM or 22KOHM0620013	POTENTIOMETER
5593	4.05.0246.1.01.5	PL	ELB-LA0-26-100KOHM/100KOHM0620013	POTENTIOMETER
5594	4.05.0247.1.01.6	PL	226.801/015/001	TRANSDUCER
5595	4.05.0248.1.01.7	PL	EL-T902-00004-D-U	TRANSDUCER (RECORDER CHORD)
5596	4.05.0249.1.01.8	PL	EL-T902-00004-U	TRANSDUCER
5597	4.05.0250.1.01.9	PL	EL-T902-00005-GL-U	TRANSDUCER (VERSINE)
5598	4.05.0251.1.01.1	PL	EL-T902-00005-U	TRANSDUCER (VERSINE)
5599	4.05.0252.1.01.2	PL	EL-T903-00001-I/500	TRANSDUCER (RECORDER CHORD)
5600	4.05.0253.1.01.3	PL	EL-T903-00001-U/1000	TRANSDUCER (T UNIT UP/DN)
5601	4.05.0254.1.01.4	PL	EL-T903-00001-U/2000	TRANSDUCER (ROLLER CHORD)
5602	4.05.0255.1.01.5	PL	EL-T903-00001-U/2500	TRANSDUCER (EXTENSION LIMITATION)
5603	4.05.0256.1.01.6	PL	EL-T904-00001-2	TRANSDUCER LHS (LEVELLING)
5604	4.05.0257.1.01.7	PL	EL-T904-00001-3	TRANSDUCER RHS (LEVELLING)
5605	4.05.0258.1.01.8	PL	EL-T904-00005LI-U/50	TRANSDUCER COMPLETE (LEVELLING)
5606	4.05.0259.1.01.9	PL	EL-T904-00005LI-U/170	TRANSDUCER COMPLETE (LEVELLING)
5607	4.05.0260.1.01.1	PL	EL-T904-00005LI-U/470	TRANSDUCER COMPLETE (LEVELLING)
5608	4.05.0261.1.01.2	PL	EL-T904-00005RE-U/50	TRANSDUCER COMPLETE (LEVELLING)
5609	4.05.0262.1.01.3	PL	EL-T904-00005RE-U/170	TRANSDUCER COMPLETE (LEVELLING)
5610	4.05.0263.1.01.4	PL	EL-T904-00005RE-U/470	TRANSDUCER COMPLETE (LEVELLING)
5611	4.05.0264.1.01.5	PL	EL-T904-00010-U	TRANSDUCER (LOGITUDINAL)
5612	4.05.0265.1.01.6	PL	EL-T905-00006-U/50	TRANSDUCER
5613	4.05.0266.1.01.7	PL	EL-T905-00002-U/90	TRANSDUCER
5614	4.05.0267.1.01.8	PL	EL-T906-00001-I/800	TRANSDUCER
5615	4.05.0268.1.01.9	PL	EL-T906-00001-U/1000	TRANSDUCER (ROLLER CHORD)
5616	4.05.0269.1.01.1	PL	EL-T906-00001-U/2000	TRANSDUCER (ROLLER CHORD)
5617	4.05.0270.1.01.2	PL	EL-T906-00008-I/3500	TRANSDUCER
5618	4.05.0271.1.01.3	PL	EL-T906-00009-I/1600	TRANSDUCER
5619	4.05.0272.1.01.4	PL	EL-T908-00003-U	POTENTIAL METER (WORK DRIVE, ACCELERATOR)
5620	4.05.0273.1.01.5	PL	EL-T9137.00	TRANSDUCER
5621	4.05.0274.1.01.6	PL	S-6.117.3	TRANSDUCER
5622	4.05.0275.1.01.7	PL	S-6.117.4	PRESSURE TRANSDUCER
5623	4.05.0276.1.01.8	PL	S-6.117.7	PRESSURE TRANSDUCER
5624	4.05.0277.1.01.9	PL	EL-T200-00001-902-4-U	ABSOLUTE VALUE TRANSDUCER (ROLLER CHORD)
5625	4.05.0278.1.01.1	PL	EL-T200-00001-903-1-U/1000	ABSOLUTE VALUE TRANSDUCER (T UNIT UP/DN)
5626	4.05.0279.1.01.2	PL	EL-T200-00001-903-1-U/2000	ABSOLUTE VALUE TRANSDUCER (ROLLER CHORD)
5627	4.05.0280.1.01.3	PL	EL-T200-00002-905-2-1-0-70	ROTARY ENCODER
5628	4.05.0281.1.01.4	PL	EL-T200-00001-906-1-U/1000	ABSOLUTE VALUE TRANSDUCER (ROLLER CHORD)
5629	4.05.0282.1.01.5	PL	EL-T200-00001-906-1-1-800	ABSOLUTE VALUE TRANSDUCER (ROLLER CHORD)

5630	4.05.0283.1.01.6	PL	EL-T200-00002-904-5LI-U	ABSOLUTE VALUE TRANSDUCER (LEVELLING)
5631	4.05.0284.1.01.7	PL	EL-T200-00002-904-5RE-U	ABSOLUTE VALUE TRANSDUCER (LEVELLING)
5632	4.05.0285.1.01.8	PL	EL-T200-00001A	ABSOLUTE VALUE TRANSDUCER (ROLLER CHORD)
5633	4.05.0286.1.01.9	PL	EL-T200-00002A	ABSOLUTE VALUE TRANSDUCER (ROTARY ENCODER)
5634	4.05.0287.1.01.1	PL	ELT-200-00001-903-1-U-1000	ABSOLUTE VALUE TRANSDUCER
5635	4.05.0288.1.01.2	PL	ELT-906-00001-U/1000	ROLLER CHORD TRANSDUCER
5636	4.05.0289.1.01.3	PL	ELT-200-00001-906-1-U-1000	ABSOLUTE VALUE TRANSDUCER
5637	4.05.0290.1.01.4	PL	ELT-904-00005LI-U/170	LEVELLING TRANSDUCER
5638	4.05.0291.1.01.5	PL	ELT-904-00005RE-U/170	LEVELLING TRANSDUCER
5639	4.05.0292.1.01.6	PL	ELT-902-00005-U	VERSINE TRANSDUCER
5640	4.05.0293.1.01.7	PL	EL-T2085	TRANSDUCER
5641	4.05.0294.1.01.8	PL	S-6.117.1(0-400 BAR)	PRESSURE TRANSDUCER-1
5642	4.05.0295.1.01.9	PL	ELT-200-00001-902-5-U	ABSOLUTE VALUE TRANSDUCER
5643	4.05.0296.1.01.1	CR	40089140	DIGITAL POTENTIOMETER
5644	4.05.0297.1.01.2	CR	40092217	LIFTING POTENTIOMETER
5645	4.05.0298.1.01.3	PL	2159-01000003	TRANSDUCER
5646	4.05.0299.1.01.4	CR	2005331	HOOK TRANSDUCER
5647	4.05.0300.1.01.5	CR	2009092	T/U UP DOWN TRANSDUCER
5648	4.05.0301.1.01.6	PL	S-6.117.1	Pressure transducer
5649	4.05.0302.1.01.7	PL	S-6.117.3	Pressure transducer
5650	4.05.0303.1.01.8	PL	S-6.117.5	Pressure transducer
5651	4.05.0304.1.01.9	PL	NTB-1301Y-03-OEM	Reservoir level transducer
5652	4.05.0305.1.01.1	PL	S-7.105.1	Signal transmitter
5653	4.05.0306.1.01.2	PL	P30LL0FRR103MA	POTENTIOMETER
5654	4.05.0307.1.01.3	PL	90297/-40GRAD	TRANSDUCER
5655	4.05.0307.1.01.4	PL	EL-T902-00004-I	TRANSDUCER
5656	4.05.0308.1.01.5	PL	EL-T200-00001-902-4-I	ABSOLUTE VALUE TRANSDUCER (ROLLER CHORD)
5657	4.05.0309.1.01.6	PL	EL-T2013.00G1	SWIVEL PART
5658	4.05.0310.1.01.7	PL	EL-T856.02	HOLDER L.H.S. FOR TRANSDUCER
5659	4.05.0311.1.01.8	PL	EL-T856.03	BRACKET R.H.S. FOR TRANSDUCER
5660	4.05.0312.1.01.9	PL	47KOHM3-1625931-3	POTENTIOMETER
5661	4.05.0313.1.01.9	PL	EL-T902-00005-3	SCALE
5662	4.05.0314.1.01.1	PL	EL-T200-00001-903-1-U/2500	ABSOLUTE VALUE TRANSDUCER (ROLLER CHORD)
5663	4.05.0315.1.01.2	PL	HDA4745-B-600-114	PRESSURE TRANSDUCER
5664	4.05.0316.1.01.3	PL	HDA4846-A-025-000	PRESSURE TRANSDUCER
5665	4.05.0317.1.01.4	PL	EL-T1064.01A	LEVER
5666	4.05.0318.1.01.5	PL	PN-A.201.001-00/1500	PRESS. TRANSDUCER
5667	4.05.0319.1.01.6	CR	40098677	Current transducer
5668	4.05.0320.1.01.7	CR	JM2-120(L)	High Transducer
5669	4.05.0321.1.01.8	CR	JM2-120(R)	High Transducer
5670	4.05.0322.1.01.9	CR	JM3-120	TRANSDUCER
5671	4.05.0323.1.01.1	CR	XM1A-760	Versine Transducer
5672	4.05.0324.1.01.2	CR	XM2-246	TRANSDUCER
5673	4.05.0325.1.01.3	CR	XM3-780	Tamping Depth Transducer
5674	4.05.0326.1.01.4	CR	XM3A-780	Displacement Transducer
5675	4.05.0327.1.01.5	CR	XM3C-1600	Follow up Transducer
5676	4.05.0328.1.01.6	KA	461.264.545/MCBP461264545	Setting device Potentiometer(for SE)
5677	4.05.0329.1.01.7	PL	ELT-906-00001-I/150	Plough inclination transducer
5678	4.05.0330.1.01.8	PL	ELT-902-00001-2	Slide rod
5679	4.05.0331.1.01.9	PL	ELT-908-00002-I	Accelerator
5680	4.05.0332.1.01.1	PL	WN80.2604-8	SHIFT ROD
5681	4.05.0333.1.01.2	PL	WN70.3406-A	Shift Rod
5682	4.05.0334.1.01.3	PL	HY154.29/100	PRESSURE TRANSDUCER
5683	4.05.0335.1.01.4	LO	A67107	TACHOMETER
5684	4.05.0336.1.01.5	PL	DMG18/10 ZE LT ME/10KOHM	Potentiometer 10kohm 10turns
5685	4.05.0337.1.01.6	PL	MUP1300R10K	Potentiometer
5686	4.06.0001.1.01.4	PL	EL-T 133.00	PENDULUM ASSEMBLY
5687	4.06.0002.1.01.5	PL	EL-T 2111.00B	PENDULUM
5688	4.06.0003.1.01.6	PL	EL-T-2021-00-1A	PENDULUM
5689	4.06.0004.1.01.7	PL	EL-T-2036-00A	PENDULUM
5690	4.06.0005.1.01.8	PL	EL-T2111.23	SHIELD
5691	4.06.0006.1.01.9	PL	EL-T2111.24	HOSE
5692	4.06.0007.1.01.1	PL	EL-T2111.25	HOSE
5693	4.06.0008.1.01.2	PL	ELT-7035	PENDULUM
5694	4.06.0009.1.01.3	PL	EL-T.700-000-10	PENDULUM SOCKET
5695	4.06.0010.1.01.4	PL	EL-T2076.04	COVER
5696	4.06.0011.1.01.5	PL	EL-T901-00001	PENDULUM
5697	4.06.0012.1.01.6	PL	EL-T2111.G1 OR EL-T2111.G1A	PENDULAM
5698	4.06.0013.1.01.7	PL	EL-T2111.G5	BRAKE for PENDULUM
5699	4.06.0014.1.01.8	PL	ELT-700-00010	Pendulum CONNECTOR
5700	4.06.0015.1.01.9	CR	JM1-360	Pendulum

5701	4.06.0016.1.01.1	KA	EL-T133.00	Pendulum
5702	4.07.0001.1.01.5	PL	DAT 2 x0.25	DATA CABLE
5703	4.07.0002.1.01.6	PL	DAT 2 x0.5	DATA CABLE
5704	4.07.0003.1.01.7	PL	DAT 6x2 x0.20	DATA CABLE
5705	4.07.0004.1.01.8	PL	DAT 6x2 x0.50	DATA CABLE
5706	4.07.0005.1.01.9	Shifted to Ann II		
5707	4.07.0006.1.01.1	AM	9900019	CABLE M30 - T28
5708	4.07.0007.1.01.2	LO	115084	LASER CUTOFF CABLE INTERMEDIATE
5709	4.07.0008.1.01.3	LO	115491	CABLE ASSY SERVO VALVE 10 FT PIGTAIL
5710	4.07.0009.1.01.4	LO	128079	PLC CABLE ANALOG 39 IN.; PLC MOD TO IFM
5711	4.07.0010.1.01.5	LO	128080	PLC CABLE ANALOG 39 IN.; PLC MOD TO IFM
5712	4.07.0011.1.01.6	LO	128082	PLC CABLE DIGITAL 39 IN.; PLC MOD TO IFM
5713	4.07.0012.1.01.7	LO	128084	PLC CABLE ANALOG 39 IN; PLC MOD TO IFM
5714	4.07.0013.1.01.8	LO	155255	CABLE CAMERA EXT 10 FT ORIAN VIII
5715	4.07.0014.1.01.9	LO	159313	CABLE ODOMETER 85 FT; ORIAN VIII
5716	4.07.0015.1.01.1	LO	162396	CABLE CONTROL 64 FT ORIAN VIII
5717	4.07.0016.1.01.2	LO	162397	CABLE HEATER 64 FT ORIAN VIII
5718	4.07.0017.1.01.3	LO	162398	CABLE CAMERA 64 FT ORIAN VIII
5719	4.07.0018.1.01.4	LO	162423	CABLE LASER CUTOFF 60 FT ECU TO CUTOFF ENCLOSURE
5720	4.07.0019.1.01.5	LO	163427	KLD ORIAN VIII GP; 110VAC 100 FT CABLE
5721	4.07.0020.1.01.6	LO	163430	CABLE CONTROL 100 FT; ORIAN VIII
5722	4.07.0021.1.01.7	LO	163431	CABLE HEATER 100 FT; ORIAN VIII
5723	4.07.0022.1.01.8	LO	163432	CABLE CAMERA 100 FT; ORIAN VIII
5724	4.07.0023.1.01.9	PL	0.5AWG20BLAU/TSR20-728	WIRE
5725	4.07.0024.1.01.1	PL	BETATRANS-35MM2 SUBSTITUTE LAPPTHERM145-35MM2/SCHWARZ	SINGLE CABLE CORE
5726	4.07.0025.1.01.2	PL	ELB-000-00006-EN-0.35M	NETWORK CABLE
5727	4.07.0026.1.01.3	PL	ELB-000-00006-EN-4M	NETWORK CABLE
5728	4.07.0027.1.01.4	PL	ELB-000-00005-EN-6M	NETWORK CABLE
5729	4.07.0028.1.01.5	PL	ELB-000-00006-EN-3M	CABLE PRE ASSEMBLED M12MSD 3M
5730	4.07.0029.1.01.6	PL	PLTHFLEX-4X2X0.15CAT6 PUR SK	NETWORK CABLE
5731	4.07.0030.1.01.7	LO	163429	CABLE LASER CUTOFF 100 FT ECU TO CUTOFF ENCLOSURE
5732	4.07.0031.1.01.8	LO	158377	CABLE DEVICENET CROSSOVER
5733	4.07.0032.1.01.9	LO	163665	CABLE ODOMETER 100FT; ORIAN VIII
5734	4.07.0033.1.01.1	LO	249198	LASER CUTOFF CABLE; INTERMEDIATE
5735	4.07.0034.1.01.2	LO	233941	CCU MAIN POWER CABLE
5736	4.07.0035.1.01.3	LO	252351-78	RAIL PROFILE CABLE KIT
5737	4.07.0036.1.01.4	LO	249194	SH CABLE CAMERA 35FT
5738	4.07.0037.1.01.5	LO	249197	LASER CUTOFF CABLE; 35FT
5739	4.07.0038.1.01.6	LO	100266	COAX CABLE RG-59/U (MIN QTY 10)
5740	4.07.0039.1.01.7	LO	126065	CONNECTOR CORD 0.50 90; CORD RANGE .125-.25
5741	4.07.0040.1.01.8	LO	114824	CONTROLNET CABLE (MIN QTY 10)
5742	4.07.0041.1.01.9	LO	127233	RTD CABLE ASSEMBLY 10FT
5743	4.07.0042.1.01.1	LO	123505	RTD 3 WIRE W/20FT LEAD
5744	4.07.0043.1.01.2	LO	250683	CABLE ASSY 8/4 X 180IN; 86IN FIRESLEEVE
5745	4.07.0044.1.01.3	LO	206263	CABLE ASSEMBLY 15 FT FEEDBACK; SHIELD CASE
5746	4.07.0045.1.01.4	LO	A47375	FIRESLEEVE (MINIMUM QTY 10)
5747	4.07.0046.1.01.5	LO	A84300	FIRESLEEVE .75 ID ORANGE
5748	4.07.0047.1.01.6	HA	401332	CABLE
5749	4.07.0048.1.01.7	HA	4012176	CABLE
5750	4.07.0049.1.01.8	HA	3401338/3401336	CABLE
5751	4.07.0050.1.01.9	HA	3401332	CABLE
5752	4.07.0051.1.01.1	HA	5045457	CABLE
5753	4.07.0052.1.01.2	HA	4022331	CABLE
5754	4.07.0053.1.01.3	LO	166306	PLC CABLE ANALOG 59 IN; PLC MOD TO IFM
5755	4.07.0054.1.01.4	PL	DZ160/G=2500/HUB200	PULLCABLE
5756	4.07.0055.1.01.5	LO	A21993	WIRE 8/4 (minimum qty 100)
5757	4.07.0056.1.01.6	LO	164253	CABLE ASSEMBLY 15 FT FEEDBACK SHIELD CASE
5758	4.08.0001.1.01.6	PL	31.5001	FUSE SOCKET
5759	4.08.0002.1.01.7	PL	19556	FUSE SOCKET
5760	4.08.0003.1.01.8	PL	19560	FUSE HOLDER

5761	4.08.0004.1.01.9	PL	29554	BRACKET
5762	4.08.0005.1.01.1	PL	1191017003	FUSE/80A
5763	4.08.0006.1.01.2	PL	1191017004	FUSE/30A
5764	4.08.0007.1.01.3	PL	1191017005	FUSE/50A
5765	4.08.0008.1.01.4	PL	1191017006	FUSE/100A
5766	4.08.0009.1.01.5	PL	1191017007	FUSE/125A
5767	4.08.0010.1.01.6	PL	1904520018	FUSE/16A
5768	4.08.0011.1.01.7	PL	0031.7601 SUB. 19560	FUSE HOLDER
5769	4.08.0012.1.01.8	PL	0034.6621 SUB. 19372K/4,0A	FUSE
5770	4.08.0013.1.01.9	PL	0118772-11MN60	BRACKET
5771	4.08.0014.1.01.1	PL	1022-01-32-1000-KURZ	ANGULAR GEAR
5772	4.08.0015.1.01.2	PL	1022-01-32-1428 / SUBS 1022-01-00-142	ANGLE GEAR
5773	4.08.0016.1.01.3	PL	1022-01-35-1000LG	ANGLE GEAR
5774	4.08.0017.1.01.4	PL	1032-04-01-1389 / 1032-04-01-1383	GEAR BOX
5775	4.08.0018.1.01.5	PL	1032-54-01-0356	GEAR BOX
5776	4.08.0019.1.01.6	PL	1080-4-749	SOCKET
5777	4.08.0020.1.01.7	PL	2-05893	STRIP
5778	4.08.0021.1.01.8	PL	272/0,5A	FUSE
5779	4.08.0022.1.01.9	PL	272/1A	FUSE
5780	4.08.0023.1.01.1	PL	272/2A	FUSE
5781	4.08.0024.1.01.2	PL	272/3,15A	FUSE
5782	4.08.0025.1.01.3	PL	272/4A	FUSE
5783	4.08.0026.1.01.4	PL	272/5A	FUSE
5784	4.08.0027.1.01.5	PL	275/1A	FUSE
5785	4.08.0028.1.01.6	PL	275/2A	FUSE
5786	4.08.0029.1.01.7	PL	275/3A	FUSE
5787	4.08.0030.1.01.8	PL	275/4A	FUSE
5788	4.08.0031.1.01.9	PL	280099-0 SUB. 0659055105	PLUG HOUSING/8POL
5789	4.08.0032.1.01.1	PL	5X20/0,2AFLINK SUB. 5X20/200MA	FUSE
5790	4.08.0033.1.01.2	PL	5X20/10AFLINK	FUSE
5791	4.08.0034.1.01.3	PL	5X20/1AFLINK	FUSE
5792	4.08.0035.1.01.4	PL	5X20/2AFLINK	FUSE
5793	4.08.0036.1.01.5	PL	5X20/3,15AFLINK	FUSE
5794	4.08.0037.1.01.6	PL	5X20/4AFLINK	FUSE
5795	4.08.0038.1.01.7	PL	5X20/6,3AFLINK	FUSE
5796	4.08.0039.1.01.8	PL	AK100000	SILICONE OIL
5797	4.08.0040.1.01.9	PL	AK2000	SILICONE OIL
5798	4.08.0041.1.01.1	PL	AK-5000	SILICON OIL
5799	4.08.0042.1.01.2	PL	BU06OZ	SOCKET
5800	4.08.0043.1.01.3	PL	BU08OZ	SOCKET
5801	4.08.0044.1.01.4	PL	BU14OZ	I.C.SOCKET/14POL
5802	4.08.0045.1.01.5	PL	BU16OZ	I.C.SOCKET/16POL
5803	4.08.0046.1.01.6	PL	BU18OZ	I.C.SOCKET/18POL
5804	4.08.0047.1.01.7	PL	BU24OZ(DIL 24MZ)	SOCKET
5805	4.08.0048.1.01.8	PL	BU28DZ	SOCKET
5806	4.08.0049.1.01.9	PL	CNY17/IV	OPTO-COUPLER
5807	4.08.0050.1.01.1	PL	EL-T 271 SA	PLUG
5808	4.08.0051.1.01.2		Shifted to Ann-II	
5809	4.08.0052.1.01.3	PL	EL-T 7126/25 AMPS	CIRCUIT BREAKER
5810	4.08.0053.1.01.4	PL	EL-T 7126/35A	CIRCUIT BREAKER
5811	4.08.0054.1.01.5		Shifted to Ann-II	
5812	4.08.0055.1.01.6	PL	EL-T190.8	PLUG
5813	4.08.0056.1.01.7	PL	EL-T376.282	ANGLE
5814	4.08.0057.1.01.8	PL	EL-T-4111-00 / EL-T-4112-00	RAIL
5815	4.08.0058.1.01.9	PL	EL-T576.08	CHORD WIRE
5816	4.08.0059.1.01.1	PL	EL-T-576-1-35	CHORD WIRE FOR TRANSDUCER
5817	4.08.0060.1.01.2	PL	EL-T596.05	AXLE
5818	4.08.0061.1.01.3	PL	EL-T596.12	SOCKET
5819	4.08.0062.1.01.4	PL	EL-T609.31LI	BRACKET
5820	4.08.0063.1.01.5	PL	EL-T609.31RE	BRACKET
5821	4.08.0064.1.01.6	PL	EL-T67.00C	CARRIER
5822	4.08.0065.1.01.7	PL	EL-T7056S-6POL. SUB. EL-T7056S	PLUG
5823	4.08.0066.1.01.8	PL	EL-T-7059-00	ELECTRIC LIFTING CYLINDER
5824	4.08.0067.1.01.9		Shifted to Ann-II	
5825	4.08.0068.1.01.1		Shifted to Ann-II	
5826	4.08.0069.1.01.2	PL	EL-T82	PLUG
5827	4.08.0070.1.01.3	PL	EL-T953K	BRACKET
5828	4.08.0071.1.01.4	PL	EL-T-966-00	TEST ADOPTER
5829	4.08.0072.1.01.5	PL	HC-49/U SUB. HC-43U	QUARTZ
5830	4.08.0073.1.01.6	PL	JK020014	RAIL
5831	4.08.0074.1.01.7	PL	LA22.5D-100-24VDC	MOTOR
5832	4.08.0075.1.01.8	PL	MBK10	TERMINAL
5833	4.08.0076.1.01.9	PL	MBK3	TERMINAL

5834	4.08.0077.1.01.1	PL	TF183	TRANSISTOR SOCKET
5835	4.08.0078.1.01.2	PL	TF53	TRANSISTOR SOCKET
5836	4.08.0079.1.01.3	PL	UD230.380 POS1.15	CHORD GUIDE DEVICE
5837	4.08.0080.1.01.4	PL	ZKR118	SOCKET
5838	4.08.0081.1.01.5	KE	183834	CIRCUIT BREAKER 15AMPS
5839	4.08.0082.1.01.6	KE	183835	CIRCUIT BREAKER 20AMPS
5840	4.08.0083.1.01.7	LO	100682	CONNECTOR MALE BNC COAX
5841	4.08.0084.1.01.8	LO	103710	FUSE 5 AMP 600 VOLT TIME DELAY
5842	4.08.0085.1.01.9	LO	103715	FUSE 1250 AMP 700 VOLT; HIGH SPEED
5843	4.08.0086.1.01.1	LO	103731	CB 15A 3P 480V ASSY DIN RAIL MOUNT
5844	4.08.0087.1.01.2	LO	103733	CB 30A 3P 480V ASSY DIN RAIL MOUNT
5845	4.08.0088.1.01.3	LO	103736	CB 70A 3P 480V ASSY DIN RAIL MOUNT
5846	4.08.0089.1.01.4	LO	105199	OVERLOAD IEC 64.0-82.0A C-2000 SERIES
5847	4.08.0090.1.01.5	LO	106429	OVERLOAD IEC 2.5-4.1A C2000 SERIES
5848	4.08.0091.1.01.6	LO	109955	FUSE HOLDER TERMINAL BLK
5849	4.08.0092.1.01.7	LO	114497	OVERLOAD E3 PLUS 9-45A FOR 100-C30...C43
5850	4.08.0093.1.01.8	LO	115991	CONT OL 5.4-27.0A FOR 100-C09..100-C23
5851	4.08.0094.1.01.9	LO	115992	CONT OL 1.0-5.0A FOR 100-C09..100-C23
5852	4.08.0095.1.01.1	LO	116399	CB 63A 1P 480V
5853	4.08.0096.1.01.2	LO	116658	CB 2500A 3P 600V CRADLE; E3 FRAME DRAWOUT
5854	4.08.0097.1.01.3	LO	117535	CB 15A 3P 480V T1 FRAME MOLDED CASE
5855	4.08.0098.1.01.4	LO	117536	CB 20A 3P 480V; T1 FRAME MOLDED CASE
5856	4.08.0099.1.01.5	LO	118944	CB DISC CABLE; 36 INCH
5857	4.08.0100.1.01.6	LO	120600	TERMINAL FEMALE MOTOR #6; PIGTAIL CONNECTOR
5858	4.08.0101.1.01.7	LO	123729	CB 2.5A 3P 480V 1.6A-2.5A OVERLOAD
5859	4.08.0102.1.01.8	LO	123731	CB 10A 3P 480V 6.3A-10.0A OVERLOAD
5860	4.08.0103.1.01.9	LO	123732	CB 16A 3P 480V 10.0A-16.0A OVERLOAD
5861	4.08.0104.1.01.1	Shifted to Ann-II		
5862	4.08.0105.1.01.2	LO	123739	CB 90A 3P 480V 63.0A-90.0A OVERLOAD
5863	4.08.0106.1.01.3	LO	123825	CB 63A 2P 480V 30MA GFI PROTECTION
5864	4.08.0107.1.01.4	LO	124236	CB 16A 2P 480V
5865	4.08.0108.1.01.5	LO	126512	CB 175A 3P 600V S3 FRAME MOLDED CASE
5866	4.08.0109.1.01.6	LO	126631	CB 400A 3P 600V S5 FRAME MOULDED CASE
5867	4.08.0110.1.01.7	LO	126849	STANDOFF THRD MALE/FEMALE; .25X2.00 8-32 THREAD
5868	4.08.0111.1.01.8	LO	128989	CB 250A 3P 600V HIGH; T4 FRAME MOLDED CASE
5869	4.08.0112.1.01.9	LO	129614	CB 80A 3P 480V ASSY DIN RAIL MOUNT
5870	4.08.0113.1.01.1	LO	134679	TERMINAL MALE MOTOR #8; PIGTAIL CONNECTOR
5871	4.08.0114.1.01.2	LO	134826	CB 100A 4P 480V; 30MA GFI PROTECTION
5872	4.08.0115.1.01.3	Shifted to Ann-II		
5873	4.08.0116.1.01.4	LO	162554	CB DISC HANDLE; FLANGE
5874	4.08.0117.1.01.5	Shifted to Ann-II		
5875	4.08.0118.1.01.6	Repeated item		
5876	4.08.0118.1.01.6	PL	1022-01-32-1428 SUBSTITUTE 1022-01-00-142	ANGLEGEAR
5877	4.08.0119.1.01.7	PL	1904520016	FUSE/8A
5878	4.08.0120.1.01.8	PL	2155-STECKER	PLUG
5879	4.08.0121.1.01.9	Shifted to Ann-II		
5880	4.08.0122.1.01.1	PL	8JD005993-032 SUBSTITUTE 0986354003	FUSE BOX
5881	4.08.0123.1.01.2	PL	BU24OZ(DIL24MZ)	SOCKET
5882	4.08.0124.1.01.3	PL	BU28OZ SUBSTITUTE 641894-1	SOCKET
5883	4.08.0125.1.01.4	PL	EL-T7056S-6POL. SUBSTITUTE EL-T7056S	PLUG
5884	4.08.0126.1.01.5	PL	RM78705	SOCKET
5885	4.08.0127.1.01.6	Shifted to Ann-II		

5886	4.08.0128.1.01.7			Shifted to Ann-II
5887	4.08.0129.1.01.8	PL	EL-T7126/20A	CIRCUIT BREAKER
5888	4.08.0130.1.01.9			Shifted to Ann-II
5889	4.08.0131.1.01.1			Shifted to Ann-II
5890	4.08.0132.1.01.2	PL	EL-T7126/40A	CIRCUIT BREAKER
5891	4.08.0133.1.01.3			Shifted to Ann-II
5892	4.08.0134.1.01.4			Shifted to Ann-II
5893	4.08.0135.1.01.5	LO	A87499	TERMINAL MALE MOTOR; PIGTAIL CONNECTOR
5894	4.08.0136.1.01.6	LO	A87500	TERMINAL FEMALE MOTOR PIGTAIL CONNECTOR
5895	4.08.0137.1.01.7	LO	B90411	CIRCUIT BREAKER 20 AMP 277VAC 3 POLE
5896	4.08.0138.1.01.8	KA	MCBI 461267.000 (India)	Logic Module Siemens Log O 1.12/24
5897	4.08.0139.1.01.9	GE	G2A-G11/2 NBR/P460NH	Connector-1
5898	4.08.0140.1.01.1	GE	1CN-22-08	Connector-2
5899	4.08.0141.1.01.2	GE	1CN-18-08	Connector-3
5900	4.08.0142.1.01.3	GE	1CN-18-06	Connector-4
5901	4.08.0143.1.01.4	GE	1CB-14-06	Connector-5
5902	4.08.0144.1.01.5	GE	2C9-14	Connector-6
5903	4.08.0145.1.01.6	GE	2C9-18	Connector-7
5904	4.08.0146.1.01.7	GE	1CB-30-12	Connector-8
5905	4.08.0147.1.01.8	GE	1CB-18-06	Connector-9
5906	4.08.0148.1.01.9	GE	1CB-14-04	Connector-10
5907	4.08.0149.1.01.1	GE	2C9-30	Connector-11
5908	4.08.0150.1.01.2	GE	1CN-36-16	Connector-12
5909	4.08.0151.1.01.3	GE	2C9-22	Connector-13
5910	4.08.0152.1.01.4	GE	1CN-18-04	Connector-14
5911	4.08.0153.1.01.5	GE	2C9-36	Connector-15
5912	4.08.0154.1.01.6	GE	1CB-22-08	Connector-16
5913	4.08.0155.1.01.7	GE	1CB-36-16	Connector-17
5914	4.08.0156.1.01.8	GE	YS02300002	Spare plug kit (Set)
5915	4.08.0157.1.01.9	CR	40100378-112	PLUG
5916	4.08.0158.1.01.1	CR	40107997	CONNECTOR
5917	4.08.0159.1.01.2	PL	EL-AM50.01	CAN BUS TERIMINAL PLUG
5918	4.08.0160.1.01.3	PL	192.168.0.54	MACHINE DATE CONNECTOR
5919	4.08.0161.1.01.4			Shifted to Ann-II
5920	4.08.0162.1.01.5			Shifted to Ann-II
5921	4.08.0163.1.01.6	PL	3600-P10-S1-15A-2350	CIRCUIT BREAKER
5922	4.08.0164.1.01.7			Shifted to Ann-II
5923	4.08.0165.1.01.8	CR	IC65H-DC 16/1P-C	CIRCUIT BREAKER-1
5924	4.08.0166.1.01.9	CR	IC65H-DC 10/1P-C	CIRCUIT BREAKER-2
5925	4.08.0167.1.01.1	CR	IC65H-DC 6/1P-C	CIRCUIT BREAKER-3
5926	4.08.0168.1.01.2	CR	IC65H-DC 20/1P-C	CIRCUIT BREAKER-4
5927	4.08.0169.1.01.3	CR	IC65H-DC 25/1P-C	CIRCUIT BREAKER-5
5928	4.08.0170.1.01.4	CR	IC65H-DC 40/1P-C	CIRCUIT BREAKER-6
5929	4.08.0171.1.01.5	CR	0.8MM	CHORD WIRE
5930	4.08.0172.1.01.6	CR	0.5MM	CHORD WIRE
5931	4.08.0173.1.01.7	PL	PVE32/157B4992	Amp plug(proportional valves)
5932	4.08.0174.1.01.8	PL	FFA.2E.304.CLAC60ZN	Plug 4pol(Inclinometer plug)
5933	4.08.0175.1.01.9	PL	FMK1	Connector housing/9 pins(communication cable plug)
5934	4.08.0176.1.01.1	PL	S-8.81.1	DOUBLE VALVE PLUG 107MM
5935	4.08.0177.1.01.2	PL	S-8.82.1	DOUBLE VALVE PLUG 134MM
5936	4.08.0178.1.01.3	PL	289-405	Transfer connection module
5937	4.08.0179.1.01.4	PL	ERB.2E.305.CLL	SOCKET 5 POLES
5938	4.08.0180.1.01.5	PL	TN-5305-T	ETHERNET SWITCH
5939	4.08.0181.1.01.6	PL	TN-5308-LV-T	ETHERNET SWITCH
5940	4.08.0182.1.01.7	PL	EL-T904-00005-2-84	PLUG ADAPTOR
5941	4.08.0183.1.01.8	PL	VS-08-RJ45-10G/Q	CONNECTOR RJ45
5942	4.08.0184.1.01.9	LO	143520	ETHERNET SWITCH; 4 PORT RJ45 MANAGED
5943	4.08.0185.1.01.1	LO	143523	CONN PLUG RJ45 IP 20
5944	4.08.0186.1.01.2	LO	100267	CONNECTOR MALE BNC COAX
5945	4.08.0187.1.01.3	LO	252351-216	CIRCUIT BREAKER REPLACEMENT KIT #1
5946	4.08.0188.1.01.4	LO	106307	TERMINAL BLOCK 10mm SINGLE LEVEL
5947	4.08.0189.1.01.5	LO	252351-21	CIRCUIT BREAKER REPLACEMENT KIT - SMALL
5948	4.08.0190.1.01.6	LO	116526	CONTROLNET Y-TAP STRAIGHT CONNECTOR
5949	4.08.0191.1.01.7	LO	117076	CONNECTOR BNC PLUG CONTROLNET CABLE
5950	4.08.0192.1.01.8	LO	129957	ISOLATOR

5951	4.08.0193.1.01.9	LO	251921	CIRCUIT BREAKER 15A 3P 600V; XT1 FIXED MOLDED CASE
5952	4.08.0194.1.01.1	LO	125996	TERMINAL BLOCK 5MM 3COND SINGLE SPRING CLAMP
5953	4.08.0195.1.01.2	LO	125998	TERMINAL BLOCK 5MM 3COND GND SINGLE SPRING CLAMP
5954	4.08.0196.1.01.3	LO	125999	TERMINAL BLOCK 5MM JUMPER 2POS SINGLE SPRING CLAMP
5955	4.08.0197.1.01.4	LO	126002	TERMINAL BLOCK END CLAMP SCREWLESS
5956	4.08.0198.1.01.5	LO	252351-57	CIRCUIT BREAKER REPLACEMENT KIT - MEDIUM
5957	4.08.0199.1.01.6	LO	252351-64	LARGE CIRCUIT BREAKER KIT
5958	4.08.0200.1.01.7	LO	160405	TERMINAL BLOCK 6mm 4COND FUSE SENSOR; SPRING CLAMP
5959	4.08.0201.1.01.8	LO	160406	TERMINAL BLOCK 5mm SENSOR SUPPLY SPRING CLAMP
5960	4.08.0202.1.01.9	LO	160407	TERMINAL BLOCK 6mm FUSE HOLDER PLUG
5961	4.08.0203.1.01.1	LO	160409	TERMINAL BLOCK 5mm SUPPLY END COVER; FOR SENSOR SUPPLY BLOCK
5962	4.08.0204.1.01.2	LO	164649	CONN MOTOR FEMALE #8; PIGTAIL
5963	4.08.0205.1.01.3	LO	252351-79	CIRCUIT BREAKER REPLACEMENT KIT - MEDIUM
5964	4.08.0206.1.01.4	LO	252351-86	ELECTRICAL CIRCUIT BREAKER KIT
5965	4.08.0207.1.01.5	LO	252351-99	LARGE CIRCUIT BREAKER KIT #2
5966	4.08.0208.1.01.6	LO	252351-101	ELECTRICAL CIRCUIT BREAKER KIT
5967	4.08.0209.1.01.7	LO	154531	PLUG DESICCANT (SMALL)
5968	4.08.0210.1.01.8	LO	A15515	GRIP CORD
5969	4.08.0211.1.01.9	LO	A17659	CONNECTOR CORD
5970	4.08.0212.1.01.1	LO	A19008	GRIP CORD
5971	4.08.0213.1.01.2	LO	A21987	CORD CONNECTOR
5972	4.08.0214.1.01.3	LO	A25487	CONNECTOR SEALTITE STR 1.00
5973	4.08.0215.1.01.4	LO	A25488	CONNECTOR 1 90 DEG
5974	4.08.0216.1.01.5	LO	A79519	CONNECTOR CORD
5975	4.08.0217.1.01.6	LO	107396	CORD CONNECTOR 1/2
5976	4.08.0218.1.01.7	PL	GR.00/25A/GL	NH FUSE
5977	4.08.0219.1.01.8	PL	GR.00/35A/GL	NH FUSE
5978	4.08.0220.1.01.9	PL	GR.00/50A/GL	NH FUSE
5979	4.08.0221.1.01.1	PL	GR.00/63A/GL	NH FUSE
5980	4.08.0222.1.01.2	PL	GR.00/80A/GL	NH FUSE
5981	4.08.0223.1.01.3	PL	GR.00/125A/GL	FUSE
5982	4.08.0224.1.01.4	PL	GR.00/160A/GL	NH FUSE
5983	4.08.0225.1.01.5	PL	5X2015AFLINK	FUSE
5984	4.08.0226.1.01.6	PL	EL-T7057B	FLANGE RECEPTACLE/6POL FEMALE
5985	4.08.0227.1.01.7	PL	ERB.2E.304.CLL OR RAE2304P	SOCKET 4POLES
5986	4.08.0228.1.01.8	PL	P-FU5X20 LED 24-5	TWO PIN FUSE
5987	4.08.0229.1.01.9	PL	EL-T7213	CAN BUS TERMINAL PLUG
5988	4.08.0230.1.01.1	PL	PLC-OSC-24DC/24DC/2/ACT	PHOTO COUPLER
5989	4.08.0231.1.01.2	PL	FBS0031.3911	G-FUSE SOCKET FBS
5990	4.08.0232.1.01.3	PL	EL-T7054-S	PENDULUM SOCKET
5991	4.08.0233.1.01.4	PL	SACC-M12MRD-4QSH	PLUG/4POLES/ANGULAR
5992	4.08.0234.1.01.5	PL	SACC-M12MSD-4QSH	PLUG/4POLES/ANGULAR
5993	4.08.0235.1.01.6	PL	SACC-M12FS-5PL SH DN	CONNECTOR SOCKET/5POLES/STRAIGHT
5994	4.08.0236.1.01.7	PL	16900128323	ISOLATER/EKS/127C/M10
5995	4.08.0237.1.01.8	PL	16900147267	ISOLATER/EKS/127A/M8
5996	4.08.0238.1.01.9	PH	UTV1 08 07/00	MCB 63
5997	4.08.0239.1.01.1	PH	UTV1 10 01/00	MCB 16AMP
5998	4.08.0240.1.01.2	PH	UTV1 10 01/00	MCB 06AMP
5999	4.08.0241.1.01.3	CR	40036220	PUSH/PULL CIRCUIT BREAKER
6000	4.08.0242.1.01.4	CR	40080639	DC circuit braker
6001	4.08.0243.1.01.5	CR	40080640	DC circuit braker
6002	4.08.0244.1.01.6	CR	40080643	DC circuit braker
6003	4.08.0245.1.01.7	CR	40095698	PUSH/PULL CIRCUIT BREAKER
6004	4.08.0246.1.01.8	CR	40096384	PUSH/PULL CIRCUIT BREAKER
6005	4.08.0247.1.01.9	CR	40096385	PUSH/PULL CIRCUIT BREAKER
6006	4.08.0248.1.01.1	CR	40096386	PUSH/PULL CIRCUIT BREAKER
6007	4.08.0249.1.01.2	KA	A3S-2T/TU16-526-015-83	Automic circuit breaker A3C-2
6008	4.08.0250.1.01.3	KA	A3S-5T/TU16-526-015-83	Automic circuit breaker A3C-5
6009	4.08.0251.1.01.4	KA	A3S-10T/TU16-526-015-83	Automic circuit breaker A3C-10
6010	4.08.0252.1.01.5	KA	A3S-15T/TU16-526-015-83	Automic circuit breaker A3C-15
6011	4.08.0253.1.01.6	KA	A3C-20/TU16-526-015-83	Automic circuit breaker A3C-20
6012	4.08.0254.1.01.7	KA	BPP-4.07 F5.3722.001TU (60A,60A,30A,30A)	Fuse block
6013	4.08.0255.1.01.8	KA	BPP-4 F5.3722.001TU (60A,60A,90A,40A)/BDP- 4F5.3722.001TU	Fuse block/UNIT

6014	4.08.0256.1.01.9	KA	BPP-13 F54.811.000TU (5A,7.5A,10A,15A,25A)	Fuse block
6015	4.08.0257.1.01.1	HA	5138459	MCB 32 AMPS
6016	4.08.0258.1.01.2	PL	1632 ITT Cannon 120001-23	Servo valve plug (Cutter chain pump)
6017	4.08.0259.1.01.3	PL	A9Z21463	(RCD)Over current circuit breaker (30MA/63A)
6018	4.08.0260.1.01.4	PL	CTP731-T	System bus connecting plug
6019	4.08.0261.1.01.5	PL	PT1.5/S-QUATTRO	Lead through terminal block
6020	4.08.0262.1.01.6	PL	17PLUS-Q02-00	Fuse base
6021	4.08.0263.1.01.7	PL	259-2113	Crimp connector bush/9pol
6022	4.08.0264.1.01.8	PL	812-6349	Plug D-Sub crimp
6023	4.08.0265.1.01.9	PL	EL-T9071.04	Carrier
6024	4.08.0266.1.01.1	PL	PTTB1.5/S	lead through terminal block
6025	4.08.0267.1.01.2	PL	PTTB4	Lead through terminal block
6026	4.08.0268.1.01.3	PL	PTTB4-PE	Earth conductor series terminal
6027	4.08.0269.1.01.4	PL	PTTB2.5	Lead through terminal block
6028	4.08.0270.1.01.5	PL	PTTB2.5-PE	Earth conductor series terminal
6029	4.08.0271.1.01.6	PL	MT1.5	Micro terminal
6030	4.08.0272.1.01.7	PL	PT1.5/S-TWIN	Lead through terminal block
6031	4.08.0273.1.01.8	PL	PT2.5-TG	Disconnect terminal block
6032	4.08.0274.1.01.9	PL	PT2.5	Lead through terminal block
6033	4.08.0275.1.01.1	PL	PT2.5-PE	Earth conductor series terminal
6034	4.08.0276.1.01.2	PL	PT4	Lead through terminal
6035	4.08.0277.1.01.3	PL	EL-T631.04B	Intercom mic
6036	4.08.0278.1.01.4	LO	259816	CB 0.63A 3P 480V; 0.40A-0.63A OVERLOAD
6037	4.08.0279.1.01.5	LO	231784	CB CLOSING COIL; 110-120VAC/DC
6038	4.08.0280.1.01.6	LO	231789	CB SPRING CHARGING MOTOR; 100- 130VAC/DC
6039	4.08.0281.1.01.7	LO	231788	CB UNDERVOLTAGE RELEASE; 110- 120VAC/DC
6040	4.08.0282.1.01.8	PL	6006017211	Switch array/D7
6041	4.08.0283.1.01.9	LO	126630	CB 2000A 3P 24VDC E3 FRAME DRAWOUT
6042	4.08.0284.1.01.1	LO	103104	FUSE 100mA 250 VOLT FAST ACTING
6043	4.08.0285.1.01.2	PL	437-K60-1-07-200A	Circuit breaker
6044	4.08.0286.1.01.3	PL	ERA-40-00(160A)	Fuse
6045	4.08.0287.1.01.4	KA	MV2300. 15.015 SUB M42300.44 15-0- 15 B-1.5G	Voltmeter (servo control)
6046	4.08.0288.1.01.5	KA	P2RF-05E (for block of G2R-1-SNDI)	Relay Base
6047	4.09.0001.1.01.7	PL	390507512	WIPER MOTOR
6048	4.09.0002.1.01.8	PL	EL-T9017.00	MOTOR
6049	4.09.0003.1.01.9	PH	4P26	D.C. MOTOR
6050	4.09.0004.1.01.1	PH	UTVI-10-01/00	WIPER MOTOR
6051	4.09.0005.1.01.2	LO	112275	FAN ASSY NO DWG
6052	4.09.0006.1.01.3	LO	112871	PILOT LIGHT CLEAR TRANSFORMER 120VAC
6053	4.09.0007.1.01.4	LO	112872	PILOT LIGHT RED; FULL VOLTAGE 24V AC/DC
6054	4.09.0008.1.01.5	LO	112887	PILOT LIGHT GREEN; FULL VOLTAGE 24V AC/DC
6055	4.09.0009.1.01.6	LO	112888	PILOT LIGHT AMBER FULL VOLTAGE 24V AC/DC
6056	4.09.0010.1.01.7	LO	117436	MOTOR GRINDING 30HP EXTENDED LIFE
6057	4.09.0011.1.01.8	LO	118351	PILOT LIGHT RED; TRANSFORMER 24 AC/DC
6058	4.09.0012.1.01.9	LO	118352	PILOT LIGHT GREEN; TRANSFORMER 24 AC/DC
6059	4.09.0013.1.01.1	LO	118408	MOTOR COLLECTOR BLOWER
6060	4.09.0014.1.01.2	LO	125951	PILOT LIGHT WHITE; FULL VOLTAGE 24V AC/DC
6061	4.09.0015.1.01.3	LO	125952	PILOT LIGHT AMBER; TRANSFORMER 120V AC
6062	4.09.0016.1.01.4	LO	126828	BLOWER 1970 CFM 120V DUAL TURBINE
6063	4.09.0017.1.01.5	LO	127805	MOTOR 30 HP
6064	4.09.0018.1.01.6	LO	156590	GENERATOR BLOWER RH MOD; 15 HP 3530 RPM
6065	4.09.0019.1.01.7	LO	158625	FAN MOTOR 1.5HP TEFC
6066	4.09.0020.1.01.8	LO	160730	HID HEADLIGHT RHS; COMBINED LED/TAIL MARKER
6067	4.09.0021.1.01.9	LO	160731	HID HEADLIGHT LHS; COMBINED LED/TAIL MARKER
6068	4.09.0022.1.01.1	LO	167054	LEESON MOTOR; 1-1/2 HP
6069	4.09.0023.1.01.2	LO	169276	TRACTION MOTOR COMBO; HYATT 6.5X12 BRG 1676 GA
6070	4.09.0024.1.01.3	LO	A79548	MOTOR 3/4 HP
6071	4.09.0025.1.01.4	LO	C83251	STROBE-BLUE 24VDC

6072	4.09.0026.1.01.5	LO	DRW90.44.13.000 (ME241)	ELECTRICAL MOTOR WITH REDUCTION GEAR.
6073	4.09.0027.1.01.6	LO	105-5081 (C9)	SELF STARTER
6074	4.09.0028.1.01.7	LO	105-5081 (C18)	SELF STARTER
6075	4.09.0029.1.01.8	LO	81769643	ALTERNATOR
6076	4.09.0030.1.01.9	LO	81852021	ALTERNATOR (POWER PACK)
6077	4.09.0031.1.01.1	LO	265.90B	DIESEL DOSE PUMP
6078	4.09.0032.1.01.2	PL	28V1.4WT5.5	INDICATION BULB
6079	4.09.0033.1.01.3	PL	31-963.2/28V	INDICATION BULB
6080	4.09.0034.1.01.4	PL	6-28V/P2-62	TEST LAMP
6081	4.09.0035.1.01.5	PL	879.94A SUBSTITUTE 805.22A	ELECTRIC MOTOR
6082	4.09.0036.1.01.6	PL	RMEL276A	Axial Fan
6083	4.09.0037.1.01.7	GE	GLLT008N-1AAWXX	LED floodlight
6084	4.09.0038.1.01.8	Shifted to Ann -II		
6085	4.09.0039.1.01.9	Shifted to Ann -II		
6086	4.09.0040.1.01.1	DE	0118 3716/0150A-44-001	SELF STARTER 24V 4.0KW
6087	4.09.0041.1.01.2	CU	4996709 (CUMMINS)	SELF STARTER
6088	4.09.0042.1.01.3	Shifted to Ann -II		
6089	4.09.0043.1.01.4	CA	4351240CW	SELF STARTER
6090	4.09.0044.1.01.5	Shifted to Ann -II		
6091	4.09.0045.1.01.6	LO	110766	WIPER MOTOR
6092	4.09.0046.1.01.7	LO	113044	WATER PUMP AND MOTOR 30HP 3600RPM 3PH TEFC
6093	4.09.0047.1.01.8	LO	132978	MOTOR SPRING CHARGING 110-130VAC/DC
6094	4.09.0048.1.01.9	LO	134112	RING OUTER SEAL(PLASTIC); TRACTION MOTOR GEARCASE
6095	4.09.0049.1.01.1	LO	134113	RING INNER SEAL(PLASTIC); TRACTION MOTOR GEARCASE
6096	4.09.0050.1.01.2	LO	123660	SEAL PINOIN PLASTIC; TRACTION MOTOR GEARCASE
6097	4.09.0051.1.01.3	LO	108696	BATTERY BOX
6098	4.09.0052.1.01.4	LO	236442	ROTOR EXCITER;WITH RECTIFIER ASSY
6099	4.09.0053.1.01.5	LO	125690	STATOR EXCITER
6100	4.09.0054.1.01.6	LO	B65877	MOTOR ELECT 30 HP 1800 RPM/286TC W/FEET
6101	4.09.0055.1.01.7	LO	245778	LIGHT 24VDC UPGRADE KIT FOR OBSOLETE 116515 LIGHT ASSEMBLY
6102	4.09.0056.1.01.8	LO	207451	MOTOR VERTICAL SHAFT; 2.25OD 1.75ID 19.62LG
6103	4.09.0057.1.01.9	LO	252351-13	LIGHT KIT #2
6104	4.09.0058.1.01.1	LO	252351-14	LIGHT KIT #3
6105	4.09.0059.1.01.2	LO	252351-16	LIGHT KIT #5
6106	4.09.0060.1.01.3	LO	114116	LABEL-HIGH VOLTAGE 4.5 ISO3864 WARNING DECAL
6107	4.09.0061.1.01.4	LO	252351-23	LIGHT KIT #6
6108	4.09.0062.1.01.5	LO	252351-25	LIGHT KIT #7
6109	4.09.0063.1.01.6	LO	252351-36	LIGHT KIT #8
6110	4.09.0064.1.01.7	LO	252351-37	LIGHT KIT #9
6111	4.09.0065.1.01.8	LO	210126	LIGHT FIX LED; 24VDC 8W
6112	4.09.0066.1.01.9	LO	252351-45	LIGHT KIT #10
6113	4.09.0067.1.01.1	LO	237682	LIGHT FIX LED; 24VDC 19W
6114	4.09.0068.1.01.2	LO	A71538	LAMP 1000W NSP
6115	4.09.0069.1.01.3	LO	252351-105	LIGHT KIT #11
6116	4.09.0070.1.01.4	KA	TU37.459.078-86	Gearmotor of windscreen wiper
6117	4.09.0071.1.01.5	HA	5058900	OT PAGE LIGHT
6118	4.09.0072.1.01.6	LO	204850	MOTOR 50 HP; COLLECTOR BLOWER
6119	4.09.0073.1.01.7	LO	111531	ALTERNATOR 24 VOLT 75 AMP
6120	4.09.0074.1.01.8	LO	163574	STARTER 24 VOLT DELCO 50MT400
6121	4.09.0075.1.01.9	LO	A88708	LAMP 120V 50WATT HIGH PRESSURE SODIUM
6122	4.09.0076.1.01.1	LO	102244	MARKER LIGHT BRKT-RIGHT
6123	4.09.0077.1.01.2	LO	102243	MARKER LIGHT BRKT-LEFT
6124	4.09.0078.1.01.3	CU	5361693	ALTERNATOR
6125	4.09.0079.1.01.4	CA	249- 0313	ALTERNATOR
6126	4.09.0080.1.01.5	PL	A-60/1554LD	Alternator BOSCH make (28V/120A)
6127	4.09.0081.1.01.6	PL	A-1867 LP/A/65	Alternator BOSCH make (28V/55A)
6128	4.09.0082.1.01.7	VM Motori	5290125	SELF STARTER
6129	4.09.0083.1.01.8	VM Motori	9990316	ALTERNATOR
6130	4.10.0001.1.01.8	PL	EK-504CA-00C	R-ADAPTER FOR CMS SYSTEM
6131	4.10.0002.1.01.9	PL	EL-08-1.0138-B92B	CONTROL BOX
6132	4.10.0003.1.01.1	PL	EL-T7087/1,5A	EL.REMOTE CONTROL
6133	4.10.0004.1.01.2	PL	EL-T7163.00-A SUB. E L-T7163.00 (4SENS)	CONTROL UNIT
6134	4.10.0005.1.01.3	LO	105418	METER BOARD

6135	4.10.0006.1.01.4	LO	120128	COMPUTER ASSY ANALYSIS REMOVAL W/DATA COLLECTION - REQUIRES SETUP PRIOR TO DISPATCH
6136	4.10.0007.1.01.5	LO	148049	DB 1P 510A 600V 2LI 4LD
6137	4.10.0008.1.01.6			Shifted to Ann-II
6138	4.10.0009.1.01.7	LO	160638	COMPUTER
6139	4.10.0010.1.01.8	LO	160639	ECU
6140	4.10.0011.1.01.9	LO	166697	COMPUTER RACK ASSY; RGI CAMP CAR
6141	4.10.0012.1.01.1	LO	171815	COMP DUOCORE 2.8 GHZ 160GB RAID 2GB RAM
6142	4.10.0013.1.01.2	PL	EL-T 631	Mike
6143	4.10.0014.1.01.3	PL	EL-T 631.11A	Microphone stuckbar
6144	4.10.0015.1.01.4	PL	DR4-29	Lowdspeaker
6145	4.10.0016.1.01.5	CR	6ES7516-3AN01-0AB0	CPU
6146	4.10.0017.1.01.6	PL	S-7.5.41	DECT-Multi interface DIG/NIMH
6147	4.10.0018.1.01.7	PL	S-7.5.42	DECT/AGS-headset digital NIMH
6148	4.10.0019.1.01.8	PL	CPU/3-0228-0150/1	CPU/PROGRAM
6149	4.10.0020.1.01.9	PL	CPU/3-0228-0270	CPU/PROGRAM
6150	4.10.0021.1.01.1	PL	CPU/3-0228-0271	CPU/PROGRAM
6151	4.10.0022.1.01.2	PL	MM1/2-CWS-1	MC TERMINAL /PROG
6152	4.10.0023.1.01.3	PL	171050	COLOUR CAMERA
6153	4.10.0024.1.01.4	PL	EL-T631.04B	MICROPHONE
6154	4.10.0025.1.01.5	PL	EL-T5201.03B/3.5M	CONNECTING CABLE ALC
6155	4.10.0026.1.01.6	PL	EL-T5558.03B/3.5M	CONNECTING CABLE ALC
6156	4.10.0027.1.01.7	PL	ELB-M00-02-003-MCL113	DATAMATIC MODULE
6157	4.10.0028.1.01.8	PL	ELB-M00-02-000-MCL113	DATAMATIC MODULE
6158	4.10.0029.1.01.9	PL	ELB-M00-02-000-MCL129	DATA MATIC
6159	4.10.0030.1.01.1	PL	ELB-M00-02-001-MCL129	DATAMATIC
6160	4.10.0031.1.01.2	PL	ELB-SM0-30-A-100-MCL123	ALC CARD
6161	4.10.0032.1.01.3	LO	163156	SEQUENCE MONITOR ASSY, 15 INCH MONITOR
6162	4.10.0033.1.01.4	LO	131137	COMP MONITOR 15.1 LCD COLOUR ACTIVE MATRIX
6163	4.10.0034.1.01.5	LO	154938	COMP KEY BOARD W/HULA POINT USB 116 KEY LAY OUT
6164	4.10.0035.1.01.6	LO	164835	RECEPTACLE COMPUTER SPEC ETHERNET/120V
6165	4.10.0036.1.01.7	LO	179889	MONITOR COLOR ASSY
6166	4.10.0037.1.01.8	LO	C83658	CAMERA DIGITAL PROCESSING 120VAC
6167	4.10.0038.1.01.9	LO	138883	POWVIEW MURPHY
6168	4.10.0039.1.01.1	LO	146606	METER MULTI-FUNCTION POWER MONITOR MODBUS
6169	4.10.0040.1.01.2	LO	250898	SH CAMERA WINDOW ASSY; RGMS
6170	4.10.0041.1.01.3	LO	249447	COMPUTER ASSY; RGMS IV
6171	4.10.0042.1.01.4	LO	247417	PLC 1756 CONTROLLER; CONTROLLOGIX 10M RAM
6172	4.10.0043.1.01.5	LO	248165	COMPUTER ASSY CONTROLS; WIN10 ENT
6173	4.10.0044.1.01.6	LO	249435	COMPUTER ASSY; RAILPRO RGMS IV RSLINX
6174	4.10.0045.1.01.7	LO	249183	ELECTRONIC CONTROL UNIT
6175	4.10.0046.1.01.8	LO	252351-139	COMPUTER SYSTEM MAINTENANCE KIT, SMALL
6176	4.10.0047.1.01.9	LO	252351-140	COMPUTER SYSTEM MAINTENANCE KIT, LARGE
6177	4.10.0048.1.01.1	LO	252351-141	COMPUTER SYSTEM REPAIR KIT, SMALL
6178	4.10.0049.1.01.2	LO	252351-142	COMPUTER SYSTEM REPAIR KIT, LARGE
6179	4.10.0050.1.01.3	LO	252351-186	PLC SYSTEM MAINTENANCE KIT, SMALL
6180	4.10.0051.1.01.4	LO	252351-187	PLC SYSTEM MAINTENANCE KIT, LARGE
6181	4.10.0052.1.01.5	LO	252351-188	PLC SYSTEM REPAIR KIT, SMALL
6182	4.10.0053.1.01.6	LO	252351-189	PLC SYSTEM REPAIR KIT, LARGE
6183	4.10.0054.1.01.7	LO	252351-190	PLC SYSTEM OVERHAUL KIT
6184	4.10.0055.1.01.8	LO	158994	METER RATE INDICATOR 9-28 VDC
6185	4.10.0056.1.01.9	PL	ELW-SM0-01	DISPLAY INSTRUMENT
6186	4.10.0057.1.01.1	PL	ELW-SM0-01-UL	DISPLAY INSTRUMENT
6187	4.10.0058.1.01.2	PL	ELW-SM0-01-1U	DISPLAY INSTRUMENT
6188	4.10.0059.1.01.3	PL	223100	COLOUR MONITOR
6189	4.10.0060.1.01.4	PL	MMI/ 1-0046-1	TOUCH SCREEN 8"
6190	4.10.0061.1.01.5	PL	MMI/ 1-0046-2	TOUCH SCREEN 12"
6191	4.10.0062.1.01.6	PL	MMI/ 1-0046-3	TOUCH SCREEN 8"
6192	4.10.0063.1.01.7	PL	CA2433820	DISPLAY

6193	4.10.0064.1.01.8	PL	494-5474	DC/AC-CONVERTER FOR DRP PRINTER
6194	4.10.0065.1.01.9	PL	31583	Designation strip
6195	4.10.0066.1.01.1	PL	24401	DISTRIBUTING BUS BAR CLAMP
6196	4.10.0067.1.01.2	PH	40141020102	ENGINE CONTROLLED AND DISPLAY UNIT
6197	4.10.0068.1.01.3	CR	40101986	CAN module
6198	4.10.0069.1.01.4	KA	PV101.M02	Morphy display
6199	4.10.0070.1.01.5	HA	4028741	DIGITAL CAN
6200	4.10.0071.1.01.6	HA	5070968	TOUCH SCREEN
6201	4.10.0072.1.01.7	HA	5138457	CCTV CAMERA
6202	4.10.0073.1.01.8	HA	E1348	LED SCREEN
6203	4.10.0074.1.01.9	PL	IM21-14-CDTRi	Monitor for engine speed
6204	4.10.0075.1.01.1	PL	ELB-SM0-01	Digital display
6205	4.10.0076.1.01.2	PL	MMI/2-CWS-1	CWS- DISPLAY
6206	4.10.0077.1.01.3	PL	6040203003 SUB:6007203240	Display
6207	4.10.0078.1.01.4	PL	EL-T6600.00-CMS044	CMS display for CSM machine
6208	5.01.0001.1.01.9	PL	0.06348395	SOCKET
6209	5.01.0002.1.01.1	ZF	0.461622103	PRESSURE LINE
6210	5.01.0003.1.01.2	ZF	0.461622104	PRESSURE LINE
6211	5.01.0004.1.01.3	ZF	0.461622105	PRESSURE LINE
6212	5.01.0005.1.01.2	ZF	0635-290-062	PLATE
6213	5.01.0006.1.01.5	ZF	36801165	SEALING RING
6214	5.01.0007.1.01.6	ZF	501315338	VALVE
6215	5.01.0008.1.01.7	ZF	501319251	SOLENOID VALVE
6216	5.01.0009.1.01.8	ZF	630302095	AXLE NEEDLE CAGE
6217	5.01.0010.1.01.9	ZF	630601006	TAB WASHER
6218	5.01.0011.1.01.1	ZF	630703032	TAB WASHER
6219	5.01.0012.1.01.2	ZF	634300185	SHAFT SEAL/SHAFT GEAR
6220	5.01.0013.1.01.3	ZF	634305009	PISTON RING
6221	5.01.0014.1.01.4	ZF	634305042	PISTON RING
6222	5.01.0015.1.01.5	ZF	634305093	PISTON RING
6223	5.01.0016.1.01.6	ZF	634306047	'O' RING
6224	5.01.0017.1.01.7	ZF	634306242	O RING
6225	5.01.0018.1.01.8	ZF	634306323	O RING
6226	5.01.0019.1.01.9	ZF	634402029	PISTON RING
6227	5.01.0020.1.01.1	ZF	634402140	PISTON RING
6228	5.01.0021.1.01.2	ZF	634801038	SEALING RING
6229	5.01.0022.1.01.3	ZF	634801045	SEALING RING
6230	5.01.0023.1.01.4	ZF	634801057	SEALING RING
6231	5.01.0024.1.01.5	ZF	634801074	SEALING RING
6232	5.01.0025.1.01.6	ZF	634801152	SEALING RING
6233	5.01.0026.1.01.7	ZF	634801165	SEALING RING
6234	5.01.0027.1.01.8	ZF	634801200	SEALING RING
6235	5.01.0028.1.01.9	ZF	634801205	SEALING RING
6236	5.01.0029.1.01.1	ZF	634801215	SEALING RING
6237	5.01.0030.1.01.2	ZF	634801227	SEALING RING
6238	5.01.0031.1.01.3	ZF	635290061	CASING DISC
6239	5.01.0032.1.01.4	ZF	635290062	SHAFT WASHER
6240	5.01.0033.1.01.5	ZF	635303056	NEEDLE SLEEVE
6241	5.01.0034.1.01.6	ZF	636015110	HEXAGON SCREW
6242	5.01.0035.1.01.7	ZF	636610109	STUD
6243	5.01.0036.1.01.8	ZF	636610127	STUD
6244	5.01.0037.1.01.9	ZF	636610177	STUD
6245	5.01.0038.1.01.1	ZF	637512004	SLOTTED NUT
6246	5.01.0039.1.01.2	ZF	637835003	UNION SCREW
6247	5.01.0040.1.01.3	ZF	637835005	UNION SCREW
6248	5.01.0041.1.01.4	ZF	637835006	UNION SCREW
6249	5.01.0042.1.01.5	ZF	732000072	CUP SPRING FOR ZF GEAR BOX
6250	5.01.0043.1.01.6	ZF	732040265	COMPRESSION SPRING
6251	5.01.0044.1.01.7	ZF	732040266	COMPRESSION SPRING
6252	5.01.0045.1.01.8	ZF	732040834	COMPRESSION SPRING
6253	5.01.0046.1.01.9	ZF	732040835	COMPRESSION SPRING
6254	5.01.0047.1.01.1	ZF	732040836	COMPRESSION SPRING
6255	5.01.0048.1.01.2	ZF	732040838	COMPRESSION SPRING
6256	5.01.0049.1.01.3	ZF	732041229	COMPRESSION SPRING
6257	5.01.0050.1.01.4	ZF	732041230	COMPRESSION SPRING
6258	5.01.0051.1.01.5	ZF	737835010	UNION SCREW
6259	5.01.0052.1.01.6	ZF	750131060	Z.F.FILTER ELEMENT
6260	5.01.0053.1.01.7	ZF	900021267	PLUG
6261	5.01.0054.1.01.8	PL	1010306005	SET OF SCREW
6262	5.01.0055.1.01.9	ZF	1019323053	COMPRESSION SPRING
6263	5.01.0056.1.01.1	ZF	1203306017	COMPRESSION SPRING
6264	5.01.0057.1.01.2	ZF	1203306019	COMPRESSION SPRING
6265	5.01.0058.1.01.3	ZF	1419306063	PISTON
6266	5.01.0059.1.01.4	ZF	4044306026	GASKET
6267	5.01.0060.1.01.5	ZF	4044306288	GASKET
6268	5.01.0061.1.01.6	ZF	4044306494	GASKET

6269	5.01.0062.1.01.7	ZF	4166041011	CONVERTER CPL
6270	5.01.0063.1.01.8	ZF	4166341177	GASKET
6271	5.01.0064.1.01.9	ZF	4609220002	Set of Converter Pressure valve (FIG 080-150)
6272	5.01.0065.1.01.1	ZF	634801098	Sealing Ring
6273	5.01.0066.1.01.2	ZF	636305023	Screw Plug
6274	5.01.0067.1.01.3	ZF	4609320002	Valve Sleeve
6275	5.01.0067.1.01.3	ZF	731201446	Cylindrical Pin Part No.
6276	5.01.0068.1.01.4	ZF	4068306029	Piston
6277	5.01.0069.1.01.5	ZF	730001828	Spring
6278	5.01.0070.1.01.6	ZF	630532004	Washer
6279	5.01.0071.1.01.7	ZF	4616105058	HYD AXLE CUT OFF / ZF AXLE DISENGAGER
6280	5.01.0072.1.01.8	ZF	4616120001	Set of Converter Relief valve for Z.F. Gear Box
6281	5.01.0073.1.01.9	ZF	635460095	Ball
6282	5.01.0074.1.01.1	ZF	732040021	Compression spring Ring
6283	5.01.0075.1.01.2	ZF	4616221012	LUBRICATION PIPE
6284	5.01.0076.1.01.3	ZF	4616221018	SUCTION TUBE
6285	5.01.0077.1.01.4	ZF	4616221026	LUBRICATION PIPE
6286	5.01.0078.1.01.5	ZF	4616221035	PRESSURE LINE
6287	5.01.0079.1.01.6	ZF	4616221038	PRESSURE LINE
6288	5.01.0080.1.01.7	ZF	4616221040	LUBRICATION PIPE
6289	5.01.0081.1.01.8	ZF	4616221049	PIPE
6290	5.01.0082.1.01.9	ZF	4616221899	UNION SCREW
6291	5.01.0083.1.01.1	ZF	4616301036	GASKET
6292	5.01.0084.1.01.2	ZF	4616301083	GASKET
6293	5.01.0085.1.01.3	ZF	4616301175	HOUSING
6294	5.01.0086.1.01.4	ZF	4616303171	OUTPUT SHAF
6295	5.01.0087.1.01.5	ZF	4616305001	OUTPUT SHAFT
6296	5.01.0088.1.01.6	ZF	4616306086	GASKET
6297	5.01.0089.1.01.7	ZF	4616306088	GASKET
6298	5.01.0090.1.01.8	ZF	4616306091	GASKET
6299	5.01.0091.1.01.9	ZF	4616307002	SPEEDO SHAFT
6300	5.01.0092.1.01.1	ZF	4616307005	SPEEDO CONN. PCB
6301	5.01.0093.1.01.2	ZF	4616321056	THREADED BUSH
6302	5.01.0094.1.01.3	ZF	4616321057	SPACER BUSH
6303	5.01.0095.1.01.4	ZF	4616329022	GASKET
6304	5.01.0096.1.01.5	ZF	4616336009	GASKET
6305	5.01.0097.1.01.6	ZF	4620306312	GASKET
6306	5.01.0098.1.01.7	ZF	4627306007	PROTECTING CAP
6307	5.01.0099.1.01.8	ZF	4644306001	GEAR SHIFT HOUSING
6308	5.01.0100.1.01.9	ZF	4644306010	PISTON
6309	5.01.0101.1.01.1	ZF	4644306050	ORIFICE
6310	5.01.0102.1.01.2	ZF	4644306488	GASKET
6311	5.01.0103.1.01.3	ZF	4644306490	GASKET
6312	5.01.0104.1.01.4	ZF	4646362013	FLANGE SHAFT
6313	5.01.0105.1.01.5	ZF	0501-319-202	SOL VALVE
6314	5.01.0106.1.01.6	ZF	0630 502 007	RETAINING RING
6315	5.01.0107.1.01.7	ZF	0630-001-012=72, 0630-001-037=54,0630-000-874=1,0630-001-828=4, 0730-002-635=1, 0730-002-137=4,0730-002-626=5,0730-004-291=1, 0730-004-292=1, 0730-101-795=3	SET OF WASHER FOR ZF GEAR BOX
6316	5.01.0108.1.01.8	ZF	0630-302-095,0635-290-061,0635-290-620	AXLE NEEDLE CAGE 0630-302-095
6317	5.01.0109.1.01.9	ZF	0635-290-062-16080	PLATE
6318	5.01.0110.1.01.1	ZF	0630-361-033	SEALING CAP FOR ZF GEAR BOX
6319	5.01.0111.1.01.2	ZF	0630-361-052	SEALING CAP FOR ZF GEAR BOX
6320	5.01.0112.1.01.3	ZF	0630-501-025=2, 0630-501-031=1, 0630-501-035=1, 0630-501-039=1, 0630-501-046=4, 0630-501-048=1, 0630-501-050=3, 0630-501-052=1, 0630-501-054=2, 0630-501-060=2	SET OF RETAINING RING FOR ZF GEAR BOX CONSISTING OF:
6321	5.01.0113.1.01.4	ZF	0630503010,0630503015,0630513092,0630503023,0635513045,0630513078, 0630513125	SET OF SNAPING RING FOR ZF GEAR BOX
6322	5.01.0114.1.01.5	ZF	0631-306-179	CYLINDER PIN FOR ZF GEAR BOX
6323	5.01.0115.1.01.6	ZF	0631-359-001	SLOTTED PLUG FOR ZF GEAR BOX
6324	5.01.0116.1.01.7	ZF	0631-501-213	FITTING KEY FOR ZF GEAR BOX
6325	5.01.0117.1.01.8	ZF	0631-511-036	WOODRUFF KEY FOR ZF GEAR BOX
6326	5.01.0118.1.01.9	ZF	0634 -303- 796	'O' RING
6327	5.01.0119.1.01.1	ZF	0634 -303- 834	'O' RING
6328	5.01.0120.1.01.2	ZF	0634 -304- 358	'O' RING
6329	5.01.0121.1.01.3	ZF	0634 -306- 306	'O' RING
6330	5.01.0122.1.01.4	ZF	0634-300-053	SHAFT SEAL
6331	5.01.0123.1.01.5	ZF	0634-300-185	SHAFT SEAL

6332	5.01.0124.1.01.6	ZF	0634-300-721	SHAFT SEAL
6333	5.01.0125.1.01.7	ZF	0634-310-733	SHAFT SEAL
6334	5.01.0126.1.01.8	ZF	0634-319-247	SHAFT SEAL
6335	5.01.0127.1.01.9	ZF	0734-319-497	SHAFT SEAL
6336	5.01.0128.1.01.1	ZF	0634300231/0634302121	SHAFT SEAL (20X32X7)
6337	5.01.0129.1.01.2	ZF	0634300721/0634319247	SHAFT SEAL (85X110X12)
6338	5.01.0130.1.01.3	ZF	0634-303-199	'O' RING
6339	5.01.0131.1.01.4	ZF	0634-303-670	'O' RING
6340	5.01.0132.1.01.5	ZF	0634-303-718	'O' RING
6341	5.01.0133.1.01.6	ZF	0634-303-951	'O' RING
6342	5.01.0134.1.01.7	ZF	0634-305-020, LFN-155-VITON	PISTON RING
6343	5.01.0135.1.01.8	ZF	0634-306-292	'O' RING
6344	5.01.0136.1.01.9	ZF	0634310733/0734319497	SHAFT SEAL (90X110X13)
6345	5.01.0137.1.01.1	ZF	0634-313-118	'O' RING
6346	5.01.0138.1.01.2	ZF	0634-313-383	'O' RING
6347	5.01.0139.1.01.3	ZF	0635-300-117	NEEDLE CAGE BEARING
6348	5.01.0140.1.01.4	ZF	0635-300-151	NEEDLE CAGE BEARING
6349	5.01.0141.1.01.5	ZF	0635-410-143	ROLLER BEARING
6350	5.01.0142.1.01.6	ZF	0635-450-126	ROLLER BEARING
6351	5.01.0143.1.01.7	ZF	0635-460-029	BALL
6352	5.01.0144.1.01.8	ZF	0636-302-009=3, 0636-307-025=1, 0636-304-009=1, 0636-305-046=1	SET OF SCREW PLUG FOR ZF GEAR BOX CONSISTING
6353	5.01.0145.1.01.9	ZF	0636-610-109, 0636-610-020, 0636-610-127, 0636-610-177	SET OF STUD FOR ZF GEAR BOX
6354	5.01.0146.1.01.1	ZF	N/A	(i) 0636-610-609=3 Nos., (ii) 0636-610/611-020=11 nos., (iii) 0636-0610-127=1 no., (iv) 0636-610-177=1 no.
6355	5.01.0147.1.01.2	ZF	0637-835-005/515	HOLLOW SCREW FOR ZF GEAR BOX
6356	5.01.0148.1.01.3	ZF	0637-880-071	PIPE UNION
6357	5.01.0149.1.01.4	ZF	0659-160-054	CABLE CLIP FOR ZF GEAR BOX
6358	5.01.0150.1.01.5	ZF	0730 061 624	RING
6359	5.01.0151.1.01.6	ZF	0730-001-879, 0730-000-257, 0730-000-258, 0730-102-459, 2050-309-066, 4607-316-081, 5010-303-020	SHIM FOR ZF GEAR BOX OFF SIZES :
6360	5.01.0152.1.01.7	ZF	0730-001-927	INTERMEDIATE RING
6361	5.01.0153.1.01.8	ZF	0730-102-464, 63, 62, 61, 60, 67, 68, 69	SHIM
6362	5.01.0154.1.01.9	ZF	0734-303-035	O RING
6363	5.01.0155.1.01.1	ZF	0735-320-110	TAPER ROLLER & CAGE ASSY
6364	5.01.0156.1.01.2	ZF	0735-320-111	NEEDLE ROLLER & CAGE ASSY
6365	5.01.0157.1.01.3	ZF	0735-320-204	NEEDLE ROLLER & CAGE ASSY
6366	5.01.0158.1.01.4	ZF	0735-320-206	NEEDLE ROLLER & CAGE ASSY
6367	5.01.0159.1.01.5	ZF	0735-320-314	NEEDLE CAGE BEARING
6368	5.01.0160.1.01.6	ZF	0735-320-315	NEEDLE CAGE BEARING
6369	5.01.0161.1.01.7	ZF	0735-353-243	ROLLER CAGE
6370	5.01.0162.1.01.8	ZF	0735-358-032	ROLLER CAGE BEARING
6371	5.01.0163.1.01.9	ZF	0750-115-356	NEEDLE SLEEVE / VALVE
6372	5.01.0164.1.01.1	ZF	0750-118-019	NEEDLE ROLLER & CAGE ASSY
6373	5.01.0165.1.01.2	ZF	098635200 (IMPORTED)	PLUG
6374	5.01.0166.1.01.3	ZF	1240-310-013/1240-3100-13	OUT PUT SHAFT
6375	5.01.0167.1.01.4	ZF	1269302164 / 4616305007	SET OF TAB WASHER FOR ZF GEAR BOX
6376	5.01.0168.1.01.5	ZF	140X149X2, 0634-305-089, 135-VITON	PISTON RING
6377	5.01.0169.1.01.6	ZF	1419-306-063=, 4620-306-255=, 4620-306-413=, 4620-306-414=, 4642-306-091=, 4644-306-010=	SET OF PISTON FOR ZF GEAR BOX CONSISTING OF:
6378	5.01.0170.1.01.7	ZF	2050-309-067/068/069	SHIM OPTIONAL
6379	5.01.0171.1.01.8	ZF	260X268X2.2, 0634-305-026	PISTON RING
6380	5.01.0172.1.01.9	ZF	320X332X2.5, 0634-305-093, 155-VITON	PISTON RING
6381	5.01.0173.1.01.1	ZF	39.5X2 0634-402-029-DIN-34110	PISTON RING FOR ZF GEAR BOX
6382	5.01.0174.1.01.2	ZF	4116-301-175	HOUSING FOR ZF GEAR BOX
6383	5.01.0175.1.01.3	ZF	4139-334-002	O' CLUTCH DISC FOR CONVERTOR CLUTCH OF ZF GEAR
6384	5.01.0176.1.01.4	ZF	4166-039-077	CONVERTOR FOR ZF GEAR BOX
6385	5.01.0177.1.01.5	ZF	4166-236-111	'I' CLUTCH DISC FOR TORQUE
6386	5.01.0178.1.01.6	ZF	420X430X03, 155-VITON, 0634-305-042	PISTON RING (22123)
6387	5.01.0179.1.01.7	ZF	4616-307-007	SHIFT CONTROL ASSEMBLY
6388	5.01.0180.1.01.8	ZF	4616.208.003	CLUTCH DISC
6389	5.01.0181.1.01.9	ZF	4616.303.046	OUTPUT FLANGE
6390	5.01.0182.1.01.1	ZF	4616.303.156	OUTPUT FLANGE
6391	5.01.0183.1.01.2	ZF	4616.308.035	'I' CLUTCH DISC
6392	5.01.0184.1.01.3	ZF	4616-000-163/207/199	Z F GEAR BOX (IMPORTED)
6393	5.01.0185.1.01.4	ZF	4616-121	SET OF PIPE

6394	5.01.0186.1.01.5	ZF	4616-159-007	SHIFT CONTROL ASSY.FOR ZF GEAR BOX 4WG-65-11WK
6395	5.01.0187.1.01.6	ZF	4616-208/223-003	O' CLUTCH DISC FOR ZF GEAR BOX
6396	5.01.0188.1.01.7	ZF	4616-301-235	HOUSING
6397	5.01.0189.1.01.8	ZF	4616-301-244	QUILL SHAFT
6398	5.01.0190.1.01.9	ZF	4616-301-304	HOUSING FOR ZF GEAR BOX
6399	5.01.0191.1.01.1	ZF	4616-301-309	HOUSING FOR ZF GEAR BOX
6400	5.01.0192.1.01.2	ZF	4616-302-112	QUILL SHAFT
6401	5.01.0193.1.01.3	ZF	4616-303-006	OIL COIL PLATE
6402	5.01.0194.1.01.4	ZF	4616-303-008	OIL FEED RING
6403	5.01.0195.1.01.5	ZF	4616-303-011	OIL FEED BUSH
6404	5.01.0196.1.01.6	ZF	4616-303-026	SPUR GEAR
6405	5.01.0197.1.01.7	ZF	4616-303-028	BALL HOUSING FOR ZF GEAR BOX
6406	5.01.0198.1.01.8	ZF	4616-303-031	COVER FOR ZF GEAR BOX
6407	5.01.0199.1.01.9	ZF	4616-303-041	OUT PUT FLANGE FOR ZF GEAR BOX
6408	5.01.0200.1.01.1	ZF	4616-303-042	OUT PUT SHAFT FOR ZF GEAR BOX
6409	5.01.0201.1.01.2	ZF	4616-306-087	COVER PLATE FOR ZF GEAR BOX
6410	5.01.0202.1.01.3	ZF	4616-306-111	GEAR FOR ZF GEAR BOX
6411	5.01.0203.1.01.4	ZF	4616-307-003	SPUR GEAR FOR ZF GEAR BOX
6412	5.01.0204.1.01.5	ZF	4616-308-031	LAY SHAFT
6413	5.01.0205.1.01.6	ZF	4616-308-052	SPUR GEAR FOR ZF GEAR BOX
6414	5.01.0206.1.01.7	ZF	4616-308-111	GEAR FOR ZF GEAR BOX
6415	5.01.0207.1.01.8	ZF	4616-329-005	PUMP FLANGE
6416	5.01.0208.1.01.9	ZF	4616-336-010	HOUSING FOR ZF GEAR BOX
6417	5.01.0209.1.01.1	ZF	4616-336-009	CONVERTOR COVER
6418	5.01.0210.1.01.2	ZF	4616-441-011R/ 4616-159-022	ELECTRIC CIRCUIT
6419	5.01.0211.1.01.3	ZF	4644-164-003	GEAR SHIFT SYSTEM COMPLETE FOR ZF GEAR BOX
6420	5.01.0212.1.01.4	ZF	4644-303-268/4607.030.034	INPUT FLANGE
6421	5.01.0213.1.01.5	ZF	4644-306-599	REDUCTION VALVE FOR ZF GEAR BOX
6422	5.01.0214.1.01.6	ZF	4WE-65ii-4616000277	ZF GEAR BOX
6423	5.01.0215.1.01.7	ZF	4WG65II/4616000206	ZF GEAR BOX
6424	5.01.0216.1.01.8	ZF	4WG65II/4616000260	ZF GEARBOX
6425	5.01.0217.1.01.9	ZF	4WG65II/4616000262	ZF GEAR BOX
6426	5.01.0218.1.01.1	ZF	5010-304-015	SHIM PLATE FOR ZF GEAR BOX
6427	5.01.0219.1.01.2	ZF	55X2.5, SH-DIN-34110, 0634-402-052	PISTON RING
6428	5.01.0220.1.01.3	ZF	6006-016-109	GEAR SELECTOR FOR ZF GEAR BOX
6429	5.01.0221.1.01.4	ZF	6011-310-001	SPRING CAP
6430	5.01.0222.1.01.5	ZF	6029-199-002.0659-050-178/100	PLUG FOR ZF GEAR BOX
6431	5.01.0223.1.01.6	ZF	604/31002	VALVE
6432	5.01.0224.1.01.7	ZF	6041-232-210/184	MODULE
6433	5.01.0225.1.01.8	ZF	6041-315-007	INDUCTIVE TRANSMITTER ZF GEAR BOX (TRANSDUCER)
6434	5.01.0226.1.01.9	ZF	630-004-388/117/ 104/103/101/100	SHIM FOR ZF GEAR BOX
6435	5.01.0227.1.01.1	ZF	6W6200/4644026290	ZF GEAR BOX
6436	5.01.0228.1.01.2	ZF	7647.955.123	Z.F. OIL PUMP
6437	5.01.0229.1.01.3	ZF	90X97X2.0634-305-009	PISTON RING FOR ZF GEAR BOX
6438	5.01.0230.1.01.4	ZF	92X2.5, 0634-402-110	PISTON RING
6439	5.01.0231.1.01.5	ZF	4616000	Set of Lubrication Pressure Valve for Z.F. Gear Box Consisting of :-
6440	5.01.0232.1.01.6	ZF	44616320011	Valve Sleeve Part No
6441	5.01.0233.1.01.7	ZF	631329158	Slot Pin
6442	5.01.0234.1.01.8	ZF	4044306022	Piston
6443	5.01.0235.1.01.9	ZF	ZF 0735-320-204	NEEDLE ROLLER & CAGE ASSY
6444	5.01.0236.1.01.1	ZF	480290017	GEAR SHIFT FORK
6445	5.01.0237.1.01.2	ZF	0501310470	VALVE
6446	5.01.0238.1.01.3	ZF	0635-290-061	HOUSING DISC
6447	5.01.0239.1.01.4	GE	TDCN-22-1861	Hydro mechanical transmission gear box complete
6448	5.01.0240.1.01.5	PL	4616303156	FLANGE
6449	5.01.0241.1.01.6	GE	8-1750(Ms372)	Torque Converter
6450	5.01.0242.1.01.7	GE	YD432D-23-19-04	Flange-4
6451	5.01.0243.1.01.8	PL	28EST1	ZF Control
6452	5.01.0244.1.01.9	KA	6.62.06.100	HYDRAULIC CONVERTER
6453	5.02.0001.1.01.1	PL	63.09.2115	BEARING COVER
6454	5.02.0002.1.01.2	ZF	LK62.302	BEARING HOUSING
6455	5.02.0003.1.01.3	LO	259368	Traction Gearbox Breather
6456	5.02.0004.1.01.4	PL	UD64.1301	DRIVE AXLE GEAR BOX HOUSING
6457	5.02.0005.1.01.5	PL	UD64.1102	SLIDING RING
6458	5.02.0006.1.01.6	PL	UD64.27	THREADED BOLT
6459	5.02.0007.1.01.7	PL	WN71.103	AXLE GEARBOX COVER
6460	5.02.0008.1.01.8	PL	WN80.2600F/1-158-V01	PUMP GEAR BOX
6461	5.02.0009.1.01.9	PL	EB-64.04.3000.240	MAIN GEAR BOX-1(FRONT)
6462	5.02.0010.1.01.1	PL	WN75.200/180(C)	DISTRIBUTION GEAR BOX
6463	5.03.0001.1.01.2	PL	64.04.3100	GEAR WHEEL
6464	5.03.0002.1.01.3	PL	64.04.3188	GEAR WHEEL

6465	5.03.0003.1.01.4	PL	64.04.3232	CARRIER
6466	5.03.0004.1.01.5	PL	64.04.3241	GEAR WHEEL
6467	5.03.0005.1.01.6	PL	64.04.3242	GEAR WHEEL
6468	5.03.0006.1.01.7	PL	64.04.3243	GEAR WHEEL
6469	5.03.0007.1.01.8	PL	64.04.3244	GEAR WHEEL
6470	5.03.0008.1.01.9	PL	64.04.3245	GEAR WHEEL
6471	5.03.0009.1.01.1	PL	64.04.3246	SHAFT WITH KEY
6472	5.03.0010.1.01.2	PL	64.04.3247	GEAR WHEEL
6473	5.03.0011.1.01.3	PL	64.04.3248	SHAFT WITH KEY
6474	5.03.0012.1.01.4	PL	64.04.3249	SHAFT WITH KEY
6475	5.03.0013.1.01.5	Shifted to Ann-III A		
6476	5.03.0014.1.01.6	PL	64.04.3257	CARRIER
6477	5.03.0015.1.01.7	PL	64.04.3261	CARRIER
6478	5.03.0016.1.01.8	PL	64.04.3263	CARRIER
6479	5.03.0017.1.01.9	PL	64.08.3055	PINION
6480	5.03.0018.1.01.1	PL	SU 611.16.25.10	GEAR WHEEL FOR 3X
6481	5.03.0019.1.01.2	PL	U 75.607	GEAR WHEEL FOR 3X
6482	5.03.0020.1.01.3	PL	WN 70-3410 E	SLIDING GEAR Z=22
6483	5.03.0021.1.01.4	PL	WN 70-3411	GEAR WHEEL Z=93
6484	5.03.0022.1.01.5	PL	WN70.1107	SHAFT
6485	5.03.0023.1.01.6	PL	WN70.1107C	SHAFT
6486	5.03.0024.1.01.7	PL	WN70.3805	DOUBLE GEAR WHEEL
6487	5.03.0025.1.01.8	PL	WN70.3806	DOUBLE GEAR WHEEL
6488	5.03.0026.1.01.9	PL	WN80.1112	SHAFT
6489	5.03.0027.1.01.1	PL	WN80.2600-13	SHAFT
6490	5.03.0028.1.01.2	PL	WN80.2600-8	SHAFT
6491	5.03.0029.1.01.3	PL	WN81.503	CARRIER
6492	5.03.0030.1.01.4	PL	WN81.703	CARRIER
6493	5.03.0031.1.01.5	PL	WN81.903	CARRIER
6494	5.03.0032.1.01.6	KE	662339	CLUTCH ASSEMBLY
6495	5.03.0033.1.01.7	AM	17042	WHEEL CROWN FOR T -28
6496	5.03.0034.1.01.8	AM	17058	WHEEL PINION FOR T 28
6497	5.03.0035.1.01.9	PH	30233005	BEVEL PINION & GEAR
6498	5.03.0036.1.01.1	PH	UTV1.11/00/00	PTO ASSEMBLY
6499	5.03.0037.1.01.2	PL	1295151007/FLANSCH-120M SUBSTITUTE N70- 1B(1295151007/FLANSCH)	POWER TAKE OFF ASSEMBLY
6500	5.03.0038.1.01.3	PL	62.13.409	SHAFT
6501	5.03.0039.1.01.4	PL	62.04.3100	GEAR WHEEL
6502	5.03.0040.1.01.5	Shifted to Ann-III A		
6503	5.03.0041.1.01.6	PL	2249137EB	SWITCH GEAR
6504	5.03.0042.1.01.7	CR	40100378-057	GEAR-1
6505	5.03.0043.1.01.8	CR	40100378-058	GEAR-2
6506	5.03.0044.1.01.9	CR	40100378-064	GEAR
6507	5.03.0045.1.01.1	CR	40100378-068	CROWN GEAR
6508	5.03.0046.1.01.2	CR	40100378-076	PINION
6509	5.03.0047.1.01.3	CR	40100378-093	SHAFT-1
6510	5.03.0048.1.01.4	CR	40100378-107	SHAFT-2
6511	5.03.0049.1.01.5	CR	40100378-109	FLANGE-2
6512	5.03.0050.1.01.6	CR	40100378-116	SHAFT-1
6513	5.03.0051.1.01.7	CR	40100378-117	FLANGE
6514	5.03.0052.1.01.8	CR	BS550(IND)-03-01-02-03	DRIVING ROLLER SHAFT
6515	5.03.0053.1.01.9	CR	BS550(IND)-03-01-03-02	DIVERT ROLLER SHAFT
6516	5.03.0054.1.01.1	CR	QS1200-29-14	GEAR
6517	5.03.0055.1.01.2	CR	BS550(IND)-09-02-02	DRIVING ROLLER SHAFT
6518	5.03.0056.1.01.3	PL	WN75.1950-2	DRIVE SHAFT
6519	5.03.0057.1.01.4	PL	WN80.2600-15	SHAFT
6520	5.03.0058.1.01.5	PL	WN80.2605-1	GEAR WHEEL SHAFT (Z=44)
6521	5.03.0059.1.01.6	PL	64.11.1436	GEAR WHEEL
6522	5.03.0060.1.01.7	PL	WN71.154Z/ 155	Crown and Pinion
6523	5.03.0061.1.01.8	PL	UD73.330	SHAFT
6524	5.03.0062.1.01.9	PL	64.04.3311	SHAFT
6525	5.03.0063.1.01.1	PL	64.04.3304	CARRIER
6526	5.03.0064.1.01.2	PL	UD64.802	SHAFT
6527	5.03.0065.1.01.3	PL	WN80.2600-2	GEAR WHEEL
6528	5.03.0066.1.01.4	PL	WN80.2600-6	GEAR WHEEL
6529	5.03.0067.1.01.5	PL	WN80.2605-4	GEAR WHEEL
6530	5.03.0068.1.01.6	PL	WN80.2605-5	GEAR WHEEL Z=103
6531	5.03.0069.1.01.7	PL	WN74.102-E.Z=77/44	Gear Wheel
6532	5.03.0070.1.01.8	PL	WN81.300(A)	Pump Drive
6533	5.03.0071.1.01.9	PL	WN81.325(A)	Pump Drive
6534	5.04.0001.1.01.3	PL	2-330-854-6	CARRIER
6535	5.04.0002.1.01.4	PL	64.13.4032	COUPLING
6536	5.04.0003.1.01.5	PL	M63 254 DB	SHOE
6537	5.04.0004.1.01.6	PL	WN.220.27	FLEXIBLE COUPLING
6538	5.04.0005.1.01.7	PL	WN220.01A	COUPLING

6539	5.04.0006.1.01.8	PL	WN220.04A	COUPLING
6540	5.04.0007.1.01.9	PL	WN220.20	COUPLING
6541	5.04.0008.1.01.1	PL	WN220.30	COUPLING
6542	5.04.0009.1.01.2	PL	WN220.31	COUPLING
6543	5.04.0010.1.01.3	PL	WN220.32	COUPLING
6544	5.04.0011.1.01.4	PL	WN220.36	COUPLING
6545	5.04.0012.1.01.5	PL	WN70.1167	SLIDER
6546	5.04.0013.1.01.6	CR	40100378-051	FLANGE, SEAL SUPPORT
6547	5.04.0014.1.01.7	CR	40100378-067	FLANGE-1
6548	5.04.0015.1.01.8	CR	BS550-07-17-00	FLANGE
6549	5.04.0016.1.01.9	PL	UD61.10074	FLANGE
6550	5.04.0017.1.01.1	PL	UD220.2780.3	BEARING FLANGE
6551	5.04.0018.1.01.2	PL	WN220.04A/3X	COUPLING
6552	5.04.0019.1.01.3	PL	WN220.04B	COUPLING
6553	5.04.0020.1.01.4	PL	WN220.59	COUPLING
6554	5.04.0021.1.01.5	PL	WN220.76	COUPLING
6555	5.04.0022.1.01.6	PL	63.09.2103	FLANGE BUSH
6556	5.04.0023.1.01.7	PL	EL-T9124.50-3	COUPLING
6557	5.04.0024.1.01.8	LO	124253	FLANGE STR 3261 04FORB
6558	5.04.0025.1.01.9	LO	124888	FLANGE BLIND 1.50; 2461 O-RING GROOVE
6559	5.04.0026.1.01.1	LO	133644	FLANGE ADAPTER 2461 12FORB
6560	5.04.0027.1.01.2	LO	143866	FLANGE STR 3261 3261C; GA PORT 3X 04FORB
6561	5.04.0028.1.01.3	LO	143885	FLANGE EL90 3261C 3261C
6562	5.04.0029.1.01.4	LO	144064	FLANGE STR 2461 2461C; GA PORT 16FORB ALUM
6563	5.04.0030.1.01.5	PL	WN22076	Coupling
6564	5.04.0031.1.01.6	PL	64.09.2000.21	COUPLING -(Bowex Coupling)
6565	5.04.0032.1.01.7	PL	M24/M	Bowex Coupling
6566	5.04.0033.1.01.8	PL	WN80.2605-6	BELL-HOUSING OF COUPLING
6567	5.05.0001.1.01.4	PL	KG120.0500.060.00	CARDON SHAFT
6568	5.05.0002.1.01.5	PL	KG180.1250.110.00/80	CARDON SHAFT
6569	5.05.0003.1.01.6	PL	KG150.0750.110.00	CARDON SHAFT
6570	5.05.0004.1.01.7	PL	KG150.0900.110.00	CARDON SHAFT
6571	5.05.0005.1.01.8	PL	KG180.0900.110.80	CARDON SHAFT
6572	5.05.0006.1.01.9	PL	KG180.0950.110.80	CARDON SHAFT
6573	5.05.0007.1.01.1	PL	KG180.1000.110.80	CARDON SHAFT
6574	5.05.0008.1.01.2	PL	KG180.1250.110.80	CARDON SHAFT
6575	5.05.0009.1.01.3	PL	KG180.1300.110.80	CARDON SHAFT
6576	5.05.0010.1.01.4	PL	KG180.1550.110.80	CARDON SHAFT
6577	5.05.0011.1.01.5	PL	KGW150.0700.110.00	CARDON SHAFT
6578	5.05.0012.1.01.6	PL	KGW150.0900.110.00	CARDON SHAFT
6579	5.05.0013.1.01.7	PL	KGW150.0950.110.00	CARDON SHAFT
6580	5.05.0014.1.01.8	PL	KGW150.1000.110.00	CARDON SHAFT
6581	5.05.0015.1.01.9	PL	KGW150.1200.110.00	CARDON SHAFT
6582	5.05.0016.1.01.1	PL	KGW180.0660.110.00	CARDON SHAFT
6583	5.05.0017.1.01.2	PL	KGW180.0700.110.50	CARDON SHAFT
6584	5.05.0018.1.01.3	PL	KGW180.0750.110.00	CARDON SHAFT
6585	5.05.0019.1.01.4	PL	KGW180.0900.110.00	CARDON SHAFT
6586	5.05.0020.1.01.5	PL	KGW180.0950.110.00	CARDON SHAFT
6587	5.05.0021.1.01.6	PL	KGW180.1000.110.00	CARDON SHAFT
6588	5.05.0022.1.01.7	PL	KGW180.1050.110.00	CARDON SHAFT
6589	5.05.0023.1.01.8	PL	KGW180.1100.110.00	CARDON SHAFT
6590	5.05.0024.1.01.9	PL	KGW180.1170.110.00	CARDON SHAFT
6591	5.05.0025.1.01.1	PL	KGW180.1200.110.00	CARDON SHAFT
6592	5.05.0026.1.01.2	PL	KGW180.1250.110.00	CARDON SHAFT
6593	5.05.0027.1.01.3	PL	KGW180.1300.110.00	CARDON SHAFT
6594	5.05.0028.1.01.4	PL	KGW180.1500.110.00	CARDON SHAFT
6595	5.05.0029.1.01.5	PL	LZ.500.L.450/187.20	CARDON SHAFT
6596	5.05.0030.1.01.6	PL	LZ.900.LA.80, UD.70.5231	CARDON SHAFT
6597	5.05.0031.1.01.7	PL	LZ1330LA110/CA72.1409	CARDON SHAFT
6598	5.05.0032.1.01.8	PL	LZ200/187,20	CARDON SHAFT
6599	5.05.0033.1.01.9	PL	LZ325LA35/0112130279 SUB. LZ325LA35/0112130800	CARDON SHAFT
6600	5.05.0034.1.01.1	PL	LZ400LA50/ 387,30	CARDON SHAFT
6601	5.05.0035.1.01.2	PL	LZ400LA50/UD72.4224	CARDON SHAFT
6602	5.05.0036.1.01.3	PL	LZ420LA40/UD72.2719G-A	CARDON SHAFT
6603	5.05.0037.1.01.4	PL	LZ470LA40/ 587,30FL.D.180	CARDON SHAFT
6604	5.05.0038.1.01.5	PL	LZ640LA110/0117111465 SUB. LZ640LA110/4369.1085.0640	CARDON SHAFT
6605	5.05.0039.1.01.6	PL	LZ740LA110/0120111001	CARDON SHAFT
6606	5.05.0040.1.01.7	PL	LZ742LA110/0158115001	CARDON SHAFT
6607	5.05.0041.1.01.8	PL	LZ760LA100/0110115001	CARDON SHAFT
6608	5.05.0042.1.01.9	PL	WN 151.120.12/24.1	CARDON SHAFT FLANGE
6609	5.05.0043.1.01.1	KE	663222	CARDON SHAFT YOKE FOR BRM
6610	5.05.0044.1.01.2	PH	UTV1 02/05/00	CARDON SHAFT
6611	5.05.0045.1.01.3	PH	UTV1 02/23/00	CARDON SHAFT

6612	5.05.0046.1.01.4	PL	4-68649	CARDAN SHAFT
6613	5.05.0047.1.01.5	PL	SOLA16-574	UNIVERSAL JOINT
6614	5.05.0048.1.01.6	KA	KPM1-220-5010-02	Cardan Shaft
6615	5.05.0049.1.01.7	KA	KPM3-2201010-12	Cardan Shaft (TGB to IGB)
6616	5.05.0050.1.01.8	KA	522A-2201010-12	Cardan Shaft
6617	5.05.0051.1.01.9	KA	KPM1-220-5010-02	Intermediate to 2nd Axle
6618	5.05.0052.1.01.1	GE	B1.1-2,Lz-225	Propeller shaft-1
6619	5.05.0053.1.01.2	GE	200.35-180/180-1000	Propeller shaft-2
6620	5.05.0054.1.01.3	GE	200.30-180/180-1050	Propeller shaft-3
6621	5.05.0055.1.01.4	GE	00.30-180/180-1000	Propeller shaft-4
6622	5.05.0056.1.01.5	GE	200.30-180/180-500	Propeller shaft-5
6623	5.05.0057.1.01.6	KA	257-2202010-17	CARDAN SHAFT
6624	5.05.0057.1.01.7	GE	200.30-180/180-1250	Propeller shaft-6
6625	5.05.0058.1.01.7	KA	2-224334	CARDAN SHAFT
6626	5.05.0059.1.01.8	PL	KG225.1550.110.00	CARDAN SHAFT
6627	5.05.0060.1.01.9	PL	KG150.1050.110.00	CARDAN SHAFT
6628	5.05.0061.1.01.1	PL	KG180.1600.110.080	CARDAN SHAFT
6629	5.05.0062.1.01.2	PL	KGW180.0665.110.00	CARDAN SHAFT
6630	5.05.0063.1.01.3	PL	KGW180.0720.110.00	CARDAN SHAFT
6631	5.05.0064.1.01.4	PL	LZ720LA110/0122140001	CARDAN SHAFT
6632	5.05.0065.1.01.5	PL	LZ550LA40/01221210001	CARDAN SHAFT
6633	5.05.0066.1.01.6	PL	LZ1000LA140/0122111001	CARDAN SHAFT(Eng to GB)
6634	5.05.0067.1.01.7	PL	KGW180.0665.110.00	CARDAN SHAFT(drive pump)
6635	5.05.0068.1.01.8	PL	KG225.1900.110.00 SUB LZ1900LA110/0120111001	CARDAN SHAFT
6636	5.05.0069.1.01.9	PL	KG180.1150.110.80	CARDAN SHAFT
6637	5.05.0070.1.01.1	PL	KG225.1300.140.00	CARDAN SHAFT
6638	5.05.0071.1.01.2	PL	LZ345LA35/387.20	CARDAN SHAFT
6639	5.05.0072.1.01.3	OEPL	222 02 00 03	CARDAN SHAFT
6640	5.05.0073.1.01.4	OEPL	223 02 00 04	CARDAN SHAFT
6641	5.05.0074.1.01.5	PL	LZ1900LA 1 10/ 0	Cardan shaft
6642	5.05.0075.1.01.6	PL	LZ760LA110/0120111001	CARDAN SHAFT
6643	5.05.0076.1.01.7	PL	RE15.279	COVERTING BLADE
6644	5.05.0077.1.01.8	PL	RE16.279	COVERTING BLADE
6645	5.05.0078.1.01.9	PL	WN120-M36X1.5	TENSION LOCK
6646	5.05.0079.1.01.1	PL	KG150.0850.110.00	CARDAN SHAFT
6647	5.05.0080.1.01.2	PL	KG180.1340.110.80	CARDAN SHAFT
6648	5.05.0081.1.01.3	PL	KG180.1650.110.80	CARDAN SHAFT
6649	5.05.0082.1.01.4	PL	KGW180.1550.110.80	CARDAN SHAFT
6650	5.05.0083.1.01.5	PL	WN151-180.5480-1	Cardan Shaft Flange
6651	5.05.0084.1.01.6	PL	LZ420LA50/UD72-2719G-A	CARDAN SHAFT
6652	5.05.0085.1.01.7	PL	64.11.1435	Carrier Shaft
6653	5.05.0086.1.01.8	PL	WN153-9017.850-1	GUIDE SHAFT
6654	5.05.0087.1.01.9	PL	U64.1311	GEAR SHIFT FORK
6655	5.05.0088.1.01.1	PL	EL-T155-03-650LG	Drive shaft
6656	5.05.0089.1.01.2	PL	EL-T155.03-850LG	Drive shaft
6657	5.05.0090.1.01.3	PL	KGW180.1300.110.80	Cardan shaft (Engine to ZFgear box)
6658	5.05.0091.1.01.4	PL	DL24006900LG	Shaft
6659	5.05.0092.1.01.5	KA	06.04.02.304	Shaft (for working Drive shifting)
6660	5.06.0001.1.01.5	AM	53879003	SEAL KIT CRAWLER REDUCTION GEAR BOX M709C3B23
6661	5.06.0002.1.01.6	PH	ADGB/GS/UTV/002	GASKET KIT FOR AXLE DRIVE GEAR BOX
6662	5.06.0003.1.01.7	PH	ADGB/GS/UTV/04	SEAL KIT FOR ADGB
6663	5.06.0004.1.01.8	PH	91500022	BREATHER CUM FILTER
6664	5.06.0005.1.01.9	PH	91500067	AXLE GEAR BOX BREATHER 3/4" BSP
6665	5.06.0006.1.01.1	PH	92000086	OIL SEAL ID.200XOD.230X15
6666	5.06.0007.1.01.2	PH	92000112	OIL SEAL
6667	5.06.0008.1.01.3	PH	92000121	DDGB OUTPUT SHAFT O RING
6668	5.06.0009.1.01.4	PL	100M12550023/G	SUPPORT
6669	5.06.0010.1.01.5	PL	61.02.200III	PISTON PUMP
6670	5.06.0011.1.01.6	PL	A2-22223	PISTON
6671	5.06.0012.1.01.7	GE	CDCK16A-56-11-00	Attachment
6672	5.06.0013.1.01.8	PL	UD222.702	VENTILATOR COVER
6673	5.06.0014.1.01.9	CR	40100378-045	RING
6674	5.06.0015.1.01.1	CR	40100378-047	RING-2
6675	5.06.0016.1.01.2	CR	40100378-060	RING, SPACER
6676	5.06.0017.1.01.3	CR	40100378-061	RING, ELASTIC-1
6677	5.06.0018.1.01.4	CR	40100378-062	RING, ELASTIC-2
6678	5.06.0019.1.01.5	CR	40100378-071	RING,SPACER
6679	5.06.0020.1.01.6	CR	40100378-072	RING, ELASTIC-3
6680	5.06.0021.1.01.7	CR	40100378-073	RING, ELASTIC-4
6681	5.06.0022.1.01.8	CR	40100378-077	RING, ELASTIC-5
6682	5.06.0023.1.01.9	CR	40100378-079	RING, ELASTIC-6
6683	5.06.0024.1.01.1	CR	40100378-080	RING, ELASTIC-7
6684	5.06.0025.1.01.2	CR	40100378-081	RING-1

6685	5.06.0026.1.01.3	CR	40100378-084	RING, ELASTIC-8
6686	5.06.0027.1.01.4	CR	40100378-085	RING-2
6687	5.06.0028.1.01.5	CR	40100378-089	RING-4
6688	5.06.0029.1.01.6	CR	40100378-106	RING, ELASTIC-9
6689	5.06.0030.1.01.7	CR	USH36.46.6	Y ring-7
6690	5.06.0031.1.01.8	CR	ISI70.80.6	Y ring-9
6691	5.06.0032.1.01.9	CR	SF-1 5525	COMPOSITE BUSHING-1
6692	5.06.0033.1.01.1	CR	SF-1 5590	COMPOSITE BUSHING-2
6693	5.06.0034.1.01.2	CR	BS550-07-14	BUSHING
6694	5.06.0035.1.01.3	CR	BS550(IND)-07-02-26	BUSHING I
6695	5.06.0036.1.01.4	CR	BS550(IND)-07-01-02-05	BUSHING I
6696	5.06.0037.1.01.5	CR	BS550(IND)-07-01-02-06	BUSHING II
6697	5.06.0038.1.01.6	CR	BS550(IND)-10-05-01-01	RING BUSHING
6698	5.06.0039.1.01.7	CR	BS550(IND)-10-05-01-02	SPACING BUSHING
6699	5.06.0040.1.01.8	CR	DPZ440-05-11	BUSHING 50X65X17.5
6700	5.06.0041.1.01.9	CR	DPZ440-05-18	BUSHING 50X65X31.5
6701	5.06.0042.1.01.1	CR	DPZ440-36-07	HINGE PIN
6702	5.06.0043.1.01.2	CR	DPZ440-05-19	BUSHING 40X55X22
6703	5.06.0044.1.01.3	CR	BS500W(IND)-13-01-12	BUSHING 40X55X65
6704	5.06.0045.1.01.4	CR	BS500W(IND)-13-20-06	BUSHING 17.5
6705	5.06.0046.1.01.5	CR	BS500W(IND)-13-20-15	PIN-1
6706	5.06.0047.1.01.6	CR	BS500W(IND)-13-20-16	PIN-2
6707	5.06.0048.1.01.7	CR	BS500W(IND)-13-20-17	PIN HANDLE
6708	5.06.0049.1.01.8	CR	BS550(IND)-15-02-07-00	MECHANIC PIN A
6709	5.06.0050.1.01.9	CR	BS550(IND)-15-02-08-00	MECHANIC PIN B
6710	5.06.0051.1.01.1	CR	23073450	Spacer
6711	5.06.0052.1.01.2	CR	23087623	pin
6712	5.06.0053.1.01.3	CR	20261420	Spacer
6713	5.06.0054.1.01.4	PL	HY-L507.1600.3ES SUB. 62.05.1000.426	FILTER ELEMENT
6714	5.06.0055.1.01.5	PL	DZ80/G=2000/HUB100	PULL CABLE
6715	5.06.0056.1.01.6	PL	DZ95/G=2000/HUB70	PULL CABLE
6716	5.06.0057.1.01.7	PL	DZ160/G=2000/HUB200	PULL CABLE
6717	5.06.0058.1.01.8	PL	DZ160/G=3000/HUB200	PULL CABLE
6718	5.06.0059.1.01.9	LO	237622	PIN .750D; MOD TILT LOCK
6719	5.06.0060.1.01.1	PL	UD71.1008	COVER FOR BEWEL GEAR BOX,
6720	5.06.0061.1.01.2	PL	SSP70.01.618	PRESSURE SPRING
6721	5.06.0062.1.01.3	PL	CU65.1602	BRACKET
6722	5.06.0063.1.01.4	PL	UD214-1506	LEVER
6723	5.06.0064.1.01.5	PL	62.13.407	CONNECTING PIECE
6724	5.06.0065.1.01.6	PL	UD215.1553	BEWEL WHEEL
6725	5.06.0066.1.01.7	PL	UD71.1048-1,0,	Distance washer
6726	5.06.0067.1.01.8	PL	UD71.1047-0,5	DISTANCE WASHER
6727	5.06.0068.1.01.9	PL	DL63.346-0,4MM ,	ADJUSTING DISC
6728	5.06.0069.1.01.1	PL	DL63.347-0,5MM ,	ADJUSTING DISC
6729	5.06.0070.1.01.2	PL	DL63.348 1MM ,	ADJUSTING DISC
6730	5.06.0071.1.01.3	PL	DL63.344-0,25MM,	ADJUSTING DISC
6731	5.06.0072.1.01.4	PL	WN71.339-0,1MM	ADJUSTING DISC
6732	5.06.0073.1.01.5	PL	WN71.341-0,25MM	ADJUSTING DISC
6733	5.06.0074.1.01.6	PL	WN71.343-0,4MM	ADJUSTING DISC
6734	5.06.0075.1.01.7	PL	WN71.345-1,0MM	ADJUSTING DISC
6735	5.06.0076.1.01.8	PL	WN71.146-0,1MM	ADJUSTING DISC
6736	5.06.0077.1.01.9	PL	WN71.147-0,15MM	ADJUSTING DISC
6737	5.06.0078.1.01.1	PL	WN71.148-0,40MM	ADJUSTING DISC
6738	5.06.0079.1.01.2	PL	WN71.149-0,75MM	ADJUSTING DISC
6739	5.06.0080.1.01.3	PL	WN71.150-0,80MM	ADJUSTING DISC
6740	5.06.0081.1.01.4	PL	WN71.151-1,00MM	ADJUSTING DISC
6741	5.06.0082.1.01.5	PL	64.02.2105.00 STKL	PINION SHAFT
6742	5.07.0001.1.01.6	PL	61.4901	Driving Axle Front of UNIMAT
6743	5.07.0002.1.01.7	PL	61.8601	Driving Axle Front of UNIMAT
6744	5.07.0003.1.01.8	PL	CU.61.8502	Running Axle for CSM
6745	5.07.0004.1.01.9	PL	UD.62.01	Driving axle-duo
6746	5.07.0005.1.01.1	PL	UD62.2404	COVER (AXLE)
6747	5.07.0006.1.01.2	PL	UD62.3301	CSM Satellite of Driving Bogie Axle
6748	5.07.0007.1.01.3	PL	UD62.3301 SPUR 1668/1676	SATELLITE AXLE
6749	5.07.0008.1.01.4	PL	WN01.850.184.IND.RT.1	AXLE WHEEL FOR IMPORTED DUO
6750	5.07.0009.1.01.5	LO	134173	WHEEL AXLE SET W GEAR; DRIVE TRUCK MULTIPLE WEAR
6751	5.07.0010.1.01.6	GE	YD432D-20-03-00	Fixing axle
6752	5.07.0011.1.01.7	CR	TX100 II -14-03-01	AXLE BOX
6753	5.07.0012.1.01.8	CR	TX100 II -14-04-01	AXLE BOX RIGHT SIDE 1
6754	5.07.0013.1.01.9	PL	WN70.3404	AXLE
6755	5.07.0014.1.01.1	CR	CDC16W(IND)-08-03-00	DRIVEN WHEELSET
6756	5.07.0015.1.01.2	CR	BS550(IND)-09-05-01	AXLE
6757	5.07.0016.1.01.3	CR	BS550(IND)-10-04-06	AXLE
6758	5.07.0017.1.01.4	CR	BS550(IND)-10-05-05	AXLE
6759	5.07.0018.1.01.5	CR	BS500W(IND)-13-26	MOUNTING AXLE
6760	5.07.0019.1.01.6	CR	DPZ440-05-13	AXLE SLEEVE

6761	5.07.0020.1.01.7	CR	DPZ440-05-10	MOUNTING AXLE 50X170
6762	5.07.0021.1.01.8	CR	DPZ440-05-17	MOUNTING AXLE 50X200
6763	5.07.0022.1.01.9	CR	DPZ440-05-15	MOUNTING AXLE 55X450
6764	5.07.0023.1.01.1	CR	BS500W(IND)-13-01-11	UPPER MOUNTING AXLE OF VERTICAL CYLINDER 40X317
6765	5.07.0024.1.01.2	CR	BS500W(IND)-13-01-14	MOUNTING AXLE 40X162 -1
6766	5.07.0025.1.01.3	CR	BS500W(IND)-13-01-16	MOUNTING AXLE 40X162 -2
6767	5.07.0026.1.01.4	CR	BS500W(IND)-13-01-20	AXLE
6768	5.07.0027.1.01.5	CR	BS500W(IND)-13-20-05	MOUNTING AXLE-1
6769	5.07.0028.1.01.6	CR	BS500W(IND)-13-20-08	MOUNTING AXLE-2
6770	5.07.0029.1.01.7	CR	BS500W(IND)-13-20-09	MOUNTING AXLE 30X170
6771	5.07.0030.1.01.8	PL	UD64.1355Z/UD64.54Z	RING GEAR/DRIVE CROWN WHEEL
6772	5.07.0031.1.01.9	PL	WN02.120.184.1.1668/1676-2	DRIVE AXLE
6773	5.07.0032.1.01.1	PL	WN02.120.184.1.1668/1676-4	DRIVE AXLE
6774	5.07.0033.1.01.2	PL	WN04-1676.850.2040-1-V03	DRIVE AXLE SET VMS
6775	5.07.0034.1.01.3	PL	WN04-1676.850.2040-1-V05	DRIVE AXLE SET VMS
6776	5.07.0035.1.01.4	LO	100148	SEAL-ROD 4.00IDx4.50 ODX.25
6777	5.07.0036.1.01.5	PL	61. 02. 236	Piston
6778	5.07.0037.1.01.6	PL	UD70.251	Intermediate Bearing
6779	5.07.0038.1.01.7	PL	64.02.2110	Bush
6780	5.07.0039.1.01.8	PL	CU6 I .8601SPI66	Additional Drive axle
6781	5.07.0040.1.01.9	PL	63.09.2080	AXLE
6782	5.07.0041.1.01.1	PL	WN04.1676.900.2105.1	DRIVE AXLE FOR BCM
6783	5.07.0042.1.01.2	PL	CU61.8601SP1668/1676	ADDL DRIVE AXLE
6784	5.07.0043.1.01.3	PL	WN70.1518	TUBE
6785	5.07.0044.1.01.4	PL	WN03-150.210.1.1668-1	Idling Axle
6786	5.07.0045.1.01.5	PL	64.02.3034	Tube
6787	5.07.0046.1.01.6	PL	WN02-150.210.1.1668-3	POWERED AXLE
6788	5.07.0047.1.01.7	PL	UD64.1300/3, 55/180	DRIVE AXLE ASSY-2
6789	5.07.0048.1.01.8	PL	UD64.1300/3.09/180W BL1(C)/BL2	DRIVE AXLE ASSY-2
6790	5.07.0049.1.01.9	PL	CU62.2600A(B)/WN03-120.184.1.1668/1676	IDLE AXLE ASSY
6791	5.07.0050.1.01.1	PL	WN01-730.184.IND.R7-2	IDLE AXLE ASSY
6792	5.07.0051.1.01.2	PL	WN03-120.184.1.1668/1676-1	RUNNING AXLE
6793	5.07.0052.1.01.3	PL	WN71.100KGV	DRIVE AXLE ASSY-2
6794	5.07.0053.1.01.4	PL	WN05-1676.900.2105-2	IDLE AXLE ASSY
6795	5.07.0054.1.01.5	PL	WN71.100KGV(C)	DRIVE AXLE ASSY
6796	5.07.0055.1.01.6	PL	WN63.01Z13KN/D6,5KN	Shock Absorber for BCM/FRM
6797	5.07.0056.1.01.7	PL	UD15.5651	AXLE
6798	5.08.0001.1.01.7	PL	WN 01-920-210-IND-7-1	WHEEL DISC
6799	5.08.0002.1.01.8	AM	16022	MOTORISED WHEEL - T 28
6800	5.08.0003.1.01.9	AM	16023	NON MOTORISED WHEEL - T 28
6801	5.08.0004.1.01.1	GE	CDCK16A-56-10-00	Lining wheel inst.
6802	5.08.0005.1.01.2	LO	113807	CARRIAGE WHEEL ASSEMBLY
6803	5.08.0006.1.01.3	LO	145472	AXLE WELDT WHEEL
6804	5.08.0007.1.01.4	LO	209926	WHEEL RIM 16.00 IN; 18.53 ODX 8.00IDX 5.50 W
6805	5.08.0008.1.01.5	PL	EL-T2105.00-KPL.	DISTANCE MEASURING WHEEL
6806	5.09.0001.1.01.8	PL	EMI 41.1067.1040 LG	DRIVE SHAFT
6807	5.09.0002.1.01.9	PL	EMI 6300.1008	PISTON
6808	5.09.0003.1.01.1	PL	EMI 6300.1009	PUMP CYLINDER (BEVEL GEAR LUB PUMP)
6809	5.09.0004.1.01.2	PL	G 10.39 PAS DU	CONE TUBE
6810	5.09.0005.1.01.3	PL	PB 61.301	AXLE BOGIE FRAME (CSM)
6811	5.09.0006.1.01.4	PL	PB 61.470	INTERMEDIATE BEARING
6812	5.09.0007.1.01.5	PL	PB 61-05	TORQUE SUPPORT (TORQUE ARM PLATE)
6813	5.09.0008.1.01.6	PL	PB 61-10	TORQUE SUPPORT (TORQUE ARM PLATE)
6814	5.09.0009.1.01.7	PL	RE 14.101	HYD. DRIVE GEAR BOX
6815	5.09.0010.1.01.8	PL	UD 61.12801.SP 1668/1676	DRIVE BOGIE FRAME FOR DUO
6816	5.09.0011.1.01.9	PL	UD 61.2831	CENTER PIN (BOGIE PIVOT)
6817	5.09.0012.1.01.1	PL	UD 61.31	PIVOT
6818	5.09.0013.1.01.2	PL	UD 61.5451	INTERMEDIATE BEARING
6819	5.09.0014.1.01.3	PL	UD 61.5460	INTERMEDIATE BEARING
6820	5.09.0015.1.01.4	PL	UD 61.605.55 SHORE	DISC SPRING
6821	5.09.0016.1.01.5	PL	UD 61.7880(A)	INTERMEDIATE BEARING (NEW DUO)
6822	5.09.0017.1.01.6	PL	UD 61.9201.SP 1668/1676 D	DRIVE AXLE BOGIE FRAME (UNI)
6823	5.09.0018.1.01.7	PL	UD 61-2635-02	ROD
6824	5.09.0019.1.01.8	PL	UD 61-9901-SP-1668-1676 R	RUNNING AXLE BOGIE FRAME (UNI)
6825	5.09.0020.1.01.9	PL	UD 62.5605	AXLE BEARING BODY
6826	5.09.0021.1.01.1	PL	UD 64.302	HELICAL GEAR OF 28 TEETH
6827	5.09.0022.1.01.2	PL	UD 64.903	HELICAL GEAR OF 28 TEETH
6828	5.09.0023.1.01.3		Shifted to Ann-III A	
6829	5.09.0024.1.01.4	PL	UD64.1017G	OIL SUMP
6830	5.09.0025.1.01.5	PL	UD64.1304	SLIDING RING
6831	5.09.0026.1.01.6	CR	BS550(IND)-20-04-00	DRIVING DEVICE HOISTING PEDESTAL

6832	5.09.0027.1.01.7	CR	BS550(IND)-20-01-00	DRIVING SUSPENSION DEVICE
6833	5.09.0028.1.01.8	CR	BS550(IND)-21-00	Idle Bogie (Complete unit)
6834	5.09.0029.1.01.9	PL	WN63.14ZD6KN	SHOCK ABSORBER
6835	5.09.0030.1.01.1	LO	252351-109	BOGIE SYSTEM MAINTENANCE KIT, SMALL
6836	5.09.0031.1.01.2	LO	252351-110	BOGIE SYSTEM MAINTENANCE KIT, LARGE
6837	5.09.0032.1.01.3	LO	252351-111	BOGIE SYSTEM REPAIR KIT, SMALL
6838	5.09.0033.1.01.4	LO	252351-112	BOGIE SYSTEM REPAIR KIT, MED
6839	5.09.0034.1.01.5	LO	252351-113	BOGIE SYSTEM REPAIR KIT, LARGE
6840	5.09.0035.1.01.6	LO	252351-114	BOGIE SYSTEM OVERHAUL KIT
6841	5.09.0036.1.01.7	LO	252351-147	BOGIE SYSTEM MAINTENANCE KIT, SMALL
6842	5.09.0037.1.01.8	LO	252351-148	BOGIE SYSTEM MAINTENANCE KIT, LARGE
6843	5.09.0038.1.01.9	LO	252351-149	BOGIE SYSTEM REPAIR KIT
6844	5.09.0039.1.01.1	PL	UD61.7872	Shaft
6845	5.09.0040.1.01.2	PL	UD186.020-3-4	PLATE(Sylomer plate)
6846	5.09.0041.1.01.3	PL	UD186.020.2-3	PLATE(Sylomer plate)
6847	5.09.0042.1.01.4	PL	UD186.020.2-2	PLATE(Sylomer plate)
6848	5.09.0043.1.01.5	PL	UD62.2605	RING
6849	5.09.0044.1.01.6	PL	UD214.3904 SP1668/1676	BRAKE BRIDGE
6850	5.09.0045.1.01.7	PL	WN63.13ZD2,5KN	SHOCK ABSORBER
6851	5.09.0046.1.01.8	PL	3FWG000.04.077.041,	SLIDING INSERT
6852	5.09.0047.1.01.9	PL	UD61.22680-1	MUD GUARD MIRRORRED
6853	5.09.0048.1.01.1	PL	WN63.01ZD20KN	Shock Absorber
6854	5.09.0048.1.01.2	PL	C61.400-I	Spring Pot
6855	5.09.0049.1.01.3	PL	WN80.2604-52	Pump Flange
6856	5.09.0050.1.01.4	LO	159431	CARRIAGE FRAME ASSY; 1676MM 12 STONE
6857	5.09.0051.1.01.5	LO	159434	CARRIAGE AXLE WELDT; RGI 1676MM GAUGE
6858	5.09.0052.1.01.6	LO	159448	CARRIAGE ASSY; 1676 GUAGE RGI INDIA
6859	5.10.0001.1.01.9	PL	62-03-123	CROWN WHEEL HAND BRAKE
6860	5.10.0002.1.01.1	PL	62-03-124	CROWN WHEEL HAND BRAKE
6861	5.10.0003.1.01.2	PL	741401 MITTEL	MAGGIE FLEXIBLE WASHER
6862	5.10.0004.1.01.3	PL	741444 MITTEL	MAGGIE FLEXIBLE WASHER
6863	5.10.0005.1.01.4	PL	E63.118	SHOCK ABSORBER (EYE BORE 25.4)
6864	5.10.0006.1.01.5	PL	UD 61-4903	TORQUE SUPPORT PLATE
6865	5.10.0007.1.01.6	PL	UD 61-4912	TORQUE SUPPORT PLATE
6866	5.10.0008.1.01.7	PL	UD63.1051	TORQUE PLATE
6867	5.10.0009.1.01.8	PL	WN 131-23,5-147-335-1-DB	SPRING
6868	5.10.0010.1.01.9	PL	WN 131-35-223-335-1-DB	SPRING
6869	5.10.0011.1.01.1	PL	WN63.01ZD2,62KN	SHOCK ABSORBER
6870	5.10.0012.1.01.2		Shifted to Ann-II	
6871	5.10.0013.1.01.3	PL	WN63.03ZD0,5KN-A	SHOCK ABSORBER
6872	5.10.0014.1.01.4	PL	WN63.04ZD2,75KN	SHOCK ABSORBER
6873	5.10.0015.1.01.5	PL	2161976	SPRING
6874	5.10.0016.1.01.6	PL	2-05196	ADAPTER PLATE
6875	5.10.0017.1.01.7	PL	732073-MG-650-S4	Maggie Spring
6876	5.10.0018.1.01.8	KA	YK923.00.00.02	Maggie Flexible Washer
6877	5.10.0019.1.01.9	CR	HU20049	UNIT BRAKE-2
6878	5.10.0020.1.01.1	PL	UD214.4104-SP.1668/1676	BRAKE BAR
6879	5.10.0021.1.01.2	PL	UD214.4105-SP.1668/1676	BRAKE BAR
6880	5.10.0022.1.01.3	PL	UD215.1406	BRAKE LEVER
6881	5.10.0023.1.01.4	PL	UD230.352	FORK HEAD
6882	5.10.0024.1.01.5	KE	732106	BRAKE BLOCK
6883	5.10.0025.1.01.6	LO	250356	SHOE BRAKE, TYPE K; IR, 1000MM WHEEL
6884	5.10.0026.1.01.7	LO	252351-108	BRAKE STAND REPAIR KIT
6885	5.10.0027.1.01.8	LO	252351-115	BRAKE SYSTEM MAINTENANCE KIT, SMALL
6886	5.10.0028.1.01.9	LO	252351-116	BRAKE SYSTEM MAINTENANCE KIT, MED
6887	5.10.0029.1.01.1	LO	252351-117	BRAKE SYSTEM MAINTENANCE KIT, LARGE
6888	5.10.0030.1.01.2	LO	252351-150	BRAKE SYSTEM MAINTENANCE KIT, SMALL
6889	5.10.0031.1.01.3	LO	252351-151	BRAKE SYSTEM MAINTENANCE KIT, MED
6890	5.10.0032.1.01.4	LO	252351-152	BRAKE SYSTEM MAINTENANCE KIT, LARGE
6891	5.10.0033.1.01.5	PL	WN63.01Z13KN/	Shock Absorber (FRM)
6892	5.10.0034.1.01.6	PL	WN 160-40.440- 1	Rod
6893	5.10.0035.1.01.7	PL	WN146.920.K1.A	BRAKE SHOE
6894	5.10.0036.1.01.8	PL	UD61.2635	TORQUE SUPPORT
6895	5.10.0037.1.01.9	PL	WN121.35.2.40P7.25.1	BUSH

6896	5.10.0038.1.01.1	PL	33X25.4X20	BUSH
6897	5.10.0039.1.01.2	PL	45X35.4X30	BUSH
6898	5.10.0040.1.01.3	PL	WN160-45.370-1	CROTCH (Brake Rod)
6899	5.10.0041.1.01.4	PL	WN160-45.370-1L	CROTCH (Brake Rod)
6900	5.10.0042.1.01.5	PL	UD215.1331	TIE ROD
6901	5.10.0043.1.01.6	PL	UD215.1332	TIE ROD
6902	5.10.0044.1.01.7	PL	UD215.1215	TIE ROD
6903	5.10.0045.1.01.8	PL	NZ60.01-9	FORK HEAD
6904	5.10.0046.1.01.9	PL	WN81.201G	HOUSING
6905	5.10.0047.1.01.1	PL	WN81.305	FLANGE
6906	5.10.0048.1.01.2	PL	UD64.76	FLANGE
6907	5.10.0049.1.01.3	HA	COMP-HCL-79864	BRAKE SHOE
6908	5.12.0001.1.01.2	PL	2-05199	ADAPTER PLATE
6909	5.12.0002.1.01.3	PL	2-05776 SUB. 2-22155	SEAL RING Part No. 2-05776 SUBST 2-22155 = 03 Nos.
6910	5.12.0003.1.01.4	PL	2-05921 (A.302943) 2.4W	PISTON RING 52 DIA
6911	5.12.0004.1.01.5	PL	2-05921 (A.302943) 3.6W	PISTON RING 52 DIA
6912	5.12.0005.1.01.6	PL	2-05922	O RING
6913	5.12.0006.1.01.7	PL	2-05928	SEAL RING
6914	5.12.0007.1.01.8	PL	2-05929	SEAL RING
6915	5.12.0008.1.01.9	PL	2-05936 SUB. A.305784	SEAL RING
6916	5.12.0009.1.01.1	PL	2-05940	SEAL RING
6917	5.12.0010.1.01.2	PL	2-05949	PISTON GASKET
6918	5.12.0011.1.01.3	PL	2-05974	SNAP RING
6919	5.12.0012.1.01.4	PL	2-06734	SNAP RING
6920	5.12.0013.1.01.5	PL	2-06782	SNAP RING
6921	5.12.0014.1.01.6	PL	2-06794	SNAP RING
6922	5.12.0015.1.01.7	PL	2-06796	SNAP RING
6923	5.12.0016.1.01.8	PL	21.89X2.62 NBR90	O RING
6924	5.12.0017.1.01.9	PL	210-033/04/00	ANGLE GEAR
6925	5.12.0018.1.01.1	PL	2-12270	SNAP RING
6926	5.12.0019.1.01.2	PL	2-15054	PISTON HOUSING
6927	5.12.0020.1.01.3	PL	2-15055	PISTON HOUSING
6928	5.12.0021.1.01.4	PL	2-17202	SNAP RING
6929	5.12.0022.1.01.5	PL	2-17981	PRESSURE SPRING
6930	5.12.0023.1.01.6	PL	2-17982	DISC
6931	5.12.0024.1.01.7	PL	2-17984	PRESSURE SPRING
6932	5.12.0025.1.01.8	PL	2-18176	PRESSURE SPRING
6933	5.12.0026.1.01.9	PL	2-18177	PRESSURE SPRING
6934	5.12.0027.1.01.1	PL	2-18672	PRESSURE PLATE
6935	5.12.0028.1.01.2	PL	2-18677	SNAP RING
6936	5.12.0029.1.01.3	PL	2-18678	SNAP RING
6937	5.12.0030.1.01.4	PL	2-18693	SNAP RING
6938	5.12.0031.1.01.5	PL	2-18710	PRESSURE PLATE
6939	5.12.0032.1.01.6	PL	2-18785	WASHER
6940	5.12.0033.1.01.7	PL	2-20884	PISTON
6941	5.12.0034.1.01.8	PL	2-20900	SPLIT RING
6942	5.12.0035.1.01.9		Repeated item	
6943	5.12.0036.1.01.1	PL	2244571/KG2394.112.054	CLUTCH CYLINDER
6944	5.12.0037.1.01.2	PL	2-24570	SEAL RING
6945	5.12.0038.1.01.3	PL	24.99X3.53-N-DIN3771-NBR90	O-RING
6946	5.12.0039.1.01.4	PL	278.77X5.33-N-DIN3771-NBR90	O-RING
6947	5.12.0040.1.01.5	PL	32.97X3.53 NBR90	O RING
6948	5.12.0041.1.01.6	PL	3-20210	ADAPTER PLATE
6949	5.12.0042.1.01.7	PL	3-20212	ADAPTER PLATE
6950	5.12.0043.1.01.8	PL	3-20892	PISTON UNIT
6951	5.12.0044.1.01.9	PL	37.69X3.53-N-DIN3771-NBR90	O-RING
6952	5.12.0045.1.01.1	PL	5/8 Z-DIN-5401/III	STEEL BALL
6953	5.12.0046.1.01.2	PL	61.02.242	SPACER RING
6954	5.12.0047.1.01.3	PL	61.02.244	RING
6955	5.12.0048.1.01.4	PL	61.02.247	SPACER RING
6956	5.12.0049.1.01.5	PL	61-02-236	PISTON
6957	5.12.0050.1.01.6	PL	61-02-237	VALVE BUSH
6958	5.12.0051.1.01.7	PL	61-02-239	SPACER RING
6959	5.12.0052.1.01.8	PL	61-02-240	SPRING
6960	5.12.0053.1.01.9	PL	61-02-241	SPRING
6961	5.12.0054.1.01.1	PL	64.02+D4161:D4181.2000.51STKL	COUPLING
6962	5.12.0055.1.01.2	PL	0367	VALVE Part No. 2-03763 = 01 No.
6963	5.12.0056.1.01.3	PL	05199	ADAPTER PLATE Part No.2-05199 = 08 Nos.
6964	5.12.0057.1.01.4	PL	05928	SEAL RING Part No. 2-05928 = 01 No.
6965	5.12.0058.1.01.5	PL	05929	SEAL RING Part No.2-05929 = 01 No.
6966	5.12.0059.1.01.6	PL	05940	SEAL RING Part No. 2-05940 = 01 No.
6967	5.12.0060.1.01.7	PL	06734	SNAP RING Part No.2-06734 = 03 Nos.
6968	5.12.0061.1.01.8	PL	06794	SNAP RING Part No. 2-06794 = 01 No.
6969	5.12.0062.1.01.9	PL	06796	SNAP RING Part No.2-06796 = 01 No.
6970	5.12.0063.1.01.1	PL	2. 15054	PISTON HOUSING Part No. 2-15054 = 01 No.

6971	5.12.0064.1.01.2	PL	2 .15055	PISTON HOUSING Part No. 2-15055 = 01 No.
6972	5.12.0065.1.01.3		Repeated item	
6973	5.12.0066.1.01.4		Repeated item	
6974	5.12.0067.1.01.5		Repeated item	
6975	5.12.0068.1.01.6	PL	18677	SNAP RING Part No. 2-18677 = 01 No.
6976	5.12.0069.1.01.7	PL	18678	SNAP RING Part No. 2-18678 = 01 No.
6977	5.12.0070.1.01.8	PL	20210	ADAPTER PLATE Part No. 3-20210 = 09 Nos.
6978	5.12.0071.1.01.9	PL	20884	PISTON Part No. 2-20884 = 01 No.
6979	5.12.0072.1.01.1	PL	20892	PISTON UNIT Part No. 3-20892 = 01 No.
6980	5.12.0073.1.01.2	PL	3.20896	DRUM-UNIT Part No. 3-20896 = 01 No.
6981	5.12.0074.1.01.3	PL	24570	SEAL RING Part No. 2-24570 = 03 Nos.
6982	5.12.0075.1.01.4	PL	64.02.2000.52STKL	COUPLING Consisting of
6983	5.12.0076.1.01.5	PL	2.03761	VALVE
6984	5.12.0077.1.01.6		Repeated item	
6985	5.12.0078.1.01.7		Repeated item	
6986	5.12.0079.1.01.8	PL	2=05922	O-RING Part No. 2-05922 = 01 No.
6987	5.12.0080.1.01.9	PL	2-25949	PISTON GASKET Part No. 2-05949 = 01 No.
6988	5.12.0081.1.01.1		Repeated item	
6989	5.12.0082.1.01.2		Repeated item	
6990	5.12.0083.1.01.3		Repeated item	
6991	5.12.0084.1.01.4		Repeated item	
6992	5.12.0085.1.01.5		Repeated item	
6993	5.12.0086.1.01.6	PL	2.18513	PISTON HOUSING Part No. A2-18513 = 01 No.
6994	5.12.0087.1.01.7		Repeated item	
6995	5.12.0088.1.01.8		Repeated item	
6996	5.12.0089.1.01.9		Repeated item	
6997	5.12.0090.1.01.1	PL	2.19692	PISTON UNIT Part No. A3-19692 = 01 No.
6998	5.12.0091.1.01.2	PL	2.20212	ADAPTER PLATE Part No. 3-20212 = 09 Nos.
6999	5.12.0092.1.01.3	PL	2.20994	PISTON HOUSING Part No. A2-20994 = 01 No.
7000	5.12.0093.1.01.4		Repeated item	
7001	5.12.0094.1.01.5	PL	2.22223	PISTON Part No. A2-22223 = 01 No.
7002	5.12.0095.1.01.6	PL	64.02.2101	CLUTCH GEAR WHEEL
7003	5.12.0096.1.01.7	PL	64.02.2103	CLUTCH GEAR WHEEL
7004	5.12.0097.1.01.8	PL	64.08.8319	PLATE
7005	5.12.0098.1.01.9	PL	64-02-2000-129STKL	COUPLING FOR BCM & FRM
7006	5.12.0099.1.01.1	PL	64-02-2000-130STKL	COUPLING FOR BCM & FRM
7007	5.12.0100.1.01.2	PL	64-09-1348	PRESSURE SPRING
7008	5.12.0101.1.01.3	PL	A2-18513	PISTON HOUSING
7009	5.12.0102.1.01.4	PL	A2-20994	PISTON HOUSING
7010	5.12.0103.1.01.5	PL	A2-22223	PISTON
7011	5.12.0104.1.01.6	PL	A3-19692	PISTON UNIT
7012	5.12.0105.1.01.7	PL	A3-20898	NAVE UNIT
7013	5.12.0106.1.01.8	PL	A3-29200	NAVE-UNIT
7014	5.12.0107.1.01.9	PL	A3-29204	DRUM-UNIT
7015	5.12.0108.1.01.1	PL	A38X44X1,5DIN7603-CU	SEAL RING
7016	5.12.0109.1.01.2	PL	ATD70-90-6DIN3760-NB	SEAL RING
7017	5.12.0110.1.01.3	PL	SU 1702-21-1-6	NAVE UNIT
7018	5.12.0111.1.01.4	PL	U61.103	PRESSURE DISC
7019	5.12.0112.1.01.5	PL	UD 70-1301	CLUTCH BELL HOUSING
7020	5.12.0113.1.01.6	PL	UD 70-4532	DRIVE SHAFT
7021	5.12.0114.1.01.7	PL	UD 76-03	SPUR WHEEL
7022	5.12.0115.1.01.8	PL	UD 76-16	CLUTCH ACTUATING ASSY.
7023	5.12.0116.1.01.9	PL	UD 76-205	SPLINED SHAFT
7024	5.12.0117.1.01.1	PL	UD 76-216	FLANGE
7025	5.12.0118.1.01.2	PL	UD 76-803	SPUR WHEEL
7026	5.12.0119.1.01.3	PL	WN 152-5480-12/24-1	CARRIER
7027	5.12.0120.1.01.4	PL	WN 152-5480-16/32-1	CARRIER
7028	5.12.0121.1.01.5	PL	WN 152-5480-5480-2	CARRIER
7029	5.12.0122.1.01.6	PL	WN 152-5480-5480-5	CARRIER
7030	5.12.0123.1.01.7	PL	WN 152-5480-5480-6	CARRIER FOR FRM SPLITTER BOX
7031	5.12.0124.1.01.8	PL	WN 21-61-95-6-1	WASHER
7032	5.12.0125.1.01.9	PL	WN 67-00C	CARRIER
7033	5.12.0126.1.01.1	PL	2-05921(A-302943)2.4W	PISTON RING 55 DIA
7034	5.12.0127.1.01.2	PL	3-20896	DRUM UNIT
7035	5.12.0128.1.01.3		Repeated item	

7036	5.12.0129.1.01.4			Repeated item
7037	5.12.0130.1.01.5			Repeated item
7038	5.12.0131.1.01.6	PL	62.09.1008	PRESSURE SPRING
7039	5.12.0132.1.01.7			Shifted to Ann-II
7040	5.12.0133.1.01.8	PL	64.02.2109	SPACER RING
7041	5.12.0134.1.01.9	PL	E4245.1.01.8 PL	SLEEVE RING
7042	5.12.0135.1.01.1	PL	A2-20994	PISTON HOUSING
7043	5.12.0136.1.01.2			Repeated item
7044	5.12.0137.1.01.3			Repeated item
7045	5.12.0138.1.01.4			Repeated item
7046	5.12.0139.1.01.5	PL	2-03763	VALVE
7047	5.12.0140.1.01.6	PL	WN74.303	SPUR WHEEL
7048	5.12.0141.1.01.7	PL	WN74.304	SPUR WHEEL
7049	5.12.0142.1.01.8	PL	WN70.3400-111	DRIVE SHAFT
7050	5.12.0143.1.01.9	PL	UD73.504	DRIVE SHAFT
7051	5.12.0144.1.01.1	PL	WN152-5480.5480-10	CARRIER
7052	5.12.0145.1.01.2	PL	M63.254-DB	PRESSURE SPRING
7053	5.12.0146.1.01.3	CR	40100378-090	PISTON, CLUTCH
7054	5.12.0147.1.01.4	PL	64.04.2118	Clutch Bearing
7055	5.12.0148.1.01.5	PL	62.04.329	CLUTCH FLANGE
7056	5.12.0149.1.01.6	PL	WN220.79	ELASTIC CLUTCH
7057	5.13.0001.1.01.3	PL	64.04.3000.114	MAIN GEAR BOX FRONT FOR BCM
7058	5.13.0002.1.01.4	PL	64.04.3000.115	MAIN GEAR BOX REAR FOR BCM
7059	5.13.0003.1.01.5	PL	EM-1045-MR-1/3-55	REDUCTION GEAR BOX ASSEMBLY COMPLETE
7060	5.13.0004.1.01.6			Shifted to Ann-II
7061	5.13.0005.1.01.7	PL	-	TURRET GEAR BOX
7062	5.13.0006.1.01.8	PL	---	PUMP DRIVE GEAR BOX FOR 09-3X
7063	5.13.0007.1.01.9	PL	---	PUMP DRIVE GEAR BOX FOR MPT
7064	5.13.0008.1.01.1	KE	799108	TRANSMISSION GEAR BOX FOR BRM
7065	5.13.0009.1.01.2	HA	H-3191 W01	GEAR BOX & AXLE ASSY. OF TRT,SL. NO.144,146,147
7066	5.13.0010.1.01.3	PH	UTV1.02/04/00	DROP DOWN GEAR BOX COMPLETE
7067	5.13.0011.1.01.4	KA	51.00.00.000.14	HYD.TRANSMISSION GEAR BOX
7068	5.13.0012.1.01.5	PL	WN43.00/EM1045F/701/00-OMT	REDUCTION GEAR BOX
7069	5.13.0013.1.01.6	GE	FAP-200	Auxiliary driving axle gearbox
7070	5.13.0014.1.01.7	GE	GEO-15K	Transmission Gear Box
7071	5.13.0015.1.01.8	GE	RR510MS/I- 4(154B5751M5+154-2259+154-5986)	Reduction box
7072	5.13.0016.1.01.9	CR	BS550(IND)-20-06-00	GEAR BOX WHEELSET -
7073	5.13.0017.1.01.1	CR	KDM 215	AXEL GEAR BOX (Complete)
7074	5.13.0018.1.01.2	PL	UD62.3900.1	SATELLITE AXEL GEAR BOX ASSY
7075	5.13.0019.1.01.3	PL	WN70.1200	GEAR BOX ASSY
7076	5.13.0020.1.01.4	PL	WN152.5480.16/32-4	CARRIER,
7077	5.13.0021.1.01.5	PL	WN152.5480.5480.5	CARRIER
7078	5.13.0022.1.01.6	PL	WN80.6700	PUMP GEAR BOX FOR NEW M/Cs
7079	5.13.0023.1.01.7	PL	WN80.7400(A)	PUMP GEAR BOX
7080	5.13.0024.1.01.8	PL	WN70.3400A	ADDITIONAL DRIVE AXLE GEAR BOX
7081	5.13.0025.1.01.9	PL	EB-64.04.3000.182 (64.04.200.182)	MAIN GEAR BOX-2(REAR)
7082	5.13.0026.1.01.1	PL	4677.07.09902 (WN80.2600F/1-042-2)	MAIN GEAR BOX-2
7083	6.01.0001.1.01.1	GE	TE03-02.01.00A-XF	Tamping uplift cylinder
7084	6.01.0002.1.01.2	GE	50.18	Squeeze cylinder
7085	6.01.0003.1.01.3	CR	40108603	Tool tilting cylinder
7086	6.01.0004.1.01.4	PL	HZSA-G-150.273	Squeezing cylinder big female complete
7087	6.01.0005.1.01.5	PL	HZSI-A-36.426/ HXSI-A-40-425	Squeezing cylinder small male complete
7088	6.01.0006.1.01.6	PL	HZSI-G-52.425 & UD19.1230/ HXSI-A-G- 57,5.246/UD19.12 30	Squeezing cylinder small fenule complete with counterweight
7089	6.03.0001.1.01.3	CR	23081889	Left outside tamping arm
7090	6.03.0002.1.01.4	CR	23081890	Right outside tamping arm
7091	6.03.0003.1.01.5	CR	23081891	Left inside tamping arm
7092	6.03.0004.1.01.6	CR	23081892	Right inside tamping arm
7093	6.03.0005.1.01.7	CR	23081888	Right tamping arm
7094	6.03.0006.1.01.8	CR	23081887	Left tamping arm
7095	6.03.0007.1.01.9	CR	23079887	LEFT TAMPING ARM
7096	6.03.0008.1.01.1	CR	23079888	RIGHT TAMPING ARM
7097	6.03.0009.1.01.2	PL	CM38X1,5DIN7604-M.MAG.	MAGNET LOCK SCREW
7098	6.03.0010.1.01.3	PL	WN02-120.184.1.1668/1676-1	DRIVE AXLE -
7099	6.03.0011.1.01.4	PL	UD67.2990-2RE	BLOCK
7100	6.03.0012.1.01.5	PL	UD67.2990-2LI	BLOCK
7101	6.03.0013.1.01.6	PL	UD64.46.0,15MM	DISTANCE WASHER
7102	6.03.0014.1.01.7	PL	UD64.48.0,4	DISTANCE WASHER.
7103	6.04.0001.1.01.4	CR	23086759	Vibration shaft assembly
7104	6.04.0002.1.01.5	CR	23078330	Eccentric Shaft

7105	6.05.0001.1.01.5	GE	TE03-01.02.33	Screw, against the tamping time
7106	6.05.0002.1.01.6	GE	CDCK16A-56-06-00	Center post
7107	6.05.0003.1.01.7	GE	GB/T2509 20-26-30	Copper alloy integrated axle bushing-1
7108	6.05.0004.1.01.8	GE	GB/T2509 25-32-30	Copper alloy integrated axle bushing-2
7109	6.05.0005.1.01.9	GE	CDC16A-56(I)-02-09	Position-limited plate
7110	6.05.0006.1.01.1	GE	PM5050DX	Sleeve-1
7111	6.05.0007.1.01.2	GE	PM5030DX	Sleeve-2
7112	6.05.0008.1.01.3	GE	4N-04	Plug
7113	6.05.0009.1.01.4	CR	BS550(IND)-20-05-01	PIN-1
7114	6.05.0010.1.01.5	CR	BS550(IND)-20-05-03	PIN-2
7115	6.05.0011.1.01.6	CR	GB/Y882-B16X90X84	PIN-3
7116	6.05.0012.1.01.7	CR	BS550(IND)-20-07-06	CENTER PIN OF CENTER PLATE
7117	6.05.0013.1.01.8	CR	40100378-094	PIN, SOLID
7118	6.05.0014.1.01.9	CR	BS550-07-04	PIN-1
7119	6.05.0015.1.01.1	CR	BS550-07-02-17-04	PIN-2
7120	6.05.0016.1.01.2	CR	BS550-07-02-18	PIN-3
7121	6.05.0017.1.01.3	CR	BS550(IND)-09-30	PIN-1
7122	6.05.0018.1.01.4	CR	BS550(IND)-09-41	PIN-2
7123	6.05.0019.1.01.5	CR	BS550-10-16-08	PIN
7124	6.05.0020.1.01.6	CR	BS500W(IND)-13-01-09	SLEEVE
7125	6.05.0021.1.01.7	CR	BS500W(IND)-13-01-10	SLEEVE 2
7126	6.05.0022.1.01.8	CR	23067096	PIN(35mm)Near vibration shaft
7127	6.05.0023.1.01.9	CR	23067097	PIN(35mm)away from vibration shaft
7128	6.05.0024.1.01.1	CR	23067098	PIN(35mm)Vertical
7129	6.05.0025.1.01.2	CR	20261423	Tamping arm Pin(55mm)
7130	6.05.0026.1.01.3	CR	20261429	Shaft(65mm Pin)
7131	6.05.0027.1.01.4	CR	23069831	PIN
7132	6.05.0028.1.01.5	PL	V 40. CPD 510	V.Ring
7133	6.05.0029.1.01.6	PL	DL10.56	Cover
7134	6.05.0030.1.01.7	PL	UD67.2990.5	BOLT
7135	6.05.0031.1.01.8	PL	UD67.2905	SLIDE PLATE
7136	6.05.0032.1.01.9	PL	UD313.3000.SP1668/1676	LIFTING AND LINING UNIT
7137	6.05.0033.1.01.1	CR	20261435	Bolt for Tool Adjustment of Tamping Unit grade 10.9
7138	6.05.0034.1.01.2	CR	20261434	Bolt for Tool Adjustment of Tamping Unit grade 10.9
7139	6.06.0001.1.01.6	CR	23067100	Pin bushing
7140	6.06.0002.1.01.7	CR	23067101	Pin bushing
7141	6.07.0001.01.6	PL	WN151-180.5463-5	Flange
7142	6.08.0001.1.01.8	GE	CU30.6820	Alloy tamping tine-9
7143	6.08.0002.1.01.9	GE	CU30.2723	Alloy tamping tine-8
7144	6.08.0003.1.01.1	CR	80264411938	TAMPING TOOLS
7145	6.08.0004.1.01.2	CR	80264411108	TAMPING TOOLS
7146	6.08.0005.1.01.3	CR	80264412930	TAMPING TOOLS
7147	6.08.0006.1.01.4	CR	80264411938=08 80264411108=08	Tamping Tools (TCTT) For PCT
7148	6.08.0007.1.01.5	CR	80264411938=04 80264411108=04 80264412930=08	Tamping Tools (TCTT) FOR MPT DDC - 16W
7149	6.11.0001.1.01.2	GE	CDCK16A-56-01-00	Lifting and lining bracket
7150	6.11.0002.1.01.3	GE	CDCK16A-56-02-00	Lifting hook kit
7151	6.11.0003.1.01.4	GE	CDCK16A-56-03	Guide post
7152	6.11.0004.1.01.5	GE	CDCK16A-56-05-00	Longitudinal displacement mechanism
7153	6.11.0005.1.01.6	GE	CDC16A-56(I)-02-00	Rail clamp ass.
7154	6.11.0006.1.01.7	GE	CDC16A-56(I)-19	Pin shaft-1
7155	6.11.0007.1.01.8	GE	CDCK16A-56-08-00	Locking device
7156	6.11.0008.1.01.9	GE	CDCK16A-56-02-01	Left guide sleeve
7157	6.11.0009.1.01.1	GE	CDCK16A-56-02-02	Lifting hook
7158	6.11.0010.1.01.2	GE	CDCK16A-56-02-04	Right guide sleeve
7159	6.11.0011.1.01.3	GE	GB/T1096 12-32	Flat key
7160	6.11.0012.1.01.4	GE	FI24(12-10-430)	Felt
7161	6.11.0013.1.01.5	GE	GB/T893.1 110	Retainer ring for hole-1
7162	6.11.0014.1.01.6	GE	CDCK16A-56-02-05	Cover
7163	6.11.0015.1.01.7	GE	CDCK16A-56-02-06	Bushing
7164	6.11.0016.1.01.8	GE	GB/T1152 M10-1	Oil cup
7165	6.11.0017.1.01.9	GE	CDCK16A-56-02-09	Pin shaft
7166	6.11.0018.1.01.1	GE	GB/T839.1 55	Retainer ring for hole-2
7167	6.11.0019.1.01.2	GE	CDC16A-56(I)-02-01	Clamp cylinder
7168	6.11.0020.1.01.3	GE	CDC16A-56(I)-02-02	Dual-arm clamp
7169	6.11.0021.1.01.4	GE	CDC16A-56(I)-02-03	Single-arm clamp
7170	6.11.0022.1.01.5	CR	23083964	CLAMP ROLLER ASSEMBLY
7171	6.11.0023.1.01.6	CR	23083963	TRACK LIFTING HOOK
7172	6.11.0024.1.01.7	CR	23083965	CLAMP ROLLER
7173	6.11.0025.1.01.8	CR	23085587	FRONT CLAMP ROLLER
7174	6.11.0026.1.01.9	PL	UD313.1002LI	Guide Piece.

7175	6.11.0027.1.01.1	PL	UD313.1002RE	Guide Piece.
7176	6.11.0028.1.01.2	PL	UD150.5808	LINING ROLLER
7177	6.11.0029.1.01.3	PL	UD311.314	PIN
7178	6.11.0030.1.01.4	PL	WN180.01-100-I-RE	LOCK
7179	6.11.0031.1.01.5	PL	UD67.2990-1	BLOCK
7180	6.11.0032.1.01.6	PL	UD313.3000SP1668/1676 (A)	LIFTING AND LINING UNITS
7181	6.11.0033.1.01.7	PL	CA311.5500-SP1676PIND	LIFTING AND LINING UNITS
7182	6.11.0034.1.01.8	PL	64.14.1000.82/64.14.1000.83	LIFTING CLAMP
7183	6.11.0035.1.01.9	PL	64.14.1000.84/64.14.1000.85	LIFTING CLAMP
7184	6.11.0036.1.01.1	PL	UD311.505	Track lifting roller
7185	6.11.0037.1.01.2	PL	DL150.01i	Track lifting roller
7186	6.11.0038.1.01.3	PL	UD150.01AS	Track lifting roller
7187	6.11.0039.1.01.4	PL	UD311.506	Track lifting roller
7188	6.11.0040.1.01.5	PL	GLF.311.840/350	Track lifting roller
7189	6.11.0041.1.01.6	CR	23069845	Pin of Hook Lifting Cylinder material grade EN-19
7190	6.11.0042.1.01.7	CR	23069839	Pin Of Cylinders In Lifting Lining Unit; Hook Lifting; Hook Rotation
7191	6.11.0043.1.01.8	CR	23071587	Bolt/Pin Of Track Lifting Cylinder
7192	7.01.0001.1.01.2	CR	40100378-063	BEARING, RADIAL BALL-1
7193	7.01.0002.1.01.3	CR	40100378-074	BEARING, RADIAL BALL
7194	7.01.0003.1.01.4	CR	40100378-099	BEARING, RADIAL BALL-3
7195	7.01.0004.1.01.5	CR	1308	SINGLE-ROW RADIAL BALL BEARING
7196	7.01.0005.1.01.6	CR	GB/T276-94-6020	SINGLE ROW DEEP GROOVE BALL BEARING
7197	7.01.0006.1.01.7	CR	GB-T276-104	DEEP GROOVE BALL BEARING
7198	7.01.0007.1.01.8	Shifted to Ann-II		
7199	7.01.0008.1.01.9	PL	S626ZSJA5C8/13EQL21 OR S626ZSJA5C8/13EQL 10-6	BEARING
7200	7.01.0009.1.01.1	PL	S6000ZSJA5C8/13EQL10-6 OR S6000GPRJL001	BEARING
7201	7.01.0010.1.01.2	PL	NA6193	Bearing
7202	7.02.0001.1.01.3	PH	90010010	CYLINDER ROLLER BEARING
7203	7.02.0002.1.01.4	CR	40100378-075	BEARING, CYLINDRICAL ROLLER-1
7204	7.02.0003.1.01.5	CR	40100378-078	BEARING, CYLINDRICAL ROLLER-2
7205	7.02.0004.1.01.6	PL	WN71.115/H67C and Sub : WN71.115	BEARING
7206	7.02.0005.1.01.7	PL	UD64.1306	ROLLER BEARING
7207	7.03.0001.1.01.4	GE	GE30ES-2RS	Spherical bearing
7208	7.03.0002.1.01.5	CR	41061562	SPHERICAL BEARING
7209	7.03.0003.1.01.6	AM	22308	Wheel Bearing
7210	7.04.0001.1.01.5	PH	90020012	TAPER ROLLER BEARING
7211	7.04.0002.1.01.6	PH	90020045	BEARING TAPER ROLLER
7212	7.04.0003.1.01.7	PH	UTV1.01/07/00	BEARING ROLLER
7213	7.08.0001.1.01.9	CR	41072226	Bush(pg bush)
7214	7.08.0002.1.01.1	PL	WN121-90.95.90-1	Plain bearing bush (Glacier bush)
7215	7.08.0003.1.01.2	PL	MB3520DU	BUSH
7216	7.08.0004.1.01.3	PL	PM3530DX	BUSH
7217	7.08.0005.1.01.4	LO	100115	BUSHING SLIDE 2.952 OD 2.265 BORE 3.12-12 THREAD
7218	7.08.0006.1.01.5	LO	242910	BUSHING HARDENED STEEL; 1.75IDX2.25 OD NO CANT
7219	7.08.0007.1.01.6	LO	100126	BUSHING SLIDE 4.875 OD 4.010 BORE 5.25-12 THREAD
7220	7.08.0008.1.01.7	LO	100140	BUSHING-HARDENED STEEL; P-64-10
7221	7.08.0009.1.01.8	LO	100178	BUSHING HARDENED STEEL 1.00 ID x 1.25 OD x .75LG
7222	7.08.0010.1.01.9	LO	208567	BUSHING-HARDENED STEEL; .75 ID X 1.00 OD X 1.00 LG
7223	7.09.0001.1.01.1	Shifted to Ann-II		
7224	7.09.0002.1.01.2	Shifted to Ann-II		
7225	7.09.0003.1.01.3	PL	WN70.1217/H67 C, SUB. LM236749/LM236710	TAPERED ROLLER BEARING
7226	7.09.0004.1.01.4	KE	161099	BROOM BEARING
7227	7.09.0005.1.01.5	KE	238975	UJ CROSS FOR BRM
7228	7.09.0006.1.01.6	Shifted to Ann-II		
7229	7.09.0007.1.01.7	KE	44353	KIT CROSS BEARING
7230	7.09.0008.1.01.8	KE	81859	BEARING
7231	7.09.0009.1.01.9	LO	109289	BEARING T.M. SUPPORT .03; UNDERSIZE 8.00 TWIN SEAL
7232	7.09.0010.1.01.1	GE	GB/T9163 GE35	Joint bearing
7233	7.09.0011.1.01.2	CR	BS550(IND)-10-04-02	BEARING PEDESTAL
7234	7.09.0012.1.01.3	PL	UD15.5252	BEARING BUSH
7235	7.09.0013.1.01.4	PL	UD61.10070KGV and Sub UD61.10070	INTERMEDIATE BEARING
7236	7.09.0014.1.01.5	PL	WN73.210-225	CARDAN SHAFT I.BEAING

7237	7.09.0015.1.01.6	LO	177643	BEARING SPHERICAL PLAIN; .75 ID X 1.50 OD W/PTFE (REPAIR PART FOR 206370)
7238	7.09.0016.1.01.7	LO	242904	BUSHING SLIDE 2.953 OD; 2.269 BORE
7239	7.09.0017.1.01.8	LO	H30290	BUSHING SPLIT 16-10
7240	7.09.0018.1.01.9	PL	GPC63.21F/H67C	BEARING
7241	8.01.0001.1.01.3	CR	40100378-066	SCREW, ALLEN, M10X55 (12.9)
7242	8.01.0002.1.01.4	CR	40100378-069	SCREW, ALLEN, M10X45 (12.9)
7243	8.01.0003.1.01.5	CR	40100378-096	SCREW, ALLEN, M10X30 (12.9)
7244	8.01.0004.1.01.6	CR	40100378-101	SCREW, ALLEN, M8X130 (8.8)
7245	8.01.0005.1.01.7	CR	40100378-108	SCREW, ALLEN, M14X45 (8.8)
7246	8.01.0006.1.01.8	CR	40100378-110	SCREW, ALLEN, M10X45 (8.8)
7247	8.01.0007.1.01.9	CR	GB/T78-M12X30	HEXAGON SOCKET SET SCREWS WITH CONE POINT
7248	8.01.0008.1.01.1	CR	GB/T78-M12X16	HEXAGON SOCKET SET SCREWS WITH CONE POINT
7249	8.01.0009.1.01.2	CR	16X40	Allen Bolt ISO 4762/DIN 912, Grade 12.9
7250	8.02.0001.1.01.4	CR	40100378-105	SCREW, HEX, M10X60 (8.8)
7251	8.02.0002.1.01.5	CR	GB-T5783-M12X40-12.9	BOLT M12X40-12.9
7252	8.02.0003.1.01.6	CR	GB/T5783-M8X40	BOLT M8X40
7253	8.02.0004.1.01.7	CR	GB-T5782-M12x40	BOLT M12X40
7254	8.02.0005.1.01.8	PL	10X80 FULL THREAD	Hex Head Bolts
7255	8.02.0006.1.01.9	CR	30007290	Hex Bolt 16X55 Grade 10.9
7256	8.02.0007.1.01.1	CR	30006850	Hex Bolt Size 12X35 grade 10.9
7257	8.03.0001.1.01.5	GE	GB/T93 8	Spring washer
7258	8.03.0002.1.01.6	GE	GB/T93 12	Spring washer
7259	8.03.0003.1.01.7	CR	40100378-019	WASHER, CONICAL-1
7260	8.03.0004.1.01.8	CR	40100378-111	WASHER, COPPER
7261	8.03.0005.1.01.9	CR	GB-T97.1-12	FLAT WASHER A-CLASS
7262	8.03.0006.1.01.1	CR	GB/T95-12	FLAT WASHER
7263	8.03.0007.1.01.2	GE	GB/T93 10	Spring washer-1
7264	8.03.0008.1.01.3	GE	GB/T93 16	Spring washer-3
7265	8.03.0009.1.01.4	GE	GB/T93 14	spring washer-1
7266	8.03.0010.1.01.5	GE	CDCK16A-56-07	Retainer plate
7267	8.03.0011.1.01.6	CR	CQS300-04-15-05	TAB WASHER
7268	8.03.0012.1.01.7	CR	BS550(IND)-09-12-03	WASHER-1
7269	8.03.0013.1.01.8	CR	BS550(IND)-09-55	WASHER-2
7270	8.03.0014.1.01.9	CR	DWY-S-02-03-07	CHECK WASHER
7271	8.03.0015.1.01.1	CR	23067102	TAFLON WASHER
7272	8.03.0016.1.01.2	LO	101813	WASHER SNUBBING
7273	8.03.0017.1.01.3	LO	125608	WASHER SNUBBING
7274	8.04.0001.1.01.6	CR	GB/T91-4X28	SPLIT PIN-1
7275	8.04.0002.1.01.7	CR	GB/T91-8X60	SPLIT PIN-2
7276	8.04.0003.1.01.8	CR	GB/T91-3.2X22	SPLIT PIN-3
7277	8.04.0004.1.01.9	CR	GB/T91-4X32	SPLIT PIN-4
7278	8.04.0005.1.01.1	CR	GB/T91-5x45	SPLIT PIN-5
7279	8.05.0001.1.01.7	GE	GB/T5782 M8-40	Bolt-2
7280	8.05.0002.1.01.8	CR	CDC16W(IND)-07-08	BOLT FOR HEXAGON SCREW ROD WITH HOLE
7281	8.05.0003.1.01.9	CR	GB-T32.1-M10X35	EYE BOLT M10X35
7282	8.05.0004.1.01.1	LO	157447	CLAMP T-BOLT 25.50-25.81 DIA
7283	8.05.0005.1.01.2	PL	64.08.10012	LOCKING BOLT
7284	8.05.0006.1.01.3	CR	10X110	C/S Bolt size 10x110 mm Grade 10.9
7285	8.05.0007.1.01.4	CR	10X120	C/S Bolt size 10x120 mm Grade 10.9
7286	8.06.0001.1.01.8	GE	GB/T70.1 M12-40	Screw-1
7287	8.06.0002.1.01.9	GE	M48-1.5	Slotted nut
7288	8.06.0003.1.01.1	CR	40100378-097	SCREW, SET M8X8
7289	8.06.0004.1.01.2	CR	GB-T6182-M12	PREVAILING TORQUE TYPE HEXAGON NUTS (WITH NON-METALLIC INSERT), STYLE 2
7290	8.06.0005.1.01.3	CR	GB-T6170-M8-8	TYPE 1 HEXAGONAL NUT
7291	8.06.0006.1.01.4	GE	15 GB/T70.1 M10-25	Screw-1
7292	8.06.0007.1.01.5	GE	GB/T70.1 M12-35	Screw-2
7293	8.06.0008.1.01.6	GE	GB/T6171 M14-1.5-10	nut
7294	8.06.0009.1.01.7	GE	GB/T70.1 M14-38-10.9	screw-1
7295	8.06.0010.1.01.8	GE	GB/T70.1 M16-45-10.9	screw-2
7296	8.06.0011.1.01.9	GE	GB/T70.1 M12-20	Screw-2
7297	8.06.0012.1.01.1	GE	GB/T5783 M16-60-10.9	screw-3
7298	8.06.0013.1.01.2	GE	TE02-01.02.16	Hexagon posi. screw
7299	8.06.0014.1.01.3	PL	62.02.347	Screw
7300	8.06.0015.1.01.4	PL	62.02.348	Screw
7301	8.06.0016.1.01.5	PL	62.02.3013	Nut
7302	8.06.0017.1.01.6	PL	62.02.3014	Nut
7303	8.06.0018.1.01.7	PL	61.04.218F	T-BOLTS STD.SIZE
7304	8.06.0019.1.01.8	CR	23083967	Nut
7305	8.07.0001.1.01.9	PL	ESNH100-3/4Z-16UNF-R60	NUT

7306	8.07.0002.1.01.1	PL	UD311.2112.4	JOINT HEAD COMPLETE
7307	8.07.0003.1.01.2	PL	UD313.1805	LEVER
7308	8.07.0004.1.01.3	PL	UD313.1806	LEVER
7309	8.07.0005.1.01.4	PL	UD72.2807	CARRIER
7310	8.07.0006.1.01.5	PL	WN 81-303	BOLT
7311	8.07.0007.1.01.6	PL	19MM	LOCK FOR S.S STRIP
7312	8.07.0008.1.01.7	PL	19X1000	S.S. STRIP
7313	8.07.0009.1.01.8	PL	WN 81-328	CARRIER
7314	8.07.0010.1.01.9	PL	SBA-75	FOUNDATION PAD
7315	8.07.0011.1.01.1	PL	UD311.307	SPRING
7316	8.07.0012.1.01.2	CR	23086606	Transverse cylinder assembly of outer frame
7317	8.07.0013.1.01.3	CR	230866076	Transverse cylinder assembly of inner frame
7318	8.07.0014.1.01.4	CR	23071657	Lifting oil cylinder
7319	8.07.0015.1.01.5	CR	23086608	support cylinder assembly
7320	8.07.0016.1.01.6	CR	23086609	Transverse cylinder assembly of guide beam
7321	8.07.0017.1.01.7	CR	23086610	Rotating cylinder assembly
7322	8.07.0018.1.01.8	CR	23067929	LINING FORK
7323	8.07.0019.1.01.9	PL	G10.39PAS. DU	Cone Tube
7324	8.07.0020.1.01.1	PL	UD72.3724	Bracket
7325	8.07.0021.1.01.2	PL	UD50.2605	Damping Disc
7326	8.07.0022.1.01.3	CR	40103037	Straight pipe
7327	8.07.0023.1.01.4	PL	UD238.3834	BELLOW
7328	8.07.0024.1.01.5	PL	WN70.3400.21	SHAFT DRIVE
7329	8.07.0025.1.01.6	PL	UD80.4204,	SLIDE PLATE
7330	8.07.0026.1.01.7	PL	WN131-31.139.210-1	PRESSURE SPRING,
7331	8.07.0027.1.01.8	PL	UD103.13	BASE PLATE,
7332	8.07.0028.1.01.9	PL	UD67.2661	DISC
7333	8.07.0029.1.01.1	PL	UD251.2201-2	DISC (Shoe)
7334	8.07.0030.1.01.2	PL	UD150.5864	SLEEVE BEARING
7335	8.07.0031.1.01.3	PL	WN121-25.2H7.32K6.30-1	BEARING BUSH
7336	8.07.0032.1.01.4	PL	UD67.2113.2	ROLLER ,
7337	8.07.0033.1.01.5	PL	UD50.1806	BOLT
7338	8.07.0034.1.01.6	PL	38X30X4X14	BUSH
7339	8.07.0035.1.01.7	PL	WN109-25H7.62.M20-1	THREADED BOLT/PIN
7340	8.07.0036.1.01.8	PL	UD214.1956,	BRAKE LINKAGE LEVER
7341	8.07.0037.1.01.9	PL	DZ80/G=1500/HUB100	PULL CABLE
7342	8.07.0038.1.01.1	PL	MSW100.1201.0444	FLANGE
7343	8.07.0039.1.01.2	PL	WN160-40.440-1,	CROTCH
7344	8.07.0040.1.01.3	PL	WN70.110	BEARING BUSH
7345	8.07.0041.1.01.4	PL	UD63.1064	Sleeve Bearing
7346	8.07.0042.1.01.5	PL	UD61.14261	Torque convertor Bearing
7347	8.07.0043.1.01.6	PL	UD61.14166	TORQUE CONVERTER BEARING
7348	8.07.0044.1.01.7	PL	WN120-M36X1,5.M36X1,5L-2	Tension Lock
7349	8.07.0045.1.01.8	PL	SU1702.21.1.4.5	TOOTHED DISC
7350	8.07.0046.1.01.9	PL	571801915-60SH	CONE BEARING
7351	8.07.0047.1.01.1	PL	WN153-75H8.712-1	GUIDE COLUMN
7352	8.07.0048.1.01.2	PL	W61.02-25	GUIDE BUSH
7353	8.07.0049.1.01.3	PL	HZ06.040.025	Guide bush
7354	8.07.0050.1.01.4	PL	HZ06.100.063	Guide bush
7355	8.07.0051.1.01.5	PL	GLF311.809	Clevis
7356	8.07.0052.1.01.6	PL	CU311230	Clamp lever
7357	8.07.0053.1.01.7	PL	WN107.20H7.71.5.2	BOLT
7358	8.07.0054.1.01.8	CR	23071699	Lubrication Sleeve
7359	8.07.0055.1.01.9	CR	23079003	Lubrication Sleeve
7360	8.07.0056.1.01.1	CR	23067095	Spline Sleeve
7361	8.07.0057.1.01.2	CR	20261454	Spline
7362	8.07.0058.1.01.3	CR	82008021592	Transducer Spring
7363	8.07.0059.1.01.4	CR	23083970	Lining Roller Assembly
7364	8.07.0060.1.01.5	CR	23071588	Spacer
7365	8.07.0061.1.01.6	CR	23069980	Pin of Lining Cylinder
7366	8.07.0062.1.01.7	CR	23071274	Spacer
7367	8.07.0063.1.01.8	CR	23073960	Plate
7368	8.07.0064.1.01.9	CR	23069037	Cooling Pipe [Cooling Coil]
7369	8.07.0065.1.01.1	CR	20262367	Pin of Shock Absorber Lower End
7370	8.07.0066.1.01.2	CR	23069848	Spacer
7371	8.07.0067.1.01.3	CR	20262366	Pin of Shock Absorber Upper End
7372	8.07.0068.1.01.4	PL	UD236.3001.8A	AXLE(DATUM WHEEL)
7373	8.07.0069.1.01.5	PL	C61.403	PRESSURE PLATE
7374	8.08.0001.1.01.1	PL	10MMDIN5401/III	STEEL BALL
7375	8.08.0002.1.01.2	PL	21 x 40DIN 1481	TENTION SLEEVE
7376	8.08.0003.1.01.3	PL	305-64-04-3246	DRIVE SHAFT FOR BCM
7377	8.08.0004.1.01.4	PL	62.11.1100.03	DRIVE STATION
7378	8.08.0005.1.01.5	PL	62.11.1100.04	DREDGER STATION FOR BCM
7379	8.08.0006.1.01.6	PL	62.11.7000.09/39	ROLLER FOR BCM & FRM
7380	8.08.0007.1.01.7	PL	62.11.7000.11/49	ROLLER
7381	8.08.0008.1.01.8	PL	62.11.7000.13/41	ROLLER

7382	8.08.0009.1.01.9	PL	62.11.7000.14/53	ROLLER
7383	8.08.0010.1.01.1	PL	62.11.7000.15/54	ROLLER
7384	8.08.0011.1.01.2	PL	62.11.7000.18/42	ROLLER
7385	8.08.0012.1.01.3	PL	62.11.7000.20/50	ROLLER
7386	8.08.0013.1.01.4	PL	62.11.7000.21/43	SUPPORT RING FOR BCM & FRM
7387	8.08.0014.1.01.5	PL	62.11.7000.23/44	ROLLER FOR BCM & FRM
7388	8.08.0015.1.01.6	PL	62.11.7000.24/45	ROLLER FOR BCM & FRM
7389	8.08.0016.1.01.7	PL	62.11.7000.25/51	ROLLER
7390	8.08.0017.1.01.8	PL	62.11.7000.27/46	ROLLER
7391	8.08.0018.1.01.9	PL	62.11.7000.28/52	ROLLER
7392	8.08.0019.1.01.1	PL	62.11.7000.29/47	ROLLER
7393	8.08.0020.1.01.2	PL	62.11.7000.49	ROLLER FOR BCM & FRM
7394	8.08.0021.1.01.3	PL	62-09-1010	LEVER
7395	8.08.0022.1.01.4	PL	62-11-7000-10/40	ROLLER
7396	8.08.0023.1.01.5	PL	62-11-7000-42	ROLLER
7397	8.08.0024.1.01.6	PL	62-11-7000-44	ROLLER
7398	8.08.0025.1.01.7	PL	62-11-7000-45	ROLLER
7399	8.08.0026.1.01.8	PL	62-11-7000-46	ROLLER
7400	8.08.0027.1.01.9	PL	64.04.3313	SHAFT OF BCM TURRET GEAR
7401	8.08.0028.1.01.1	PL	64.08.1000.201	CHAIN GUIDE EMPTY FOR BCM
7402	8.08.0029.1.01.2	PL	64.08.8000.39	COVERING HOOD
7403	8.08.0030.1.01.3	PL	64.08.8075	GUARD PLATE
7404	8.08.0031.1.01.4	PL	64.08.8146	FRAME JOINT
7405	8.08.0032.1.01.5	PL	64.08.8163	SIDE WALL
7406	8.08.0033.1.01.6	PL	64.08.8170	TRAVERSE BEAM
7407	8.08.0034.1.01.7	PL	64.08.8317	SIDE WALL
7408	8.08.0035.1.01.8	PL	64.08.8323	GUARD PLATE
7409	8.08.0036.1.01.9		Shifted to Annexure-IIIB	
7410	8.08.0037.1.01.1		Shifted to Annexure-IIIB	
7411	8.08.0038.1.01.2	PL	64.11.10088	ROLL HOLDER
7412	8.08.0039.1.01.3	PL	64.11.3198	ROLL HOLDER
7413	8.08.0040.1.01.4	PL	64.14.1005	FLANGE
7414	8.08.0041.1.01.5	PL	64.14.1006	FLANGE
7415	8.08.0042.1.01.6		Shifted to Ann-II	
7416	8.08.0043.1.01.7	PL	64-08-3000-22	DREDGER DRUM GEAR BOX
7417	8.08.0044.1.01.8	PL	64-09-842	RUBBER PAD
7418	8.08.0045.1.01.9	PL	64-11-1000-02	DREDGER STATION
7419	8.08.0046.1.01.1	PL	64-11-1000-04	DREDGER STATION
7420	8.08.0047.1.01.2	PL	64-93-5000-103	DRIVE STATION
7421	8.08.0048.1.01.3	PL	90X60X56 MM	ROLLER TYDCR
7422	8.08.0049.1.01.4	PL	As per list	CUTTER BAR MODIFICATION SET Consisting of
7423	8.08.0050.1.01.5	PL	2.32	Mounting Block Part No. HY150.32 (1 no.)
7424	8.08.0051.1.01.6	PL	2.559	Bracket Part No. IN43-559 (2 Nos.)
7425	8.08.0052.1.01.7	PL	2.534	Bracket Part No. IN43-534 (2 Nos.)
7426	8.08.0053.1.01.8	PL	2.5.2X16	Plastic Clamp Assembly Part No. WN4-5.2X16(6 Nos.)
7427	8.08.0054.1.01.9	PL	2.0130	Cylinder Part No. RM08A-27-0130 (2 Nos.)
7428	8.08.0055.1.01.1	PL	2.0110	Fork Part No. RM08A-27-0110 (2 Nos.)
7429	8.08.0056.1.01.2	PL	2.1995	Block Part No. 64.08.1995 (2 Nos.)
7430	8.08.0057.1.01.3	PL	2.1927	Bush Part No. 64.08.1927 (2 Nos.)
7431	8.08.0058.1.01.4	PL	2.N90	Wiper Part No. DA17-0450-N90 (2 Nos.)
7432	8.08.0059.1.01.5	PL	2.1481	Tension Sleeve Part No. 21X40DIN1481 (8 Nos.)
7433	8.08.0060.1.01.6	PL	2.02	Wear Plate Part No. RM08-25,2150-02(1 No.)
7434	8.08.0061.1.01.7	PL	2.1007	Switch Box Part No. 64-07-3000-1007(1 No.)
7435	8.08.0062.1.01.8	PL	2.1006	Switch Box Part No. 64-07-3000-1006(1 No.)
7436	8.08.0063.1.01.9	PL	2.273	Plug Part No. IN43-273 (5 Nos.)
7437	8.08.0064.1.01.1	PL	2.472	Circlip Part No. 160DIN472 (2 Nos.)
7438	8.08.0065.1.01.2	PL	2.1947	Bolt Part No. 64-08-1947 (2 Nos.)
7439	8.08.0066.1.01.3	PL	62.04.0114	SEAL SET FOR EXTRA LIFTING
7440	8.08.0067.1.01.4		Repeated item	
7441	8.08.0068.1.01.5	PL	97,79X3.53-N-DIN3771-NBR90	O-Ring Part No. 97,79X3.53-N-DIN3771-NBR90(1 No.)
7442	8.08.0069.1.01.6	PL	2.023	Grooved Sealing Ring Part No. G10.63(0040.070.023) (2 Nos.)
7443	8.08.0070.1.01.7	PL	2.63(2512005.209	Wiper Part No. P7-63(2512005.209) (2 Nos.)
7444	8.08.0071.1.01.8	PL	EC-2045/FE/1600	MAIN CONVEYOR BELT DRIVE REDUCTION GEAR BOX
7445	8.08.0072.1.01.9	PL	IN43.399	DISTRIBUTOR
7446	8.08.0073.1.01.1	PL	IN43.540 SUB. IN43.54	DISTRIBUTOR
7447	8.08.0074.1.01.2	PL	RE 15-200-24	PLATE

7448	8.08.0075.1.01.3	PL	RE 15-200-25	PLATE
7449	8.08.0076.1.01.4	PL	RE 20.204-LI	BRACKET
7450	8.08.0077.1.01.5	PL	RE 20.204-RE	BRACKET
7451	8.08.0078.1.01.6	PL	RE 20.420	COVER
7452	8.08.0079.1.01.7	PL	RE 20.610	BRACKET
7453	8.08.0080.1.01.8		Repeated item	
7454	8.08.0081.1.01.9	PL	TYPGR-Dia-90X60X56	ROLLER FOR BCM & FRM
7455	8.08.0082.1.01.1	PL	U 75-913	SHAFT
7456	8.08.0083.1.01.2	PL	U75.14	CONNECTING PIECE
7457	8.08.0084.1.01.3	PL	UD 50-1803	ROLLER FOR SAT. SUPPORT
7458	8.08.0085.1.01.4	PL	UD 61-453	PRESSURE PLATE
7459	8.08.0086.1.01.5	PL	UD72.302	DOUBLE U-BEARING
7460	8.08.0087.1.01.6	PL	WN70.3803	DRIVE SHAFT
7461	8.08.0088.1.01.7	PL	21X40DIN1481	TENSION SLEEVE
7462	8.08.0089.1.01.8	PL	22g8M16X75X100DIN1438	BOLT
7463	8.08.0090.1.01.9	PL	59,7X52X79M.FAC.	BUSH
7464	8.08.0091.1.01.1	PL	61.04.211	INTERMEDIATE LINK
7465	8.08.0092.1.01.2	PL	62.08.8192	ANGLE
7466	8.08.0093.1.01.3	PL	63.09.2076	FLANGE
7467	8.08.0094.1.01.4	PL	63.09.2077	RING
7468	8.08.0095.1.01.5	PL	63.09.2078	DISC
7469	8.08.0096.1.01.6	PL	63.11.1022	BUSH
7470	8.08.0097.1.01.7	PL	64.02.1111	BOLT
7471	8.08.0098.1.01.8	PL	64.02.2000.153	EXCHANGE SET WORK IN GDRIVE
7472	8.08.0099.1.01.9	PL	64.02.2000.154	EXCHANGE SET DRIVE GEAR
7473	8.08.0100.1.01.1	PL	64.02.2107.00	BUSH
7474	8.08.0101.1.01.2	PL	64.04.1120	FLANGE
7475	8.08.0102.1.01.3	PL	656.080.1050	BOLT
7476	8.08.0103.1.01.4	PL	MSB-T-AC-27642	ROUND CONNECTOR M12
7477	8.08.0104.1.01.5	PL	MSDLO-AC-T-27646	ROUND CONNECTOR M12
7478	8.08.0105.1.01.6	PL	NATR17PP	ROLLER
7479	8.08.0106.1.01.7		Shifted to Ann-II	
7480	8.08.0107.1.01.8	PL	S-5.14.1.1A	FLANGE
7481	8.08.0108.1.01.9	PL	SB115	SNAP RING
7482	8.08.0109.1.01.1	PL	SB26	RING
7483	8.08.0110.1.01.2	PL	SB52	SNAP RING
7484	8.08.0111.1.01.3		Repeated item	
7485	8.08.0112.1.01.4	PL	HI1A1845C360	SPRING
7486	8.08.0113.1.01.5	PL	HN2	RIVETING MACHINE
7487	8.08.0114.1.01.6	PL	U75.812	SHAFT
7488	8.08.0115.1.01.7	PL	64.08.10083 FOR RM08B.27.0200	CONNECTING ELBOW
7489	8.08.0116.1.01.8	PL	62.11.4000.15	DRIVE STATION
7490	8.08.0117.1.01.9	PL	62.08.3068	Drive shaft
7491	8.08.0118.1.01.1	PL	62.05.1073	MOUNTING BLOCK
7492	8.08.0119.1.01.2	PL	64.02.2017	AXLE BUSH
7493	8.08.0120.1.01.3	PL	64.04.3309	SHAFT
7494	8.08.0121.1.01.4	PL	64.04.3343	SHAFT
7495	8.08.0122.1.01.5	PL	64.08.1000.237	LOCKING DEVICE ASSY
7496	8.08.0123.1.01.6	PL	RM.64.08.4000.04.PIND.SP1676	CHAIN TENSIONING CYLINDER
7497	8.08.0124.1.01.7	PL	RM.64.08.2000.33/89GLIEDER-IN.PIND.SP1676	CUTTER CHAIN (89 links)
7498	8.08.0125.1.01.8	PL	RM.08B.25.2150.01.PIND.SP1676	CUTTER BAR
7499	8.08.0126.1.01.9	PL	RM.08.27.0100.PIND.SP1676	CONNECTING ELBOW
7500	8.08.0127.1.01.1	PL	RM.08.27.0150.PIND.SP1676	CONNECTING ELBOW (Right, D/S)
7501	8.08.0128.1.01.2	PL	RM.64.08.5000.23.PIND.SP1676	CORNER ROLLER ASSEMBLY COMPLETE
7502	8.08.0129.1.01.3	PL	RM.61.04.519.PIND.SP1676	DREDGER DRUM DISC
7503	8.08.0130.1.01.4	PL	64.11.10284	DRIVE SHAFT FOR MAIN CONVEYOR(DOUBLE DRIVE)
7504	8.08.0131.1.01.5	PL	64.11.3000.39	DREDGER STATION
7505	8.08.0132.1.01.6	PL	64.11.1433	PINION SHAFT
7506	8.08.0133.1.01.7	PL	G120.09	SPRING
7507	8.08.0134.1.01.8	PL	UD67.7101RE	BLOCK LEVER
7508	8.08.0135.1.01.9	PL	UD67.7101 LI	BLOCK LEVER
7509	8.08.0136.1.01.1	PL	UD67.7102	BRACKET
7510	8.08.0137.1.01.2	PL	UD63.1024	SLEEVE BEARING
7511	8.08.0138.1.01.3	PL	WL320.8/E6	ROLLER
7512	8.08.0139.1.01.4	PL	UD64.1106	VENTILATION
7513	8.08.0140.1.01.5	PL	UD64.1104	JOINING FLANGE
7514	8.08.0141.1.01.6	PL	SK16L/G3/4z	sight glass
7515	8.08.0142.1.01.7	PL	HZ60.01-5	CLEVIS BUTT STRAP LATERAL,
7516	8.08.0143.1.01.8	PL	64.02.3019	BRAKE BLOCK INSERT
7517	8.08.0144.1.01.9	PL	64.08.10084	CONNECTING ELBOW (Right, D/S)
7518	8.08.0145.1.01.1	PL	WN131-17,5.74,5.210-1	Pressure Spring
7519	8.08.0146.1.01.2	PL	64.11.1000.144	DRIVE STATION

7520	8.08.0147.1.01.3	PL	62.11.1220	Top belt guiding station (Dredger station)
7521	8.08.0148.1.01.4	PL	64.08.1000.343	CHAIN TROUGH ASCENDING
7522	8.08.0149.1.01.5	PL	64.08.8293	PLATE
7523	8.08.0150.1.01.6	PL	64.08.8202	STRIP
7524	8.08.0151.1.01.7	PL	64.08.8262	WEAR PLATE
7525	8.08.0152.1.01.8	PL	64.08.8263	WEAR PLATE
7526	8.08.0153.1.01.9	PL	64.08.8264	WEAR PLATE
7527	8.08.0154.1.01.1	PL	RE20.309	COVER
7528	8.08.0155.1.01.2	PL	64.09.8377	SUPPORT
7529	8.08.0156.1.01.3	PL	64.09.8382	SUPPORT
7530	8.08.0157.1.01.4	PL	64.09.8380	SUPPORT
7531	8.08.0158.1.01.5	PL	64.09.8369	SUPPORT
7532	8.08.0159.1.01.6	PL	64.09.8368	SUPPORT
7533	8.08.0160.1.01.7	PL	64.09.8381	SUPPORT
7534	8.08.0161.1.01.8	PL	64.11.3217	SIDE MEMBER
7535	8.08.0162.1.01.9	PL	64.11.3215	SIDE MEMBER
7536	8.08.0163.1.01.1	PL	64.08.8289	Wear Plate
7537	8.08.0164.1.01.2	PL	64.09.8412	WEAR PLATE
7538	8.08.0165.1.01.3	PL	64.09.8413	WEAR PLATE
7539	8.08.0166.1.01.4	PL	64.09.8378	SUPPORTS
7540	8.08.0167.1.01.5	PL	64.09.8407	SUPPORTR
7541	8.08.0168.1.01.6	PL	64.09.8408	SUPPORT
7542	8.08.0169.1.01.7	PL	64.09.8372	SUPPORT
7543	8.08.0170.1.01.8	PL	64.09.8373	SUPPORT
7544	8.08.0171.1.01.9	PL	64.09.8370	STRIP
7545	8.08.0172.1.01.1	PL	64.09.8371	STRIP
7546	8.08.0173.1.01.2	PL	64.09.8033	ANGLE
7547	8.08.0174.1.01.3	PL	64.09.8376	SUPPORT
7548	8.08.0175.1.01.4	PL	64.09.7012	Washer
7549	8.08.0176.1.01.5	PL	64.09.7105	PLATE BEARING
7550	8.08.0177.1.01.6	PL	64.09.8374	SUPPORT,
7551	8.08.0178.1.01.7	PL	64.09.8401	SUPPORT,
7552	8.08.0179.1.01.8	PL	62.02.1000.27	RAIL SCRAPER
7553	8.08.0180.1.01.9	PL	64.11.10008	Guide plate
7554	8.09.0001.1.01.2	PL	62.03.115	BUSH
7555	8.09.0002.1.01.3	PL	6,4X18STAHL/KOPFDURCHM.19 SUB. TSP/D/BS8190	RIVET WITH WASHER
7556	8.09.0003.1.01.4	PL	62088032/62088033	COVER BOW FOR CONVEYOR DRUM
7557	8.09.0004.1.01.5	PL	64.11.1000.37	GEAR BOX FOR MAIN CONVEYOR DRIVE OF BCM
7558	8.09.0005.1.01.6	PL	8MM/6MM	RIVETS FOR FRM
7559	8.09.0006.1.01.7	PL	RE 30-150-2	CONVEYOR SHAFT
7560	8.09.0007.1.01.8	PL	RE 30-273-3	DRIVE SHAFT FOR EXCAVATING CONVEYOR SHAFT
7561	8.09.0008.1.01.9	PL	RE 350.101	SIDE WALL
7562	8.09.0009.1.01.1	PL	RE 350.102	SIDE WALL
7563	8.09.0010.1.01.2	PL	RE 350.103	SIDE WALL
7564	8.09.0011.1.01.3	PL	RE 350.104	SIDE WALL
7565	8.09.0012.1.01.4	PL	RE 350.105	SIDE WALL
7566	8.09.0013.1.01.5	PL	RE 350.106	SIDE WALL
7567	8.09.0014.1.01.6	PL	RE 350.107	SIDE WALL
7568	8.09.0015.1.01.7	PL	RE 350.108	SIDE WALL
7569	8.09.0016.1.01.8	PL	RE20.275-2	DRIVE SHAFT
7570	8.09.0017.1.01.9	PL	RE-21-205	SLIDER FOR EXCAVATING UNIT OF FRM-80
7571	8.09.0018.1.01.1	PL	RE22.209	GUIDE BLOCK FRM MACHINE
7572	8.09.0019.1.01.2	PL	RE-30-151	COVER BOW OF MAIN CONVEYOR UNIT OF FRM-80
7573	8.09.0020.1.01.3	PL	RE-30-152	COVER BOW OF MAIN CONVEYOR UNIT OF FRM-80
7574	8.09.0021.1.01.4		Repeated item	
7575	8.09.0022.1.01.5	PL	SSP-70-01-610	CARRIER
7576	8.09.0023.1.01.6	PL	SU1201.708.1.2.1 SUB. RE20.250-2	SPROCKET DRIVE STATION FRM (SHAFT)
7577	8.09.0024.1.01.7	PL	WN 70-9102	SLIDING GEAR
7578	8.09.0025.1.01.8	PL	WN70.402E	TOOTHED GEAR
7579	8.09.0026.1.01.9	PL	WN80.2604-2	SHAFT
7580	8.09.0027.1.01.1	GE	5OMV-630/151B3108	Motor
7581	8.09.0028.1.01.2	CR	BS500W(IND)-11-02-01-05-01	upper feeding end screen
7582	8.09.0029.1.01.3	CR	BS500W(IND)-11-02-01-05-02	upper screen
7583	8.09.0030.1.01.4	CR	BS500W(IND)-11-02-01-06-01	Lower screen-1
7584	8.09.0031.1.01.5	CR	BS500W(IND)-11-02-01-06-02	Lower screen-2

7585	8.09.0032.1.01.6	CR	BS550(IND)-07-00 / BS550(IND)-36-00	Left Excavating Device/ Right Excavating Device (Complete)
7586	8.09.0033.1.01.7	CR	BS550(IND)-07-01-00	LEFT EXCAVATOR
7587	8.09.0034.1.01.8	CR	BS550(IND)-36-01-00	RIGHT EXCAVATOR
7588	8.09.0035.1.01.9	CR	BS550(IND)-07-02-00	LEFT EXCAVATING EQUIPMENT CHAIN GUIDE
7589	8.09.0036.1.01.1	CR	BS550(IND)-36-02-00	RIGHT EXCAVATING EQUIPMENT CHAIN GUIDE
7590	8.09.0037.1.01.2	CR	BS550(IND)-07-03-00	EXCAVATING EQUIPMENT MOUNTING FRAME
7591	8.09.0038.1.01.3	CR	BS550(IND)-07-05-00	EXCAVATING EQUIPMENT SAFETY CHAIN
7592	8.09.0039.1.01.4	CR	GB561-65 A3.5	OPEN TURNBUCKLE
7593	8.09.0040.1.01.5	CR	BS550-07-02-17-03	PLATE
7594	8.09.0041.1.01.6	CR	BS550(IND)-07-01-01-00	LEFT EXCAVATOR BRACKET
7595	8.09.0042.1.01.7	CR	BS550(IND)-36-01-01-00	RIGHT EXCAVATOR BRACKET
7596	8.09.0043.1.01.8	CR	BS550(IND)-07-01-03-00	DRIVING DEVICE
7597	8.09.0044.1.01.9	CR	BS550-07-01-04-00	CHAIN WHEEL COMPONENT
7598	8.09.0045.1.01.1	CR	BS550(IND)-07-01-04-00	EXCAVATING CHAIN
7599	8.09.0046.1.01.2	CR	BS550(IND)-07-01-05	OPERATION SIDE WEAR PLATE I
7600	8.09.0047.1.01.3	CR	BS550(IND)-07-01-06	OPERATION SIDE WEAR PLATE II
7601	8.09.0048.1.01.4	CR	BS550(IND)-07-01-07	OPERATION SIDE WEAR PLATE III
7602	8.09.0049.1.01.5	CR	BS550(IND)-07-01-08	OPERATION SIDE WEAR PLATE IV
7603	8.09.0050.1.01.6	CR	BS550(IND)-07-01-51	OPERATION SIDE WEAR PLATE VIII
7604	8.09.0051.1.01.7	CR	BS550(IND)-07-01-09	OPERATION SIDE WEAR PLATE V
7605	8.09.0052.1.01.8	CR	BS550(IND)-07-01-10	OPERATION SIDE WEAR PLATE VI
7606	8.09.0053.1.01.9	CR	BS550(IND)-07-01-11	OPERATION SIDE WEAR PLATE VII
7607	8.09.0054.1.01.1	CR	BS550(IND)-07-01-12-00	EXCAVATING CHAIN SLOT COMPONENT I
7608	8.09.0055.1.01.2	CR	BS550(IND)-07-01-13-00	EXCAVATING CHAIN SLOT COMPONENT II
7609	8.09.0056.1.01.3	CR	BS550(IND)-07-01-14-00	EXCAVATING CHAIN SLOT COMPONENT III
7610	8.09.0057.1.01.4	CR	BS550(IND)-07-01-15-00	EXCAVATING CHAIN SLOT COMPONENT IV
7611	8.09.0058.1.01.5	CR	BS550(IND)-07-01-16-00	EXCAVATING CHAIN SLOT COMPONENT V
7612	8.09.0059.1.01.6	CR	BS550(IND)-07-01-17-00	EXCAVATING CHAIN SLOT COMPONENT VI
7613	8.09.0060.1.01.7	CR	BS550(IND)-07-01-18-00	EXCAVATING CHAIN SLOT COMPONENT VII
7614	8.09.0061.1.01.8	CR	BS550(IND)-07-01-19-00	EXCAVATING CHAIN SLOT COMPONENT VIII
7615	8.09.0062.1.01.9	CR	BS550(IND)-07-01-20-00	EXCAVATING CHAIN SLOT COMPONENT IX
7616	8.09.0063.1.01.1	CR	BS550(IND)-07-01-21-00	EXCAVATING CHAIN SLOT COMPONENT X
7617	8.09.0064.1.01.2	CR	BS550(IND)-07-01-22-00	EXCAVATING CHAIN SLOT COMPONENT XI
7618	8.09.0065.1.01.3	CR	BS550(IND)-07-01-23-00	EXCAVATING CHAIN SLOT COMPONENT XII
7619	8.09.0066.1.01.4	CR	BS550(IND)-07-01-61-00	INNER BRACKET I OF ISOLATION HOOD I
7620	8.09.0067.1.01.5	CR	BS550(IND)-07-01-62-00	INNER BRACKET II OF ISOLATION HOOD II
7621	8.09.0068.1.01.6	CR	BS550(IND)-07-01-28-00	INNER BRACKET II OF ISOLATION HOOD III
7622	8.09.0069.1.01.7	CR	BS550(IND)-07-01-29-00	INNER BRACKET III OF ISOLATION HOOD IV
7623	8.09.0070.1.01.8	CR	BS550(IND)-36-01-29-00	INNER BRACKET III OF ISOLATION HOOD V
7624	8.09.0071.1.01.9	CR	BS550(IND)-07-01-26-00	HALFTONE COVER
7625	8.09.0072.1.01.1	CR	BS550(IND)-07-01-69	HALFTONE I
7626	8.09.0073.1.01.2	CR	BS550(IND)-07-01-70	HALFTONE II
7627	8.09.0074.1.01.3	CR	BS550(IND)-07-01-71	HALFTONE III
7628	8.09.0075.1.01.4	CR	BS550(IND)-07-01-32	PLATEN OF ISOLATION HOOD BRACKET III

7629	8.09.0076.1.01.5	CR	BS550(IND)-07-01-33	PLATEN OF ISOLATION HOOD BRACKET IV
7630	8.09.0077.1.01.6	CR	BS550(IND)-07-01-34	PLATEN OF ISOLATION HOOD BRACKET V
7631	8.09.0078.1.01.7	CR	BS550(IND)-07-01-35	PLATEN OF ISOLATION HOOD BRACKET VI
7632	8.09.0079.1.01.8	CR	BS500W(IND)-07-01-65	INNER JUNCTION PLATE
7633	8.09.0080.1.01.9	CR	BS500W(IND)-07-01-66	OUTER JUNCTION PLATE
7634	8.09.0081.1.01.1	CR	BS500W(IND)-07-01-67-00	LEFT SHIELD OF TENSION CYLINDER
7635	8.09.0082.1.01.2	CR	BS500W(IND)-07-01-68-00	RIGHT SHIELD OF TENSION CYLINDER
7636	8.09.0083.1.01.3	CR	BS550(IND)-07-01-02-01-00	Digging Plate Assemble (Complete)
7637	8.09.0084.1.01.4	CR	BS550(IND)-07-01-02-01-02	DIGGING PLATE MAIN PART
7638	8.09.0085.1.01.5	CR	BS550(IND)-07-01-02-01-01-00	DIGGING PLATE WELDING COMPONENT
7639	8.09.0086.1.01.6	CR	BS500W(IND)-07-01-02-01-03	SLEEVE
7640	8.09.0087.1.01.7	CR	BS500W(IND)-07-01-02-01-00	DIGGING PLATE ASSEMBLE
7641	8.09.0088.1.01.8	CR	BS550(IND)-07-01-02-02-00	CHAIN ASSEMBLE
7642	8.09.0089.1.01.9	CR	BS550(IND)-07-01-02-03	EXCAVATING CHAIN CONNECTION SHAFT I
7643	8.09.0090.1.01.1	CR	BS550(IND)-07-01-02-07	ROLLER
7644	8.09.0091.1.01.2	CR	BS550(IND)-07-02-01-00	LEFT EXCAVATING EQUIPMENT CHAIN GUIDE BODY
7645	8.09.0092.1.01.3	CR	BS550(IND)-36-02-01-00	RIGHT EXCAVATING EQUIPMENT CHAIN GUIDE BODY
7646	8.09.0093.1.01.4	CR	BS550(IND)-07-02-02-00	OUTER LEFT BALLAST- GATHERING- PLATE
7647	8.09.0094.1.01.5	CR	BS550(IND)-36-02-02-00	OUTER RIGHT BALLAST-GATHERING- PLATE
7648	8.09.0095.1.01.6	CR	BS550(IND)-07-02-03-00	INNER LEFT BALLAST- GATHERING-PLATE
7649	8.09.0096.1.01.7	CR	BS550(IND)-36-02-03-00	INNER RIGHT BALLAST- GATHERING- PLATE
7650	8.09.0097.1.01.8	CR	BS550(IND)-07-02-27-00	BALLAST-GATHERING- PLATE JACK STAY
7651	8.09.0098.1.01.9	CR	BS550(IND)-07-02-28-00	INNER BALLAST- GATHERING-PLATE JACK STAY
7652	8.09.0099.1.01.1	CR	BS550(IND)-07-02-16	ARTICULATED SHAFT
7653	8.09.0100.1.01.2	CR	BS550(IND)-07-02-07	BOTTOM WEAR PLATE I
7654	8.09.0101.1.01.3	CR	BS550(IND)-07-02-08	BOTTOM WEAR PLATE II
7655	8.09.0102.1.01.4	CR	BS550(IND)-07-02-09	END WEAR PLATE
7656	8.09.0103.1.01.5	CR	BS550(IND)-07-02-10	SIDE WEAR PLATE I
7657	8.09.0104.1.01.6	CR	BS550(IND)-07-02-11	SIDE WEAR PLATE II
7658	8.09.0105.1.01.7	CR	BS550(IND)-07-02-12	SIDE WEAR PLATE III
7659	8.09.0106.1.01.8	CR	BS550(IND)-07-02-13	SIDE WEAR PLATE IV
7660	8.09.0107.1.01.9	CR	BS550(IND)-07-02-14	SIDE WEAR PLATE V
7661	8.09.0108.1.01.1	CR	BS550(IND)-07-02-15	SIDE WEAR PLATE VI
7662	8.09.0109.1.01.2	CR	BS550(IND)-07-02-06-00	LEFT CHAIN GUIDE DIGGING PLATE COMPONENT-1
7663	8.09.0110.1.01.3	CR	BS550(IND)-36-02-06-00	LEFT CHAIN GUIDE DIGGING PLATE COMPONENT-2
7664	8.09.0111.1.01.4	CR	BS550(IND)-06-01-00	HEAD OF MACHINE
7665	8.09.0112.1.01.5	CR	BS550(IND)-06-02-00	MIDDLE PART 1
7666	8.09.0113.1.01.6	CR	BS550(IND)-06-03-00	MIDDLE PART
7667	8.09.0114.1.01.7	CR	BS550(IND)-06-04-00	MACHINE TAIL PART
7668	8.09.0115.1.01.8	CR	BS550(IND)-06-05-00	BALLAST FUNNEL
7669	8.09.0116.1.01.9	CR	BS550(IND)-06-06-00	PEDESTAL
7670	8.09.0117.1.01.1	CR	BS550(IND)-06-07-00	SUPPORT-1
7671	8.09.0118.1.01.2	CR	BS550(IND)-06-08-00	SUPPORT-2
7672	8.09.0119.1.01.3	CR	BS550(IND)-06-16-00	DRIVE PULLEY GROUP
7673	8.09.0120.1.01.4	CR	BS550(IND)-06-01-01-00	HEAD FRAME
7674	8.09.0121.1.01.5	CR	BS550-06-01-05-00	THROUGHING IDLER GROUP
7675	8.09.0122.1.01.6	CR	BS550-06-01-06-00	RETURN IDLER
7676	8.09.0123.1.01.7	CR	BS550(IND)-06-01-02-00	TOUNGE SCRAPER
7677	8.09.0124.1.01.8	CR	BS550(IND)-06-01-03-00	SUPPORT OF CONVEYOR BELT
7678	8.09.0125.1.01.9	CR	BS550(IND)-06-01-04-00	BAFFLE SUPPORT
7679	8.09.0126.1.01.1	CR	BS550(IND)-06-01-05-00	SPRING SCRAPER
7680	8.09.0127.1.01.2	CR	BS550(IND)-06-01-06	SUPPORTING PLATE OF BEARING PEDESTAL
7681	8.09.0128.1.01.3	CR	BS550(IND)-06-01-07	STIFFENED PANEL
7682	8.09.0129.1.01.4	CR	CQS300-17-01-06	DECKPLATE
7683	8.09.0130.1.01.5	CR	BS550(IND)-06-01-08	DECKPLATE 1
7684	8.09.0131.1.01.6	CR	BS550(IND)-06-02-02	STEEL PLATE
7685	8.09.0132.1.01.7	CR	BS550(IND)-06-01-11	STEEL PLATE Δ6 -2

7686	8.09.0133.1.01.8	CR	BS550(IND)-06-01-12	BATTEN 1
7687	8.09.0134.1.01.9	CR	BS550(IND)-06-01-13	STEEL PLATE Δ6 -3
7688	8.09.0135.1.01.1	CR	BS550(IND)-06-02-08	BATTEN
7689	8.09.0136.1.01.2	CR	BS550-06-01-05-02-00	BRACKET OF IDLER ROLLER
7690	8.09.0137.1.01.3	CR	BS550-06-01-05-01-00	ROLLER Φ102X245
7691	8.09.0138.1.01.4	CR	BS550-06-01-06-01-00	HANGING BRACKET
7692	8.09.0139.1.01.5	CR	BS550-06-01-06-02-00	ROLLER Φ102X730
7693	8.09.0140.1.01.6	CR	BS550(IND)-06-02-01-00	MIDDLE PART FRAME 2
7694	8.09.0141.1.01.7	CR	BS550(IND)-06-02-03	STEEL PLATE Δ6 -5
7695	8.09.0142.1.01.8	CR	BS550(IND)-06-02-04	BATTEN 2
7696	8.09.0143.1.01.9	CR	BS550(IND)-06-02-05	STEEL PLATE Δ6 -6
7697	8.09.0144.1.01.1	CR	BS550(IND)-06-02-09	BATTEN 4
7698	8.09.0145.1.01.2	CR	BS550(IND)-06-02-10	BATTEN 5
7699	8.09.0146.1.01.3	CR	BS550(IND)-06-02-11	STEEL PLATE Δ6 -7
7700	8.09.0147.1.01.4	CR	BS550(IND)-06-02-12	STEEL PLATE Δ6 -8
7701	8.09.0148.1.01.5	CR	BS550(IND)-06-03-01-00	MIDDLE PART FRAME
7702	8.09.0149.1.01.6	CR	BS550-06-02-04-00	BELOW CENTRING FLAT IDLER
7703	8.09.0150.1.01.7	CR	BS550(IND)-06-03-02-00	UPPER CENTRING FLAT IDLER
7704	8.09.0151.1.01.8	CR	BS550(IND)-06-03-02	STEEL PLATE Δ6 -9
7705	8.09.0152.1.01.9	CR	BS550(IND)-06-03-03	STEEL PLATE Δ6 -11
7706	8.09.0153.1.01.1	CR	BS550(IND)-06-03-04	BATTEN-4
7707	8.09.0154.1.01.2	CR	BS550(IND)-06-03-02-01-00	LARGE ROLLER
7708	8.09.0155.1.01.3	CR	BS550(IND)-03-02-00	ROTATING PEDESTAL
7709	8.09.0156.1.01.4	CR	CQS300-04-16-00	LOCKING DEVICE
7710	8.09.0157.1.01.5	CR	BS550(IND)-03-01-01-00	FRAME
7711	8.09.0158.1.01.6	CR	BS550(IND)-03-01-02-00	DRIVE PULLEY GROUP
7712	8.09.0159.1.01.7	CR	BS550(IND)-03-01-03-00	DIVERT ROLLER GROUP
7713	8.09.0160.1.01.8	CR	BS550(IND)-03-01-04-00	TENSIONER
7714	8.09.0161.1.01.9	CR	BS550(IND)-03-01-05-00	CARRIER FLAT IDLER
7715	8.09.0162.1.01.1	CR	BS550(IND)-03-01-06-00	IMPACT IDLER SET
7716	8.09.0163.1.01.2	CR	BS550(IND)-03-01-07-00	PARALLEL RETURN IDLER SET
7717	8.09.0164.1.01.3	CR	BS550(IND)-03-01-08-00	SPRING SCRAPER
7718	8.09.0165.1.01.4	CR	BS550(IND)-03-01-09-00	RETURN SCRAPER
7719	8.09.0166.1.01.5	CR	BS550(IND)-03-01-10-00	BAFFLE
7720	8.09.0167.1.01.6	CR	CQS300-17-02-02-01	PEDESTAL BODY
7721	8.09.0168.1.01.7	CR	BS550(IND)-03-01-02-01-00	PULLEY BODY
7722	8.09.0169.1.01.8	CR	DWY-S-02-03-06	SHAFT END BAFFLE
7723	8.09.0170.1.01.9	CR	BS550(IND)-03-01-02-02-01	END COVER
7724	8.09.0171.1.01.1	CR	BS550(IND)-03-01-03-01-00	ROLLER BODY
7725	8.09.0172.1.01.2	CR	BS550(IND)-03-02-01-00	PEDESTAL-1
7726	8.09.0173.1.01.3	CR	BS550(IND)-03-02-02-00	SUPPORT-1
7727	8.09.0174.1.01.4	CR	BS550(IND)-03-02-03-00	SUPPORT-2
7728	8.09.0175.1.01.5	CR	BS550(IND)-03-02-04-00	CHASSIS
7729	8.09.0176.1.01.6	CR	BS550(IND)-03-02-05	COVER PLATE
7730	8.09.0177.1.01.7	CR	CQS300-04-11	PEDESTAL-2
7731	8.09.0178.1.01.8	CR	CQS300-04-15-03-00	ASSEMBLY OF GUARD COVER
7732	8.09.0179.1.01.9	CR	CQS300-04-15-04	SHAFT END BAFFLE-2
7733	8.09.0180.1.01.1	CR	BS550(IND)-22-13-07-00	SWIVEL JOINT ASSEMBLY
7734	8.09.0181.1.01.2	CR	BS550(IND)-09-02-00	DRIVE PULLEY GROUP
7735	8.09.0182.1.01.3	CR	BS550(IND)-09-03-00	ROLLER GROUP OF CONVEYOR BELT
7736	8.09.0183.1.01.4	CR	BS550(IND)-09-04-00	SCRAPER FRAME
7737	8.09.0184.1.01.5	CR	BS550(IND)-09-05-00	IDLER PULLEY-1
7738	8.09.0185.1.01.6	CR	BS550(IND)-09-06-00	IDLER PULLEY-2
7739	8.09.0186.1.01.7	CR	BS550(IND)-09-07-00	ANGLE SCRAPER
7740	8.09.0187.1.01.8	CR	BS550(IND)-09-08-00	ROLLING FRAME-1
7741	8.09.0188.1.01.9	CR	BS550(IND)-09-09-00	ROLLING FRAME-2
7742	8.09.0189.1.01.1	CR	BS550(IND)-09-10-00	WHEEL BRACKET
7743	8.09.0190.1.01.2	CR	BS550(IND)-09-11-00	TAIL DIVERT ROLLER GROUP
7744	8.09.0191.1.01.3	CR	BS550(IND)-09-12-00	REAR BAFFLE
7745	8.09.0192.1.01.4	CR	BS550(IND)-09-13-00	ROLLER GROUP 2 OF CONVEYOR BELT
7746	8.09.0193.1.01.5	CR	BS550(IND)-09-14-00	BAFFLE-1
7747	8.09.0194.1.01.6	CR	BS550(IND)-09-15-00	BAFFLE-2
7748	8.09.0195.1.01.7	CR	BS550(IND)-09-16-00(R)	BAFFLE 2
7749	8.09.0196.1.01.8	CR	BS550(IND)-09-17-00	SUPPORT-1
7750	8.09.0197.1.01.9	CR	BS550(IND)-09-18-00	BAFFLE-3
7751	8.09.0198.1.01.1	CR	BS550(IND)-09-19-00	FUNNEL
7752	8.09.0199.1.01.2	CR	BS550(IND)-09-20-00	INTERFACE WITH EXCAVATING EQUIPMENT

7753	8.09.0200.1.01.3	CR	BS550(IND)-09-21-00	SPIRAL TENSIONER
7754	8.09.0201.1.01.4	CR	BS550(IND)-09-22-00	SAFETY CHAIN
7755	8.09.0202.1.01.5	CR	BS550(IND)-09-23-00	MOUNTING PEDESTAL
7756	8.09.0203.1.01.6	CR	BS550(IND)-09-25	IDLER RING
7757	8.09.0204.1.01.7	CR	BS550(IND)-09-26	SPRING PEDESTAL-1
7758	8.09.0205.1.01.8	CR	BS550(IND)-09-27	SPRING PEDESTAL-2
7759	8.09.0206.1.01.9	CR	BS550(IND)-09-29	COMPRESSING SPRING
7760	8.09.0207.1.01.1	CR	BS550(IND)-09-33	GUARD PLATE STRIP
7761	8.09.0208.1.01.2	CR	BS550(IND)-09-39	IDLER BRACKET
7762	8.09.0209.1.01.2	CR	BS550(IND)-09-43	BATTEN 3
7763	8.09.0210.1.01.4	CR	BS550(IND)-09-44	BATTEN 2
7764	8.09.0211.1.01.5	CR	BS550(IND)-09-45	BATTEN 1
7765	8.09.0212.1.01.6	CR	BS550(IND)-09-47	BAFFLE-4
7766	8.09.0213.1.01.7	CR	BS550(IND)-09-48	BATTEN
7767	8.09.0214.1.01.8	CR	BS550(IND)-09-50	PLATEN
7768	8.09.0215.1.01.9	CR	BS550(IND)-09-52	BATTEN 4
7769	8.09.0216.1.01.1	CR	BS550(IND)-09-53	COVER PLATE
7770	8.09.0217.1.01.2	CR	BS550(IND)-09-54-00	SUPPORT-2
7771	8.09.0218.1.01.3	CR	BS550(IND)-09-02-01-00	PULLEY BODY-1
7772	8.09.0219.1.01.4	CR	BS550(IND)-06-16-02-00	BEARING PEDESTAL-1
7773	8.09.0220.1.01.5	CR	BS550(IND)-06-16-03-00	BEARING PEDESTAL-2
7774	8.09.0221.1.01.6	CR	BS550(IND)-09-03-01-00	SLOTTED IDLER-1
7775	8.09.0222.1.01.7	CR	BS550(IND)-09-03-02-00	SLOTTED IDLER-2
7776	8.09.0223.1.01.8	CR	BS550(IND)-09-03-04	STIFFENED PANEL
7777	8.09.0224.1.01.9	CR	BS550(IND)-09-03-05	BRACKET
7778	8.09.0225.1.01.1	CR	BS550(IND)-09-05-01-00	PULLEY BODY-2
7779	8.09.0226.1.01.2	CR	BS550(IND)-09-03-01-05	COVER
7780	8.09.0227.1.01.3	CR	BS550(IND)-09-20-01-00	ASSEMBLY OF UPPER SUPPORT
7781	8.09.0228.1.01.4	CR	BS550-09-64-02-00	ASSEMBLY OF LOWER SUPPORT
7782	8.09.0229.1.01.5	CR	BS550(IND)-09-20-02-00	SUPPORTING BEAM
7783	8.09.0230.1.01.6	CR	BS550(IND)-09-16-00(L)	BAFFLE5(L)
7784	8.09.0231.1.01.7	CR	BS550(IND)-09-17-00(L)	SUPPORT
7785	8.09.0232.1.01.8	CR	BS550(IND)-09-01-01-00	RECTANGULAR TUBE-1
7786	8.09.0233.1.01.9	CR	BS550(IND)-09-01-02	WING PLATE
7787	8.09.0234.1.01.1	CR	BS550(IND)-09-01-03	CONNECTING BEAM-1
7788	8.09.0235.1.01.2	CR	BS550(IND)-09-01-04	ANGLE STEEL-1
7789	8.09.0236.1.01.3	CR	BS550(IND)-09-01-05	INNER SIDE PLATE
7790	8.09.0237.1.01.4	CR	BS550(IND)-09-01-06	ANGLE STEEL-2
7791	8.09.0238.1.01.5	CR	BS550(IND)-09-01-07(L)	INNER SIDE PLATE(R)
7792	8.09.0239.1.01.6	CR	BS550(IND)-09-01-08(L)	INNER SIDE PLATE(L)
7793	8.09.0240.1.01.7	CR	BS550(IND)-09-01-09	INNER SIDE PLATE 2
7794	8.09.0241.1.01.8	CR	BS550(IND)-09-01-10	SUPPORTING PLATE
7795	8.09.0242.1.01.9	CR	BS550(IND)-09-01-11	RECTANGULAR TUBE-2
7796	8.09.0243.1.01.1	CR	BS550(IND)-09-01-12	BLOCKING PLATE
7797	8.09.0244.1.01.2	CR	BS550(IND)-09-01-13	CONNECTING PLATE
7798	8.09.0245.1.01.3	CR	BS550(IND)-09-01-14	ANGLE STEEL-3
7799	8.09.0246.1.01.4	CR	BS550(IND)-09-01-15	ANGLE STEEL-4
7800	8.09.0247.1.01.5	CR	BS550(IND)-09-01-16	BENDING PLATE-1
7801	8.09.0248.1.01.6	CR	BS550(IND)-09-01-17	BENDING PLATE-2
7802	8.09.0249.1.01.7	CR	BS550(IND)-09-01-18	ENFORCING PLATE
7803	8.09.0250.1.01.8	CR	BS550(IND)-09-01-19	CONNECTING BEAM-2
7804	8.09.0251.1.01.9	CR	BS550-10-03-02-00	ROLLER-1
7805	8.09.0252.1.01.1	CR	BS550-10-03-03-00	ROLLER-2
7806	8.09.0253.1.01.2	CR	BS550(IND)-10-05-00	DRIVE PULLEY GROUP
7807	8.09.0254.1.01.3	CR	BS550-10-06-02-00	ROLLER-3
7808	8.09.0255.1.01.4	CR	BS550(IND)-10-07-00	SPRING SCRAPER
7809	8.09.0256.1.01.5	CR	BS550-10-07-02-00	ROLLER-4
7810	8.09.0257.1.01.6	CR	BS550-10-08-02-00	COMBING ROLLER
7811	8.09.0258.1.01.7	CR	BS550(IND)-10-06-00	RETURN SCRAPER
7812	8.09.0259.1.01.8	CR	BS550(IND)-10-04-00	TAIL IDLER
7813	8.09.0260.1.01.9	CR	BS550-10-04-01-00	IMPACT ROLLER-1
7814	8.09.0261.1.01.1	CR	BS550-10-04-02-00	IMPACT ROLLER-2
7815	8.09.0262.1.01.2	CR	BS550(IND)-10-04-01-00	TAIL ROLLER
7816	8.09.0263.1.01.3	CR	BS550-06-01-02-01-01	PEDESTAL BODY
7817	8.09.0264.1.01.4	CR	BS500W(IND)-13-00	Assembly of Side Plough (Complete)
7818	8.09.0265.1.01.5	CR	BS500W(IND)-13-01-00	LEFT SIDE PLOUGH
7819	8.09.0266.1.01.6	CR	BS500W(IND)-13-02-00	RIGHT SIDE PLOUGH
7820	8.09.0267.1.01.7	CR	BS500W(IND)-13-08	WING PLATE
7821	8.09.0268.1.01.8	CR	BS500W(IND)-13-09	STIFFENED PANEL 1 OF VEHICLE FRAME
7822	8.09.0269.1.01.9	CR	BS500W(IND)-13-10	STIFFENED PANEL 2 OF VEHICLE FRAME
7823	8.09.0270.1.01.1	CR	BS500W(IND)-13-11	STIFFENED PANEL 3 OF VEHICLE FRAME

7824	8.09.0271.1.01.2	CR	BS500W(IND)-13-12	STIFFENED PANEL 4 OF VEHICLE FRAME
7825	8.09.0272.1.01.3	CR	BS500W(IND)-13-22-00	TURNBUCKLE ASSEMBLE
7826	8.09.0273.1.01.4	CR	BS500W(IND)-13-14-00	SAFETY CHAIN
7827	8.09.0274.1.01.5	CR	DPZ440-05-39	SHAFT PEDESTAL
7828	8.09.0275.1.01.6	CR	DPZ440-05-41	SHAFT SLEEVE
7829	8.09.0276.1.01.7	CR	160A-05-06-00F	COMPOSITION OF TURN-OVER CYLINDER HINGE SHAFT
7830	8.09.0277.1.01.8	CR	DPZ440-05-24	SHAFT END PLATEN
7831	8.09.0278.1.01.9	CR	BS500W(IND)-13-20-00	LEFT REAR PLOUGH PLATE
7832	8.09.0279.1.01.1	CR	BS500W(IND)-13-21-00	REAR RIGHT PLOUGH PLATE
7833	8.09.0280.1.01.2	CR	BS500W(IND)-13-01-01-00	LEFT WING PLOUGH
7834	8.09.0281.1.01.3	CR	BS500W(IND)-13-01-02-00	LEFT PLOUGH PLATE
7835	8.09.0282.1.01.4	CR	BS500W(IND)-13-01-03-00	INNER HORIZONTAL TELESCOPIC CYLINDER
7836	8.09.0283.1.01.5	CR	BS500W(IND)-13-01-04-00	OUTER HORIZONTAL TELESCOPIC CYLINDER
7837	8.09.0284.1.01.6	CR	BS500W(IND)-13-01-05-00	VERTICAL TELESCOPIC CYLINDER
7838	8.09.0285.1.01.7	CR	BS500W(IND)-13-01-06	COVER PLATE OF VERTICAL TELESCOPIC CYLINDER
7839	8.09.0286.1.01.8	CR	BS500W(IND)-13-01-07	MOUNTING SHAFT OF PLOUGH PLATE AND WING PLATE
7840	8.09.0287.1.01.9	CR	BS500W(IND)-13-01-08	SHAFT END PLATEN-1
7841	8.09.0288.1.01.1	CR	DPZ440-05-25	BRASS SLEEVE
7842	8.09.0289.1.01.2	CR	BS500W(IND)-13-01-15	SHAFT END COVER PLATE
7843	8.09.0290.1.01.3	CR	BS500W(IND)-13-01-18	SPACING PLATE
7844	8.09.0291.1.01.4	CR	BS500W(IND)-13-01-21	PLATEN
7845	8.09.0292.1.01.5	CR	BS550(IND)-13-01-01-00	Left Wing Plough (Complete)
7846	8.09.0293.1.01.6	CR	BS500W(IND)-13-01-01-18	INNER BLADE OF WING PLOUGH
7847	8.09.0294.1.01.7	CR	BS550(IND)-13-01-02-00	Left Plough Plate (Complete)
7848	8.09.0295.1.01.8	CR	BS500W(IND)-13-01-02-08	MAIN SIDE PLOUGH INNER BLADE(H)
7849	8.09.0296.1.01.9	CR	BS500W(IND)-13-20-01-00	BASEPLATE
7850	8.09.0297.1.01.1	CR	BS500W(IND)-13-20-02-00	LEFT ROTATING PLATE
7851	8.09.0298.1.01.2	CR	BS500W(IND)-13-20-03-00	INNER VERTICAL TELESCOPIC CYLINDER
7852	8.09.0299.1.01.3	CR	BS500W(IND)-13-20-04-00	OUTER VERTICAL TELESCOPIC CYLINDER
7853	8.09.0300.1.01.4	CR	BS500W(IND)-13-20-10	SHAFT END COVER PLATE
7854	8.09.0301.1.01.5	CR	BS500W(IND)-13-20-11	MOUNTING PEDESTAL-1
7855	8.09.0302.1.01.6	CR	BS500W(IND)-13-20-12	MOUNTING PEDESTAL-2
7856	8.09.0303.1.01.7	CR	BS500W(IND)-13-20-13	LOCKING OTIC PLACODE (IND)
7857	8.09.0304.1.01.8	CR	160A-05-00-15-02	SEALING CUP (Φ26)
7858	8.09.0305.1.01.9	CR	BS500W(IND)-13-20-04-08	SUPPORT
7859	8.09.0306.1.01.1	CR	BS500W(IND)-13-20-18	LIMITED BLOCK
7860	8.09.0307.1.01.2	CR	BS500W(IND)-13-20-19-00	GUARD RAIL COVER
7861	8.09.0308.1.01.3	CR	BS500W(IND)-13-21-01-00	RIGHT BASEPLATE
7862	8.09.0309.1.01.4	CR	BS500W(IND)-13-21-02-00	RIGHT ROTARY PLATE
7863	8.09.0310.1.01.5	CR	BS550(IND)-15-01-00	LINE BRUSH CLEANING (Complete)
7864	8.09.0311.1.01.6	CR	BS550(IND)-15-01-01-00	LINE BRUSH MOUNTING FRAME
7865	8.09.0312.1.01.7	CR	BS550(IND)-15-01-02-00	LIFTING SLIDING ROD
7866	8.09.0313.1.01.8	CR	BS550(IND)-15-01-03-00	SLIDING SLEEVE
7867	8.09.0314.1.01.9	CR	BS550(IND)-15-01-05-00	ROLLER SET
7868	8.09.0315.1.01.1	CR	BS550(IND)-15-01-07-00	AIR CYLINER ASSEMBLE
7869	8.09.0316.1.01.2	CR	GB/T63-M20	LIFTING NUT
7870	8.09.0317.1.01.3	CR	BS550(IND)-15-01-08-00	AIR LOCK
7871	8.09.0318.1.01.4	CR	BS550(IND)-15-01-06-00	GUIDING SLEEVE FIXING PEDESTAL
7872	8.09.0319.1.01.5	CR	BS550(IND)-15-01-15	8MM BRUSH(EDGE)
7873	8.09.0320.1.01.6	CR	BS550(IND)-15-01-12	4MM BRUSH (MIDDLE)
7874	8.09.0321.1.01.7	CR	BS550(IND)-15-01-16	BRUSH LOCK PLATE
7875	8.09.0322.1.01.8	CR	BS550(IND)-15-01-14	4MM BRUSH(EDGE)
7876	8.09.0323.1.01.9	CR	BS550(IND)-15-01-02-04	LIFTING ROD WEAR PLATE
7877	8.09.0324.1.01.1	CR	BS550(IND)-15-02-01-00	MOBILE PEDESTAL (LEFT)
7878	8.09.0325.1.01.2	CR	BS550(IND)-15-02-03-00	SLIDING RAIL ASSEMBLE
7879	8.09.0326.1.01.3	CR	BS550(IND)-15-02-02-00	LIFTING AIR CYLINDER ASSEMBLE
7880	8.09.0327.1.01.4	CR	BS550(IND)-15-02-12	CONNECTING BLOCK (UPPER)
7881	8.09.0328.1.01.5	CR	BS550(IND)-15-02-11	PLATEN
7882	8.09.0329.1.01.6	CR	BS550(IND)-15-02-09	SLIDING RAIL COVER PLATE
7883	8.09.0330.1.01.7	CR	BS550(IND)-15-02-10	STIFFENED PANEL
7884	8.09.0331.1.01.8	CR	BS550(IND)-15-02-05	STIFFENED PANEL OF LEFT BROOM
7885	8.09.0332.1.01.9	CR	BS550(IND)-15-02-06-00	MECHANIC PIN PEDESTAL
7886	8.09.0333.1.01.1	CR	30mm	KEY RING
7887	8.09.0334.1.01.2	CR	BS550(IND)-15-02-13	LIMITATION STOP
7888	8.09.0335.1.01.3	CR	23067083	Gripping oil cylinder
7889	8.09.0336.1.01.4	PL	3000.08.141-US	BALLAST DEFLECTOR SHIELD
7890	8.09.0337.1.01.5	PL	PP.BOP.0678	SWEEPER WIRE BRUSH METAL

7891	8.09.0338.1.01.6	PL	RE25.975-1	BEARING BODY
7892	8.09.0339.1.01.7	PL	RE25.975-3	DRIVE SHAFT
7893	8.09.0340.1.01.8	PL	RE30.475	DRIVE STATION
7894	8.09.0341.1.01.9	PL	RE30.475-1	DRIVE SHAFT
7895	8.09.0342.1.01.1	PL	RE401.04	PINION
7896	8.09.0343.1.01.2	PL	SU1702.21.10.9	ROD END
7897	8.09.0344.1.01.3	PL	SU 1702.521.5.19	Fork head
7898	8.09.0345.1.01.4	PL	RE08.41.100	EXCAVATION CHAIN
7899	8.09.0346.1.01.5	PL	200412351	Buffer Unit
7900	8.09.0347.1.01.6	PL	200504384	Shaft Assembly
7901	8.09.0348.1.01.7	PL	200480107	V Belt Pulley
7902	8.09.0349.1.01.8	PL	201387092	Flywheel
7903	8.09.0350.1.01.9	PL	200608778	Balance Wheel
7904	8.09.0351.1.01.1	PL	200608358	Balance Wheel
7905	8.09.0352.1.01.2	PL	200608402	Balance Wheel
7906	8.09.0353.1.01.3	PL	WN152-5480.5480-8	Pump Carrier
7907	8.09.0354.1.01.4	PL	64.04.3290A	Pump Carrier
7908	8.09.0355.1.01.5	PL	64.04.3291A	Pump Carrier
7909	8.09.0356.1.01.6	PL	64.02.2291	DOUBLE GEAR WHEEL, Z=57/37
7910	8.09.0357.1.01.7	PL	WN70.8901	DRIVE SHAFT
7911	8.09.0358.1.01.8	PL	SU1702.21.1.4.3	BUSH
7912	8.09.0359.1.01.9	PL	RE20.218	COVER
7913	8.09.0360.1.01.1	PL	SU126.2011.1.8	COVER
7914	8.09.0361.1.01.2	PL	RE16.162	SIDE SHIELD
7915	8.09.0362.1.01.3	PL	RE25.975-7	FLANGE
7916	8.09.0363.1.01.4	PL	UD80.1003	Slide plate
7917	8.09.0364.1.01.5	PL	RE16.255	SLIDE PLATE
7918	8.09.0365.1.01.6	PL	RE15.255	SLIDE PLATE
7919	8.09.0366.1.01.7	PL	UD67.2105 LI	SLIDE PLATE
7920	8.09.0367.1.01.8	PL	UD67.2105 RE	SLIDE PLATE
7921	8.09.0368.1.01.9	PL	RE14.200LI/RE	CUTTER CHAIN DUCT UNIT ASSY LH
7922	8.09.0369.1.01.1	PL	RE15.200	CUTTER CHAIN DUCT UNIT ASSY LH
7923	8.09.0370.1.01.2	PL	RE16.200	CUTTER CHAIN DUCT UNIT ASSY RH
7924	8.09.0371.1.01.3	PL	RE20.275A	EXCAVATING CONVEYOR DRIVE STATION
7925	8.09.0372.1.01.4	PL	RE20.1050	EXCAVATING CONVEYOR IDLE STATION (REDIRECTING)
7926	8.09.0373.1.01.5	PL	RE30.150	MAIN CONVEYOR IDLE STATION
7927	8.09.0374.1.01.6	PL	RE20.550	DISTRIBUTION CONVEYOR IDLE STATION
7928	8.09.0375.1.01.7	PL	RE25.875	WASTE CONVEYOR DRIVE STATION
7929	8.09.0376.1.01.8	PL	RE25.250	WASTE CONVEYOR IDLE STATION
7930	8.09.0377.1.01.9	PL	RE30.450	TRANSFER CONVEYOR IDLE STATION
7931	8.09.0378.1.01.1	PL	RE600.200LI	SHOULDER PLOUGH UNIT LH
7932	8.09.0379.1.01.2	PL	RE600.200RE	SHOULDER PLOUGH UNIT RH
7933	8.09.0380.1.01.3	PL	RE800.100SP.1676LI	FRONT PLOUGH LH
7934	8.09.0381.1.01.4	PL	RE800.100SP.1676RE	FRONT PLOUGH RH
7935	8.09.0382.1.01.5	PL	RE403.200	BUCKET LINING
7936	8.09.0383.1.01.6	PL	RE25.975	Distribution Conveyor Belt complete Drive Station assembly
7937	8.09.0384.1.01.7	PL	RE20.511	GUIDE MEMBER,
7938	8.09.0385.1.01.8	PL	RE30.112	COVER,
7939	8.09.0386.1.01.9	PL	RE350.109	FRONT SECTION
7940	8.09.0387.1.01.1	PL	SU1702.521.3.20	WEAR PLATE
7941	8.09.0388.1.01.2	PL	SU1702.521.3.21	WEAR PLATE
7942	8.09.0389.1.01.3	PL	SU1702.21.1.4.2	BOLT
7943	8.09.0390.1.01.4	PL	SU1702.521.3.15	WEAR PLATE
7944	8.09.0391.1.01.5	PL	RE254.00 RE/LI	SAFETY DEVICE FRM 80
7945	8.09.0392.1.01.6	PL	RE20.310	STRIP
7946	8.09.0393.1.01.7	PL	RE20.311	STRIP
7947	8.09.0394.1.01.8	PL	RE403.101	Wear plate
7948	8.09.0395.1.01.9	PL	RE403.102	Wear plate
7949	8.09.0396.1.01.1	PL	RE403.103	Wear plate
7950	8.09.0397.1.01.2	PL	RE403.104	Wear plate
7951	8.09.0398.1.01.3	PL	RE403.205	Wear plate
7952	8.09.0399.1.01.4	PL	RE403.206	Wear plate
7953	8.09.0400.1.01.5	PL	RE403.207	Wear plate
7954	8.09.0401.1.01.6	PL	RE403.208	Wear plate
7955	8.09.0402.1.01.7	PL	RE403.109	Wear plate
7956	8.09.0403.1.01.8	PL	RE403.110	Wear plate
7957	8.09.0404.1.01.9	PL	RE403.111	Wear plate
7958	8.09.0405.1.01.1	PL	RE403.112	Wear plate
7959	8.09.0406.1.01.2	PL	RE403.113	Wear plate
7960	8.09.0407.1.01.3	PL	RE403.114	Wear plate
7961	8.09.0408.1.01.4	PL	RE403.115	Wear plate
7962	8.09.0409.1.01.5	PL	RE403.216	Wear plate
7963	8.09.0410.1.01.6	PL	RE403.217	Wear plate
7964	8.09.0411.1.01.7	PL	RE403.218	Wear plate
7965	8.09.0412.1.01.8	PL	RE403.219	Wear plate
7966	8.09.0413.1.01.9	PL	RE403.122	Wear plate
7967	8.09.0414.1.01.1	PL	RE403.223	Wear plate
7968	8.09.0415.1.01.2	PL	RE403.224	Wear plate
7969	8.09.0416.1.01.3	PL	RE403.225	Wear plate

7970	8.09.0417.1.01.4	PL	RE403.226	Wear plate
7971	8.09.0418.1.01.5	PL	RE403.227	Wear plate
7972	8.09.0419.1.01.6	PL	RE403.228	Strip
7973	8.10.0001.1.01.3	KE	30294	BUSHING
7974	8.10.0002.1.01.4	KE	82153	CLUTCH RELEASE YOKE
7975	8.10.0003.1.01.5	PL	UD 214-5430-DB	BRAKE BLOCK SHOE
7976	8.10.0004.1.01.6	PL	UD 61-402 PAS	SLIDE PLATE
7977	8.10.0005.1.01.7	PL	UD 67-2108 PAS	SLIDE PLATE (UNIMAT T. UNIT FRAME,TEFLAN PLATE)
7978	8.10.0006.1.01.8	Shifted to Ann II		
7979	8.10.0007.1.01.9	PL	62.08.8057	STRIP
7980	8.10.0008.1.01.1	KE	83705	BREATHER
7981	8.10.0009.1.01.2	KE	90583	YOKE SLIP WITH DUST CAP A
7982	8.10.0010.1.01.3	KE	115941	BOLT,PLOW 1/2"X2"
7983	8.10.0011.1.01.4	PL	SU 1702-21-1-5	TOOTHED DISK
7984	8.10.0012.1.01.5	PL	TSP/D/BS 8190	POP REVITS
7985	8.10.0013.1.01.6	KE	132179	PUSH PULL CABLE THROTTLE
7986	8.10.0014.1.01.7	KE	132277	PUSH PULL CABLE HIGH/LOW
7987	8.10.0015.1.01.8	PL	SU 1702-21-1-16	GUIDANCE
7988	8.10.0016.1.01.9	PL	SU 1702-21-1-17	GUIDANCE
7989	8.10.0017.1.01.1	KE	142123	CONTROL PROPELLING
7990	8.10.0018.1.01.2	PL	MSW 100 1101-31	SPRING BRAKE LINER REVERSER
7991	8.10.0019.1.01.3	PL	RE 20-275-2A	DRIVE SHAFT FOR EXCAVATING CONVEYOR BELT
7992	8.10.0020.1.01.4	PL	RE 20-415	COVER
7993	8.10.0021.1.01.5	PL	RE 20-416	COVER
7994	8.10.0022.1.01.6	PL	RE 30-275-3	DRIVE SHAFT FOR MAIN CONVEYOR BELT
7995	8.10.0023.1.01.7	KE	150064	BOLT, 1/2"X1 1/2"
7996	8.10.0024.1.01.8	KE	150101	CAP SCREW, HX HD 3/4"-10X2"
7997	8.10.0025.1.01.9	KE	150740	NUT (PLOW)
7998	8.10.0026.1.01.1	KE	150742	NUT 5/8"
7999	8.10.0027.1.01.2	KE	150744	LOCKNUT, 3/4"-10
8000	8.10.0028.1.01.3	KE	150746	LOCKNUT 1"-8
8001	8.10.0029.1.01.4	KE	150840	WASHER 5/8" LOCK
8002	8.10.0030.1.01.5	KE	151882	NUT 5/8"
8003	8.10.0031.1.01.6	PL	CRW-400-8790A	WEAR PLATE FOR R11
8004	8.10.0032.1.01.7	PL	CRW-400-8791A	WEAR PLATE FOR R11
8005	8.10.0033.1.01.8	PL	CRW-400-8792A-8P1667	WEAR PLATE FOR R11
8006	8.10.0034.1.01.9	PL	CRW-400-8793A-8P1667	WEAR PLATE FOR R11
8007	8.10.0035.1.01.1	PL	CRW-400-8794A-8P1667	WEAR PLATE FOR R11
8008	8.10.0036.1.01.2	PL	CRW-400-8795A-8P1667	WEAR PLATE FOR R11
8009	8.10.0037.1.01.3	PL	CRW-400-8796A-8P1667	WEAR PLATE FOR R11
8010	8.10.0038.1.01.4	PL	CRW-400-8799A-8P1667	WEAR PLATE FOR R11
8011	8.10.0039.1.01.5	PL	CRW-600-10-9A	WEAR STRIP FOR R11
8012	8.10.0040.1.01.6	PL	CRW-600-224	WEAR STRIP FOR R11
8013	8.10.0041.1.01.7	PL	CRW-800-909 LI-8P 1676	BALLST DEFLECTOR SHIELD -R11
8014	8.10.0042.1.01.8	PL	CRW-800-909 RE-8P 1676	BALLST DEFLECTOR SHIELD -R11
8015	8.10.0043.1.01.9	PL	CU 65-1062	BRACKET
8016	8.10.0044.1.01.1	PL	E 34-143 AS	DAMPING DISC
8017	8.10.0045.1.01.2	KE	186197	SPRING INNER FOR BRM
8018	8.10.0046.1.01.3	KE	186198	SPRING OUTER
8019	8.10.0047.1.01.4	PL	CRW-400-8789A	WEAR PLATE FOR R11
8020	8.10.0048.1.01.5	PL	CRW-400-8789A-8P1667	WEAR PLATE FOR R11
8021	8.10.0049.1.01.6	KE	194037	BROOM ELEMENT CLAMPS
8022	8.10.0050.1.01.7	KE	195258	STABILIZER FOR BRM
8023	8.10.0051.1.01.8	KE	196438	BOLT, PLOW
8024	8.10.0052.1.01.9	PL	CRW-400-8787B	WEAR PLATE FOR R11
8025	8.10.0053.1.01.1	PL	CRW-400-8788A	WEAR PLATE FOR R11
8026	8.10.0054.1.01.2	KE	201681	SOCHK ABSORBER
8027	8.10.0055.1.01.3	KE	203842	SPRING INNER
8028	8.10.0056.1.01.4	KE	207660	CLEVIS
8029	8.10.0057.1.01.5	KE	210011	CHAIN 60 DOUBLE
8030	8.10.0058.1.01.6	KE	211153	LINK MASTER
8031	8.10.0059.1.01.7	KE	211222	BUSHING
8032	8.10.0060.1.01.8	KE	211620	BUSHING
8033	8.10.0061.1.01.9	PL	CRW-400-8785A-8P1667	WEAR PLATE FOR R11
8034	8.10.0062.1.01.1	PL	CRW-400-8786B	WEAR PLATE FOR R11
8035	8.10.0063.1.01.2	KE	219265	ROLLER WITHOUT BEARING
8036	8.10.0064.1.01.3	KE	221427	BOLT, GRADER BLADE
8037	8.10.0065.1.01.4	KE	228553	TUBE PROPELLING BRM
8038	8.10.0066.1.01.5	PL	CRW-400-8784A8P1667	WEAR PLATE FOR R11
8039	8.10.0067.1.01.6	KE	229072	SPROKET
8040	8.10.0068.1.01.7	PL	CRW-400-8728-8P1667	WEAR PLATE FOR R11
8041	8.10.0069.1.01.8	PL	CRW-400-8729-8P1667	WEAR PLATE FOR R11
8042	8.10.0070.1.01.9	PL	CRW-400-8730-8P1667	WEAR PLATE FOR R11
8043	8.10.0071.1.01.1	PL	CRW-400-8731-8P1667	WEAR PLATE FOR R11

8044	8.10.0072.1.01.2	PL	CRW-400-8732-8P1667	WEAR PLATE FOR R11
8045	8.10.0073.1.01.3	PL	CRW-400-8781A-8P1667	WEAR PLATE FOR R11
8046	8.10.0074.1.01.4	PL	CRW-400-8782A-8P1667	WEAR PLATE FOR R11
8047	8.10.0075.1.01.5	PL	CRW-400-8783A-8P1667	WEAR PLATE FOR R11
8048	8.10.0076.1.01.6	KE	662089	SWIVEL
8049	8.10.0077.1.01.7	KE	662264	ADAPTOR SHAFT
8050	8.10.0078.1.01.8	PL	CRW 600-408 LI	GLIDER
8051	8.10.0079.1.01.9	PL	CRW 600-408 RE	GLIDER
8052	8.10.0080.1.01.1	PL	CRW-400-8717-8P1667	WEAR PLATE FOR R11
8053	8.10.0081.1.01.2	PL	CRW-400-8727-8P1667	WEAR PLATE FOR R11
8054	8.10.0082.1.01.3	KE	663182	SHAFT, INP UT TRANSMISSION
8055	8.10.0083.1.01.4	PL	CRW 600-406 RE	BRACKET
8056	8.10.0084.1.01.5	KE	700077	WING PINS
8057	8.10.0085.1.01.6	PL	CRW 600-10A-LI	WING
8058	8.10.0086.1.01.7	PL	CRW 600-10A-RE	WING
8059	8.10.0087.1.01.8	KE	718362	SPROKET
8060	8.10.0088.1.01.9	KE	704923 & 704334	SLIDER BOX & MOUNTING WING WITH BUSHES
8061	8.10.0089.1.01.1	KE	AR /120/132/12	WIPER
8062	8.10.0090.1.01.2	PL	CA216 100-1-STKL	BRAKE BLOCKS -R11
8063	8.10.0091.1.01.3	PL	CRW 600-109 N SA LI	PLOUGH PLATE
8064	8.10.0092.1.01.4	PL	CRW 600-109 N SA RE	PLOUGH PLATE
8065	8.10.0093.1.01.5	KE	731429	TUBE PROPELLING
8066	8.10.0094.1.01.6	KE	731430	TUBE PROPELLING
8067	8.10.0095.1.01.7	KE	799151	BRM WING ASSEMBLY
8068	8.10.0096.1.01.8	PL	62-11-1101	BEARING BODY
8069	8.10.0097.1.01.9	PL	62-11-1112	SHAFT
8070	8.10.0098.1.01.1	PL	UD61.402-PAS-LX	SLIDE PLATE
8071	8.10.0099.1.01.2	PL	CRW600.406LI	BRACKET
8072	8.10.0100.1.01.3	PL	CRW800.563	DOOR NAIL
8073	8.10.0101.1.01.4	PL	CRW800.906LI	COVER
8074	8.10.0102.1.01.5	PL	CRW800.906RE	COVER
8075	8.10.0103.1.01.6	KE	112533	PIN
8076	8.10.0104.1.01.7	KE	47520	CLEVIS
8077	8.10.0105.1.01.8	KE	176892	BOLT CARRIAGE
8078	8.10.0106.1.01.9	KE	510531	REEL FOR BROOM ASSY
8079	8.10.0107.1.01.1	KE	662242	FORK
8080	8.10.0108.1.01.2	KE	708158	ROD ADJUSTING
8081	8.10.0109.1.01.3	KE	708163	TUBE
8082	8.10.0110.1.01.4	KE	708164	BAR
8083	8.10.0111.1.01.5	PL	3000.08.139 US	BALLAST DEFLECTOR SHIELD
8084	8.10.0112.1.01.6	PL	3000.08.140	ROD END
8085	8.10.0113.1.01.7	PL	3000.03.122ABR	CHAIN WHEEL
8086	8.11.0001.1.01.4	PL	15-IN-20-10-I	SYNCRONISING SHAFT BIG FLANGE TYPE
8087	8.11.0002.1.01.5	PL	15-IN-20-10-II	SYNCRONISING SHAFT SMALL FLANGE TYPE
8088	8.11.0003.1.01.6	PL	15-IN-32-07	ADOPTER PLATE FOR PQRS
8089	8.11.0004.1.01.7	PL	62-10-4076	SWEEPER ELEMENT
8090	8.11.0005.1.01.8	SI	242001150001	MMS100 CUPLING
8091	8.12.0001.1.01.5	PL	02011507-0-006	O. T. CONVEYOR ASSEMBLY
8092	8.12.0002.1.01.6	HA	B8534 WAA	ROLLER SLED ASSEMBLY FOR TRT
8093	8.12.0003.1.01.7	HA	C 2511 WAA / C 2511 WAB	CARRIER WELDMENT FOR TRT
8094	8.12.0004.1.01.8	HA	C2510WAA	WATCH BEND SLED ASSEMBLY
8095	8.12.0005.1.01.9	HA	D 1911 VAD	OLD SLEEPER PICKUP UNIT
8096	8.12.0006.1.01.1	HA	D1913 WAC	ARM WELDMENT FOR TRT
8097	8.13.0001.1.01.6	AM	17083	SPRING HELICAL BALANCING - T 28
8098	8.13.0002.1.01.7		Shifted to Ann II	
8099	8.13.0003.1.01.8	AM	79632900	MANUAL CONTRL LEVER W/O CABLE T-28-VDO 8A
8100	8.13.0004.1.01.9	AM	222090009	BRAKE SHAFT FOR UTV
8101	8.13.0005.1.01.1	AM	2031001	T-28 Complete Frame
8102	8.13.0006.1.01.2	AM	2031006	T-28 Horizontal Structure with Rollers and Pins
8103	8.13.0007.1.01.3	AM	OO17022	T-28 Vertical Structure with Rollers and Pins
8104	8.13.0008.1.01.4	AM	RRULPC377D	Guide Roller PC366C
8105	8.13.0009.1.01.5	AM	61800009	Flow Divider PLD20/20
8106	8.13.0010.1.01.6	AM	60501015	Pipe Winder A2S-420
8107	8.13.0011.1.01.7	AM	2038001	Horizontal Sliding cylinder for T-28
8108	8.13.0012.1.01.8	COLMAR	H8802400	BRIDGE HOSE REEL WINDER
8109	8.13.0013.1.01.9	COLMAR	H8802401	BRIDGE HOSE REEL WINDER
8110	8.13.0014.1.01.1	COLMAR	H6031010	FILTER CATRIDGE KDW 702
8111	8.13.0015.1.01.2	COLMAR	H6031020	OIL FILTER CATRIDGE KDW 702
8112	8.13.0016.1.01.3	COLMAR	H6031030	AIR FILTER CATRIDGE KDW 702
8113	8.13.0017.1.01.4	COLMAR	H6032140	FILTER CATRIDGE 15LD 225
8114	8.13.0018.1.01.5	COLMAR	H6032150	OIL FILTER CATRIDGE 15LD 225
8115	8.13.0019.1.01.6	COLMAR	H6032160	FILTER CATRIDGE 15LD 225

8116	8.13.0019.1.01.7	COLMAR	H2035020	Valve
8117	8.13.0020.1.01.7	VOLVO PENTA	22253730	VISCOUS CLUTCH COUPLING
8118	8.13.0020.1.01.8	COLMAR	H1730070	Crawler Chain for T-28 (It includes 1 Nos of Crawler Chain, 55 Nos of Track Rubber Shoes, Screws and Nuts having 220 nos)
8119	8.14.0001.1.01.7	PL	GLF311.841 Sub. GLF311.856	ROLLER
8120	8.14.0002.1.01.8	PL	GLF311.847	AXLE
8121	8.14.0003.1.01.9	PL	U 73-253-D	VENTILATOR FOR DGS
8122	8.14.0004.1.01.1	PL	UD 220-9602	BRACKET
8123	8.14.0005.1.01.2	PL	UD 220-9603	BRACKET
8124	8.14.0006.1.01.3	PL	UD 220-9607	RING
8125	8.14.0007.1.01.4	PL	UD 236-3425	SCREWING PIECE
8126	8.14.0008.1.01.5	PL	UD 311-307	SPRING FOR DGS
8127	8.14.0009.1.01.6	PL	UD 313-3850-8	SPRING
8128	8.14.0010.1.01.7	PL	UNDRIVE M6000-07401000A10	COMMANDER UNIT
8129	8.14.0011.1.01.8	PL	UD64.16	Spacer ring
8130	8.14.0012.1.01.9	PL	UD64.344	Shaft
8131	8.14.0013.1.01.1	PL	GLF311.824	SLEEVE
8132	8.14.0014.1.01.2	PL	UD313.3850	Unit Stabilizer
8133	8.14.0015.1.01.3	PL	GLF70.259	Bearing Caze
8134	8.14.0016.1.01.4	PL	GLF70.212	Bearing Caze
8135	8.14.0017.1.01.5	PL	GLF311.2700/350-1SP1668/1676	VIBRATION UNIT (HORIZONTAL VIBRATOR)
8136	8.14.0018.1.01.6	PL	GLF.70.800	Horizontal vibrator (Yoke)
8137	8.14.0019.1.01.7	PL	GLF.70.850	Horizontal vibrator (Yoke)
8138	8.15.0001.1.01.8	PH	30210018	BEARING RETAINER
8139	8.15.0002.1.01.9	PH	30214006	BEARING CARRIER
8140	8.15.0003.1.01.1	PH	30214014	BEARING CARRIER
8141	8.15.0004.1.01.2	PH	30266001	SPRING DISC
8142	8.15.0005.1.01.3	PH	93010041	EXTERNAL CIRCLIP TYPE A
8143	8.15.0006.1.01.4	PH	1P2	CIRCLIP
8144	8.15.0007.1.01.5	PH	1P5	GM BUSH
8145	8.15.0008.1.01.6	PH	2P1	BOTTOM COVER
8146	8.15.0009.1.01.7	PH	2P11	PIN
8147	8.15.0010.1.01.8	PH	2P17	PIN
8148	8.15.0011.1.01.9	PH	2P18	G.M.BUSH
8149	8.15.0012.1.01.1	PH	2P2	CIRCLIP
8150	8.15.0013.1.01.2	PH	2P21	PIN LOCK PLATE
8151	8.15.0014.1.01.3	PH	2P22	PIN
8152	8.15.0015.1.01.4	PH	2P27	PIN
8153	8.15.0016.1.01.5	PH	2P31	PIN LOCK PLATE
8154	8.15.0017.1.01.6	PH	2P32	PIN
8155	8.15.0018.1.01.7	PH	2P36	PIN
8156	8.15.0019.1.01.8	PH	3ADGB06	SPACER SEAL INPUT
8157	8.15.0020.1.01.9	PH	3P1	MAIN BOOM
8158	8.15.0021.1.01.1	PH	3P18	RETAINER PLATE
8159	8.15.0022.1.01.2	PH	3P26	RETAINER PLATE
8160	8.15.0023.1.01.3	PH	3P3	2ND EXTENSION BOOM
8161	8.15.0024.1.01.4	PH	3P4	3RD EXTENSION BOOM
8162	8.15.0025.1.01.5	PH	3P5	HOOK
8163	8.15.0026.1.01.6	PH	3P7	RETAIN LOCK PLATE
8164	8.15.0027.1.01.7	PH	3P8	SLOTTED NUT
8165	8.15.0028.1.01.8	PH	6P8	10MM STEEL TUBING WITH SWIVEL ENDS
8166	8.15.0029.1.01.9	PH	7P6	10MM STEEL TUBING WITH SWIVEL ENDS
8167	8.15.0030.1.01.1	PH	UTV 1-04-09/00	BRAKE BLOCK FOR UTV
8168	8.15.0031.1.01.2	PH	UTV-0451/00	BUSH
8169	8.15.0032.1.01.3	PH	UTV1.04/41/00	BUSH
8170	8.15.0033.1.01.4	PH	UTV1.04/44/00	BUSH
8171	8.15.0034.1.01.5	PH	UTV1.04/45/00	BUSH
8172	8.15.0035.1.01.6	PH	UTV1.04/46/00	BUSH
8173	8.15.0036.1.01.7	PH	UTV1.04/47/00	BUSH
8174	8.15.0037.1.01.8	PH	UTV1.04/48/00	BUSH
8175	8.15.0038.1.01.9	PH	UTV1.04/49/00	BUSH
8176	8.15.0039.1.01.1	PH	UTV1.04/50/00	BUSH
8177	8.15.0040.1.01.2	PH	UTVI.01.09/00	HELICAL COIL SPRING
8178	8.15.0041.1.01.3	PH	UTVI.04 43/00	BUSH
8179	8.15.0042.1.01.4	PH	UTVI.04.42/00	BUSH
8180	8.15.0043.1.01.5	PH	UTVI-03 03/00	DUST SHIELD SPRING
8181	8.15.0044.1.01.6	PH	UTVI-03 04/00	DUST SHIELD
8182	8.15.0045.1.01.7	PH	UTVI-03 08/00	GUIDE BUSH
8183	8.15.0046.1.01.8	PH	UTVI-03 18/00	PIN
8184	8.15.0047.1.01.9	OEPL	447040010	ROLLER
8185	8.15.0048.1.01.1	OEPL	447050001	BRONZE WEAR BAR
8186	8.15.0049.1.01.2	PH	4P-25	COUPLING
8187	8.16.0001.1.01.9	PH	V 4OC PD 510	V RING

8188	8.16.0002.1.01.1	LO	104698	VALVE PRESS SECOND STAGE FITS UNDER DPCV
8189	8.16.0003.1.01.2	LO	109788	INSERT SHAFT COUPLING 500 SERIES HYTREL 50D
8190	8.16.0004.1.01.3	LO	109789	COUPLING HUB SPLINE 14T 12/24 SPLINE SPLIT
8191	8.16.0005.1.01.4	LO	112952	REGULATOR .75 NPT
8192	8.16.0006.1.01.5	LO	112991	THROTTLE SINGLE DIRECTION
8193	8.16.0007.1.01.6	LO	115045	DESICCANT PLUGS
8194	8.16.0008.1.01.7	LO	115307	BRUSH HOLDER ASSY; CONSTANT PRESSURE STYLE
8195	8.16.0009.1.01.8	LO	118407	FAN WHEEL COLLECTOR BLOWER
8196	8.16.0010.1.01.9	LO	120889	DOOR HOLDER
8197	8.16.0011.1.01.1	LO	124433	COUPLING SPLINED 13T 16/32DP X 17T 16/32DP
8198	8.16.0012.1.01.2	LO	126293	BLOWER COOLING LH 5 HP
8199	8.16.0013.1.01.3	LO	126294	BLOWER COOLING RH 5 HP
8200	8.16.0014.1.01.4	LO	127470	VALVE BTFL 90PSI 50GPM 4861 4861C SWITCH
8201	8.16.0015.1.01.5	LO	148468	VALVE REGULATOR CONTROL
8202	8.16.0016.1.01.6	LO	157789	BLANKET SPARK .13X17.25X131.00
8203	8.16.0017.1.01.7	LO	158496	BLANKET SPARK 17.46X19.69
8204	8.16.0018.1.01.8	LO	158634	ELEMENT
8205	8.16.0019.1.01.9	LO	159491	REGULATOR
8206	8.16.0020.1.01.1	LO	159498	ELEMENT OIL SEPERATOR
8207	8.16.0021.1.01.2	LO	159499	VALVE PRESSURE RELIEF
8208	8.16.0022.1.01.3	LO	159501	COOLER
8209	8.16.0023.1.01.4	LO	159502	FAN
8210	8.16.0024.1.01.5	LO	160494	BLANKET SPARK .065X33.00X147.00
8211	8.16.0025.1.01.6	LO	136247	STONE STOP MOUNTED ON MOTOR SHAFT
8212	8.16.0026.1.01.7	LO	144591	STONE 10V STD ; 10.23X6.00X3.25
8213	8.16.0027.1.01.8	LO	161253	COMP ASSY CONTROLS RGI
8214	8.16.0028.1.01.9	LO	161286	480V LOCKER ASSY; RGI CONTROL CAR
8215	8.16.0029.1.01.1	LO	177695	AIR CONDITIONER UNIT; TOP MOUNT
8216	8.16.0030.1.01.2	LO	177834	AIR CONDITIONER UNIT; BOTTOM MOUNT
8217	8.16.0031.1.01.3	LO	117440-ROLL	SPARK BLANKET 40 WIDE - 900" ROLL
8218	8.16.0032.1.01.4	LO	A61103	JOURNAL BOX 6.50 X 12.00; PLAIN/JEM TYPE
8219	8.16.0033.1.01.5	LO	A76178	END BRASS
8220	8.16.0034.1.01.6	LO	A78094	COUPLING HUB 1.88B .50 KW 500 SERIES SET SCREW
8221	8.16.0035.1.01.7	LO	A85052	VALVE SOL .50 NPT N CLSD 24 VDC
8222	8.16.0036.1.01.8	LO	B75056	NOZZLE FIRE HOSE 1 INCH SWIVEL INLET
8223	8.16.0037.1.01.9	LO	H22363	COUPLING 02FNPT 02FNPT; 3000# FS
8224	8.16.0038.1.01.1	LO	158672	ELEC INTERCONNECT ASSY; RGI5
8225	8.16.0039.1.01.2	LO	A86534	COVER DISTRIBUTION BLOCK
8226	8.16.0040.1.01.3	LO	111542	E STOP KIT
8227	8.16.0041.1.01.4	LO	111543	HEATER BLOCK ENGINE 120V 3000WATT
8228	8.16.0042.1.01.5	LO	162572	Bar gauge(Gauge Rail 66.00)
8229	8.16.0043.1.01.6	LO	148898	Star Gauge(Star Gauge 221195-1)
8230	8.16.0044.1.01.7	LO	117489	Isolator Universal Mount
8231	8.16.0045.1.01.8	LO	117573	Safty gate
8232	8.16.0046.1.01.9	LO	168477	SPRING ELLIPTIC BOLS SPCL; HEAVY DUTY .527 LEAVES
8233	8.16.0047.1.01.1	LO	160164	DRIVE TRUCK ASSY HD W TM
8234	8.16.0048.1.01.2	LO	110768	WIPER BLADE
8235	8.16.0049.1.01.3	LO	113853	ELBOW EXHAUST LEFT BANK; RG302 FRONT CONTROL CAR
8236	8.16.0050.1.01.4	LO	129421	HANDLE DS RED/YEL NEMA 4X
8237	8.16.0051.1.01.5	LO	129423	SHAFT DS FOR HANDLE
8238	8.16.0052.1.01.6	LO	162926	DITCH SPRAY GP ASSEMBLY
8239	8.16.0053.1.01.7	LO	163001	OIL COOLER ELEC ASSY; RGI GC
8240	8.16.0054.1.01.8	LO	B75603	NOZZLE ASSEMBLY 90X30-5
8241	8.16.0055.1.01.9	LO	C84386	NOZZLE FIRE HOSE 1 INCH SWIVEL INLET
8242	8.16.0056.1.01.1	LO	A48676	BEARING T.M.SUPPORT STANDARD 8.00 TWIN SEAL
8243	8.16.0057.1.01.2	LO	109290	BEARING T.M.SUPPORT .06 UNDERSIZE 8.00 TWIN SEAL
8244	8.16.0058.1.01.3	LO	109291	BEARING T.M.SUPPORT .09 UNDERSIZE 8.00 TWIN SEAL
8245	8.16.0059.1.01.4	LO	109292	BEARING T.M.SUPPORT .13 UNDERSIZE 8.00 TWIN SEAL

8246	8.16.0060.1.01.5	LO	123480	BEARING T.M.SUPPORT STANDARD 8.25 TWIN SEAL
8247	8.16.0061.1.01.6	LO	123461	BEARING T.M.SUPPORT .03 UNDERSIZE 8.25 TWIN SEAL
8248	8.16.0062.1.01.7	LO	123462	BEARING T.M.SUPPORT .06 UNDERSIZE 8.25 TWIN SEAL
8249	8.16.0063.1.01.8	LO	123463	BEARING T.M.SUPPORT .09 UNDERSIZE 8.25 TWIN SEAL
8250	8.16.0064.1.01.9	LO	123464	BEARING T.M.SUPPORT .13 UNDERSIZE 8.25 TWIN SEAL
8251	8.16.0065.1.01.1	LO	A72380	SEAL RING 8.00 DIA FOR T.M.SUPPORT BEARING
8252	8.16.0066.1.01.2	LO	123469	SEAL RING 8.25 DIA FOR T.M.SUPPORT BEARING
8253	8.16.0067.1.01.3	LO	123470	SEAL RING 8.25 DIA FOR T.M.SUPPORT BEARING
8254	8.16.0068.1.01.4	LO	A71693	GUARD RUBBER DUST SUPPORT BRG TO WHEEL HUB
8255	8.16.0069.1.01.5	LO	A71692	CLAMP DUST GUARD
8256	8.16.0070.1.01.6	LO	133765	GEARCASE ASSY RG TRACTION MOTOR
8257	8.16.0071.1.01.7	LO	142359	COVER BOTTOM BRUSH LARGE FOR CAST FRAME
8258	8.16.0072.1.01.8	LO	142360	COVER BOTTOM BRUSH LARGE FOR FAB FRAME
8259	8.16.0073.1.01.9	LO	142361	COVER BOTTOM BRUSH SMALL FOR CAST/FAB FRAME
8260	8.16.0074.1.01.1	LO	142362	GASKET BOTTOM BRUSH COVER LARGE FOR CAST FRAME
8261	8.16.0075.1.01.2	LO	142363	GASKET BOTTOM BRUSH COVER LARGE FOR FAB FRAME
8262	8.16.0076.1.01.3	LO	142364	GASKET BOTTOM BRUSH COVER SMALL FOR CAST/FAB FRAME
8263	8.16.0077.1.01.4	LO	140194	TM SUSPENSION ASSY RUBBER NOSE PACK
8264	8.16.0078.1.01.5	LO	117146	TUBE ASSY.BENT 0.50X.065 ss orfs; carriage cyl.lift top
8265	8.16.0079.1.01.6	LO	252351-170	FUEL SYSTEM MAINTENANCE KIT, SMALL
8266	8.16.0080.1.01.7	LO	252351-171	FUEL SYSTEM MAINTENANCE KIT, LARGE
8267	8.16.0081.1.01.8	LO	252351-172	FUEL SYSTEM REPAIR KIT, SMALL
8268	8.16.0082.1.01.9	LO	252351-173	FUEL SYSTEM REPAIR KIT, LARGE
8269	8.16.0083.1.01.1	LO	252351-174	ENGINE/POWER SYSTEM MAINTENANCE KIT, SMALL
8270	8.16.0084.1.01.2	LO	252351-175	ENGINE/POWER SYSTEM MAINTENANCE KIT, LARGE
8271	8.16.0085.1.01.3	LO	252351-176	ENGINE/POWER SYSTEM REPAIR KIT, SMALL
8272	8.16.0086.1.01.4	LO	252351-177	ENGINE/POWER SYSTEM REPAIR KIT, MED
8273	8.16.0087.1.01.5	LO	252351-178	ENGINE/POWER SYSTEM REPAIR KIT, LARGE
8274	8.16.0088.1.01.6	LO	252351-179	ENGINE/POWER SYSTEM OVERHAUL KIT
8275	8.16.0089.1.01.7	LO	252351-59	ENGINE INJECTOR KIT #2
8276	8.16.0090.1.01.8	LO	252351-60	ENGINE INJECTOR KIT #1
8277	8.16.0091.1.01.9	LO	125627	MAIN RESERVOIR (LEFTHAND)
8278	8.16.0092.1.01.1	LO	125628	MAIN RESERVOIR (RIGHTHAND)
8279	8.16.0093.1.01.2	LO	252351-2	ENGINE EXHAUST KIT #1
8280	8.16.0094.1.01.3	LO	252351-11	ENGINE SYSTEM KIT #1
8281	8.16.0095.1.01.4	LO	252351-12	ENGINE SYSTEM KIT #2
8282	8.16.0096.1.01.5	LO	249744	AIR FILTER; SECONDARY
8283	8.16.0097.1.01.6	LO	249743	AIR FILTER; PRIMARY
8284	8.16.0098.1.01.7	LO	251111	PRECLEANER; AIR CLEANER
8285	8.16.0099.1.01.8	LO	249344	ELBOW 90 DEG; MACHINE LEFT
8286	8.16.0100.1.01.9	LO	249345	ELBOW 90 DEG; MACHINE RIGHT
8287	8.16.0101.1.01.1	LO	249378	ELBOW 90 DEG WITH BELLOWES; MACHINE LEFT
8288	8.16.0102.1.01.2	LO	252351-69	EXHAUST INSULATION REPAIR KIT #1
8289	8.16.0103.1.01.3	LO	249641	INSULATION SILENCER RH
8290	8.16.0104.1.01.4	LO	249640	INSULATION SILENCER LH
8291	8.16.0105.1.01.5	LO	249636	INSULATION ELBOW; LEFT BANK EXHAUST
8292	8.16.0106.1.01.6	LO	249637	INSULATION ELBOW; RIGHT BANK EXHAUST
8293	8.16.0107.1.01.7	LO	252351-70	AIR CLEANER REPAIR KIT
8294	8.16.0108.1.01.8	LO	252351-72	ENGINE REPAIR KIT #3
8295	8.16.0109.1.01.9	LO	252351-75	ENGINE BELTS KIT

8296	8.16.0110.1.01.1	LO	240415	CIRCUIT BREAKER DS HANDLE FLANGE; W/ 48" CIRCUIT BREAKER & MECH
8297	8.16.0111.1.01.2	LO	167046	V-BELT
8298	8.16.0112.1.01.3	LO	166938	FILTER GENERATOR STEEL 20X25X2
8299	8.16.0113.1.01.4	LO	252351-87	ENGINE REPAIR KIT #3
8300	8.16.0114.1.01.5	LO	237620	BRACKET MOD CATCH
8301	8.16.0115.1.01.6	LO	252351-91	ENGINE REPAIR KIT #3
8302	8.16.0116.1.01.7	LO	251160	FILTER AIR;SECONDARY TOP/REAR
8303	8.16.0117.1.01.8	LO	207052	FILTER 4IN 16X20; PLEATED PAPER
8304	8.16.0118.1.01.9	LO	252351-103	ENGINE REPAIR KIT
8305	8.16.0119.1.01.1	LO	B83501	THERMOSTAT
8306	8.16.0120.1.01.2	LO	115079	CUT OFF ENCLOSURE 1
8307	8.16.0121.1.01.3	LO	115080	ENCLOSURE 2 CUT OFF
8308	8.16.0122.1.01.4	LO	144046	AC/HEATER UNIT 115VAC 60HZ 1PHASE
8309	8.16.0123.1.01.5	LO	252351-77	RAIL PROFILE REPAIR KIT - LARGE
8310	8.16.0124.1.01.6	LO	252351-180	ELECTRICAL SYSTEM MAINTENANCE KIT, SMALL
8311	8.16.0125.1.01.7	LO	252351-181	ELECTRICAL SYSTEM MAINTENANCE KIT, LARGE
8312	8.16.0126.1.01.8	LO	252351-182	ELECTRICAL SYSTEM REPAIR KIT, SMALL
8313	8.16.0127.1.01.9	LO	252351-183	ELECTRICAL SYSTEM REPAIR KIT, MED
8314	8.16.0128.1.01.1	LO	252351-184	ELECTRICAL SYSTEM REPAIR KIT, LARGE
8315	8.16.0129.1.01.2	LO	252351-185	ELECTRICAL SYSTEM OVERHAUL KIT
8316	8.16.0130.1.01.3	LO	252351-1	ELECTRICAL KIT #1
8317	8.16.0131.1.01.4	LO	252351-215	ELECTRICAL KIT #2
8318	8.16.0132.1.01.5	LO	252351-3	ELECTRICAL KIT #3
8319	8.16.0133.1.01.6	LO	252351-5	ELECTRICAL KIT #4
8320	8.16.0134.1.01.7	LO	131706	BUZZER 24V AC/DC ROUND BLACK
8321	8.16.0135.1.01.8	LO	252351-18	ELECTRICAL KIT #5
8322	8.16.0136.1.01.9	LO	115416	FAN COOLING 100CFM 120VAC 60HZ
8323	8.16.0137.1.01.1	LO	252351-22	ELECTRICAL KIT #6
8324	8.16.0138.1.01.2	LO	116405	RECEPTACLE DPLEX 120V 15A DIN RAIL MOUNT COMPLETE
8325	8.16.0139.1.01.3	LO	252351-24	ELECTRICAL KIT #7
8326	8.16.0140.1.01.4	LO	252351-28	ELECTRICAL KIT #8
8327	8.16.0141.1.01.5	LO	252351-29	ELECTRICAL KIT #9
8328	8.16.0142.1.01.6	LO	118098	CONTROLNET TERMINATOR 75 OHM
8329	8.16.0143.1.01.7	LO	252351-35	ELECTRICAL KIT #10
8330	8.16.0144.1.01.8	LO	260016	CABLE OPERATED FLANGE KIT; XT3 CB
8331	8.16.0145.1.01.9	LO	242911	CLEVIS BRACKET MACHINED; MOD LIFT ROD END
8332	8.16.0146.1.01.1	LO	126257	CONDUIT ST 2.00 CONN MYERS
8333	8.16.0147.1.01.2	LO	252351-48	METER REPLACEMENT KIT #1
8334	8.16.0148.1.01.3	LO	252351-51	ELECTRICAL KIT #11
8335	8.16.0149.1.01.4	LO	252351-52	ELECTRICAL KIT #12
8336	8.16.0150.1.01.5	LO	252351-53	ENGINE REPAIR KIT #2
8337	8.16.0151.1.01.6	LO	252351-55	ELECTRICAL KIT #13
8338	8.16.0152.1.01.7	LO	139276	CONDUIT RIG RDG BUSHING; 2 IN TO 1 IN
8339	8.16.0153.1.01.8	LO	252351-67	ELECTRICAL KIT #14
8340	8.16.0154.1.01.9	LO	252351-68	ELECTRICAL KIT #15
8341	8.16.0155.1.01.1	LO	A39313	CONDUIT SEALTITE 1-1/4 (MINIMUM QTY 10)
8342	8.16.0156.1.01.2	LO	252351-89	ELECTRICAL KIT #16
8343	8.16.0157.1.01.3	LO	252351-96	ELECTRICAL KIT #17
8344	8.16.0158.1.01.4	LO	252351-98	ELECTRICAL KIT #18
8345	8.16.0159.1.01.5	LO	252351-102	ELECTRICAL KIT #19
8346	8.16.0160.1.01.6	LO	A87501	BOOT RUBBER MOTOR LEADS FOR PIGTAIL CONNECTOR
8347	8.16.0161.1.01.7	LO	A88802	CONDUIT GASKET 1.25 SEAL
8348	8.16.0162.1.01.8	LO	252351-104	ELECTRICAL KIT #20
8349	8.16.0163.1.01.9	LO	252351-106	ELECTRICAL KIT #21
8350	8.16.0164.1.01.1	LO	B83657	LENS 2.8-12MM ASPHERICAL DC IRIS
8351	8.16.0165.1.01.2	LO	255115	CAMERA VIDEO 2.1MP HD; 30FPS HD- ANALOG HD-TVI or HD-CVI OUTPUTS
8352	8.16.0166.1.01.3	LO	252351-207	ELECTRICAL REPAIR KIT - SMALL
8353	8.16.0167.1.01.4	LO	252351-219	TRACTION SYSTEM KIT
8354	8.16.0168.1.01.5	LO	252351-221	TRACTION SYSTEM KIT #2
8355	8.16.0169.1.01.6	LO	244116	CARRIAGE SUPPORT WELDT; RH
8356	8.16.0170.1.01.7	LO	252351-46	TRACTION SYSTEM HOSE AND FITTING KIT
8357	8.16.0171.1.01.8	LO	169947	SKID PLATE ASSEMBLY FLEX BUGGY

8358	8.16.0172.1.01.9	LO	242906	MODULE TILT ASSY
8359	8.16.0173.1.01.1	LO	252351-222	TRACTION SYSTEM KIT #3
8360	8.16.0174.1.01.2	LO	242925	MODULE ASSY 25HP
8361	8.16.0175.1.01.3	LO	252351-82	FILTER KIT #2
8362	8.16.0176.1.01.4	LO	242929	CARRIAGE SUPPORT ASSY LH
8363	8.16.0177.1.01.5	LO	252351-121	TRACTION SYSTEM MAINTENANCE KIT, SMALL
8364	8.16.0178.1.01.6	LO	252351-122	TRACTION SYSTEM MAINTENANCE KIT, LARGE
8365	8.16.0179.1.01.7	LO	252351-123	TRACTION SYSTEM REPAIR KIT, SMALL
8366	8.16.0180.1.01.8	LO	252351-124	TRACTION SYSTEM REPAIR KIT, LARGE
8367	8.16.0181.1.01.9	LO	252351-125	TRACTION SYSTEM OVERHAUL KIT
8368	8.16.0182.1.01.1	LO	172844	MANIFOLD ASSEMBLY BUGGY LIFT
8369	8.16.0183.1.01.2	LO	244208	BOTTOM PLATE MACHINED; MODULE ASSY
8370	8.16.0184.1.01.3	LO	244205	TOP PLATE MACHINED; MODULE ASSY
8371	8.16.0185.1.01.4	LO	157035	TUBE SLIDE ASSEMBLY BUGGY TOW
8372	8.16.0186.1.01.5	LO	244952	BRACKET ASSY; SLIDE TUBE TOW BALL
8373	8.16.0187.1.01.6	LO	245342	SPARK GUARD UPPER; 17.50X22.50X11GA
8374	8.16.0188.1.01.7	LO	114771	STRAINER SUCTION 3 NPT INTANK 30 MESH W/BYPASS
8375	8.16.0189.1.01.8	LO	252351-42	CYLINDER SEAL KIT #1
8376	8.16.0190.1.01.9	LO	252351-43	CYLINDER SEAL KIT #2
8377	8.16.0191.1.01.1	LO	252351-44	CYLINDER SEAL KIT #3
8378	8.16.0192.1.01.2	LO	142885	O-RING FUEL LIFT PUMP ELECTRIC
8379	8.16.0193.1.01.3	LO	252351-71	CYLINDER SEAL KIT #4
8380	8.16.0194.1.01.4	LO	252351-73	CYLINDER SEAL KIT #5
8381	8.16.0195.1.01.5	LO	252351-74	GRINDING SYSTEM KIT #2
8382	8.16.0196.1.01.6	LO	161650	PLATE SEAL 3261C 3261C; .50 THICK THROUGH HOLES
8383	8.16.0197.1.01.7	LO	237639	TILT STOP WELDT; GAUGE LH
8384	8.16.0198.1.01.8	LO	252351-217	DERAIL DETECTION KIT
8385	8.16.0199.1.01.9	LO	251112	HUMP HOSE REDUCER; 7.00X5.50
8386	8.16.0200.1.01.1	LO	A37405	SEAL ROD STANDARD POLYPAK 2.25 IDX2.75 ODX.25 W
8387	8.16.0201.1.01.2	LO	252351-90	CYLINDER END KIT #2
8388	8.16.0202.1.01.3	LO	A66395	SEAL CLAMP FLAT SS 6.00 DIA
8389	8.16.0203.1.01.4	LO	252351-95	GAUGE REPAIR KIT #1
8390	8.16.0204.1.01.5	LO	252351-97	GAUGE REPAIR KIT #2
8391	8.16.0205.1.01.6	LO	237691	TILT STOP WELDT; FIELD/STONE CHANGE
8392	8.16.0206.1.01.7	LO	242945	SNAP RING 1.78 OD; INVERTED LUGS .062 WIDTH
8393	8.16.0207.1.01.8	LO	252351-191	MECHANICAL SYSTEM MAINTENANCE KIT, SMALL
8394	8.16.0208.1.01.9	LO	252351-192	MECHANICAL SYSTEM MAINTENANCE KIT, LARGE
8395	8.16.0209.1.01.1	LO	252351-193	MECHANICAL SYSTEM REPAIR KIT, SMALL
8396	8.16.0210.1.01.2	LO	252351-194	MECHANICAL SYSTEM REPAIR KIT, LARGE
8397	8.16.0211.1.01.3	LO	252351-199	10 STONE BUGGY SYSTEM REPAIR KIT, SMALL
8398	8.16.0212.1.01.4	LO	252351-200	10 STONE BUGGY SYSTEM REPAIR KIT, LARGE
8399	8.16.0213.1.01.5	LO	252351-201	10 STONE BUGGY SYSTEM MAINTENANCE KIT, SMALL
8400	8.16.0214.1.01.6	LO	252351-202	10 STONE BUGGY SYSTEM MAINTENANCE KIT, MED
8401	8.16.0215.1.01.7	LO	252351-203	10 STONE BUGGY SYSTEM MAINTENANCE KIT, LARGE
8402	8.16.0216.1.01.8	LO	252351-204	10 STONE BUGGY SYSTEM OVERHAUL KIT
8403	8.16.0217.1.01.9	LO	252351-30	MECHANICAL KIT #4
8404	8.16.0218.1.01.1	LO	252351-31	MECHANICAL KIT #5
8405	8.16.0219.1.01.2	LO	252351-32	MECHANICAL KIT #6
8406	8.16.0220.1.01.3	LO	252351-34	MECHANICAL KIT #8
8407	8.16.0221.1.01.4	LO	242926	TILT STOP ASSY; RGM BUGGY FIELD/GAUGE
8408	8.16.0222.1.01.5	LO	242930	CARRIAGE SUPPORT WELDT; LH
8409	8.16.0223.1.01.6	LO	207214	MOTOR GRINDING STR SHAFT; 256TC ALUMINUM FRAME TEAO
8410	8.16.0224.1.01.7	LO	247870	DITCH AND TIE SPRAY ASSY; DITCH 8-30GPM/TIE 1.5GPM

8411	8.16.0225.1.01.8	LO	252351-134	RAIL MEASUREMENT SYSTEM MAINTENANCE KIT, SMALL
8412	8.16.0226.1.01.9	LO	252351-135	RAIL MEASUREMENT SYSTEM MAINTENANCE KIT, LARGE
8413	8.16.0227.1.01.1	LO	252351-136	RAIL MEASUREMENT SYSTEM REPAIR KIT, SMALL
8414	8.16.0228.1.01.2	LO	252351-137	RAIL MEASUREMENT SYSTEM REPAIR KIT, LARGE
8415	8.16.0229.1.01.3	LO	252351-138	RAIL MEASUREMENT SYSTEM OVERHAUL KIT
8416	8.16.0230.1.01.4	LO	252351-143	MECHANICAL SYSTEM MAINTENANCE KIT, SMALL
8417	8.16.0231.1.01.5	LO	252351-144	MECHANICAL SYSTEM MAINTENANCE KIT, LARGE
8418	8.16.0232.1.01.6	LO	252351-145	MECHANICAL SYSTEM REPAIR KIT, SMALL
8419	8.16.0233.1.01.7	LO	252351-146	MECHANICAL SYSTEM REPAIR KIT, LARGE
8420	8.16.0234.1.01.8	LO	245610-02	DOOR ASSY 5ST; BUGGY DUST CONTAINMENT
8421	8.16.0235.1.01.9	LO	252351-S01	STONE 10V STD 10.23ODX6.00IDX3.25
8422	8.16.0236.1.01.1	LO	252351-S02	STONE GRINDING WHEEL 11V; 6.00OD X 2.50ID X 3.00
8423	8.16.0237.1.01.2	LO	165739	BRACKET WELDT; SPARK BLANKET
8424	8.16.0238.1.01.3	LO	102154	CONDUIT GASKET 1.50 SEAL (MIN QTY 10)
8425	8.16.0239.1.01.4	LO	207476	LATCH FLEX DRAW
8426	8.16.0240.1.01.5	LO	106759	CLAMP-EASY DUCT 12.00 DIA
8427	8.16.0241.1.01.6	LO	207567	PIVOT WELDT; DUST CONTAINMENT
8428	8.16.0242.1.01.7	LO	112175	STRIKER-PADDLE LATCH
8429	8.16.0243.1.01.8	LO	208669	PIN MODULE LIFT STOP; .75 OD M12 THREAD
8430	8.16.0244.1.01.9	LO	252351-17	MECHANICAL KIT #1
8431	8.16.0245.1.01.1	LO	252351-20	MECHANICAL KIT #2
8432	8.16.0246.1.01.2	LO	115298	ENCLOSURE 10X4X3 NEMA 4
8433	8.16.0247.1.01.3	LO	117095	SLEEVE 25.13 I.D.
8434	8.16.0248.1.01.4	LO	208800	BRACKET MOTOR TOP LH; SPARK GUARD DEFLECTOR
8435	8.16.0249.1.01.5	LO	117428	STANDOFF THRD MALE/FEMALE; .25 X.50 8-32 THREAD
8436	8.16.0250.1.01.6	LO	252351-27	MECHANICAL KIT #3
8437	8.16.0251.1.01.7	LO	245329	BULKHEAD WELDT; DUST CONTAINMENT 5ST
8438	8.16.0252.1.01.8	LO	242902	CLAMP BLOCK; TILT BUSHING
8439	8.16.0253.1.01.9	LO	118703	DOOR LATCH GROUP METRIC VERSION
8440	8.16.0254.1.01.1	LO	209346	BRACKET GAS SPRING; LEFT HAND
8441	8.16.0255.1.01.2	LO	244169	STONE HOLDER ASSY; 10" STRAIGHT SHAFT
8442	8.16.0256.1.01.3	LO	209347	BRACKET GAS SPRING; RIGHT HAND
8443	8.16.0257.1.01.4	LO	207720	SPARK BLANKET CENTER; DUST CONTAINMENT
8444	8.16.0258.1.01.5	LO	178368	STONE HOLDER ASSY 6 INCH; FOR STRAIGHT SHAFT MOTOR
8445	8.16.0259.1.01.6	LO	154040	MOUNT WELDT; PUMP DRIVE
8446	8.16.0260.1.01.7	LO	241590-00	ENCL ASSY LADDER BOM ONLY; BASE COMPONENTS
8447	8.16.0261.1.01.8	LO	178203	STONE STOP 6 INCH STONE; FOR STRAIGHT SHAFT MOTOR
8448	8.16.0262.1.01.9	LO	129008	FILTER ELEMENT REPLACEMENT FOR 125419 BLOWER1/12HP 460VAC
8449	8.16.0263.1.01.1	LO	252351-58	MECHANICAL KIT #9
8450	8.16.0264.1.01.2	LO	131538	TENSIONER ASSY AUTO FAN IDLER
8451	8.16.0265.1.01.3	LO	252351-63	MECHANICAL KIT #10
8452	8.16.0266.1.01.4	LO	178223	STONE STOP 10 INCH STONE FOR STRAIGHT SHAFT MOTOR
8453	8.16.0267.1.01.5	LO	252351-65	MECHANICAL KIT #11
8454	8.16.0268.1.01.6	LO	252351-66	MECHANICAL KIT #12
8455	8.16.0269.1.01.7	LO	146636	SPRING TORSION
8456	8.16.0270.1.01.8	LO	245343	SPARK GUARD LOWER; 9.50X22.50X11GA
8457	8.16.0271.1.01.9	LO	249332	CAP RAIN COVER
8458	8.16.0272.1.01.1	LO	165090	BLANKET SPARK LONG
8459	8.16.0273.1.01.2	LO	165711	BLANKET SPARK SHORT
8460	8.16.0274.1.01.3	LO	207719	SPARK BLANKET SHORT; DUST CONTAINMENT
8461	8.16.0275.1.01.4	LO	245236	SHAFT 3.00; 2.00 ID X 48.25 LG
8462	8.16.0276.1.01.5	LO	252351-76	SPARK CONTAINMENT REPAIR KIT SMALL

8463	8.16.0277.1.01.6	LO	207696	SPARK BLANKET LONG; DUST CONTAINMENT
8464	8.16.0278.1.01.7	LO	207568	END WALL WELDT; DUST CONTAINMENT
8465	8.16.0279.1.01.8	LO	252351-83	MECHANICAL KIT #13
8466	8.16.0280.1.01.9	LO	252351-84	MECHANICAL KIT #14
8467	8.16.0281.1.01.1	LO	252351-85	MECHANICAL KIT #15
8468	8.16.0282.1.01.2	LO	248744	BRACKET WELDT; SPARK BLANKET 1600MM
8469	8.16.0283.1.01.3	LO	A26562	EYE SWIVEL
8470	8.16.0284.1.01.4	LO	249479	CLAMP V-BAND
8471	8.16.0285.1.01.5	LO	A61025	GROMMET TOP (REPLACES A61027)
8472	8.16.0286.1.01.6	LO	A61026	GROMMET BOTTOM (REPLACES A92141)
8473	8.16.0287.1.01.7	LO	252351-92	MECHANICAL KIT #16
8474	8.16.0288.1.01.8	LO	252351-93	MECHANICAL KIT #17
8475	8.16.0289.1.01.9	LO	A70871	CONDUIT GASKET 1.00 SEAL
8476	8.16.0290.1.01.1	LO	245357	CLAMP T-BOLT 6.28 IN - 6.59 IN
8477	8.16.0291.1.01.2	LO	A83286	KIT-SOUND UNIT REPAIR FOR USE W/A15560-HORN
8478	8.16.0292.1.01.3	LO	252351-100	VALVE REPAIR KIT #1
8479	8.16.0293.1.01.4	LO	252351-S03	STONE C715 STD; 10.23X6.00X3.25
8480	8.16.0294.1.01.5	LO	B82744	FITTING-LUBE MODIFIED
8481	8.16.0295.1.01.6	LO	178224	STONE HOLDER ASSY 10 INCH; FOR STRAIGHT SHAFT MOTOR
8482	8.16.0296.1.01.7	LO	H17570	FITTING LUBE .12NPT STR EXTRA SHORT
8483	8.16.0297.1.01.8	LO	252351-206	MECHANICAL REPAIR KIT - SMALL
8484	8.16.0298.1.01.9	LO	H26774	GASKET
8485	8.16.0299.1.01.1	LO	252351-209	MECHANICAL REPAIR KIT #1
8486	8.16.0300.1.01.2	LO	252351-210	MECHANICAL REPAIR KIT #2
8487	8.16.0301.1.01.3	LO	252351-211	MECHANICAL REPAIR KIT #3
8488	8.16.0302.1.01.4	LO	209896	BRACKET BULKHEAD SUPPORT; RIGHT HAND
8489	8.16.0303.1.01.5	LO	252351-212	MECHANICAL REPAIR KIT #4
8490	8.16.0304.1.01.6	LO	252351-213	MECHANICAL REPAIR KIT #5
8491	8.16.0305.1.01.7	LO	165391	SKID WELDT DERAIL DETECTION
8492	8.16.0306.1.01.8	LO	171788	BUMPER 1.01 FREE HEIGHT
8493	8.16.0307.1.01.9	LO	252351-38	AIR SYSTEM KIT #2
8494	8.16.0308.1.01.1	LO	157441	DUST HOPPER ASSY
8495	8.16.0309.1.01.2	LO	160969	DUST BLOWER ASSEMBLY
8496	8.16.0310.1.01.3	LO	252351-166	DUST SYSTEM MAINTENANCE KIT, SMALL
8497	8.16.0311.1.01.4	LO	252351-167	DUST SYSTEM MAINTENANCE KIT, LARGE
8498	8.16.0312.1.01.5	LO	252351-168	DUST SYSTEM REPAIR KIT, SMALL
8499	8.16.0313.1.01.6	LO	252351-169	DUST SYSTEM REPAIR KIT, LARGE
8500	8.16.0314.1.01.7	LO	157439	DUCT; 12.00 DIA X 6.00 LG
8501	8.16.0315.1.01.8	LO	157440	DUCT; 12.00 DIA X 19.13 LG
8502	8.16.0316.1.01.9	LO	251110	AIR CLEANER ASSEMBLY
8503	8.16.0317.1.01.1	LO	112798	MODULE BASE PLATE
8504	8.16.0318.1.01.2	LO	159425	CARRIAGE AXLE ASSY; RGI 1676MM GAUGE
8505	8.16.0319.1.01.3	LO	159301	MODULE TILT ASSY HYD TILT
8506	8.16.0320.1.01.4	LO	158838	GENERATOR 900KW
8507	8.16.0321.1.01.5	LO	159424	CONTAINMENT GROUP
8508	8.16.0322.1.01.6	LO	159451	CENTER BEAM WELDT
8509	8.16.0323.1.01.7	LO	114886	TUBE ENGINE AIR INLET; 7.00ODX10.00
8510	8.16.0324.1.01.8	LO	152100	INSULATION SILENCER LH; NO DWG
8511	8.16.0325.1.01.9	LO	152099	INSULATION SILENCER RH; NO DWG
8512	8.16.0326.1.01.1	LO	115177	HOOK ASSY
8513	8.16.0327.1.01.2	LO	148472	SWITCH COMPRESSOR TEMP
8514	8.16.0328.1.01.3	LO	148475	SWITCH COMPRESSOR OVERPRESSURE
8515	8.16.0329.1.01.4	LO	159500	CONTROL SWITCH
8516	8.16.0330.1.01.5	LO	100171	ROD END MALE 1.00
8517	8.16.0331.1.01.6	LO	A61520	CLEVIS BRACKET .50
8518	8.16.0332.1.01.7	LO	159427	BLANKET SPARK CARRIAGE END
8519	8.16.0333.1.01.8	LO	126302	BLANKET END
8520	8.16.0334.1.01.9	LO	125362	ENGINE QST 30-G5
8521	8.16.0335.1.01.1	LO	131531	TURBOCHARGER HX80
8522	8.16.0336.1.01.2	LO	131533	PUMP FUEL INJECTOR BOSCH RIGHT SIDE
8523	8.16.0337.1.01.3	LO	131534	PUMP FUEL INJECTOR BOSCH LEFT SIDE
8524	8.16.0338.1.01.4	LO	127007	MAG PICKUP
8525	8.16.0339.1.01.5	LO	A31556	KIT CONTACT
8526	8.16.0340.1.01.6	LO	A31557	KIT CONTACT
8527	8.16.0341.1.01.7	LO	113856	SHAFT WELDT
8528	8.16.0342.1.01.8	LO	159433	A FRAME WELDT; RGI 1676MM GAUGE
8529	8.16.0343.1.01.9	LO	A24365	SWIVEL EYE .75
8530	8.16.0344.1.01.1	LO	112793	BRACKET ASSY
8531	8.16.0345.1.01.2	LO	112799	MODULE TOP PLATE

8532	8.16.0346.1.01.3	LO	B61167	BRACKET EYE ASSY
8533	8.16.0347.1.01.4	LO	D90671	STONE HOLDER 10 INCH
8534	8.16.0348.1.01.5	LO	123414	BUSHING HARDENED STEEL 1.00 ODX.63 IDX.63 LG
8535	8.16.0349.1.01.6	LO	A76173	GAUGE-OIL MANUAL
8536	8.16.0350.1.01.7	LO	111546	GAUGE MANUAL COOLANT TEMP
8537	8.16.0351.1.01.8	LO	161511	DIVIDER FLOW 2 SECT GEAR 7-14 GPM PER SECTION
8538	8.16.0352.1.01.9	LO	149564	COIL D03 PLUGIN 24VDC DIN
8539	8.16.0353.1.01.1	LO	149569	COIL D05 24VDC DIN
8540	8.16.0354.1.01.2	LO	124382	RECESSED WINDOW ASSY
8541	8.16.0355.1.01.3	LO	114466	CONTACTOR 05.0 HP IEC 120 VAC COIL 1 NO
8542	8.16.0356.1.01.4	LO	A72594	CONTACT BLOCK - PUSH BUTTON
8543	8.16.0357.1.01.5	LO	117488	ISOLATOR UNIVERSAL MOUNT .38 BOLT 130 LBA/36 LBR
8544	8.16.0358.1.01.6	LO	125988	MANIFOLD AIR
8545	8.16.0359.1.01.7	LO	133166	GUARD SHAFT AND BEARING; FOR SIZE 22 ARR 1 FAN
8546	8.16.0360.1.01.8	LO	120016	COMPUTER SHARING DEVICE
8547	8.16.0361.1.01.9	LO	126926	WINDOW FT HTD RH
8548	8.16.0362.1.01.1	LO	126925	WINDOW FT HTD LH
8549	8.16.0363.1.01.2	LO	105970	WIPER MOTOR CENTER
8550	8.16.0364.1.01.3	LO	127404	MUD FLAP ASSEMBLY 6X30 RUBBER FLAP
8551	8.16.0365.1.01.4	LO	132001	MIRROR W/WIDE ANGLE UNIVERSAL MOUNT
8552	8.16.0366.1.01.5	LO	128542	BUSHING; 3.00 OD X 2.31 ID X 2.75 LG
8553	8.16.0367.1.01.6	LO	159142	Modular Base plate
8554	8.16.0368.1.01.7	LO	159141	MODULE TILT WELDT
8555	8.16.0369.1.01.8	LO	119466	CLEVIS BRACKET ASSY
8556	8.16.0370.1.01.9	LO	112777	RADIATOR
8557	8.16.0371.1.01.1	LO	131535	INJECTOR FUEL
8558	8.16.0372.1.01.2	LO	117220	BUSHING HARDENED STEEL 1.00 ID X 1.50 OD X 1.00
8559	8.16.0373.1.01.3	LO	120829	BRACKET WELDT
8560	8.16.0374.1.01.4	LO	115179	CLEVIS PIN 1.00X7.25
8561	8.16.0375.1.01.5	LO	160179	MOUNT SPARK GUARD LH
8562	8.16.0376.1.01.6	LO	152016	ELBOW 90 DEG WITH BELLOWS; 6.00 IN DIA
8563	8.16.0377.1.01.7	LO	151363	ELBOW WELDT 90D 6 DIA; LEFT BANK EXHAUST
8564	8.16.0378.1.01.8	LO	151364	ELBOW WELDT 90D 6 DIA; RIGHT BANK EXHAUST
8565	8.16.0379.1.01.9	LO	113879	BRACKET ASSY 1.00
8566	8.16.0380.1.01.1	LO	115155	TOW BAR WELDT
8567	8.16.0381.1.01.2	LO	124626	COVER DOMED 14 INCH SS; JIC TYPE WITH GASKET
8568	8.16.0382.1.01.3	LO	E85665	ENCODER AXLE DRIVE ASSY; 100T 6 1/2 X 12
8569	8.16.0383.1.01.4	LO	160173	SPARK SHIELD END WELDT
8570	8.16.0384.1.01.5	LO	157787	SPARK GUARD BEAM WELDT
8571	8.16.0385.1.01.6	LO	160180	MOUNT SPARK GUARD RH
8572	8.16.0386.1.01.7	LO	B32577	SWITCH LIMIT-MOD
8573	8.16.0387.1.01.8	LO	136917	HORN 10-30VDC 104dB 10 TONE GRAY
8574	8.16.0388.1.01.9	LO	128285	ADPT TRACTION MOTOR WLDT
8575	8.16.0389.1.01.1	LO	112905	BEAM WELDT
8576	8.16.0390.1.01.2	LO	A32666	ELBOW 90 DEG RUBBER 8.00 ID
8577	8.16.0391.1.01.3	LO	115031	TOW BAR ASSY
8578	8.16.0392.1.01.4	LO	152101	INSULATION ELBOW NO DWG; LEFT BANK EXHAUST
8579	8.16.0393.1.01.5	LO	A32667	HUMP STRAIGHT RUBBER 8.00 ID
8580	8.16.0394.1.01.6	LO	MTF1017-0031.00	TUBE RD 7.00 ODX16GA; (.065)WALL
8581	8.16.0395.1.01.7	LO	117846	SHAFT WELDT-AXLE STUB 100 TON TRUCK
8582	8.16.0396.1.01.8	LO	117995	BLANKET BRACKET
8583	8.16.0397.1.01.9	LO	117684	SEAL CLAMP 2 PIECE 8.00 DIA
8584	8.16.0398.1.01.1	LO	113861	CATCH PLATE; 6.00DIAx1.25
8585	8.16.0399.1.01.2	LO	201989	EXHAUST TUBE WELDT
8586	8.16.0400.1.01.3	LO	152098	INSULATION TUBE 8 IN; NO DWG
8587	8.16.0401.1.01.4	LO	152103	INSULATION ELBOW NO DWG; RIGHT BANK EXHAUST
8588	8.16.0402.1.01.5	LO	106511	HUMP STRAIGHT RUBBER 10.00 ID
8589	8.16.0403.1.01.6	LO	118937	GAUGE BRACKET
8590	8.16.0404.1.01.7	LO	115245-0060.00	T/A STR .75X.095W SS; 12FORFS 12FORFS 3550MOP
8591	8.16.0405.1.01.8	LO	152102	INSULATION ELBOW; WITH BELLOWS NO DWG
8592	8.16.0406.1.01.9	LO	A68206	VALVE BALL .38 NPT; BRONZE 600 PSI W/LOCK
8593	8.16.0407.1.01.1	LO	A37033	VALVE BALL 1.50 NPT; BRONZE 600 PSI
8594	8.16.0408.1.01.2	LO	A38671	SEAL KIT
8595	8.16.0409.1.01.3	LO	A61295	COVER GASKET
8596	8.16.0410.1.01.4	LO	154505	SHOE BRAKE 14X2.00 ANCHOR; LOW
8597	8.16.0411.1.01.5	LO	A15741	SHOE BRAKE 12 LG 2.00 THK; HIGH FRICTION COMPOSITION
8598	8.16.0412.1.01.6	LO	A79590	CONNECTOR - FEMALE
8599	8.16.0413.1.01.7	LO	A37667	LENS HEADLIGHT MRS64/1000

8600	8.16.0414.1.01.8	LO	139583	LENS RED
8601	8.16.0415.1.01.9	LO	136778	LIGHT LENS
8602	8.16.0416.1.01.1	LO	132614	LATCH KEYPED
8603	8.16.0417.1.01.2	LO	113949	WIPER BLADE 700MM
8604	8.16.0418.1.01.3	LO	110767	WIPER ARM
8605	8.16.0419.1.01.4	LO	A46865	DIAL POT
8606	8.16.0420.1.01.5	LO	H37764	SCREW CAP-SOCKET HD; #10-32NFX.75 GR8
8607	8.16.0421.1.01.6	LO	128312	BATTERY ISOLATOR; 25A 6-50VDC
8608	8.16.0422.1.01.7	LO	H17621	PIN COTTER .12DIA X1.00
8609	8.16.0423.1.01.8	LO	H22406	PIPE EL45 12FNPT 12FNPT; 3000#FS
8610	8.16.0424.1.01.9	LO	A47406	CONDUIT SEALTITE 1-1/2
8611	8.16.0425.1.01.1	LO	H30547	SCREW CAP-SOCKET HD; .50-13NCX2.50 GR8
8612	8.16.0426.1.01.2	LO	A94423	CAP
8613	8.16.0427.1.01.3	LO	A49119	CLAMP T-BOLT 3.50-3.81 DIA
8614	8.16.0428.1.01.4	LO	A75119	CLAMP T-BOLT 5.94-6.21 DIA
8615	8.16.0429.1.01.5	LO	A30337	GAUGE RESTRICTION 0-30 INCHES WATER
8616	8.16.0430.1.01.6	LO	A78475	LUG TERMINAL 6-350 MCM
8617	8.16.0431.1.01.7	LO	153892	CAP ENGINE OIL FILL WITH CHAIN
8618	8.16.0432.1.01.8	LO	153375	GASKET COVER FOR 124626
8619	8.16.0433.1.01.9	LO	A87648	BUSHING 0.7500 BORE
8620	8.16.0434.1.01.1	LO	160165	CONTAINMENT LID ASSY
8621	8.16.0435.1.01.2	LO	H22349	PIPE PLUG 06MNPT SKT HD; 3000#FS CSINK
8622	8.16.0436.1.01.3	LO	106390	SWITCH SEL 4 POS MAINT SQUARE BLACK
8623	8.16.0437.1.01.4	LO	106377	SWITCH SEL 2 POS MAINT SQUARE BLACK
8624	8.16.0438.1.01.5	LO	111489	HANDLE 4.00X1.31X.31
8625	8.16.0439.1.01.6	LO	106386	SWITCH SEL 3 POS SRC SQUARE YELLOW
8626	8.16.0440.1.01.7	LO	126857	LEG WELDT
8627	8.16.0441.1.01.8	LO	151876	DB 3P 420A 600V 1LI 4LD
8628	8.16.0442.1.01.9	LO	164709	CIRCUIT BREAKER DISC; MECHANISM RH MOUNT
8629	8.16.0443.1.01.1	LO	A47071	CLAMP-V BAND 5.00
8630	8.16.0444.1.01.2	LO	A30333	HUMP REDUCER RUBBER 8.00 IDX7.00 ID
8631	8.16.0445.1.01.3	LO	H25568	CORD CONNECTOR
8632	8.16.0446.1.01.4	LO	A39312	CONNECTOR 1-1/4
8633	8.16.0447.1.01.5	LO	115244-0060.00	TA STR .50X.065 SS; 08 ORFS 08 ORFS 3650MOP
8634	8.16.0448.1.01.6	LO	H94901	SCREW CAP-SOCKET HD SHLDR; .50-13NCX1.50 GR8
8635	8.16.0449.1.01.7	LO	120441	LOUVER RECTANGULAR
8636	8.16.0450.1.01.8	LO	H45630	SCREW CAP-SOCKET HD; .50-13NCX3.00 GR8
8637	8.16.0451.1.01.9	LO	103234	EXHAUST FLOW CONTROL W/SILENCER
8638	8.16.0452.1.01.1	LO	102698	CONNECTOR 1.50 ST 45 DEG
8639	8.16.0453.1.01.2	LO	H28598	SCREW CAP-SOCKET HD; .50-13NCX1.75 GR8
8640	8.16.0454.1.01.3	LO	A20266	LEVER ARM, ADJUSTABLE
8641	8.16.0455.1.01.4	LO	A70652	CONNECTOR 1-1/2
8642	8.16.0456.1.01.5	LO	117616	STRIP .12X1.50; X28.00
8643	8.16.0457.1.01.6	LO	117996	STRIP WELDT; BLANKET MTG 28.00 LG
8644	8.16.0458.1.01.7	LO	A64971	CLAMP MULTI 16-2-3 SPCL
8645	8.17.0001.1.01.1	PL	41656	HANDLE
8646	8.17.0002.1.01.2	PL	506896	SERVO ADJUSTMENT DEVICE
8647	8.17.0003.1.01.3	PL	986352000	SOLDERING IRON PLUG
8648	8.17.0004.1.01.4	PL	C-001	BAND-IT-TOOL
8649	8.17.0005.1.01.5	PL	DL131.06-KPL	MULTIPURPOSE EXTRACTING DEVICE
8650	8.17.0006.1.01.6	PL	IN43.623	HANDLE
8651	8.17.0007.1.01.7	PL	RCH-603T	CYLINDER-60T
8652	8.17.0008.1.01.8	PL	SU 1502.208.1.2.3	JACK
8653	8.17.0009.1.01.9	PL	SU 1502.208.1.2.4	JACK
8654	8.17.0010.1.01.1	PL	WN180.01A-VERSTAERKT	LOCK
8655	8.17.0011.1.01.2	PL	WN180.02	DOOR HANDLE
8656	8.17.0012.1.01.3	PL	WN180.13-SPERRE 7221-1045	DOOR HANDLE
8657	8.17.0013.1.01.4	PL	WN81.204	LOCKING PIECE
8658	8.17.0014.1.01.5	LO	107164	WATER CANNON GROUP 125 GPM
8659	8.17.0015.1.01.6	PL	AK5000	SILICONE OIL
8660	8.17.0016.1.01.7	PL	ELB-KGO-OO	RPM CONTROL
8661	8.17.0017.1.01.8	PL	SE27	ROSTA ELEMENT
8662	8.17.0018.1.01.9	PL	HY717D.08/6.8KW/EL	Diesel Emergency Unit
8663	8.17.0019.1.01.1	PL	64.09.7000.30	Ballast Guide Assembly
8664	8.17.0020.1.01.2	GE	YD432D-20-02	Anti-loosen lock
8665	8.17.0021.1.01.3	GE	H25	Dust-proof cover
8666	8.17.0022.1.01.4	GE	08-03-2901	Micro muffle
8667	8.17.0023.1.01.5	Volvo Penta	82269261	Filter
8668	8.17.0024.1.01.6	Volvo Penta	22856665	Filter
8669	8.17.0025.1.01.7	Volvo Penta	21315240	SENSOR
8670	8.17.0026.1.01.8	Volvo Penta	23763152	Viscous Clutch

8671	8.17.0027.1.01.9	Volvo Penta	VOLVO Mix 40/60 (Green colour) Part no. 22567233	Engine cooling agent
8672	8.17.0028.1.01.1	AM	51206014	Threaded Stem Joint
8673	8.17.0029.1.01.1	GE	3/8-16UNC-35	Bolt-1
8674	8.17.0030.1.01.3	GE	GB/T5782 M16-40	Bolt-2
8675	8.17.0031.1.01.4	GE	7/16-14UNC-35	Bolt-3
8676	8.17.0032.1.01.5	GE	GB/T5786 M14-1.5-50-10.9	Bolt-1
8677	8.17.0033.1.01.6	GE	GB/T5786 M14-1.5-45-10.9	Bolt-2
8678	8.17.0034.1.01.7	GE	DCL32-23-01-02-01-05	Steel pipe-1
8679	8.17.0035.1.01.8	GE	DCL32-23-01-02-01-03	Steel pipe-2
8680	8.17.0036.1.01.9	GE	DCL32-23-01-02-01-01	Steel pipe-3
8681	8.17.0037.1.01.1	GE	DCL32-23-01-02-01-07	Steel pipe-4
8682	8.17.0038.1.01.2	GE	DCL32-23-01-02-05-01	Steel pipe-5
8683	8.17.0039.1.01.3	GE	CDCM16A-23-01-02	Steel pipe-6
8684	8.17.0040.1.01.4	GE	DCL32-23-01-02-19	Steel pipe-7
8685	8.17.0041.1.01.5	GE	DGMPC-5-ABN-BAN- 30	Double-way hydraulic lock
8686	8.17.0042.1.01.6	GE	DGMPC-3-ABN-BAN- 30	Hydraulic lock (Set)
8687	8.17.0043.1.01.7	CR	BS550(IND)-20-10-00	RAIL SCRAPER (RIGHT)
8688	8.17.0044.1.01.8	CR	BS550(IND)-20-09-00	RAIL SCRAPER (LEFT)
8689	8.17.0045.1.01.9	CR	BS550(IND)-20-07-00	CENTER PLATE ASSEMBLE
8690	8.17.0046.1.01.1	CR	BS550(IND)-20-03-00	SIDE BEARING ASSEMBLY
8691	8.17.0047.1.01.2	CR	BS550(IND)-20-05-05	UNDERBOARDING
8692	8.17.0048.1.01.3	CR	T50-J47C13U	OIL DAMPER
8693	8.17.0049.1.01.4	CR	BS550(IND)-20-03-03	SHIM
8694	8.17.0050.1.01.5	CR	BS550(IND)-20-03-01-00	SIDE BEARING BOX
8695	8.17.0051.1.01.6	CR	BS550(IND)-20-07-05	U CARD
8696	8.17.0052.1.01.7	CR	BS550(IND)-20-07-04	SPHERICAL SUSPENDER
8697	8.17.0053.1.01.8	CR	BS550(IND)-20-07-01	UPPER CENTER PLATE
8698	8.17.0054.1.01.9	CR	40100378-053	SHIM, 0.19 MM
8699	8.17.0055.1.01.1	CR	40100378-054	SHIM, 0.25 MM
8700	8.17.0056.1.01.2	CR	40100378-055	SHIM, 0.35 MM
8701	8.17.0057.1.01.3	CR	40100378-070	REDUCER
8702	8.17.0058.1.01.4	CR	40100378-082	EXTERNAL DISC
8703	8.17.0059.1.01.5	CR	40100378-083	INTERNAL DISC
8704	8.17.0060.1.01.6	CR	40100378-086	SPRING
8705	8.17.0061.1.01.7	CR	40100378-088	BELL
8706	8.17.0062.1.01.8	CR	40100378-100	HOUSING-1
8707	8.17.0063.1.01.9	CR	40100378-103	HOUSING-2
8708	8.17.0064.1.01.1	CR	40100378-104	MANIFOLD
8709	8.17.0065.1.01.2	CR	BS550(IND)-20-02-00(3)	FRAME (3)
8710	8.17.0066.1.01.3	CR	T50-J47C13M	OIL DAMPER RIGHT
8711	8.17.0067.1.01.4	CR	BS550(IND)-20-05-02	SUPPORTING BLOCK
8712	8.17.0068.1.01.5	CR	36.41.20	Guide collar
8713	8.17.0069.1.01.6	CR	BS550(IND)-30-16-03	COOLING PIPE
8714	8.17.0070.1.01.7	CR	CQS300-19-03-01	ALLOCATION BLOCK
8715	8.17.0071.1.01.8	CR	BS500W(IND)-30-31	MOUNTING PLATE
8716	8.17.0072.1.01.9	CR	N 008 734 08	QUICK CONNECTOR SOCKET
8717	8.17.0073.1.01.1	CR	BS550(IND)-07-01-52	TAB SHIM
8718	8.17.0074.1.01.2	CR	GB/T1096-8X7X28	NORMAL TYPE FLAT KEY
8719	8.17.0075.1.01.3	CR	GB/T13871-FB80X110X10	SEALING RING
8720	8.17.0076.1.01.4	CR	CQS300-17-02-05	KEY
8721	8.17.0077.1.01.5	CR	BS550(IND)-09-37	PLYWOOD-5
8722	8.17.0078.1.01.6	CR	BS550(IND)-09-40	PLYWOOD-6
8723	8.17.0079.1.01.7	CR	BS550(IND)-09-42	STIFFENER
8724	8.17.0080.1.01.8	CR	BS550(IND)-06-16-05	KEY
8725	8.17.0081.1.01.9	CR	GB/T894.2-70	CIRCLIP FOR SHAFT
8726	8.17.0082.1.01.1	CR	1308JV	DUSTPROOF RING
8727	8.17.0083.1.01.2	CR	BS550(IND)-10-04-03	COLLAR
8728	8.17.0084.1.01.3	CR	GB/T893.1-190	CIRCLIP FOR HOLES
8729	8.17.0085.1.01.4	CR	BS550(IND)-10-05-02	KEY
8730	8.17.0086.1.01.5	CR	DIN3404-A R1/4 St	GREASE NUZZLE
8731	8.17.0087.1.01.6	CR	BS550(IND)-10-05-01-04	BEARING CAP
8732	8.17.0088.1.01.7	CR	BS550-10-02-01-00	PULLEY BODY
8733	8.17.0089.1.01.8	CR	BS550(IND)-10-05-03	RING
8734	8.17.0090.1.01.9	CR	BS500W(IND)-13-03-00	PEDESTAL WELDING
8735	8.17.0091.1.01.1	CR	BS500W(IND)-13-05-00	AIR LOCK DEVICE-1
8736	8.17.0092.1.01.2	CR	BS500W(IND)-13-06-00	MAIN LOCK PEDESTAL
8737	8.17.0093.1.01.3	CR	BS500W(IND)-13-07-00	AIR LOCK DEVICE-2
8738	8.17.0094.1.01.4	CR	BS500W(IND)-13-25	UNIVERSAL SOCKET
8739	8.17.0095.1.01.5	CR	41064504	Seal ring
8740	8.17.0096.1.01.6	CR	20261427	Lubrication sleeve
8741	8.17.0097.1.01.7	CR	20261430	Lubrication sleeve
8742	8.17.0098.1.01.8	CR	20261426	Lubrication plate
8743	8.17.0099.1.01.9	CR	23008098	Piston
8744	8.17.0100.1.01.1	CR	23067085	Piston Rod
8745	8.17.0101.1.01.2	CR	82008021480	piston rod
8746	8.17.0102.1.01.3	CR	82008021482	cylinder head

8747	8.17.0103.1.01.4	CR	82008021481	cylinder body
8748	8.17.0104.1.01.5	CR	82008021490	piston rod
8749	8.17.0105.1.01.6	CR	82008021492	cylinder head
8750	8.17.0106.1.01.7	CR	82008021491	cylinder body
8751	8.17.0107.1.01.8	CR	82008021506	piston rod
8752	8.17.0108.1.01.9	CR	82008021508	cylinder head
8753	8.17.0109.1.01.1	CR	82008021507	cylinder body
8754	8.17.0110.1.01.2	CR	82010040054	piston rod
8755	8.17.0111.1.01.3	CR	82010040055	cylinder head
8756	8.17.0112.1.01.4	CR	82008021437	cylinder body
8757	8.17.0113.1.01.5	CR	23068419	OIL CYLINDER PIN
8758	8.17.0114.1.01.6	CR	23069242	INSTALLATION OF OIL CYL. HEAD
8759	8.17.0115.1.01.7	CR	30030540	SPHERIC JOINT
8760	8.17.0116.1.01.8	CR	23083971	ROLLER
8761	8.17.0117.1.01.9	CR	23083972	LUBRICATION SLEEVE
8762	8.17.0118.1.01.1	CR	40101896	JOINT HEAD
8763	8.17.0119.1.01.2	CR	40103143	SPLINE SHAFT
8764	8.17.0120.1.01.3	CR	40089258	4 WAY OPERATIONAL ROD
8765	8.17.0121.1.01.4	CR	23067084	SQUEEZING CYL. BODY
8766	8.17.0122.1.01.5	CR	23070028	DEPTH SENSOR BASE
8767	8.17.0123.1.01.6	CR	40083643	BRAKE SHOE HOLDER
8768	8.17.0124.1.01.7	CR	40098537	BRAKE SHOE
8769	8.17.0125.1.01.8	CR	23066373	MAGNETIC SCREW PLUG
8770	8.17.0126.1.01.9	CR	40105701	AIR CYL. WITH MAGNETIC RING
8771	8.17.0127.1.01.1	PL	BX-38.3.11.08.95	ADJUSTING BRUSH
8772	8.17.0128.1.01.2	PL	CA250.2402	BEARING SUPPORT
8773	8.17.0129.1.01.3	PL	TYPER90/60DX56 or F64.11.1000	GUIDE ROLLER
8774	8.17.0130.1.01.4	PL	U221.721	DRIVE SHAFT
8775	8.17.0131.1.01.5	PL	63.09.2104	RING
8776	8.17.0132.1.01.6	PL	63.09.2105	RING
8777	8.17.0133.1.01.7	PL	63.09.2106	RING
8778	8.17.0134.1.01.8	VOLVO PENTA	21538975	FILTER
8779	8.17.0135.1.01.9	VOLVO PENTA	21746575	FILTER
8780	8.17.0136.1.01.1	VOLVO PENTA	23381562	FILTER (ADBLUE)
8781	8.17.0137.1.01.2	VOLVO PENTA	21164790	TEMPERATURE SENSOR
8782	8.17.0138.1.01.3	VOLVO PENTA	21426987	SPEED SENSOR
8783	8.17.0139.1.01.4	VOLVO PENTA	21537231	GASKET
8784	8.17.0140.1.01.5	VOLVO PENTA	21746511	FUEL PIPE
8785	8.17.0141.1.01.6	VOLVO PENTA	21880678	PRESSURE SENSER
8786	8.17.0142.1.01.7	VOLVO PENTA	22128302	FUEL HOSE
8787	8.17.0143.1.01.8	VOLVO PENTA	22254065	GASKET
8788	8.17.0144.1.01.9	VOLVO PENTA	22707523	V RIBBED BELT
8789	8.17.0145.1.01.1	VOLVO PENTA	22795892	FUEL HOSE
8790	8.17.0146.1.01.2	VOLVO PENTA	22796425	FUEL HOSE
8791	8.17.0147.1.01.3	VOLVO PENTA	22827991	SENSOR
8792	8.17.0148.1.01.4	VOLVO PENTA	22827993	SENSOR
8793	8.17.0149.1.01.5	VOLVO PENTA	22899626	PRESSURE SENSOR
8794	8.17.0150.1.01.6	VOLVO PENTA	23307414	VACCUM SWITCH
8795	8.17.0151.1.01.7	VOLVO PENTA	23958454	OIL FILTER KIT
8796	8.17.0152.1.01.8	VOLVO PENTA	24037387	Level Sensor
8797	8.17.0153.1.01.9	VOLVO PENTA	22224040	Control Valve kit
8798	8.17.0154.1.01.1	VOLVO PENTA	23552770	Coolant Pump
8799	8.17.0155.1.01.2	VOLVO PENTA	21795852	Gasket
8800	8.17.0156.1.01.3	VOLVO PENTA	990821	O-Ring
8801	8.17.0157.1.01.4	VOLVO PENTA	21746213	Thermostat
8802	8.17.0158.1.01.5	VOLVO PENTA	24170981	Sensor
8803	8.17.0159.1.01.6	VOLVO PENTA	969163	Fuse
8804	8.17.0160.1.01.7	VOLVO PENTA	969162	Fuse
8805	8.17.0161.1.01.8	VOLVO PENTA	22422785	Sensor
8806	8.17.0162.1.01.9	VOLVO PENTA	21976026	Pressure sensor
8807	8.17.0163.1.01.1	PL	USIG	SAFETY CLIP
8808	8.17.0164.1.01.2	PL	2.7902. 2.31.08 00	RADIATOR
8809	8.17.0165.1.01.3	PL	64.08.8203	ANGLE
8810	8.17.0166.1.01.4	PL	64.05.1073	MOUNTING BLOCK
8811	8.17.0167.1.01.5	PL	RE13.42.2201	Drive station
8812	8.17.0168.1.01.6	PL	RE13.38.1102	Drive station
8813	8.17.0169.1.01.7	PL	RE13.38.1301	Drive station
8814	8.17.0170.1.01.8	PL	RE13.52.30201	Drive station
8815	8.17.0171.1.01.9	PL	RE13.38.1402	Redirecting station
8816	8.17.0172.1.01.1	PL	RE13.38.1302	Redirecting station
8817	8.17.0173.1.01.2	PL	RE13.42.2202	Redirecting station
8818	8.17.0174.1.01.3	PL	RE13.38.3402	Redirecting station
8819	8.17.0175.1.01.4	PL	RE13.52.30202-LI	Redirecting station
8820	8.17.0176.1.01.5	PL	RE13.52.30202-RE	Redirecting station
8821	8.17.0177.1.01.6	PL	RE13.38.1401	Drive station
8822	8.17.0178.1.01.7	PL	RE11.09.1101-4	DRIVE SHAFT (B1 belt)
8823	8.17.0179.1.01.8	PL	RE11.09.1102-1	CROSS SHAFT of turn station (B1 belt)
8824	8.17.0180.1.01.9	PL	UD251.13816	BUSH

8825	8.17.0181.1.01.1	PL	684-02-026-01	SHACKLE FWG
8826	8.17.0182.1.01.2	PL	64.08.10014	LOCKING NUT
8827	8.17.0183.1.01.3	PL	2E71.19ST	SUSPENSION BRACKET
8828	8.17.0184.1.01.4	PL	UD80.6010A	BUFFER
8829	8.17.0185.1.01.5	PL	64.05.3064	Joint eye
8830	8.17.0186.1.01.6	PL	UD61.450	SPRING POT
8831	8.17.0187.1.01.7	PL	DL213.36	PRESSURE SPRING
8832	8.17.0188.1.01.8	PL	OB50.505	Damping Disc
8833	8.17.0189.1.01.9	PL	UD62.4013	PRESSURE SPRING
8834	8.17.0190.1.01.1	PL	HZ60.01-06	CLEVIS,
8835	8.17.0191.1.01.2	PL	UD67.2206	Slide plate
8836	8.17.0192.1.01.3	PL	WN71.106	SPACER RING
8837	8.17.0193.1.01.4	PL	WN71.107	SLIDING RING
8838	8.17.0194.1.01.5	PL	UD214.6622	BUMPER
8839	8.17.0195.1.01.6	PL	WN80.2605-2	SPACER RING
8840	8.17.0196.1.01.7	PL	WN80.2605-3	BEARING FLANGE
8841	8.17.0197.1.01.8	PL	WN80.2605-11	BEARING BUSH
8842	8.17.0198.1.01.9	PL	WN80.2605-18	FLANGE
8843	8.17.0199.1.01.1	PL	64.08.3067	LABRYNTH RING
8844	8.17.0200.1.01.2	PL	62.08.3063	FLANGE
8845	8.17.0201.1.01.3	PL	WN70.3405	Gear shift fork
8846	8.17.0202.1.01.4	PL	WN75.137	Drive Wheel
8847	8.17.0203.1.01.5	PL	SU40.3.1.18	Switch Ring
8848	8.17.0204.1.01.6	PL	UD61.10094	Slide Plate
8849	8.17.0205.1.01.7	PL	UD61.14292	Pressure Plate
8850	8.17.0206.1.01.8	PL	UD61.22670-1	MUD GUARD MIRRORED
8851	8.17.0207.1.01.9	PL	WN121-130.223.38-1	PRESSURE SPRING
8852	8.17.0208.1.01.1	PL	UD61.2630	Pivot complete
8853	8.17.0209.1.01.2	PL	64.09.1348	PRESSURE SPRING
8854	8.17.0210.1.01.3	PL	64.02.3035	REVERSE SPRING
8855	8.17.0211.1.01.4	PL	GLF311.840-V01	ROLLER COMPLETE
8856	8.17.0212.1.01.5	PL	UD61.453	Pressure Plate
8857	8.17.0213.1.01.6	PL	EB-64.09.1000.95	VIBRATION SCREEN WITHOUT SCREEN DRIVE (64.09.2000.33)
8858	8.17.0214.1.01.7	PL	64.09.1000.95/IND KPL	VIBRATION SCREEN COMPLETE
8859	8.17.0215.1.01.8	PL	UD64.340	NUT
8860	8.17.0216.1.01.9	PL	UD238.3835	RAIL GUIDE
8861	8.17.0217.1.01.1	PL	UD313.3850-6	PRESSURE DISC
8862	8.17.0218.1.01.2	PL	UD313.1982	SUPPORT
8863	8.17.0219.1.01.3	PL	UD69.2990-2LI	BLOCK
8864	8.17.0220.1.01.4	PL	P27-0540	Rain Cover
8865	8.17.0221.1.01.5	LO	110437	GLASS FRONT CENTER
8866	8.17.0222.1.01.6	LO	A38400	BRUSH GR.DE 7
8867	8.17.0223.1.01.7	PL	64.11.10009	GUIDE PLATE
8868	8.17.0224.1.01.8	PL	64.11.10010	GUIDE PLATE
8869	8.17.0225.1.01.9	PL	64.09.8406	TROUGH PLATE
8870	8.17.0226.1.01.1	PL	UD64.16	SPACER BUSH
8871	8.17.0227.1.01.2	PL	UD80.4208	ROLLER
8872	8.17.0228.1.01.3	PL	64.09.4051	WEAR PLATE
8873	8.17.0229.1.01.4	PL	UD80.106	SPACER RING
8874	8.17.0230.1.01.5	PL	DL10-73	ADJUSTING SCREW
8875	8.17.0231.1.01.6	PL	UD64.1103	SPARE BUSH.
8876	8.17.0232.1.01.7	PL	UD64.27-1	LOCKING PLATE
8877	8.17.0233.1.01.8	PL	UD61.408	SUPPORTING PLATE
8878	8.17.0234.1.01.9	PL	UD61.7875	LOCKING PLATE
8879	8.17.0235.1.01.1	PL	RE30.181	CURVE
8880	8.17.0236.1.01.2	PL	RE30.183	SEGMENT 36
8881	8.17.0237.1.01.3	PL	RE30.180	SIGMENT 21
8882	8.17.0238.1.01.4	PL	RE30.184	CURVE
8883	8.17.0239.1.01.5	PL	63.5X100-M16-AUSF.B,	SLIDE GUIDE ROLLER LATERAL
8884	8.17.0240.1.01.6	PL	C800.405	GUIDE
8885	8.17.0241.1.01.7	PL	WN70.1168	BOLT
8886	8.17.0242.1.01.8	PL	UD50.104	BUSH
8887	8.17.0243.1.01.9	PL	RM08A.27.0110	FORK
8888	8.17.0244.1.01.1	PL	RE401.101	Wear Plate
8889	8.17.0245.1.01.2	PL	GLF311.2700/350-2SP1668/1676	PIN
8890	8.17.0246.1.01.3	PL	62.03.123	BEVEL WHEEL
8891	8.17.0247.1.01.4	PL	62.03.124	BEVEL WHEEL
8892	8.17.0248.1.01.5	PL	64.07.7000.31	BALLAST LOCK FLAPS
8893	8.17.0249.1.01.6	PL	CRW600.1011-LI	WEAR STRIP
8894	8.17.0250.1.01.7	PL	UD72.12814	Support
8895	8.17.0251.1.01.8	PL	UD72.1620 LI	Support
8896	8.17.0252.1.01.9	PL	UD72.1620 RE	Support
8897	8.17.0253.1.01.1	PL	UD314.103	GUIDE ROLLER
8898	8.17.0254.1.01.2	PL	UD314.102-4	CLAMP
8899	8.17.0255.1.01.3	PL	64.09.5549	PLATE LW80
8900	8.17.0256.1.01.4	PL	WN121-20.2H7.28K6.25-1	BEARING BUSH
8901	8.17.0257.1.01.5	PL	2E71.21G	BRACKET
8902	8.17.0258.1.01.6	PL	64.11.3195	Metal wearing plate
8903	8.17.0259.1.01.7	PL	64.11.3216	Interior side part
8904	8.17.0260.1.01.8	PL	64.11.3218	Interior side part

8905	8.17.0261.1.01.9	PL	64.10.1487	Side wall
8906	8.17.0262.1.01.1	PL	64.10.1488	Side wall
8907	8.17.0263.1.01.2	PL	64.10.1482	Shaft
8908	8.17.0264.1.01.3	PL	64.09.8403	Side wall
8909	8.17.0265.1.01.4	PL	74.09.8404	Side wall
8910	8.17.0266.1.01.5	PL	DL150.07 IAS	Bush
8911	8.17.0267.1.01.6	PL	DL150.10IAS	Pressure Disc
8912	8.17.0268.1.01.7	PL	DL150.03	BUSH
8913	8.17.0269.1.01.8	PL	DI150.08IAS	Bush
8914	8.17.0270.1.01.9	PL	DL150.05	Intermediate ring
8915	8.17.0271.1.01.1	PL	64.10.4284	Scraper unit
8916	8.17.0272.1.01.2	PL	64.08.5000.21	Corner roller assy
8917	8.17.0273.1.01.3	PL	62.09.1066	U-Clamp
8918	8.17.0274.1.01.4	PL	62.09.5248	U-Clamp
8919	8.17.0275.1.01.5	PL	64.09.8346	Side screen fixing rubbers
8920	8.17.0276.1.01.6	PL	64.09.8242	Side screen fixing rubbers
8921	8.17.0277.1.01.7	PL	64.09.1712	Tension screw
8922	8.17.0278.1.01.8	PL	64.09.8014	Front wall
8923	8.17.0279.1.01.9	PL	64.09.8029	Deflector plate
8924	8.17.0280.1.01.1	PL	UD313.492	ROLLER
8925	8.17.0281.1.01.2	PL	HZSI-K.40.418	Piston rod
8926	8.17.0282.1.01.3	PL	HZ10.100.050.820.1	Piston rod
8927	8.17.0283.1.01.4	PL	HZ10.125.050.0450.1.002	Piston rod
8928	8.17.0284.1.01.5	SI	SE6352-220-01-00-B	DUPLEX CHAIN
8929	8.17.0285.1.01.6	SI	SE6352-220-02-00-B	SIMPLEX CHAIN
8930	8.17.0286.1.01.7	SI	C100000113-150-18-00-B	DRIVING CHAIN
8931	8.17.0287.1.01.8	PL	35-210-100-S(200A)	Battery Key
8932	8.17.0288.1.01.9	CR	40101433	Universal Drive Shaft
8933	8.17.0289.1.01.1	CR	40101430	Universal Drive Shaft
8934	8.17.0290.1.01.2	CR	40102784	Universal Drive Shaft
8935	8.17.0291.1.01.3	CR	40102783	Universal Drive Shaft
8936	8.17.0292.1.01.4	KA	64568-001 PC 160MM.2 MM GROOVE	PCB Guide Rail;Standard type
8937	8.17.0293.1.01.5	KA	Centa -CP 032P- 00216-5002-27141/ CP-5-F-11-2- R-60196	Clutch
8938	8.17.0294.1.01.6	CR	40103030	Upper Feeding End Screen Mesh 60x60 mm
8939	8.17.0295.1.01.7	CR	23134443	Upper Feeding End Screen Mesh 35x35 mm
8940	8.17.0296.1.01.8	CR	23124442	Upper Feeding End Screen Mesh 42x42 mm
8941	8.17.0297.1.01.9	CR	23134444	Upper Feeding End Screen Mesh 30x30 mm
8942	8.17.0298.1.01.1	CR	23071156	Side Wear Plate IV
8943	8.17.0299.1.01.2	CR	23071151	Bottom Wear Plate II
8944	8.17.0300.1.01.3	CR	23071155	Side Wear Plate III
8945	8.17.0301.1.01.4	CR	23071150	Bottom Wear Plate I
8946	8.17.0302.1.01.5	CR	23067175	Modified Excavating Chain Connection Shaft I
8947	8.17.0303.1.01.6	CR	23070042	Running Surface Wear Plate VI
8948	8.17.0304.1.01.7	CR	23070043	Running Surface Wear Plate VII
8949	8.17.0305.1.01.8	CR	23070039	Running Surface Wear Plate III
8950	8.17.0306.1.01.9	CR	23070040	Running Surface Wear Plate IV
8951	8.17.0307.1.01.1	CR	23070037	Running Surface Wear Plate I
8952	8.17.0308.1.01.2	CR	23078456	Connecting Plate
8953	8.17.0309.1.01.3	CR	23070038	Running Surface Wear Plate II
8954	8.17.0310.1.01.4	CR	23070041	Running Surface Wear Plate V
8955	8.17.0311.1.01.5	CR	23067248	Copper Bushing
8956	8.17.0312.1.01.6	CR	40102857	Vibrating Screen Beam
8957	8.17.0313.1.01.7	CR	23088003	Double Shaft Sleeve
8958	8.17.0314.1.01.8	CR	23088004	Double Shaft Sleeve
8959	8.17.0315.1.01.9	CR	23086761	Single Shaft Sleeve
8960	8.17.0316.1.01.1	CR	23067249	Copper Bushing
8961	8.17.0317.1.01.2	CR	23083985	Swing Arm Assembly
8962	8.17.0318.1.01.3	Volvo Penta	23958454/23273538/21913334	OIL FILTER KIT
8963	8.18.0001.1.01.2	LO	106938	OIL-SYNTHETIC GEAR T/M BULL GEAR LUBE ; ORDER MULTIPLE OF 48 EACH = 1 BOX
8964	8.18.0002.1.01.3	LO	A81853	PALLUBE 32 LUBRICOLANT; 5 GALLON CONTAINER
8965	8.18.0003.1.01.4	SHELL	SHELL SPIRAX S4TXM - 10W30	LUB OIL for ZF
8966	8.18.0004.1.01.5	SHELL	SHELL RIMULA R6 LM 10W40	LUBE OIL for Engine
8967	8.18.0005.1.01.6	SHELL	SHELL RIMULA R4 15W40	LUBE OIL
8968	8.18.0006.1.01.7	SHELL	Shell Omala S2 G 68	Hydraulic Oil
8969	8.18.0007.1.01.8	SHELL	Shell Tellus S2 MX 100	Hydraulic Oil
8970	8.18.0008.1.01.9	SHELL	Shell Tellus S2 MX 68	Hydraulic Oil
8971	8.18.0009.1.01.1	SHELL	Shell Tellus S2 VX 68	Hydraulic Oil
8972	8.18.0010.1.01.2	SHELL	Shell Gadus S2 V 100 2	GREASE
8973	8.18.0011.1.01.3	SHELL	SHELL GADUS S3 V220 C2	GREASE
8974	8.18.0012.1.01.4	SHELL	Shell Omala S2 G 100	GEAR OIL
8975	8.18.0013.1.01.5	SHELL	Shell OMALA S4 GX V150	GEAR OIL
8976	8.18.0014.1.01.6	SHELL	SPIRAX S2 G 80W90	GEAR OIL
8977	8.18.0015.1.01.7	MOBIL	Mobil DELVAC 1 ATF	GEAR OIL for ZF
8978	8.18.0016.1.01.8			Repeated item

8979	8.18.0017.1.01.9	CR	0165.20.075	Engine diesel coarse filter (on tank)
8980	8.18.0018.1.01.1	CR	S6 AXME 75W90	GEAR OIL
8981	8.18.0019.2.01.2	CR	0165.22.248	Engine Air filter (OUTER)
8982	8.18.0020.1.01.3	CR	0165.22.249	Engine Air filter (INNER)
8983	8.18.0021.1.01.4	CR	80262200765	Diesel metal filter
8984	8.18.0022.1.01.5	CR	0165-22-248	AIR FILTER OUTER
8985	8.18.0023.1.01.6	CR	0165-22-249	AIR FILTER INNER
8986	8.18.0024.1.01.7	CR	2443833/41064314	Engine Rough Diesel Filter
8987	8.18.0025.1.01.8	CR	40095692/2676398	Air Drying Agent Filter
8988	8.18.0026.1.01.9	CR	40095697/74671181	CAT Genset Diesel Filter
8989	8.18.0027.1.01.1	CR	4692718	COOLANT -20 LTR
8990	8.18.0028.1.01.2	CR	7W2327	OIL FILTER
8991	8.18.0029.1.01.3		Shifted to Ann II	
8992	8.18.0030.1.01.4	CR	40097602	DRYING AGENT
8993	8.18.0031.1.01.5	CR	40102522	FILTER CARTRIDGE
8994	8.18.0032.1.01.6		Shifted to Ann II	
8995	8.18.0033.1.01.7	AM	9990187 and Donaldson part no.P553315	LUBE OIL FILTER
8996	8.18.0034.1.01.8		Shifted to Ann II	
8997	8.18.0035.1.01.9		Shifted to Ann II	
8998	8.18.0036.1.01.1		Shifted to Ann II	
8999	8.18.0037.1.01.2	CR	SHELL TELLUS S100	TAMPING UNIT OIL
9000	8.18.0038.1.01.3	PL	UD80.1115	MUSHROOM-SHAPED PRESSURE PIECE
9001	8.18.0039.1.01.4	CU	504626	Valvoline Premium Blue 7800 PLUS
9002	8.18.0040.1.01.5	HA	Gulf Leypower Cool-40	Coolant for Radiator
9003	8.19.0001.1.01.3		Shifted to Ann II	
9004	8.19.0002.1.01.4	CU	41064318	ENGINE BELT
9005	8.19.0003.1.01.5	LO	127019	BELT FAN POLY V 23 RIB K SECTION
9006	8.19.0004.1.01.6	HA	Fenner Part No. CX102C2650203	AIR COMPRESSOR DRIVE V BELT
9007	8.20.0001.1.01.4	KA	MSVP.461264-547	SETTING DEVICE
9008	8.20.0002.1.01.5	KA	PD 1.1.5 M PQ27SH	PRESSURE RECEIVER
9009	8.20.0003.1.01.6	KA	PK 16.11S 5008.T3	SWITCH
9010	8.20.0004.1.01.7	KA	PP2X-XX-10A-JIM	Control Handle
9011	8.20.0005.1.01.8	KA	1834.0380000V1	Engine Radiator Assembly AGK
9012	8.21.0001.1.01.5		Repeated item	
9013	8.21.0002.1.01.6	PL	UD150.1554	STOPPING DISC
9014	8.21.0003.1.01.7	PL	UD257.406	ROLLER COMPLETE
9015	8.21.0004.1.01.8	PL	UD80.4230	BUSH
9016	8.21.0005.1.01.9	PL	WN119-M16.80-1	HEX SCREW WITH CONED HALF DOG
9017	8.21.0006.1.01.1	PL	WN121-30H7.35j6.20-1	INTERMEDIATE BUSHING
9018	8.21.0007.1.01.2	PL	WN141-19H7.40.15-2	FISH PLATE
9019	8.21.0008.1.01.3	PL	WN141-28H7.180.20-1	FISH PLATE
9020	8.21.0009.1.01.4	PL	WN141-35J7.180.50.20-1	FISH PLATE
9021	8.21.0010.1.01.5	PL	WN141-35J7.65.20-1	FISH PLATE
9022	8.21.0011.1.01.6	PL	WN141-62H7.100.150.35-1	FISH PLATE
9023	8.22.0001.1.01.6	PL	SU-3"-JV	CHAIN
9024	8.22.0002.1.01.7	PL	0950/L5320/R200/B150	ENERGY CHAIN
9025	8.22.0003.1.01.8	PL	RE13.11.501	Ballast guide blade
9026	8.22.0004.1.01.9	PL	RE152.37.111	Guide
9027	8.22.0005.1.01.1	PL	RE152.5812	Slider
9028	8.22.0006.1.01.2	PL	RM10.40.0151	Tunnel
9029	8.22.0007.1.01.3	PL	UD190.1309	Roller
9030	8.22.0008.1.01.4	PL	RE11.09.1105	SUPPORT WITH OUT BEARING
9031	8.22.0009.1.01.5	PL	RE11.09.1106	SUPPORT COMPLETE WITH BEARING
9032	8.22.0010.1.01.6	PL	SU1600.509.1.5	SUPPORTS WITH OUT BEARING
9033	8.22.0011.1.01.7	PL	SU1600.509.1.6	SUPPORT WITH BEARING
9034	8.22.0012.1.01.8	PL	RE11.11.2112-1HA	CONVEYOR TRACK B+E 1745
9035	8.22.0013.1.01.9	PL	RE11.14.1112-42	WEAR STRIP B+E 1020
9036	8.22.0014.1.01.1	PL	RE11.14.1112-43	WEAR STRIP B+E 1020
9037	8.22.0015.1.01.2	PL	RE11.08.2112-33	WEAR STRIP B+E 770
9038	8.22.0016.1.01.3	PL	RE11.08.2112-34	WEAR STRIP B+E 770
9039	8.22.0017.1.01.4	PL	RE08.31.409-3Z/4Z	SPLIT CHAIN WHEEL (SPROCKET)
9040	8.22.0018.1.01.5	PL	63.08.2006-GEHAERTET	SECURING BOLT
9041	8.22.0019.1.01.6	PL	RE08.11.202	ASC.ELBOW JOINT
9042	8.22.0020.1.01.7	PL	RE08.11.302	DES.ELBOW JOINT
9043	8.22.0021.1.01.8	PL	RE08.02.716	Rod head(connecting elbow)
9044	8.22.0022.1.01.9	PL	RE11.24.2113-30	B3 slewing gear box
9045	8.22.0023.1.01.1	PL	RE151.102.N-TS	ROLLER CLAMP ASSEMBLY
9046	8.22.0024.1.01.2	PL	RE153.804	ROLLER CLAMP ASSEMBLY
9047	8.22.0025.1.01.3	PL	WN83.50W	PLANETARY GEAR
9048	8.22.0026.1.01.4	PL	RE11.09.1101-4	DRIVE SHAFT
9049	8.22.0027.1.01.5	PL	RE11.09.1102-1	CROSS SHAFT of turn station
9050	8.22.0028.1.01.6	PL	RE11.08.2101-4	DRIVE SHAFT
9051	8.22.0029.1.01.7	PL	SU1512.1108.6.2.1	CROSS SHAFT B600, D199
9052	8.22.0030.1.01.8	PL	RE08.02.1003	Locking chock
9053	9.01.0001.1.01.4	PL	786030	CONE BEARING

9054	9.01.0002.1.01.5	PL	13100602 SUB. 786030MITTEL	CONE BEARING
9055	9.01.0003.1.01.6	PL	571801313-50SH	CONE BEARING
9056	9.01.0004.1.01.7	PL	571801917-70SH	CONE BEARING
9057	9.01.0005.1.01.8	PL	UD72.304 SUB. 586280025	DAMPING BLOCK
9058	9.01.0006.1.01.9	PL	UD72.305 SUB. GE1576(02301/1)	DAMPING BLOCK
9059	9.01.0007.1.01.1	PL	5018053-11MN55	CONE BEARING
9060	9.02.0001.1.01.5	PL	5118002.11MN70	BEARING
9061	9.02.0002.1.01.6	PL	5418069B	BEARING
9062	9.02.0003.1.01.7	PH	UTV1-02-10/00	ANTI VIBRATION MOUNTING
9063	9.02.0004.1.01.8	PH	UTV1-02-11/01	ANTI VIBRATION MOUNTING
9064	9.02.0005.1.01.9	PH	UTV1-02-14/00	ANTI VIBRATION MOUNTING
9065	9.02.0006.1.01.1	PH	UTVI-02-11/00	ANTI VIBRATION MOUNTING
9066	9.02.0007.1.01.2	PL	571801313-11MN50	CONE BEARING
9067	9.02.0008.1.01.3	PL	UD103.10-1-STKL	Tank Suspension
9068	9.02.0009.1.01.4	PL	40X30M10A/(VR1629-1-155)	Damper (Rubber Mounting)
9069	9.02.0010.1.01.5	PL	M-8 (30X20M8A/A)	RUBBER MOUNTING
9070	9.03.0001.1.01.6	CR	BS550(IND)-06-00	Dirt Conveyor Belt (Main Conveyor) complete
9071	9.03.0002.1.01.7	CR	EP300X650X3(4+2)-39250	RUBBER BELT
9072	9.03.0003.1.01.8	CR	BS550(IND)-03-00	Assembly of Rotating Conveyer Belt Assembly (Complete)
9073	9.03.0004.1.01.9	CR	BS550(IND)-03-01-00	ROTATING CONVEYER BELT
9074	9.03.0005.1.01.1	CR	EP300 600X3(4.5+2)X19530	CONVEYOR BELT
9075	9.03.0006.1.01.2	CR	BS550(IND)-09-01-00(L)	MAIN FRAME OF LEFT MIXED BALLAST BELT
9076	9.03.0007.1.01.3	CR	BS550(IND)-10-00	Back Filling Conveyer Belt (Complete)
9077	9.03.0008.1.01.4	CR	BS550(IND)-10-00(L)	LEFT BACK FILLING CONVEYOR BELT
9078	9.03.0009.1.01.5	CR	BS550(IND)-10-00(R)	RIGHT BACK FILLING CONVEYOR BELT
9079	9.03.0010.1.01.6	CR	BS550(IND)-10-00 (R)	Right Back Filling Conveyor Belt (Complete)
9080	9.03.0011.1.01.7	PL	BR25.6720	CONVEYOR BELT
9081	9.03.0012.1.01.8	PL	BR 1000.1907	STEEP BELT CONVEYOR
9082	9.03.0013.1.01.9	PL	64.11.3000.219	DISTRIBUTING CONVEYOR COMPLETE (LH)
9083	9.03.0014.1.01.1	PL	64.11.3000.220	DISTRIBUTING CONVEYOR COMPLETE (RH)
9084	9.03.0015.1.01.2	PL	64.11.1000.163	MAIN CONVEYOR COMPLETE
9085	9.03.0016.1.01.3	PL	64.11.2000.119	WASTE CONVEYOR COMPLETE
9086	9.03.0017.1.01.4	PL	RE25.900LI	DISTRIBUTOR CONVEYOR COMPLETE(LH)
9087	9.03.0018.1.01.5	PL	RE25.900RE	DISTRIBUTOR CONVEYOR COMPLETE(RH)
9088	9.03.0019.1.01.6	PL	RE30.300	MAIN CONVEYOR COMPLETE
9089	9.03.0020.1.01.7	PL	RE25.800	WASTE CONVEYOR COMPLETE
9090	9.03.0021.1.01.8	PL	RE20.1000LI	EXCAVATING CONVEYOR COMPLETE (LH) EXCAVATION
9091	9.03.0022.1.01.9	PL	RE20.1000RE	EXCAVATING CONVEYOR COMPLETE (RH) EXCAVATION
9092	9.03.0023.1.01.1	PL	RE30.400	TRANSFER CONVEYOR COMPLETE
9093	9.03.0024.1.01.2	CR	23070727	Left Mixed Ballast Belt (Excavating Conveyor Belt)
9094	9.03.0025.1.01.3	CR	23067039	Rotating Conveyor Belt (Waste Conveyor Belt)
9095	9.03.0026.1.01.4	CR	40102386	Right Mixed Ballast Belt (Excavating Conveyor Belt)
9096	9.03.0027.1.01.5	CR	40102130	DIRT CONVEYOR BELT (MAIN CONVEYOR BELT)
9097	9.04.0001.1.01.7	PL	9830382	SEAL RING
9098	9.04.0002.1.01.8	PL	9830978	SEAL RING
9099	9.04.0003.1.01.9	PL	9830979	SEAL RING
9100	9.04.0004.1.01.1	PL	1630820 SUB. 050302	SHAFT SEAL RING
9101	9.04.0005.1.01.2	PL	C400.116SP1668	RUBBER SCRAPER BLADE
9102	9.04.0006.1.01.3	PL	62.02.114	RUBBER ELEMENT
9103	9.04.0007.1.01.4	SI	778322	Rubber coupling
9104	9.05.0001.1.01.8	PL	33X55X280MM	SWEEP BRUSH
9105	9.05.0002.1.01.9	PL	33X55X305MM	SWEEP BRUSH
9106	9.05.0003.1.01.1	PL	33X55X310MM	SWEEP BRUSH
9107	9.05.0004.1.01.2	PL	33X55X315MM	SWEEP BRUSH
9108	9.05.0005.1.01.3	PL	33X55X320MM	SWEEP BRUSH
9109	9.05.0006.1.01.4	PL	33X55X330MM	SWEEP BRUSH
9110	9.05.0007.1.01.5	PL	33X55X335MM	SWEEP BRUSH
9111	9.05.0008.1.01.6	PL	33X55X340MM	SWEEP BRUSH
9112	9.05.0009.1.01.7	PL	33X55X345MM	SWEEP BRUSH
9113	9.05.0010.1.01.8	PL	33X55X350MM	SWEEP BRUSH
9114	9.05.0011.1.01.9	PL	230016	BROOM ELEMENT FOR BRM
9115	9.05.0012.1.01.1	PL	EL-T874.00	MARKING

9116	9.05.0013.1.01.2	PL	MMI/2-CMS-1	MC TERMINAL/PROG.
9117	9.05.0014.1.01.3	KA	43.01.00.049	Brake shoe
9118	9.05.0015.1.01.4	PL	732073/MG670 S6	MEGGIE SPRING
9119	9.05.0016.1.01.5	HA	HO403Y02	OT RUBBER PAD
9120	9.05.0017.1.01.6	PL	UD61.14168	RUBBER SPRING ELEMENT
9121	9.05.0018.1.01.7	PL	732073-MG660-S5	MAGGIE SPRING
9122	9.05.0019.1.01.8	CR	40100378-065	O-RING-1
9123	9.05.0020.1.01.9	CR	40100378-095	O-RING-2
9124	9.05.0021.1.01.1	CR	40100378-102	O-RING-3
9125	9.05.0022.1.01.2	CR	40100378-113	O-RING-1
9126	9.05.0023.1.01.3	CR	40100378-114	RING-1
9127	9.05.0024.1.01.4	CR	40100378-115	O-RING-2
9128	9.05.0025.1.01.5	CR	101.19.3.53	O ring-15
9129	9.05.0026.1.01.6	CR	56.3.5	O ring-16
9130	9.05.0027.1.01.7	CR	26.3.1	O ring-11
9131	9.05.0028.1.01.8	CR	73.3.5	O ring-12
9132	9.05.0029.1.01.9	CR	70.75.15	Guide ring-13
9133	9.05.0030.1.01.1	CR	93.3.5	O ring-17
9134	9.05.0031.1.01.2	CR	41.8.3.1	O ring-18
9135	9.05.0032.1.01.3	CR	59.3.5	O RING-1
9136	9.05.0033.1.01.4	CR	FA45.55.6.5.3/7	SCRAPPER RING
9137	9.05.0034.1.01.5	CR	ISI45.55.6	Y RING-1
9138	9.05.0035.1.01.6	CR	45.50.15	GUIDE RING-1
9139	9.05.0036.1.01.7	CR	SPD63.52.4.2	GUIDE RING-2
9140	9.05.0037.1.01.8	CR	58.63.10	GUIDE RING-3
9141	9.05.0038.1.01.9	CR	ISI40.50.6	Y RING-2
9142	9.05.0039.1.01.1	CR	75.80.10	GUIDE RING-4
9143	9.05.0040.1.01.2	CR	SPD80.64.5.6.3	GUIDE RING-5
9144	9.05.0041.1.01.3	CR	40.45.10	GUIDE RING-6
9145	9.05.0042.1.01.4	CR	33.8.3.1	O RING-5
9146	9.05.0043.1.01.5	CR	36.46.6	Y ring-4
9147	9.05.0044.1.01.6	CR	36.41.10	Guide ring-8
9148	9.05.0045.1.01.7	CR	48.3	O ring-7
9149	9.05.0046.1.01.8	CR	20.2.2.4	O ring-8
9150	9.05.0047.1.01.9	CR	83.3.5	O ring-31
9151	9.05.0048.1.01.1	CR	50.55.10	Guide ring-21
9152	9.05.0049.1.01.2	CR	ISI50.60.6	Y ring-16
9153	9.05.0050.1.01.3	CR	GS50.65.1.6.3	Stern ring-2
9154	9.05.0051.1.01.4	CR	45.55.6	Y ring-13
9155	9.05.0052.1.01.5	CR	45.50.6	Guide ring-18
9156	9.05.0053.1.01.6	CR	USH45.55.6	Y ring-12
9157	9.05.0054.1.01.7	CR	45.50.10	Guide ring-16
9158	9.05.0055.1.01.8	CR	73.8.3.1	O ring-23
9159	9.05.0056.1.01.9	CR	ISI80.90.6	Y ring-15
9160	9.05.0057.1.01.1	CR	80.85.15	Guide ring-20
9161	9.05.0058.1.01.2	CR	ISI32.42.6	Y ring-10
9162	9.05.0059.1.01.3	CR	32.37.15	Guide ring-14
9163	9.05.0060.1.01.4	CR	57.3.1	O ring
9164	9.05.0061.1.01.5	CR	22.2.65	O ring-20
9165	9.05.0062.1.01.6	CR	26.7.2.65	O ring-22
9166	9.05.0063.1.01.7	CR	BS550(IND)-15-02-00	VERTICLE ROTARY WIPER (Complete)
9167	9.05.0064.1.01.8	CR	BS550(IND)-15-02-04-03	8MM ROTARY BRUSH
9168	9.05.0065.1.01.9	GE	CDCK16A-56-13	Gasket
9169	9.05.0066.1.01.1	CR	I516033-1	CONE RUBBER SPRING
9170	9.05.0067.1.01.2	CR	BS550(IND)-20-07-02	CENTER PLATE GASKET
9171	9.05.0068.1.01.3	CR	40100378-091	GASKET-1
9172	9.05.0069.1.01.4	CR	40100378-092	GASKET-2
9173	9.05.0070.1.01.5	CR	40100378-098	GASKET-3
9174	9.05.0071.1.01.6	CR	I516008-5	CONE RUBBER SPRING
9175	9.05.0072.1.01.7	CR	BS550(IND)-07-01-72	RUBBER PLATE OF ISOLATION HOOD I
9176	9.05.0073.1.01.8	CR	BS550(IND)-07-01-73	RUBBER PLATE OF ISOLATION HOOD II
9177	9.05.0074.1.01.9	CR	BS550(IND)-07-01-74	RUBBER PLATE OF ISOLATION HOOD III
9178	9.05.0075.1.01.1	CR	BS550(IND)-07-01-42	RUBBER PLATE OF ISOLATION HOOD VII
9179	9.05.0076.1.01.2	CR	BS550(IND)-07-01-43	RUBBER PLATE OF ISOLATION HOOD VIII
9180	9.05.0077.1.01.3	CR	BS550(IND)-07-01-44	RUBBER PLATE OF ISOLATION HOOD IX
9181	9.05.0078.1.01.4	CR	BS550(IND)-07-01-45	RUBBER PLATE OF ISOLATION HOOD X
9182	9.05.0079.1.01.5	CR	BS550(IND)-07-02-20	RUBBER PLATE I
9183	9.05.0080.1.01.6	CR	BS550(IND)-07-02-21	RUBBER PLATE II
9184	9.05.0081.1.01.7	CR	BS550(IND)-06-01-09	RUBBER PLATE-1
9185	9.05.0082.1.01.8	CR	BS550(IND)-06-01-10	RUBBER PLATE-2

9186	9.05.0083.1.01.9	CR	BS550(IND)-06-01-14	RUBBER PLATE Δ5 -1
9187	9.05.0084.1.01.1	CR	BS550(IND)-06-02-06	RUBBER PLATE Δ5 -2
9188	9.05.0085.1.01.2	CR	BS550(IND)-06-02-07	RUBBER PLATE Δ5 -3
9189	9.05.0086.1.01.3	CR	BS550(IND)-06-02-13	RUBBER PLATE Δ5 -4
9190	9.05.0087.1.01.4	CR	BS550(IND)-06-03-05	RUBBER PLATE Δ5 -5
9191	9.05.0088.1.01.5	CR	EP200X800X3(4+2)-9256	RUBBER BELT
9192	9.05.0089.1.01.6	CR	BS550(IND)-09-00(R)	Right Mixed Ballast Belt complete
9193	9.05.0090.1.01.7	CR	BS550(IND)-09-01-00(R)	RIGHT MIXED BALLAST BELT MAIN PART
9194	9.05.0091.1.01.8	CR	BS550(IND)-09-34	RUBBER SCRAPER-1
9195	9.05.0092.1.01.9	CR	BS550(IND)-09-36	RUBBER PARTS
9196	9.05.0093.1.01.1	CR	BS550(IND)-09-38	RUBBER SCRAPER-2
9197	9.05.0094.1.01.2	CR	BS550(IND)-09-46	RUBBER PLATE-1
9198	9.05.0095.1.01.3	CR	BS550(IND)-09-49	RUBBER PLATE-2
9199	9.05.0096.1.01.4	CR	BS550(IND)-09-51	RUBBER PLATE-3
9200	9.05.0097.1.01.5	CR	BS550(IND)-09-00(L)	Left Mixed Ballast Belt complete
9201	9.05.0098.1.01.6	CR	EP300X650X3(4+2)-16230	RUBBER BELT
9202	9.05.0099.1.01.7	CR	BS550-10-01-16	RUBBER PLATE
9203	9.05.0100.1.01.8	CR	BS550(IND)-10-02-05-02	RUBBER ELEMENT
9204	9.05.0101.1.01.9	CR	BS550(IND)-15-01-04-00	RUBBER STICK SET
9205	9.05.0102.1.01.1	CR	20261419	Rubber ring
9206	9.05.0103.1.01.2	CR	40103560/40095760	Hydraulic cylinder sealing ring (full set)
9207	9.05.0104.1.01.3	PL	555384300001	RILSON BRUSH
9208	9.05.0105.1.01.4	PL	UD61.37	BELLOWS
9209	9.05.0106.1.01.5	COLMAR	H1730080	Track Rubber Shoes
9210	9.06.0001.1.01.9	PL	101,32X1,78-N-DIN3771-NBR90	O-RING
9211	9.06.0002.1.01.1	PL	18.72X2.62 NBR90	O RING
9212	9.06.0003.1.01.2	PL	196,2X5,33-N-DIN3771-NBR90	O-RING
9213	9.06.0004.1.01.3	PL	40,2X3-N-DIN-3771-NBR-90	O RING
9214	9.06.0005.1.01.4	PL	46,2X3 N DIN 3771 NBR 90	O RING
9215	9.06.0006.1.01.5	PL	47.22X3.53 NBR90	O RING
9216	9.06.0007.1.01.6	PL	50X3-N-DIN3771-NBR90	O-RING
9217	9.06.0008.1.01.7	PL	56,74X3,53-N-DIN3771-NBR90	O-RING
9218	9.06.0009.1.01.8	PL	69,44X3,53-N-DIN3771-NBR90	O-RING
9219	9.06.0010.1.01.9	PL	85X6-N-DIN3771-NBR90	O-RING
9220	9.06.0011.1.01.1	PL	97,79X5,33-N-DIN3771-NBR90	O-RING
9221	9.06.0012.1.01.2	PL	A13X20X1,5DIN7603-CU	SEAL RING
9222	9.06.0013.1.01.3	PL	BA230-255-15DIN3760-NB	SEAL RING
9223	9.06.0014.1.01.4	PH	3P28	MELAMINE SHEET
9224	9.06.0015.1.01.5	PH	30516001	GASKET 0.8 TH
9225	9.06.0016.1.01.6	PH	UTVI-01 13/00	FELT RING
9226	9.06.0017.1.01.7	PH	UTVI-03 07/00	RUBBER PACKING RING
9227	9.06.0018.1.01.8	PH	UTVI-03 12/00	RUBBER SNUBBER
9228	9.06.0019.1.01.9	PH	UTV1-03 17/00	SHOCK ABSORBER
9229	9.06.0020.1.01.1	LO	106566	BOOT RUBBER #4 LEADS FOR PIGTAIL CONNECTOR
9230	9.06.0021.1.01.2	LO	A32670	DUCT FLEX
9231	9.06.0022.1.01.3	Repeated item		
9232	9.06.0023.1.01.4	PL	129,2X5,7-N-DIN3771-NBR90	O-RING
9233	9.06.0024.1.01.5	PL	1630820 SUBSTITUTE 050302	SHAFT SEAL RING
9234	9.06.0025.1.01.6	PL	164,2X5,7-N-DIN3771-NBR90	O-RING
9235	9.06.0026.1.01.7	PL	170,82X5,33-N-DIN3771-NBR90	O-RING
9236	9.06.0027.1.01.8	PL	171,12X2,62-DIN3771-NBR90	O-RING
9237	9.06.0028.1.01.9	PL	190X3-N-DIN-3771-NBR90	O-RING
9238	9.06.0029.1.01.1	PL	45,69X2,62-N-DIN3771-NBR90	O-RING
9239	9.06.0030.1.01.2	PL	63,09X3,53-N-DIN3771-NBR90	O-RING
9240	9.06.0031.1.01.3	PL	72,62X3,53-N-DIN3371-NBR90	O-RING
9241	9.06.0032.1.01.4	PL	85,32X3,53-N-DIN3771-NBR90	O-RING
9242	9.06.0033.1.01.5	PL	86X6-N-DIN3771-NBR90	O-RING
9243	9.06.0034.1.01.6	PL	BGS-12"-DS	PISTON RUBBER PACKING 12"
9244	9.06.0035.1.01.7	PL	OMV500/630DS	SEAL KIT
9245	9.06.0036.1.01.8	PL	62.02.2064	RING
9246	9.06.0037.1.01.9	PL	2-05922 = 01 No.	O-RING
9247	9.06.0038.1.01.1	PL	33X55X370MM-LG	SWEEP BRUSH
9248	9.06.0039.1.01.2	PL	33X55X375MM-LG	SWEEP BRUSH
9249	9.06.0040.1.01.3	PL	33X55X380MM-LG	SWEEP BRUSH
9250	9.06.0041.1.01.4	PL	33X55X400MM-LG	SWEEP BRUSH
9251	9.06.0042.1.01.5	PL	33X55X410MM-LG	SWEEP BRUSH
9252	9.06.0043.1.01.6	PL	33X55X420MM-LG	SWEEP BRUSH
9253	9.06.0044.1.01.7	PL	38X51X350MM	Sweep Brush
9254	9.06.0045.1.01.8	PL	38X51X345MM	Sweep Brush
9255	9.06.0046.1.01.9	PL	38X51X340MM	Sweep Brush
9256	9.06.0047.1.01.1	PL	38X51X335MM	Sweep Brush
9257	9.06.0048.1.01.2	PL	38X51X330MM	Sweep Brush
9258	9.06.0049.1.01.3	PL	38X51X320MM	Sweep Brush
9259	9.06.0050.1.01.4	PL	38X51X315MM	Sweep Brush
9260	9.06.0051.1.01.5	PL	38X51X310MM	Sweep Brush
9261	9.06.0052.1.01.6	PL	38X51X235MM	Sweep Brush

9262	9.06.0053.1.01.7	PL	38X51X280MM	Sweep Brush
9263	9.06.0054.1.01.8	PL	38X51X150MM	Sweep Brush
9264	9.06.0055.1.01.9	PL	RE401.100(A)	SWEEPER BRUSH
9265	9.07.0001.1.01.1	PL	DL12.22A	RADIAL SEAL
9266	9.07.0002.1.01.2	PL	2E34.228-6.95	TAFLON WASHER
9267	9.07.0003.1.01.3	PL	2E34.228-7.00	TAFLON WASHER
9268	9.07.0004.1.01.4	PL	2E34.228-7.05	TAFLON WASHER
9269	9.07.0005.1.01.5	PL	2E34.228-7.10	TAFLON WASHER
9270	9.07.0006.1.01.6	PL	2E34.228-7.15	TAFLON WASHER
9271	9.07.0007.1.01.7	PL	2E34.228-7.20	TAFLON WASHER
9272	9.07.0008.1.01.8	PL	2E34.228-7.25	TAFLON WASHER

Kailash Narayan
Director Track Machine-I