


LOADING AND SECURING ARRANGEMENT DIAGRAM FOR 01 NOS OF 59"(1498.6 mm) STEEL PIPE

- NOTE:-**
- 01 NO. PIPES HAVING DIAMETER OF 59"(1498.6 mm APPROX) SHALL BE LOADED AS SHOWN IN LOADING DIAGRAM.
 - PIPE LOADED AT WAGON CENTRE AS PER LENGTH, END OF THE PIPES SHOULD BE EQUAL DISTANCE FROM EACH SIDE WALL.
 - BEFORE LOADING PIPES ON THE WAGON, ENSURE THAT WOODEN LOGS ARE PLACED IN CORRECT POSITION AS SHOWN IN DRAWING.
 - AFTER LOADING, PIPE SHALL BE UNITIZED BY 05 NOS. OF LASHING CHAIN/ HEAVY DUTY STRAP & TIGHTEN ADEQUATELY.
 - TO AVOID SHIFTING OF PIPES DURING RUN, WOODEN LOG, WOODEN WEDGES AND 05 NOS OF LASHING CHAIN/ HEAVY DUTY STRAP TO BE USED PROPERLY.
 - THE LASHING CHAIN / HEAVY DUTY STRAP USED SHOULD HAVE MINIMUM BREAKING STRENGTH 5000 KG PER CHAIN/STRAP.
 - PIPES ARE LOADED ALONG THE LENGTH OF WAGON AS SHOWN IN DRAWING & ALL DIMENSION IN MM.
 - THE TOTAL CONSIGNMENT LOAD SHOULD NOT EXCEED THE PAY LOAD OF THE WAGON.
 - THE LOADING/UNLOADING OF PIPES TO BE CARRIED OUT IN SUCH A WAY THAT IT WILL NOT DAMAGE THE WAGON & LOOSE DURING TRANSPORTATION.



ITEM	DESCRIPTION	MT&SPEC	REMARKS
5	LASHING CHAIN OR HEAVY DUTY STRAP	STEEL OR NYLON WEBING HEAVY DUTY STRAP	
4	WOODEN WEDGE	WOOD	
3	WOODEN CRADLE	WOOD	
2	ISOLATION HOOK	STEEL	
1	STEEL PIPE 59" (Ø 1498.6 mm)	STEEL	
		NO. OF PCS/ WAGON	

DATE	SCALE	BY	CHECKED	DATE	SCALE	BY	CHECKED
06/23	1:1	MS-30349	MS-30349	06/23	1:1	MS-30349	MS-30349

ALTY ITEM AUTHY.	DESCRIPTION	DATE ASSY.	DROGS.

GROUP	R.D.S.O.	[W]
WD-23059-S-01		

B.G.	R.D.S.O.	[W]

LOADING DIAGRAM OF 59" STEEL PIPES IN BOST WAGON & ITS VARIANTS